

1.4 DISK DRIVES

"A" enclosures will always house a minimum of two drives, one removable cartridge drive and one Winchester drive. "B" enclosures will house between 0 and four Winchester drives.

"A" ENCLOSURE (REAR VIEW)

D0	D1
D3	D2

FIRST "B" ENCLOSURE WITH AN FP (REAR VIEW)

D4	D5
D7	D6

Even if there are drives missing in the "A" enclosure, the first drive in the next "B" enclosure will be D4.

* DRIVE CABLING

The disk drives are connected to the FP board by a daisy chained control cable and four data cables, one for each drive. The plugs on the FP board are clearly marked to indicate which data cable should be connected.

* DRIVE STRAPPING

ALL drives are strapped with ALL drive selections jumpered. The selection takes place in the cable. This allows any Winchester drive to be moved to any other slot without changing the jumpers.

* DRIVE TERMINATION

In the "A" enclosure, the termination pack should be present on D1, the first Winchester drive after the Syquest and absent from all the other drives in that cabinet. In a "B" enclosure, the termination pack will always be on D(nX4), e.g. D4, D8, etc. and absent from all other drives.

The Maxtor XT-1000 Family

Recording Media

- Metallic film plated on a 130 mm diameter aluminum substrate.
- 9.57 megabytes of data per disk surface.
- 918 tracks per disk surface.

Read/Write Heads

- Whitney type (IBM 3380) ferrite heads.
- Low mass/low load force.
- Reliable contact start/stop.
- Dedicated landing/shipping zone at power off.

Air Filtration System

- Disks, heads and actuator fully sealed in clean air chamber.
- Recirculation air system with absolute filter.
- Absolute breather air filter permits pressure equalization with ambient air without contamination.


Rotary Voice Coil Actuator

- Highly efficient rotary voice coil actuator allows for low power consumption.

- Average access time several times faster than stepper motor drives.
- Simple, reliable construction:
 - Two-bearing structures
 - Low-cost magnet assembly
 - Highly efficient coil configuration
- Pre-programmed acceleration profile allows high performance for all length seeks.
- Statically balanced structure for high mechanical stability and maximum vibration resistance.
- Fully-automatic, positive actuator latch.

Closed Loop Track Following Servo System

- Provides precise thermal compensation and "on-track" stability.
- "Index" and "Track Zero" indicators recorded on the servo track eliminate the need for transducers and their adjustments.
- New high-volume servo track-writing techniques maximize manufacturability and repeatability.



SPECIFICATIONS

Performance Specifications

	<u>XT-1065</u>	<u>XT-1105</u>	<u>XT-1140</u>
Capacity, unformatted			
Per drive (MB)	66.99	105.27	143.55
Per Surface (MB)	9.57	9.57	9.57
Per Track (Bytes)	10,416	10,416	10,416
Capacity, formatted**			
Per drive (MB)	52.6	82.7	112.8
Per surface (MB)	7.5	7.5	7.5
Per track (Bytes)	8192	8192	8192
Per sector (Bytes)	256	256	256
Sectors/track	32	32	32
Transfer rate, Mbits/sec	5.0		
Access Time, msec			
Average*	30		
Track-to-track*	5		
Maximum*	48		

Functional Specifications

Rotational Speed (rpm)	3600		
Average latency (ms)	8.33		
Recording density (bpi)	9875		
Flux density (fci)	9875		
Track density (tpi)	980		
Cylinders	918		
Tracks	6426	10,098	13,770
Sectors**	205,632	323,136	440,640
Data heads	7	11	15
Servo heads	1	1	1
Disks	4	6	8

*Includes settling

**Formatted with ST506/412 compatible format (32 sectors/track)

Physical Specifications

- Environmental limits (operating)
 - Ambient temperature = 40° to 122° F (4° to 50° C)
 - Relative humidity = 8% to 95% non-condensing
 - Maximum wet bulb = 78.8° F (26° C)
- DC voltage requirements
 - +12 VDC ± 5% 1.4A typical, 4.5A maximum (at power-on)
 - +5 VDC ± 5% 1.7A typical, 1.9A maximum
- Mechanical dimensions
 - Height = 3.25 in. (82.55 mm)
 - Width = 5.75 in. (146.05 mm)
 - Depth = 8.00 in. (203.20 mm)
 - Weight = 6.3 lbs. (2.8 Kg)
- Heat dissipation = 25 watts typical, 28 watts maximum

Reliability Specifications

- MTBF: 11,000 POH, typical usage
- PM: not required
- MTTR: 30 minutes
- Component design life: 5 years
- Error Rates:
 - Soft read errors: 1 per 10¹⁰ bits read
 - Hard read errors: 1 per 10¹² bits read
 - Seek errors: 1 per 10⁶ seeks

Maxtor

Maxtor Corporation
61 East Daggett Drive
San Jose, CA 95134
408 942-1700
TELEX 171074

1.19

DISK MODULE POWER SUPPLY

The disk module power supply receives 115 VAC from the main power supply, even if the main power supply is connected to a 230 VAC source.

AC INPUTS ON CONNECTOR J1

PIN	VOLTAGE
1	CHASSIS GROUND
2	AC LINE 47 - 63 Hz at 85 - 130 VAC
3	AC NEUTRAL

VOLTAGE	TOLERANCE	RIPPLE	IMIN	IMAX
+5VDC	4.75 - 5.25	50MV	.5ADC	2ADC
+12VDC	11.4 - 12.6	50MV	.5ADC	5ADC

TEST POINTS ON J2

PIN	VOLTAGE
1	+12V
2	+12V (RETURN)
3	+5V (RETURN)
4	+5V

MODULE II

SOFTWARE OVERVIEW

2.1 Overview

2.2 Bootstrapping

2.3 Initialization

2.4 Running

OBJECTIVE:

Upon completion of this topic, the student will be able to describe the operating systems used with the Megaframe and the three classes of board operation.

TRAINING MATERIALS:

Student Handbook

Megaframe System

2.1 OVERVIEW

The Megaframe is capable of running multiple operating systems at the same time. The various 80186 based boards each boot and run special versions of CTOS and the Applications Processor boots and runs CTIX.

CTIX communicates with disks and peripherals by sending request messages to the appropriate CTOS board.

With CTIX and CTOS both installed, the Megaframe can communicate with workstations as well as CTIX terminals. A user at a CTIX terminal can also access some commands and all files available to CTOS users at workstations. CTOS users do not have direct access to CTIX files and cannot execute any CTIX commands.

2.2 BOOTSTRAPPING

- * Master FP board boots from first disk containing a system image. The file containing the OS is <sys>sysimage.sys and can be on any disk drive.
- * 80186 boards bootstrap a file specified in the <sys>master.cnf file which is the file used by all boards in the system.
- * AP's boot the file specified in master.cnf and boots last.
- * LEDs on processor boards shift circularly when a board is waiting to bootstrap. (walking the dog)
- * The master FP reads a location in each processor's memory to determine which type of board it is and whether it requires bootstrap service.

2.3 INITIALIZATION

- * Subsequent to bootstrapping, each board runs an initialization program. If this program detects any hardware failures, entries will be made in the system error log.
- * When CTOS is loaded and initialized, a 20 will be displayed on the front panel.
- * If an AP is present and configured in master.cnf, the display will indicate an 11 and will progress toward 20.
- * If the AP board does not initialize, a 15 will be left in the display. This is generally caused by an incorrect configuration file.
- * If the AP initializes properly, a 20 will be displayed.

2.4 RUNNING

- * When the system is running, display = 20.
- * Bottom LED on processor boards blink about once per second when the board is running.

III MEGAFRAME HARDWARE INSTALLATION MODULE

3.1 Overview

3.2 "A" Enclosure Installation

3.3 "B" Enclosure Installation

OBJECTIVE

Upon completion of this topic, the student will be able to install a Megafame system.

TRAINING MATERIALS

Megafame Installation Manual

Visuals

Megafame System

3.1 OVERVIEW

Megaframe systems always consist of one "A" enclosure and zero to five "B" enclosures. "A" enclosures differ from "B" enclosures in that they have an operator's panel and one Syquest removable disk drive; the "B" enclosures have neither.

Enclosures are added by extending the system bus via bus repeater boards and flexible cables. The connection is made inside the Megaframe plastic housing. The enclosures are bolted together side by side. The Megaframe system grows from left to right and the "A" enclosure is always at the extreme left.

3.2 "A" ENCLOSURE INSTALLATION

- * Unpack system (page 2-1 Megaframe installation Manual).
- * Check for any physical damage.
- * Check Syquest drive for any shipping inserts.
- * Check receptacle for proper wiring.
- * Ensure power switch is in the off position.
- * Plug in power cord.
- * Turn on power switch.
- * Boot system and check for a 20 on front panel.
- * Turn off power.
- * Attach peripheral cables and route them beneath cable guide.
- * Cable guide is secured by two knurled screws.

3.3 "B" ENCLOSURE INSTALLATION

- * Unpack system. (page 6-1 of Megaframe Installation manual)
- * Install bus repeater board in leftmost (looking from the back) slot of "A" cabinet. File processor must be removed to gain access to slot.
- * Remove the right side panel from the "A" enclosure and install it on the right side of the "B" enclosure.
- * Attach the "B" enclosure to the right side of the "A" enclosure, using the hardware provided.
- * Install the two flexprint cables between the bus repeaters in the "A" enclosure and the "B" enclosure.
- * Check receptacle for proper wiring
- * Energize system.

MODULE 4

CONFIGURATION FILES

4.1 OVERVIEW

4.2 MASTER CONFIGURATION FILE

4.3 BOARD CONFIGURATION FILES

4.4 DISK CONFIGURATION FILES

4.5 PROCESSOR BOARD JOB FILES

OBJECTIVE

Upon completion of this topic, the participant will be able to modify configuration files to support a requested system configuration.

TRAINING MATERIALS

Student Handbook

Visuals

Megaframe system

4.1 Master Configuration file

- * This file is [sys]<sys>Master.cnf .
- * Read by the master FP to determine which OS a requesting board should be bootstrapped with.
- * Indicates which hardware configuration file the various processor boards should use.
- * If this file is modified, the system must be re-booted before it will actually affect system operation.

See sample on the next page.

SAMPLE [SYS]<SYS>MASTER.CNF

NoWatchDog

```
AP [sys]<sys>Unix.sys
CP [sys]<sys>CpCtos.sys
Include [sys]<sys>Cp00.cnf
CP [sys]<sys>CpCtos.sys
Include [sys]<sys>Cp01.cnf
TP [sys]<sys>TpCtos.sys
Include [sys]<sys>Tp00.cnf
DP [sys]<sys>DpCtos.sys
Include [sys]<sys>Dp00.cnf
```

- * The file shown above is for a system with 1 FP, 1 AP, 2 CPs, 1 TP, and a DP.
- * NoWatchdog indicates that the watchdog process is not to be installed and executed on the master FP.
- * Each processor board in the system, except the master FP, must have an entry if it is going to be used.
- * The "include" line indicates which file a specific board will read for configuration information.
- * When there are multiple occurrences of the same processor type in a system, there must be an entry for each occurrence.
- * Processor boards will receive boot service in the order that they occur in master.cnf.
- * The lowest numbered RS-232 channel on the first CP or TP on the master.cnf must be connected to the CTIX console.
- * This file has a tendency to be case sensitive. Match up the OS name (CpCtos.sys for example) with the actual file name. Use the FILES command- with the parameter for filename(s) being ??????.sys - this will give you the actual file name.
- * With 3.0 Megaframe CTOS and higher, you can have three different versions of Master.cnf depending on which position your keyswitch was in when you bootstrapped. If your key was in the manual position, your FP will look at Master.cnf.M first. If that file does not exist, then it will look at plain old Master.cnf. The same goes for the other two key positions- Master.cnf.R for REMOTE and MASTER.CNF.M for MANUAL

4.2 BOARD CONFIGURATION FILES

- * The file names listed alongside the INCLUDE statement in the Master.cnf file are of specific formats and must be edited to indicate the operating parameters used by that board's hardware.
- * The AP does not use a configuration file because it doesn't communicate directly with any I/O channels.

SAMPLE CP BOARD CONFIGURATION FILE

```
async 1, speed=9600 , parity=none , stopbits=1 , charbits=8
async 2, speed=9600 , parity=none , stopbits=1 , charbits=8
async 3, speed=9600 , parity=none , stopbits=1 , charbits=8
PT=2
line 1,clock=307k
line 2,clock=2M
```

- * This file is pointed to by Master.cnf.
- * The three RS-232C channel parameters are defined by the first three lines.
- * The first two lines can be made synchronous by deleting the complete line.
- * Async line 3 must never be deleted.
- * The fourth line indicates that a total of two PT terminals will be connected to the cluster ports. This information will be used by CTIX to assign TTY numbers.
- * The last two lines define the cluster baud rates.
- * Ngen workstations are the only type of workstation that can be connected to a 2M cluster line.

SAMPLE FILE PROCESSOR CONFIGURATION FILE

DISK 0 DEVICE=d0, PASSWORD=d0
DISK 1 DEVICE=d1, PASSWORD=d1
DISK 2 DEVICE=d2, PASSWORD=d2
DISK 3 DEVICE=d3, PASSWORD=d3

* Example given would be used for FP00.

* Generally, the FP configuration file does not need to be changed.

SAMPLE DP CONFIGURATION FILE

DISK 0 DEVICE=s0, PASSWORD=s0
DISK 1 DEVICE=s1, PASSWORD=s1
DISK 2 DEVICE=s2, PASSWORD=s2
DISK 3 DEVICE=s3, PASSWORD=s3

* Pointed to by Master.cnf

* Supplies device names and passwords for 4 SMD drives.

SAMPLE TP BOARD CONFIGURATION FILE

```
async 1, speed=9600 , parity=none , stopbits=1 , charbits=8
async 2, speed=9600 , parity=none , stopbits=1 , charbits=8
async 3, speed=9600 , parity=none , stopbits=1 , charbits=8
async 4, speed=9600 , parity=none , stopbits=1 , charbits=8
async 5, speed=9600 , parity=none , stopbits=1 , charbits=8
async 6, speed=9600 , parity=none , stopbits=1 , charbits=8
async 7, speed=9600 , parity=none , stopbits=1 , charbits=8
async 8, speed=9600 , parity=none , stopbits=1 , charbits=8
async 9, speed=9600 , parity=none , stopbits=1 , charbits=8
async 10, speed=9600 , parity=none , stopbits=1 , charbits=8
        connect=ctos
```

* Pointed to by Master.cnf

* Defines the operation of the 10 RS-232C channels

* Connect=ctos indicates that the CTOS debugger can be used on async channel 10.

4.4 DISK CONFIGURATION FILES

OVERVIEW

Due to the numerous disk drives presently available and those just over the horizon, the Megaframe software allows drives with varying head/cylinder organizations to be used with the FP board.

Each drive has to have a configuration file so that the MIVOLUME program will know how to format it. After the drive is formatted, the head/cylinder information is written into the VOLUME HOME BLOCK (Track 0, Head 0, Sector 0) so that any time the system is shut down and turned back on, the software can read the VHB and adjust its device dependant routines to properly utilize the disk drive.

Drive Configuration Files

- * A drive configuration file must exist for each different type of drive in the system.
- * The files are found on the system disk.
- * Files contain information about the media organization and the rate at which the drive can step.
- * Information in the files will be used by the MIVOLUME command when formatting the disk (Device type).
- * The information in the files will be written into the Volume Home Block when the MIVOLUME writes the volume control structures on the disk.

SAMPLE DRIVE CONFIGURATION FILE

```
;THIS IS FOR AN ATASI DRIVE  
CYLINDERS=645  
TRACKS=7  
SECTORS=16  
BYTES=512  
STEP=0  
SEEK=100  
SETTLE=100  
REMOVABLE=no
```

- * The file above is named [sys]<sys>IVAtasi46.cnf .
- * Tracks means heads.
- * Seek time is a maximum measured in tenths of a millisecond.

* Settle time is a maximum measured in tenths of a millisecond.

* Step rate of 0 = maximum rate of 20 microseconds.

STEP RATE TABLE

0	=	20	MICROSECONDS
1	=	.5	MILLISECONDS
2	=	1.0	MILLISECONDS
3	=	1.5	MILLISECONDS
4	=	2.0	MILLISECONDS
5	=	2.5	MILLISECONDS
6	=	3.0	MILLISECONDS
7	=	3.5	MILLISECONDS
8	=	4.0	MILLISECONDS
9	=	4.5	MILLISECONDS
10	=	5.0	MILLISECONDS
11	=	5.5	MILLISECONDS
12	=	6.0	MILLISECONDS
13	=	6.5	MILLISECONDS
14	=	7.0	MILLISECONDS
15	=	7.5	MILLISECONDS

NOTE: All drives used with the Megaframe use a step rate code of zero because the drives are intelligent enough to buffer the step pulses issued by the controller.

4.4 PROCESSOR BOARD INITIALIZATION FILES

OVERVIEW

After a board bootstraps its operating system, it then executes the job list in its JCL (Job Control Language) file. Each board has its own JCL file which is executed only once.

* JCL FILE NAMING CONVENTION

[sys]<sys>initBTxx.jcl

BT = Board type

xx= Board sequence number

EXAMPLES:

First FP executes [sys]<sys>initfp00.jcl

Second CP executes [sys]<sys>initcp01.jcl

* JCL FILE SYNTAX

\$run runfilename,parameter1,parameter2,...parameterN

Sample Entry:

\$run [sys]<sys>mtapeserver.run,8,10

* JCL FILE APPLICATIONS

If the system administrator wanted the queue manager to be automatically installed on FP00 and the spooler to be installed on CP00, the JCL files for those two boards would be edited to appear as follows:

File name: [sys]<sys>initfp00.jcl

Contents:

```
$run [sys]<sys>minstallqmgr.run
```

File name: [sys]<sys>initcp00.jcl

Contents:

```
$run [sys]<sys>mspoolermgr.run
```

With the JCL files shown above, the FP would install the queue manager immediately after bootstrapping and the CP would install the spooler after booting.

* MEGAFRAME ADMINISTRATOR AGENT

A common use of a JCL file would be to install the Megaframe administrator agent on a board. The administrator agent allows the megaframe to execute 'M' commands which are usually executed to perform system administrator functions (tape backup for example). When an M command is issued the corresponding run file will execute on the board that is running the administrator agent. Only one workstation can execute M commands at a time.

File name: [sys]<sys>initfp00.jcl

Contents:

```
$run [sys]<sys>MfAdminAgent.run
```

NOTE: If the entry shown above is placed in a JCL file, it must be the **LAST** entry in that file.

5.1 QUEUE.INDEX

5.2 SPOOLER CONFIGURATION FILES

5.3 PRINTER CONFIGURATION FILES

5.4 SYS.PRINTERS- THE UTILITY PROGRAM MENU FILE

6.1 X, Y, AND Z BLOCK ALLOCATION

7.1 TEMPORARY DIRECTORIES - <\$>

8.1 OPERATING SYSTEM SYSGENS

MODULE 9

ERROR CODE INTERPRETATION MODULE

9.1 ERROR CODE LEVELS

9.2 BOOTSTRAP ERRORS

9.3 INITIALIZATION ERRORS

9.4 CRASH STATUS ERRORS

9.5 STATUS CODES

OBJECTIVE

Upon completion of this topic, the student will be able to interpret error codes reported by the boot roms, CTOS initialization procedures, CTOS device managers, and the CTOS crash routine.

TRAINING MATERIALS

STUDENT HANDBOOK

MEGAFRAME SYSTEM

OVERVIEW

Error codes reported by the Megaframe are often helpful when isolating a hardware problem. Error codes and messages can come from various sources; so there are different error code listings for each of the sources of error codes. The discussion that follows intends to explain the various sources of error codes and which error code listing to use when interpreting the error code.

9.1 ERROR CODE LEVELS

BOOT - Bootstrap errors are errors by tests burnt into a bootstrap rom. The error code is displayed in hex on the board-edge LEDs.

INITIALIZATION- These errors are reported by the CTOS initialization routines and are recorded in plain English on the system log. *3 use MP104*

CRASH ERRORS- These are serious errors detected by CTOS interrupt handlers and are recorded in the system log. Crashes cause an auto re-boot to occur if the keyswitch is in normal.

STATUS ERRORS- These errors are not as severe as crash errors. CTOS logs status errors related to possible hardware malfunctions.

BOOTSTRAP ERRORS

If a board, other than the FP, does not progress to the point where it is "walking the dog" (rotating leds), the board will display a !!! *** BOOTSTRAP *** !!! error code on its board edge L.E.D's.

The designated file processor is a special case in that it never "walks the dog". If the file processor never reaches a value of 7 in the front panel it has found a bootstrap error and this error can be read on the board edge L.E.D's.

The designated FP also reports status codes on the front panel. These codes can be interpreted by using the FRONT PANEL SYSTEM STATUS AND ERROR CODES list on the pages that follow.

Once it has been determined that a board is reporting a boot error, the next step is to read the board edge lamps. The 8 board edge lamps form a 2 digit hexi-decimal number that corresponds to an error code explanation in the bootstrap error code listings.

The top lamp represents bit 2 (7) and the bottom lamp represents bit 2 (0).

EXAMPLE OF BOOT ERROR ON AN 80186 BASED BOARD

```
Top lamp Off = 0
          Off = 0   = 0
          Off = 0
          Off = 0

          On  = 1
          Off = 0
          On  = 1   = B
Bottom lamp On  = 1
```

Error Code = 0B Meaning - Bad I/O ports

INITIALIZATION ERRORS

When the operating system loads into a board, certain initialization routines are run. The routines initialize and test, if possible and applicable, the following:

1. Memory above the operating system
2. Interrupt controller(s)
3. Timers
4. The boards ability to detect a bus time-out
5. The boards ability to detect a parity error
6. Communications controllers

If any of these routines detect an error, the error will be logged and the operating system will not be executed on that board. Initialization errors are logged in plain English. Use the MPLOG command to check for initialization errors.

CRASH STATUS ERRORS

Certain hideous hardware errors can be detected by CTOS and are reported as crash status errors. These errors are recorded in the system log and can be viewed by using the MPLOG command. If a crash occurs, the bottom led on the board will stop blinking. If the WATCHDOG process is enabled and the key switch is in normal, the system will automatically reboot. Rebooting can be inhibited by placing the key switch in the manual position; this action can be useful when isolating a failing board.

Crash Errors

ERC 21 - Non-existent memory location.

A processor board tried to write its own memory via the system bus.

ERC 22 - Bus time-out.

A processor board attempted to make a transfer involving a non-existent memory location or I/O port. (software problem)

A processor board attempted to make a transfer to an existing I/O port or memory location but an acknowledge was not received due to a circuitry failure. (hardware problem)

ERC 23 - An uncorrectable memory error has occurred.

ERC 24 - Power failed and returned in time to log it.

ERC 25 - A non-maskable interrupt was received but the value in the NMI status register does not indicate that any of the NMI conditions occurred.

ERC 26 - A maskable interrupt was received but the vector sent by the interrupt controller is illegal.

The 80186 microprocessor fetched an illegal instruction.

ERC 27 - Divide overflow. A number was divided by zero.

ERC 28 - Double bit error occurred when a transfer involving another boards memory was taking place. The double bit error was in the other boards memory.

When ERC 21 - 28 occur, the error log entry also contains (8) hex words that further describe the error.

- Field 1 - Hex equivalent of the decimal ERC.
- Field 2 - Process number of the process that was running when the error occurred. This information is of little use when a hardware error has occurred.
- Field 3 - Contents of the General Status Register. This register is loaded when a non-maskable interrupt occurs. The contents of this register can be decoded to determine specifics about the crash status that was reported. The bits in the General Status Register are described below.
- Field 4 - Contents of the memory location that was read when a double bit error occurred.
- Field 5 - Contents of the remote slot register.
- Field 6 - Contents of base register 0. Base register 0 holds bits 16 - 31 of the off-board memory address. In the case of ERC 23, this field contains the contents of the ECC syndrome register.
- Field 7 - Contents of the CS register following the execution of the instruction that caused the crash.
- Field 8 - Contents of the IP register following the execution of the instruction that caused the crash.

GENERAL STATUS REGISTER

This register's contents are reported in field 3 of the crash status codes.

BIT		MEANING
15	ME	0 = Memory expansion is installed.
14	SE	0 = At least one board in the system is driving the system error line on the system bus.
13	LR	0 = Last reset by power up or reset switch. 1 = Last reset by software.
12	NEM	0 = If NMI was caused by a reference to a non-existence memory location. The reference could have been initiated locally or by a processor or DMA controller on another board.
11	PF	0 = Powerfail.
10	TO	0 = Bus time out. No acknowledge was received from a memory or I/O timing circuit.
9	BE	0 = Bus error. A remote double bit error or or a nonexistent memory location.
8	DBE	0 = Double bit error.
7	REM	0 = The trapped address was generated by another board.
6	CAD	0 = The trapped address was generated by the CPU.
5	DMA	0 = The trapped address was generated by the local DMA controller.
4	DFP	1 = This board is the designated file processor.
3	REM	1 = Panel switch is in remote. Only applicable on the designated FP.
2	NOR	1 = Panel switch is in normal. Only applicable on the designated FP.
1	A19	Bit 19 of the trapped address.
0	A18	Bit 18 of the trapped address.

A19	A18	
0	0	Base Memory
0	1	Expansion Memory
1	0	Expansion Memory
1	1	Memory on another Processor Board

SAMPLE CRASH STATUS IN SYSTEM LOG

ERC 22 Bus time-out CP in slot 74

 (1) (2) (3) (4) (5) (6) (7) (8)
Status words 0016H 0008H DBA3H 0000H 0075H 0000H 0301H 0009H

- (1) 16 hexidecimal = 22 decimal.
- (2) Failure occurred in process 8.
- (3) Bit 10 - Time out.
 Bit 6 - Cpu address.
 Bit 1,0 - Address greater than or equal to C0000h.
- (4) Only applies to ERC 23.
- (5) Board in slot 75 was being referenced.
- (6) Memory lower than address FFFFh (64K) was being referenced.
- (7)/(8) Instruction proceeding the instruction at address 03010:0009 was being executed when the time-out occurred.

POSSIBLE CAUSES:

- 1. Board in slot 75
- 2. Board in slot 74
- 3. Programming error

STATUS CODES

Errors reported on the screen and the system log other than crash errors are simply referred to as status codes. Status codes can be caused by either hardware or software problems. To decipher an error code found in the system error log or reported on the screen, use the status code listing provided in this manual.

Status errors in the 3xx range apply to disk. These errors have plain english descriptions and often status and command bytes. The interpretation of these bytes exceeds the scope of this level of service training. If one were to interpret the bytes by using the various IC data sheets required, it would soon be realized that you have not gained any more insight than was given in the plain english description of the error.

Error codes in the range of 8xxxx relate to problems with cluster communications. These errors messages are also accompanied by status bytes and a plain english description of the error. The status bytes are read from the internal registers of the 2652 communications controller.

ERC 301 IS A DISK READ ERROR. THIS ERROR CAN CAUSE A CRASH IF IT IS IN A RUN FILE.

STATUS CODES IN LEDS

If a board crashes, the switch is in manual, and the watchdog process is activated; the 80186 board LEDS will indicate a status code. This code can not always be trusted because the lamps are not capable of indicating a code greater than 255. The information in the lamps can be useful at times, some common errors to look for in the lamps are:

301 decimal	--	2D hex	-	Disk I/O error
203 decimal	--	CB hex	-	No Such File

Error 203 is most commonly encountered when there is an error in a JCL or .cnf file. Other missing files can also cause this error to be reported and consequently a system crash.

SYSTEM TROUBLESHOOTING MODULE

OBJECTIVE

Upon completion of this module, the participant will be able to isolate and repair MegaFrame and programmable terminals at the board level.

OVERVIEW

The MegaFrame has built in software features and indicators which will assist the troubleshooter in locating the failing logic board, disk drive, or power supply. Familiarity with software operation and configurability will facilitate expedient isolation of problems.

SOFTWARE CONFIGURATION PROBLEMS

Due to the numerous software configuration files used by the MegaFrame system, it is always a good idea to suspect a software configuration problem when something in the system was changed and it suddenly stopped working. Leaving blank lines in JCL files and forgetting to place carriage return after each line are the most common cause of errors. These mistakes will often prevent the system from successfully booting.

HUMAN INDUCED PROBLEMS

1. Trying to use disk drives in an "A" enclosure with the cartridge drive removed. This would most likely cause intermittent read errors (error 301) on the Winchester drives.
2. Failing to place the jumper in the correct plug on a memory expansion board.
3. Forgetting to install the private bus jumper between a board and its expansion memory.
4. Installing boards in a non-contiguous manner.
5. Installing a Winchester drive that has not had the termination resistor pack removed.
7. "B" enclosures must have terminator in the first drive.

7. Installing a Winchester drive that does not have all four drive selection straps jumpered.
8. Pulling out a cartridge disk before the indicator stops blinking.
9. Failing to terminate cluster lines properly.
10. Using a cluster cable on a fast cluster line that does not meet the required specifications.
11. Running the cluster test on a PT that is still connected to the MegaFrame. This can seriously confuse the MegaFrame and other stations connected to the line. This problem can be resolved by re-bootstrapping the MegaFrame and associated workstations and terminals.
12. Plugging an RS-232 cable into the printer port when an energized peripheral is connected to the other end. This can destroy the ICs that drive the printer channel. It is also possible to punch through the ICs and contaminate the main data bus.
13. Configuration file does not match printer characteristics.
14. Neglecting to connect an SC board to an SP board at J3 by using a private bus jumper.

ISOLATION TECHNIQUES

SIMPLIFICATION TECHNIQUE

Malfunctions are best isolated by using the simplification technique. In other words, a malfunctioning system should be reduced to the bare minimum and add boards and drives back to it until a failure occurs, thus indicating that the part re-introduced to the system is at fault.

JCL FILE PROBLEMS

Connect an RS-232 terminal to channel 3 of a CP or Channel 9 of a TP. The connect = ctos entry must be in the corresponding .cnf file. The JCL entries being processed by that board will be written on the screen. This information is often useful for finding problems because any error encountered during the execution of the JCL entries will also be reported on the screen.

DISK AND FILE PROCESSOR ISOLATION

The FP Board won't boot from D1 !!!

- Is the FP malfunctioning ?
- Is the Winchester drive malfunctioning ?
- Are the Cables bad ?
- Is the power supply producing the correct voltages?
- Has the software on the hard disk been destroyed?
- Wish I had some parts to swap.

The situation described above offers many questions. The fastest solution to the problem is to exchange parts until the problem subsides. But parts may not be readily available.

A bootstrappable cartridge could be used to determine with a reasonable degree of certainty whether the FP or the Winchester drive is bad. If the system bootstraps the cartridge then the problem has a very high probability of being the Winchester drive.

BEFORE SIGNING A WINCHESTER'S DEATH CERTIFICATE, ONE SHOULD ATTEMPT TO RE-INITIALIZE AND RE-INSTALL SOFTWARE. IN MANY CASES, THIS ACTION WILL RESOLVE THE PROBLEM. BE SURE TO ENTER THE INFORMATION FROM THE BAD SPOTS CARD ATTACHED TO THE DRIVE.

If the FP has a serious malfunction, it will report a bootstrap error code in its board edge light emitting diodes, thus indicating that the FP is faulty.

As mentioned above, the system should be reduced to its minimum required configuration to allow deductive isolation of another failing part.

INTERMITTENT PROBLEMS

The information recorded in the system log is often helpful when isolating an intermittent error. For example, the ERC 22 (bus time out) error logs the slot number of the processor board being referenced. With this information, the trouble could be isolated to one of two boards.

SYSTEM LOG

Using the MPLOG command and the error listings provided is the most expedient technique for finding a problem.

MEGAFRAME TROUBLE ISOLATION

#1

SYMPTOMS

Power on indicator does not glow but fans blow.

POSSIBLE CAUSES

1. Blown fuse in main power supply.
2. Disconnected power indicator cable.
3. Bad power indicator.

#2

SYMPTOMS

Power indicator off and fans do not blow.

POSSIBLE CAUSES

1. System not plugged in.
2. Circuit breaker tripped.
3. Main AC fuse blown.

#3

SYMPTOMS

Power indicator is on but fans do not blow.

POSSIBLE CAUSES

1. AC plug on top of power supply is loose or bad.
2. Wires at fan are disconnected.

#4

SYMPTOMS

Display panel does not display 00 when the key switch is in the stop position.

POSSIBLE CAUSES

1. FP board is not installed.
2. Display cable connector is loose.
3. Display assembly is malfunctioning.

#5
SYMPTOMS

FP will boot from D0 but not from D1.

POSSIBLE CAUSES

1. D1 does not contain a bootable operating system.
2. Cables on D1 are loose or bad.
3. D1 disk module is bad.
4. FP board is bad.

#6
SYMPTOMS

FP board boots from D1 but will not boot from D0.

POSSIBLE CAUSES

1. Cartridge has never been initialized.
2. Cartridge does not contain a bootstrappable file.
3. Cartridge is bad.
4. Cables are loose on D0.
5. D0 disk module is bad.
6. FP board is bad.

#7
SYMPTOMS

FP boots and blinks bottom LED but no other boards will boot.

POSSIBLE CAUSES

1. [sys]<sys>master.cnf file contains incorrect text.
2. The operation systems for the other boards are not on the disk.
3. The slot adjacent to the FP is empty.
4. One of the boards has a bus logic failure, remove one board at a time.
5. Bent or loose pin on one of system bus connectors.
6. Master FP is bad;

#8

SYMPTOM

Boards in a slot beyond a certain board will not boot.

POSSIBLE CAUSES

1. Board next to last successfully bootstrapped board is bad.
2. The boards are not listed in [sys]<sys>master.cnf.
2. Bent pin is system bus connector.
3. Bad board seating.

#9

SYMPTOM

Boards in a certain enclosure will not boot.

POSSIBLE CAUSES

1. Boards are not listed in [sys]<sys>master.cnf.
2. Loose flexible print connectors.
3. Loose or bad BUS REPEATER BOARD
4. Boards are not in contiguous slots on the right side of the machine (front view).

#10

SYMPTOM

Display panel indicates 15.

POSSIBLE CAUSE

1. [sys]<sys>initfp00.jcl does not contain the entry that indicates that ufs.run should be executed on the FP board.

#11

SYMPTOM

Display panel indicates 21.

POSSIBLE CAUSES

1. None of the disks contain <sys>sysimage.sys.
2. AC power cable between the power supply and the disk power supplies is loose or disconnected.
3. Bad FILE PROCESSOR BOARD.
4. Improper disk drive termination.

#12
SYMPTOM

A board never tries to boot (does not shift LED's) .

POSSIBLE CAUSES

1. The board is bad.
2. Bent pin on system bus connector.
3. Private bus jumper is incorrectly installed.

#13
SYMPTOM

Checking volume status on a drive causes an ERROR 300.

POSSIBLE CAUSES

1. Loose drive cables.
2. Loose connection between disk power supply and the drive.
3. Disk power supply fuse is blown.
4. Disk power supply AC connector is loose or bad.
5. Disk module is bad.
6. FP board is bad.

#14
SYMPTOM

Checking volume status on drive causes an ERROR 216.

POSSIBLE CAUSES

1. Loose or bad cables.
2. Drive has never been initialized by using the MIVOLUME command.
3. Diagnostics have been run on drive but the drive has not been re-initialized by using the MIVOLUME command.
4. Disk module is bad.
5. FP board is bad.

#15

SYMPTOM

!!!! INTERMITTENT ERROR 301 !!!!!

PROBABLE CAUSES

1. Bad spot information was not entered when the drive was initialized using the MIVOLUME command.
2. Loose drive cables.
3. Disk drives are not terminated properly.
4. Disk module is bad.
5. FP board is bad.

#16

SYMPTOM

Cartridge drive will only read cartridges created on that drive.

POSSIBLE CAUSE

1. Cartridge drive module is bad.

#17

SYMPTOM

Cartridge or system drive only boots when another drive is disconnected.

POSSIBLE CAUSES

1. The drive that was disconnected is bad.
2. Drive cabling is loose or bad.
3. FP board is bad in that it is selecting more than one drive at a time.