

Configuration Guide to TurboDOS 1.2

May, 1982

Copyright (C) 1982 by Software 2000, Inc.

**Copyright (C) 1982 by Software 2000, Inc.
All rights reserved.**

The TurboDOS operating system software and documentation are the proprietary intellectual property of Software 2000, Inc. Copyrights thereon are owned by Software 2000, Inc. and have been registered with the Copyright Office of the Library of Congress in Washington, D.C. The word "TurboDOS" is a trademark of Software 2000, Inc., and has been registered in the United States and in the State of California.

No part of this publication may be reproduced, transmitted, transcribed, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Software 2000, Inc., 1127 Hetrick Avenue, Arroyo Grande, California 93420, U.S.A.

Software 2000, Inc. makes no representations or warranties with respect to the contents of this publication, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Software 2000, Inc. shall under no circumstances be liable for consequential damages or related expenses, even if it has been notified of the possibility of such damages. Software 2000, Inc. reserves the right to revise this publication from time to time without obligation to notify any person of such revision.

NOTE: CP/M, MP/M and CP/NET are trademarks of Digital Research, Inc.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

Table of Contents

TABLE OF CONTENTS

SECTION 1 -- INTRODUCTION

Generating TurboDOS Configurations	1-1
Implementing Driver Modules	1-1
Licensing Requirements	1-2
Serialization	1-3
OEM Responsibilities	1-3
Dealer Responsibilities	1-4
TurboDOS Support	1-4

SECTION 2 -- SYSTEM GENERATION

Module Hierarchy	2-2
Process-Level Modules	2-4
Kernel-Level Modules	2-5
Universal Driver-Level Modules	2-7
Hardware-Dependent Driver-Level Modules	2-8
Standard Configurations	2-8
Estimating Memory Requirements	2-10
Linking and Loading	2-11
GEN Command	2-12
Symbolic Patch Facility	2-14
TurboDOS Patch Points	2-15
Explanations of Certain TurboDOS Patch Points	2-18
Examples of Disk, Printer and Network Tables	2-21
Step-by-Step Procedure for System Generation	2-23
SERIAL Command	2-24
Step-by-Step Procedure for OEM Re-Distribution	2-25

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

Table of Contents

SECTION 3 — SYSTEM IMPLEMENTATION

Assembler Requirements	3-1
Programming Conventions:	
Dynamic Memory Allocation	3-2
Threaded Lists	3-3
Dispatching	3-4
Interrupt Service Routines	3-6
Poll Routines	3-7
Re-Entrancy and Mutual Exclusion	3-8
Sample Interrupt-Driven Device Driver	3-9
Sample Polled Device Driver	3-10
Initialization Segments	3-11
Page-Oriented Segments	3-11
Inter-Process Messages	3-12
Console Subroutines	3-13
Creating a Resident Process	3-14
Driver Interface Specifications:	
Initialization	3-16
Console Drivers	3-17
Printer Drivers	3-17
Network Circuit Drivers	3-18
Disk Drivers	3-20
Real-Time Clock Driver	3-22
Comm Channel Driver	3-23
Bootstrap ROM	3-24

APPENDIX -- Sample Driver Listings

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

Introduction

INTRODUCTION

This Configuration Guide to TurboDOS provides the information that OEMs, dealers, and sophisticated end-users need to generate various operating system configurations and to implement driver modules for various peripheral components.

A companion document, entitled User's Guide to TurboDOS, provides the information that users need to write and run programs under the TurboDOS operating system. It includes an overview of operating system features, a discussion of architecture and theory of operation, a description of each command, and a definition of each user-callable function.

Generating TurboDOS Configurations

TurboDOS is a modular operating system consisting of more than 40 separate functional modules. These modules are "building blocks" which can be combined in various ways to produce a family of compatible operating systems. TurboDOS configurations include single-task, spooling, network master and network slave, with numerous subtle variations possible in each of these broad categories.

Functional modules of TurboDOS are distributed in relocatable form. Hardware-dependent device drivers are packaged in the same fashion. The GEN command is a specialized linkage editor which may be used to combine the desired combination of modules into an executable version of TurboDOS configured with the desired set of functions and device drivers. The GEN command also includes a symbolic patch facility which may be used to alter a variety of operating system parameters.

Section 2 describes each functional module of TurboDOS in detail, illustrates how these modules can be combined in various configurations, and provides step-by-step system generation procedures.

Implementing Driver Modules

TurboDOS has been designed to run on any Z80-based microcomputer with at least 48K of RAM, a random-access mass storage device, and a full-duplex character-oriented console device (or on an interconnected network of such microcomputers). The functional modules of TurboDOS are not dependent upon the specific peripheral devices to be used. Rather, a set of hardware-dependent device driver modules must be included in each TurboDOS configuration in order to adapt the operating system to the specific hardware environment.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

Introduction

Typical hardware-dependent device driver modules include:

- Console driver
- Printer driver
- Disk driver
- Network circuit driver
- Real-time clock driver
- Communications driver

Although Software 2000 Inc. can supply TurboDOS pre-configured for certain specific hardware configurations, most OEMs and many dealers and end-users will want to implement their own hardware-dependent drivers. Driver modules may be readily written by any competent assembly-language programmer, using a relocating Z80 assembler such as Digital Research's RMAC, Microsoft's MACRO-80, or Phoenix Software Associates' PASM. Section 3 provides detailed instructions to programmers for implementing such driver modules, and the Appendix includes assembly listings of various sample drivers.

Licensing Requirements

TurboDOS is a proprietary software product of Software 2000 Inc. TurboDOS may be used only after the user has paid the required license fee, signed a copy of the TurboDOS software license agreement, and returned the signed agreement to Software 2000 Inc. Then it may be used only in strict conformance with the terms of the software license. Each TurboDOS software license agreement must be filled-out and signed by the end-user (not by an OEM or dealer on his customer's behalf).

Each software license permits the use of TurboDOS only on one specific computer system identified by make, model and serial number. A separate license fee must be paid and a separate license signed for each computer system on which TurboDOS is used. Network slave computers which are also capable of stand-alone operation under TurboDOS must each be licensed separately, but slave computers which cannot be used stand-alone (e.g., because they have no mass storage) do not.

Software 2000 Inc. intends to initiate vigorous legal action against anyone who uses or reproduces TurboDOS software in a manner which is not in strict conformance with the terms of the TurboDOS software license agreement.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

Introduction

Serialization

Each copy of TurboDOS is magnetically serialized with a unique serial number in order to facilitate tracing of unlicensed copies of TurboDOS.

Each relocatable TurboDOS module which is distributed to a dealer or end-user is magnetically serialized with a unique serial number. The serial number consists of two components: an origin number (which identifies the issuing OEM) and a unit number (which uniquely identifies each copy of TurboDOS issued by that OEM). The GEN command verifies that all functional modules which make up a TurboDOS configuration are serialized consistently, and magnetically serializes the resulting executable version of TurboDOS accordingly.

Each relocatable TurboDOS module which is distributed to an OEM is partially serialized with an origin number only. Each OEM is provided with a SERIAL command which must be used to add a unique unit number to the relocatable modules of each copy of TurboDOS issued by that OEM. The GEN command will not accept partially serialized modules that have not been uniquely serialized by the OEM. Conversely, the SERIAL command will not re-serialize modules which have already been fully serialized.

OEM Responsibilities

Each OEM is provided with a master copy of TurboDOS relocatable modules and command processors on diskette. An OEM is authorized to reproduce and distribute copies of TurboDOS to dealers and end-users for use on specifically authorized hardware configurations manufactured or distributed by the OEM. The OEM is required to serialize each copy of TurboDOS with a unique sequential magnetic serial number, and to register each serial number promptly by returning a registration card to Software 2000 Inc. This registration requirement for OEMs is in addition to (not in lieu of) the requirement for licensing of each end-user.

Each OEM is provided with a master copy of TurboDOS documentation either in camera-ready form or in ASCII files on diskette. The OEM is responsible for reproducing the documentation and providing it with each copy of TurboDOS issued by that OEM.

An OEM must require a dealer to sign the TurboDOS dealer agreement and return it to Software 2000 Inc. before the OEM may issue copies of TurboDOS to that dealer. An OEM must require an end-user to sign the TurboDOS software license and return it to Software 2000 Inc. before the OEM may issue a copy of TurboDOS directly to

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

Introduction

that end-user.

Dealer Responsibilities

A TurboDOS dealer is permitted to purchase individual serialized copies of TurboDOS software and documentation from an authorized TurboDOS OEM, and to resell them to end-users. Dealers are not authorized to make copies of TurboDOS software or documentation for any purpose whatever.

A TurboDOS dealer must require each end-user to sign the TurboDOS software license and return it to Software 2000 Inc. before issuing a copy of TurboDOS software or documentation to the end-user.

TurboDOS Support

Software 2000 maintains a telephone "hot-line" to provide TurboDOS-related technical assistance to its OEMs. Authorized TurboDOS OEMs should feel free to take advantage of this service whenever technical questions arise concerning the use or configuration of TurboDOS.

It is the responsibility of each OEM to provide technical support to its dealers and end-user customers. Software 2000 cannot assist dealers or end-users directly. Where exceptional circumstances seem to require direct contact between Software 2000 technical personnel and a dealer or end-user, this must be handled strictly by prior arrangement with Software 2000 by the OEM.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

SYSTEM GENERATION

TurboDOS is a modular operating system consisting of more than 40 separate functional modules. These modules are "building blocks" which can be combined in various ways to produce a family of compatible operating systems. TurboDOS configurations include single-task, spooling, time-sharing and networking, with numerous subtle variations possible in each of these broad categories. This section describes each functional module of TurboDOS in detail, illustrates how these modules can be combined in various configurations, and provides step-by-step system generation procedures.

Functional modules of TurboDOS are distributed in relocatable form. Hardware-dependent device drivers are packaged in the same fashion. The GEN command processor is a specialized linkage editor which may be used to bind together the desired combination of modules into an executable version of TurboDOS configured with the desired set of functions and device drivers. GEN also includes a symbolic patch facility which may be used to alter a variety of operating system parameters.

To simplify the system generation process, the most commonly used combinations of TurboDOS functional modules are pre-packaged into several standard configurations. Most requirements for TurboDOS can be satisfied by linking the appropriate standard package together with the requisite hardware-dependent drivers.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Module Hierarchy

The flow diagram on the facing page illustrates the functional inter-relationship of TurboDOS modules. As the diagram shows, the software elements of TurboDOS can be viewed as a three-level hierarchy.

The highest level is known as the "process" level. TurboDOS can support many concurrent processes at this level, and can share the resources of the local computer among them. There are active processes for users who are executing commands and/or transient programs on the local computer. There are also processes for users who are running on remote computers but making network requests of the local computer. There are processes to support de-spooling on local printers. Finally, there is a process which periodically causes buffered disk records to be flushed (i.e., written out) to disk.

The intermediate level is known as the "kernel" level. The kernel supports the various numbered TurboDOS functions (about 100 of them), and controls the sharing of microcomputer resources such as processor time, memory, peripheral devices, and disk files. Processes make requests of the kernel through a single entrypoint (OSNTRY) which decodes each function by number and invokes the appropriate module in the kernel.

The lowest level is known as the "driver" level, and contains all of the device-dependent drivers necessary to interface TurboDOS to a particular configuration of microcomputer hardware. Drivers must be provided for each printer, console, disk controller, and network interface. A driver is also required for the real-time clock or other periodic interrupt source (used for time-slicing among processes and for timing of delays). TurboDOS operates most efficiently with interrupt-driven, buffered or DMA-type devices, but can also work satisfactorily with polled and programmed-I/O devices.


The TurboDOS loader OSLOAD.COM is a special program which contains an abbreviated version of the kernel and drivers. Its purpose is to load the full operating system into memory at each system start-up.

All TurboDOS process-level and kernel-level modules permit re-entrant execution in multi-process situations. Most driver-level modules are not re-entrantly coded, and must utilize a mutual-exclusion mechanism to prevent re-entrant execution.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation



TurboDOS Module Hierarchy

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Process-Level Modules

LCLUSR -- Supports a transient program area for a user of the local microcomputer.

LCLMSG -- Contains all operating system messages, which are segregated into a separate module to facilitate adaptation to other languages.

LCLTBL -- Local user initialization tables.

CMDINT -- Command interpreter routine called by LCLUSR to process local user commands and multi-command strings.

AUTLOD -- Automatic program load routine called by LCLUSR to process COLDSTRT.AUT and WARMSTRT.AUT files if they are present.

SGLUSR -- Buffer flushing routine called by LCLUSR to flush and unlink all disk buffers at every console input. Included in single-user configurations only.

AUTLOG -- Automatic log-on routine called by LCLUSR to automatically log-on the local user in configurations where logon/logoff security is not desired. To activate this feature, use the symbolic patch facility to patch the public symbol AUTUSR to the desired user number, with the sign-bit set for a privileged log-on (typically AUTUSR = 80).

SUBMIT -- Optional module which emulates the processing by CP/M of \$\$.SUB files (not recommended due to significant performance penalty).

NETSVC -- Network service process which receives and services network requests from other microcomputers.

NETTBL -- Tables which define the topology of the network as seen from a particular processor.

DSPOOL -- De-spool process which supports printing of spooled print jobs concurrent with other system activities. In multi-printer configurations, there is a separate re-entrant instance of the DSPOOL process for each printer.

FLUSHR -- Buffer flusher process which causes memory-resident disk buffers to be flushed (i.e., written out) to disk periodically.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

Kernel-Level Modules

OSNTRY -- Common kernel entrypoint which decodes each function by number and invokes the appropriate module in the kernel.

FILMGR -- File manager which processes requests involving local files.

FILSUP -- File support routines used by FILMGR.

FILCOM -- Processors for common file-oriented functions which are never sent over the network.

FILLOK -- File- and record-level interlock routines called by FILMGR.

FFOMGR -- FIFO management routines called by FILLOK.

DRVLOK -- Drive interlock routines.

FASLOD -- Program load optimizer.

NORLOD -- Non-optimized program load routine which may be used instead of FASLOD when memory space is at a premium.

BUFMGR -- Buffer manager called by FILMGR. It maintains a pool of memory-resident record buffers used for all record-oriented access to local disk storage.

DSKMGR -- Disk manager called by BUFMGR and FASLOD to perform physical accesses to local disk storage.

DSKTBL -- Tables which define how drive letters are mapped into local and remote drives, and the location on the network of any remote drives.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

NONFIL -- Non-file request manager which handles kernel requests which are not file-oriented.

CPMSUP -- Optional function processors for little-used functions (7, 8, 24, 28, 29, 31, 37, and 107) included in TurboDOS solely for compatibility with CP/M.

SGLLOG -- Optional module which may be included in multi-user configurations to prevent two or more non-privileged users from logging-on to the same user number concurrently.

CONMGR -- Console manager which handles local console input/output.

CONTBL -- Table which defines how the local console is interfaced.

DOMGR -- DO-file manager which handles activation of DO-files. When a DO-file is active, this module is called by CONMGR to satisfy console input requests from the DO-file.

INPLN -- Console input line editor used for buffered console input (function 10), and used by CMDINT.

LSTMGR -- List manager which handles printer-oriented functions.

LSTTBL -- Tables which define how printer and queue letters are mapped into local and remote printers and queues, and the location on the network of any remote printers and queues.

SPOOLR -- Spooler routine which diverts print output to spool files when the spooler is activated. Also handles direct printing to remote printers.

COMMGR -- Comm channel manager which handles the communications channel.

NETREQ -- Network request processor which creates network request messages to be passed to remote processors for service.

MSGFMT -- Network message format table used by NETREQ.

NETMGR -- Network message routing mechanism used by NETSVC and NETREQ.

NETTBL -- Tables which define the topology of the network as seen from a particular processor.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

RTCMGR -- Real-time clock manager which maintains system date and time.

DSPCHR -- Multi-process dispatcher which controls the sharing of local processor time among multiple competing processes.

DSPSGL -- Null dispatcher used as an alternative to DSPCHR when only one process is required (e.g., in OSLOAD.COM and in minimal single-user configurations without spooling).

MEMMGR -- Memory manager which controls the dynamic allocation and deallocation of memory segments.

COMSUB -- Common subroutines utilized in all configurations.

SYSNIT -- System initialization routine which is executed at system start-up.

PATCH -- Optional module consisting of 64 bytes of zeroes which may be included to provide space for any required operating system patches.

Universal Driver-Level Modules

RTCNUL -- Null real-time clock driver for use in configurations in which there is no periodic interrupt source.

CONREM -- Remote console driver for network master to allow access from slave consoles by means of the MASTER command.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Hardware-Dependent Driver-Level Modules

Driver modules are hardware-dependent, and may vary significantly from one TurboDOS implementation to another. In general, the following drivers are required as a minimum:

CONDR@ -- Console driver allows character-by-character input from a console keyboard and output to a console display.

LSTDRA@ -- Printer driver allows character-by-character output to a hardcopy peripheral. TurboDOS supports multiple printer drivers.

COMDRV -- Comm. channel driver allows character-by-character input and output over one or more communications channels.

DSKDR@ -- Disk controller driver allows input and output of physical-records on a random-access mass storage device (usually flexible or hard disk). TurboDOS supports multiple disk controller drivers, each of which may support multiple drives.

CKTDR@ -- Network circuit driver allows sending and receiving messages to or from remote processors. TurboDOS supports multiple network circuit drivers, each of which may communicate with multiple remote processors.

RTCDRV -- Real-time clock driver services interrupts from a periodic interrupt source, used for time-slicing, delay measurement, and updating the system date and time.

HDWNIT -- Hardware initialization routine called by SYSNIT. This module usually consists of calls to initialization entrypoints in other drivers.

Standard Configurations

To simplify the system generation process, the most commonly used combinations of TurboDOS functional modules are pre-packaged into the standard configurations shown in the table on the facing page: STDLOADR, STDSINGL, STDSPOOL, STDMASTR, STDSLAVE and STDSLAVX. Most requirements for TurboDOS can be satisfied by linking the appropriate standard package together with the requisite driver modules.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

<u>Module</u>	<u>Size</u>	<u>O/S</u>	<u>Loader</u>	<u>Single User</u>	<u>Single User w/Spooling</u>	<u>Network Master</u>	<u>Simple Slave</u>	<u>Complex Slave</u>
		Kb	<u>STDLOADR</u>	<u>STDSSINGL</u>	<u>STDSPPOOL</u>	<u>STDMASTR</u>	<u>STDSSLAVE</u>	<u>STDSSLAVX</u>
LCLUSR	.9	-	LCLUSR	LCLUSR	LCLUSR	LCLUSR	LCLUSR	LCLUSR
LCLMSG	.1	-	LCLMSG	LCLMSG	LCLMSG	LCLMSG	LCLMSG	LCLMSG
LCLTBL	.0	-	LCLTBL	LCLTBL	LCLTBL	LCLTBL	LCLTBL	LCLTBL
CMDINT	.9	-	CMDINT	CMDINT	CMDINT	CMDINT	CMDINT	CMDINT
AUTLOD	.2	-	AUTLOD	AUTLOD	AUTLOD	AUTLOD	AUTLOD	AUTLOD
SGLUSR	.1	-	SGLUSR	SGLUSR	-	-	SGLUSR	
AUTLOG	.0	-	AUTLOG	AUTLOG	AUTLOG	AUTLOG	AUTLOG	AUTLOG
SUBMIT	.1	-	-	-	-	-	-	-
NETSVC	1.0	-	-	-	NETSVC	-	-	
DSPOOL	.8	-	-	DSPOOL	DSPOOL	-	DSPOOL	
FLUSHR	.2	-	-	-	FLUSHR	-	-	
OSLOAD	1.4	OSLOAD	-	-	-	-	-	
LDRMSG	.1	LDRMSG	-	-	-	-	-	
OSNTRY	.4	OSNTRY	OSNTRY	OSNTRY	OSNTRY	OSNTRY	OSNTRY	
FILMGR	1.4	FILMGR	FILMGR	FILMGR	FILMGR	-	FILMGR	
FILSUP	1.9	FILSUP	FILSUP	FILSUP	FILSUP	-	FILSUP	
FILCOM	.2	FILCOM	FILCOM	FILCOM	FILCOM	FILCOM	FILCOM	
FILLOK	1.3	-	-	-	FILLOK	-	-	
FFOMGR	.7	-	-	-	FFOMGR	-	-	
DRVLOK	.2	-	-	-	DRVLOK	-	-	
FASLOD	.3	-	FASLOD	FASLOD	FASLOD	-	FASLOD	
NORLOD	.1	-	-	-	-	-	-	
BUFMGR	1.0	BUFMGR	BUFMGR	BUFMGR	BUFMGR	-	BUFMGR	
DSKMGR	.6	DSKMGR	DSKMGR	DSKMGR	DSKMGR	-	DSKMGR	
DSKTBL	.0	DSKTBL	DSKTBL	DSKTBL	DSKTBL	DSKTBL	DSKTBL	
NONFIL	.1	NONFIL	NONFIL	NONFIL	NONFIL	NONFIL	NONFIL	
SGLLOG	.1	-	-	-	-	-	-	
CPMSUP	.2	-	-	-	-	-	-	
CONMGR	.3	CONMGR	CONMGR	CONMGR	CONMGR	CONMGR	CONMGR	
CONTBL	.0	CONTBL	CONTBL	CONTBL	CONTBL	CONTBL	CONTBL	
DOMGR	.3	-	DOMGR	DOMGR	DOMGR	DOMGR	DOMGR	
INPLN	.1	-	INPLN	INPLN	INPLN	INPLN	INPLN	
LSTMGR	.1	-	LSTMGR	LSTMGR	LSTMGR	LSTMGR	LSTMGR	
LSTTBL	.1	-	LSTTBL	LSTTBL	LSTTBL	LSTTBL	LSTTBL	
SPOOLR	.4	-	-	SPOOLR	SPOOLR	SPOOLR	SPOOLR	
COMMGR	.1	-	COMMGR	COMMGR	COMMGR	COMMGR	COMMGR	
NETREQ	.9	-	-	-	-	NETREQ	NETREQ	
MSGFMT	.1	-	-	-	-	MSGFMT	MSGFMT	
NETMGR	.3	-	-	-	NETMGR	NETMGR	NETMGR	
NETTBL	.0	-	-	-	NETTBL	NETTBL	NETTBL	
RTCMGR	.1	-	RTCMGR	RTCMGR	RTCMGR	-	RTCMGR	
DSPCHR	.6	-	-	DSPCHR	DSPCHR	DSPCHR	DSPCHR	
DSPSQL	.1	DSPSQL	DSPSQL	-	-	-	-	
MEMMGR	.3	-	MEMMGR	MEMMGR	MEMMGR	MEMMGR	MEMMGR	
COMSUB	.2	COMSUB	COMSUB	COMSUB	COMSUB	COMSUB	COMSUB	
SYSNIT	.0	-	SYSNIT	SYSNIT	SYSNIT	SYSNIT	SYSNIT	

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Estimating Memory Requirements

To estimate memory requirements for a particular TurboDOS configuration, it is necessary to take into account the combined size of functional modules (see table on previous page), hardware-dependent driver modules, disk buffers and other dynamically allocated storage segments.

Hardware-dependent drivers typically require 1K to 3K of memory, depending on the complexity of the hardware involved. Disk buffer space should be as large as possible for optimum performance, especially in a network master. About 4K of disk buffer space is acceptable for a single-user system, although less can be used in a pinch. Other dynamic storage usually doesn't exceed 1K in a single-user system, 2K in a networking system.

The following table gives typical memory requirements of standard TurboDOS configurations:

	O/S Loader <u>STDLOADR</u>	Single User <u>STDsingl</u>	Single User w/Spooling <u>STDSPool</u>	Network Master <u>STDMASTR</u>	Simple Slave <u>STDSlave</u>	Complex Slave <u>STDslavX</u>
TurboDOS	8K	10K	12K	15K	7K	14K
Drivers	2K	2K	2K	3K	1K	3K
Disk Buffers	4K	4K	4K	16K	0K	4K
Dynamic Space	<u>±1K</u>	<u>±1K</u>	<u>±1K</u>	<u>±3K</u>	<u>±2K</u>	<u>±2K</u>
Total Size	15K	17K	19K	37K	10K	23K
TPA (in 64K)	n/a	47K	45K	27K	54K	41K

Typical TurboDOS Memory Requirements

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

Linking and Loading

Functional modules of TurboDOS are distributed in relocatable form. Hardware-dependent device drivers are packaged in the same fashion. The GEN command processor is a specialized linkage editor which may be used to bind together the desired combination of modules into an executable version of TurboDOS configured with the desired set of functions and device drivers. GEN also includes a symbolic patch facility which may be used to alter a variety of operating system parameters.

To generate a TurboDOS system, the GEN command must be used to create both an executable loader OSLOAD.COM and an executable master operating system OSMASTER.SYS. In networking configurations, the GEN command must also be used to create a slave operating system OSSLAVE.SYS. The GEN command can also be used to generate the code for a start-up PROM (or boot track).

At system start-up, the start-up PROM (or boot track) loads the loader program OSLOAD.COM into the TPA of the master computer and executes it. OSLOAD loads the master operating system OSMASTER.SYS into the topmost portion of memory. In networking configurations, the master operating system down-loads the slave operating system OSSLAVE.SYS into the slave computers on the network.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

GEN Command

The GEN command is used for TurboDOS system generation (and may also be used as a general purpose linker for Microsoft-format .REL modules). It links a collection of relocatable modules together into a single executable file. The command format is:

```
GEN filename1 filename2 ;options
```

where "filename1" specifies the name of the configuration file (type .GEN) and parameter file (type .PAR) to be used, and "filename2" specifies the name of the executable file (normally type .COM or .SYS) to be created. If "filename2" is omitted from the command line, then "filename1" is used for the executable file and should include an explicit file type (.COM or .SYS).

If the configuration file (type .GEN) is found, it must contain the list of relocatable files to be linked together. If the configuration file is not found, then the GEN command operates in an interactive mode, reading successive directives from the console until terminated by a null directive. The format of each directive (or each line of the configuration file) is:

```
relfile1, relfile2, ..., relfileN
```

The GEN command links together all of the specified modules, a two-pass process which displays the name of each module as it is encountered. At the end of the second pass, the GEN command looks for a parameter file (type .PAR) and processes it (if found). Finally, the executable file is written out to disk.

Each relocatable TurboDOS module is magnetically serialized with a unique serial number. The serial number consists of two components: an origin number (which identifies the issuing OEM) and a unit number (which uniquely identifies each copy of TurboDOS issued by that OEM). The GEN command verifies that all modules to be linked are serialized consistently, and serializes the executable file accordingly.

The ";options" argument may contain either ";Lxxxx" or ";Uxxxx" to define either the lower or upper boundary of the executable program ("xxxx" is a hexadecimal memory address). The default boundary is ";L0100" if the output file is of type .COM, and ";UFFFF" if the output file is of type .SYS.

The ";options" argument may also contain ";X" to display undefined symbol references (quite normal in TurboDOS system generation), ";M" to print a load map on the printer, and ";S" to print a full symbol table on the printer.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Example:

The following example uses the GEN command to link the modules listed in OSMASTER.GEN and the patch parameters in OSMASTER.PAR, creating the executable file OSMASTER.SYS.

```
0A}GEN OSMASTER.SYS ;UBFFF
* STDSINGL, CON192, LSTCTS, SPD442
* SER480, BRT442O, RTC442
* DSK401, DSTBL8, HDWNIT

Pass 1.
LCLUSR    LCLTBL    CMDINT    AUTLOD    SGLUSR    AUTLOG
OSNTRY    FILMGR    FILSUP     FASLOD    BUFMGR    DSKMGR
DSKTBL    NONFIL    CONMGR    CONTBL    DOMGR     INPLN
LSTMGR    LSTTBL    COMMGR    RTCMGR    DSPSGL    MEMMGR
COMSUB    SYSNIT    CON192    LSTCTS    SPD442    SER480
BRT442    RTC442    DSK401    DSTBL8    HDWNIT

Pass 2.
LCLUSR    LCLTBL    CMDINT    AUTLOD    SGLUSR    AUTLOG
OSNTRY    FILMGR    FILSUP     FASLOD    BUFMGR    DSKMGR
DSKTBL    NONFIL    CONMGR    CONTBL    DOMGR     INPLN
LSTMGR    LSTTBL    COMMGR    RTCMGR    DSPSGL    MEMMGR
COMSUB    SYSNIT    CON192    LSTCTS    SPD442    SER480
BRT442    RTC442    DSK401    DSTBL8    HDWNIT

Processing parameter file:
AUTUSR = 80
NMBUFS = 8
PTRAST = 2
EOPCHR = 1A
SRHDRV = 1
Writing output file.
0A}
```

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Symbolic Patch Facility

The GEN command supports a symbolic patch facility which may be used to override various operating system parameters as well as to effect necessary software corrections. Symbolic patches must be stored in a parameter file (type .PAR), which may be built using any ordinary file editor. The format of each .PAR file entry is:

```
location = value1, value2, ..., valueN ;comments
```

where "value1" through "valueN" are to be loaded into consecutive memory locations starting with "location".

The argument "location" may be a public symbol name, a hexadecimal number, or an expression composed of names and hexadecimal numbers connected by "+" or "-". Hexadecimal numbers must begin with a decimal digit (e.g., "0FFFF"). The location expression must be followed by an equal-sign character.

The arguments "value1" through "valueN" may be expressions (as defined above) or quoted ASCII strings, and must be separated by commas. An expression is stored as a 16-bit word if its value exceeds 255 or if it is enclosed in parentheses; otherwise, an expression is stored as an 8-bit byte. A quoted ASCII string may be enclosed by either quotes or apostrophes, and is stored as a sequence of 8-bit bytes. Within a quoted string, ASCII control characters may be specified by using the circumflex (e.g., "^X" denotes CTRL-X).

Example:

```
CLBLEN = 9D      ;Command line buffer length (157)
CLSCHR = "\"      ;Command line separator character
ATNCHR = "^S"      ;Attention character
LOADFN = 0,"OSMASTER","SYS" ;File name to load
DSKAST = 00,DSKDRA,01,DSKDRA,00,DSKDRB,80,(0000),81,(0000)
```

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

TurboDOS Patch Points

Public symbols in the hardware-independent portion of TurboDOS which may be useful to patch are shown below, together with their default (unpatched) values. (Other patchable symbols may exist in hardware-dependent drivers, and are beyond the scope of this document.)

In AUTLOAD Module:

LDCOLD = OFF	Cold-start autoload enable flag (0 to disable)
LDWARM = OFF	Warm-start autoload enable flag (0 to disable)
COLDFN = 0,"COLDSTRT","AUT"	Cold-start autoload file name (12 bytes)
WARMFN = 0,"WARMSTRT","AUT"	Warm-start autoload file name (12 bytes)

In AUTLOG Module:

AUTUSR = OFF	Automatic log-on user number (sign-bit if privileged)
--------------	---

In BUFMGR Module:

BUFSIZ = 3	Default buffer size (0=128, 1=256, 2=512,..., 7=16K)
NMBUFS = 4	Default number of buffers

In CMDINT Module:

CLBLEN = 9D	Command line buffer length (default 2*80-3 = 157)
CLSCHR = "\\"	Command line separator character
CLPCHR = "J"	Command line prompt character
SRHDRV = 0	Search drive (0=off, 1="A", 2="B",..., 0FF=sysdsk)

In CONTBL Module:

ATNCHR = "^S"	Attention character
ATNBEL = "^G"	Attention-received warning
RESCHR = "^Q"	Resume character (attention response)
ABTCHR = "^C"	Abort character (attention response)
ECHOCHR = "^P"	Echo character (attention response)
PRTCHR = "^L"	End-print character (attention response)
CONAST = 00,CONDRA	Console assignment table

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

In DSKTBL Module:

DSKAST = 00,DSKDRA,01,DSKDRA,0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)

Disk assignment table (master, 16 3-byte entries)

In FILCOM Module:

LOGUSR = 1F User number for log-off (standard is 31)

In FILLOK Module:

COMPAT = 00 File/record locking compatibility flags

In FLUSHR Module:

BFLDLY = (012C) Buffer flush delay (in ticks, no flush if zero)

In LCLTBL Module:

PRTMOD = 1 Default print mode (0=direct, 1=spoooled, 2=console)
QUEPTR = 1 Default queue/printer (0=off, 1="A", 2="B", ...)
SPLDRV = 0FF Default spool drive (0="A", 1="B", ..., 0FF=sysdsk)

In LCLUSR Module:

MEMRES = (0100) Reserved memory above TPA

In LSTTBL Module:

EOPCHR = 0 End-of-print character (if nonzero)
DSPPAT = 1,...,1 De-spool printer assignment table (16 bytes)
PTRAST = 00,LSTDRA,0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)

Printer assignment table (master, 16 3-byte entries)

QUEAST = 00,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)
0FF,(0),0FF,(0),0FF,(0),0FF,(0)

Queue assignment table (master, 16 3-byte entries)

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

In MEMMGR Module:

MEMBLL = (1103) Memory base lower limit (standard assures 4K TPA)

In NETMGR Module:

NMBMBS = 0 Number of pre-allocated message buffers

In NETSVC Module:

NMBSVC = 2 Number of NETSVC server processes activated

SLVFN = "OSSLAVE ","SYS"
Name of .SYS file to download

In NETTBL Module:

NMBCKT = 1 Number of network circuits

DEFID = (0) Default network destination ID

CKTAST = (0000),CKTDRA,(0100),CKTDRB,(0200),CKTDRC,(0300),CKTDRD
Circuit assignment table (NMBCKT 4-byte entries)

FWDTBL = 0FF,0FF,0FF,0FF,0FF,0FF,0FF,0FF
Forwarding table (2-byte entries)

In NONEIL Module:

CPMVER = 30 CP/M BDOS version number (returned by function 12)

In OSLOAD Module:

LOADFN = 0,"OSMASTER","SYS"
Default drive and filename for OSLOAD (12 bytes)

MEMTOP = (0FFFF) Top limit of OSLOAD RAM test (don't test if zero)

In SUBMIT Module:

SUBFN = 0,"\$\$","SUB"
Submit file name

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

NOTE: In slave configurations STDSLAVE and STDSLAVX, the following default values change:

In DSktbl Module:

DSKAST = 80,(0),81,(0),82,(0),83,(0)
84,(0),85,(0),86,(0),87,(0)
88,(0),89,(0),8A,(0),8B,(0)
8C,(0),8D,(0),8E,(0),8F,(0)

Disk assignment table (slave, 16 3-byte entries)

In Lsttbl Module:

PTRAST = 80,(0),81,(0),82,(0),83,(0)
84,(0),85,(0),86,(0),87,(0)
88,(0),89,(0),8A,(0),8B,(0)
8C,(0),8D,(0),8E,(0),8F,(0)

Printer assignment table (slave, 16 3-byte entries)

QUEAST = 80,(0),81,(0),82,(0),83,(0)
84,(0),85,(0),86,(0),87,(0)
88,(0),89,(0),8A,(0),8B,(0)
8C,(0),8D,(0),8E,(0),8F,(0)

Queue assignment table (slave, 16 3-byte entries)

Explanations of Certain TurboDOS Patch Points

AUTUSR may be patched to cause an automatic log-on at cold-start time (rather than the usual password-protected log-on procedure). If automatic log-on is desired, patch AUTUSR to the desired user number (00...1F) and set the sign-bit if a privileged log-on is desired. The patch "AUTUSR = 80" should generally be included in single-user configurations to cause an automatic privileged log-on to user number zero.

SRHDRV may be patched to cause TurboDOS to automatically search another drive for a command processor (.COM file) if it is not found on the current default drive. Patch SRHDRV to 1 to search drive "A", 2 to search drive "B", etc. Alternatively, patch SRHDRV to OFF to search the system disk drive (i.e., whichever drive was used to boot up TurboDOS).

ATNCHR defines the keyboard character interpreted by TurboDOS as an "attention" request. It should be patched if the usual "^S" conflicts with the needs of applications (such as WordStar). A common alternative choice is ATNCHR = "^@" which allows the BREAK key to be used for attention on many systems.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

CONAST is a 3-byte entry which defines how console input/output is handled. The first byte is passed to the console driver module, and commonly defines the channel number (e.g., serial port) to be used for the console. The next word specifies the entrypoint address of the console driver to be used.

DSKAST is an array of sixteen 3-byte entries, one for each drive letter A...P, which define whether the corresponding drive is local, remote, or invalid.

- For a local drive, the first byte must not have the sign-bit set. That byte is passed to the disk driver module, and is commonly used to differentiate between multiple drives connected to a single controller. The next word specifies the entrypoint address of the disk driver to be used.
- For a remote drive, the first byte must have the sign-bit set. The low-order bits of that byte specifies the drive letter to be accessed on the remote processor. The next word specifies the network address of the remote processor.
- For an invalid drive, the first byte must be OFF, and the next word should be zero.

DSPPAT is an array of sixteen bytes, one for each printer letter A...P, which defines the initial de-spool queue to which each printer is assigned. Byte values 1...16 correspond to queues A...P, and zero means that the corresponding printer is initialized to off-line.

PTRAST is an array of sixteen 3-byte entries, one for each printer letter A...P, which define whether the corresponding printer is local, remote, or invalid.

- For a local printer, the first byte must not have the sign-bit set. That byte is passed to the list driver module, and commonly defines the channel number (e.g., serial port) to be used for the printer. The next word specifies the entrypoint address of the list driver to be used.
- For a remote printer, the first byte must have the sign-bit set. The low-order bits of that byte specifies the printer letter to be accessed on the remote processor. The next word specifies the network address of the remote processor.
- For an invalid printer, the first byte must be OFF, and the next word should be zero.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

QUEAST is an array of sixteen 3-byte entries, one for each queue letter A...P, which define whether the corresponding queue is local, remote, or invalid.

- For a local queue, all three bytes must be set to zero.
- For a remote queue, the first byte must have the sign-bit set. The low-order bits of that byte specifies the queue letter to be accessed on the remote processor. The next word specifies the network address of the remote processor.
- For an invalid queue, the first byte must be OFF, and the next word should be zero.

EOPCHR may be patched to any non-null ASCII character, in which case the presence of that character in the print output stream will automatically signal an end-of-print-job condition.

NMBMBS is a byte value that specifies the number of network message buffers to pre-allocate at cold-start time. This value may be left at zero, but memory fragmentation may be reduced by assigning a positive value (NMBCKT plus two is a good value to try).

NMBSVC is a byte value that specifies the number of NETSVC server processes to be created (the number of slave processors is a good value to try).

CKTAST is a table of 4-byte (2-word) entries. There are NMBCKT entries, one for each network circuit to which this processor is attached. The first word of each entry specifies the network address by which this processor is known on a particular circuit, and the second word specifies the entrypoint address of the circuit driver responsible for that circuit. (Possibly, several circuits may be handled by the same driver.)

FWDTBL is a table of 2-byte entries which define any explicit message forwarding routes which this processor may utilize. The first byte of each entry specifies a circuit number "N" which is not directly connected to this processor, and the second byte specifies a corresponding circuit number "C" which is directly-connected. Any network messages destined for circuit "N" will be routed via circuit "C". This table is variable length (possibly empty), and must be terminated with a byte OFF.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

Examples of Disk, Printer and Network Tables

Suppose we wish to generate a TurboDOS configuration in which disk drives A...E are to be defined as follows: Drive A is a local hard disk. Drives B and C are local floppies. Drives D and E are remote drives belonging to another processor whose network address is 05-09 (circuit 5, node 9), and are known to that processor as its drives A and B. The .GEN file would include disk driver modules for both hard disk and floppy controllers:

..., DSKHARD, DSKFLOP, ...

and the .PAR file would set up the disk assignment table for drives A...E as:

DSKAST = 00,DSKDRA, 00,DSKDRB, 01,DSKDRB, 80,(0509), 81,(0509)

Furthermore, suppose printers A...E are to be defined as follows: Printers A and B are serial printers using XON/XOFF protocol and connected to serial channels 1 and 2. Printers C and D are serial printers using CTS handshaking and connected to serial channels 3 and 4. Printer E is a remote printer belonging to the processor at network address 02-01 (circuit 2, node 1) and known to that processor as printer B. The .GEN file would include printer drivers for both XON/XOFF and CTS:

..., LSTXON, LSTCTS, ...

and the .PAR file would set up the printer assignment table for printers A...E as:

PTRAST = 01,LSTDRA, 02,LSTDRA, 03,LSTDRB, 04,LSTDRB, 81,(0201)

If de-spoiled printing is desired on all five printers, with one queue defined per printer (four local queues and one remote queue), then the .PAR file might set up the queue and de-spool printer assignment tables as:

QUEAST = 0,(0), 0,(0), 0,(0), 0,(0), 81,(0201)
DSPPAT = 1,2,3,4,5

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

Finally, suppose this processor is connected to two network circuits, a high-speed circuit (#5) and a low-speed circuit (#2). Suppose further that this processor is known on the high-speed circuit as network address 05-07, and on the low-speed circuit as network address 02-06. Suppose also that one of the other processors on circuit #5 can forward messages to circuits #8 and #9. The .GEN file would include network circuit drivers for both high- and low-speed circuits:

..., CKTHIGH, CKTLOW, ...

and the .PAR file might set up the network tables as follows:

```
NMBCKT = 2
CKTAST = (0507),CKTDRA, (0206),CKTDRB
DEFDID = (0509)
FWDTBL = 08,05, 09,05, OFF
```

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

Step-by-Step Procedure for System Generation

To generate a new version of TurboDOS, the following steps may be followed:

1. Bring up a single-user operating system, either CP/M or (preferably) a previous version of TurboDOS. If you are using CP/M, all diskettes will have to be in a format compatible with both CP/M and TurboDOS (e.g., eight-inch, one-sided, single-density, 128-byte sector size).
2. Make a working copy of your TurboDOS distribution diskette. Do not use the original diskette (in case something goes wrong). Insert the working diskette in a convenient disk drive.
3. Using an editor, create or revise the file OSMASTER.GEN containing the names of the relocatable files to be linked together. In most cases, this will consist of the appropriate STDxxxxx file plus all required device drivers.
4. Using an editor, create or revise the file OSMASTER.PAR containing any required patches. This may be omitted if no patches are desired.
5. Using the command "GEN OSMASTER.SYS", generate an executable system file. If the target machine has less than 64K of memory installed, don't forget to specify a ";Uxxxx" option on the GEN command.
6. If you need to generate a new O/S loader, create or revise the files OSLOAD.GEN and OSLOAD.PAR, and use the command "GEN OSLOAD.COM" to generate an executable loader file.
6. If you need to generate a new slave O/S for a networking configuration, create or revise the files OSSLAVE.GEN and OSSLAVE.PAR, and use the command "GEN OSSLAVE.SYS" to generate an executable down-load file.
7. To test the newly generated system, log onto your working diskette, eject all other diskettes, and enter the command "OSLOAD". If the new system fails to come up or to function properly, you will have to start over at step 1; there is most likely an error in one of your .GEN or .PAR files.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

SERIAL Command

Each relocatable TurboDOS module which is distributed to an OEM is partially serialized with an origin number only. Each OEM is provided with a SERIAL command processor which must be used to add a unique unit number to the relocatable modules of each copy of TurboDOS issued by that OEM.

The format of the SERIAL command is:

```
SERIAL srcfile destfile ;Unnn options
```

where "srcfile", "destfile" and "options" have exactly the same meanings as in the COPY command, and "nnn" is the unit number expressed as a decimal integer. The SERIAL command works exactly like the COPY command, except that it has the additional function of magnetically serializing .REL files.

The GEN command will not accept partially serialized modules that have not been uniquely serialized by the OEM. Conversely, the SERIAL command will not re-serialize modules which have already been fully serialized.

Example:

```
0A}SERIAL A: B: ;U289 N
A:ASSIGN.COM copied to B:ASSIGN.COM
.
.
.
A:USER.COM copied to B:USER.COM
0A}
```

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Generation

Step-by-Step Procedure for OEM Re-Distribution

To generate a serialized copy of TurboDOS for re-distribution by an OEM to a dealer or end-user, the following steps must be followed:

1. Assign a unique sequential unit number for this copy of TurboDOS, and register it promptly by filling-out a serial number registration card and mailing it to Software 2000 Inc.
2. Initialize a new diskette, and label it with the TurboDOS version number, the origin and unit numbers, and the required notice "Copyright (C) 1982 by Software 2000, Inc.".
3. Using the SERIAL command, copy and serialize the following files from your OEM redistribution master to the new diskette:

single-user without spooling: .REL files for STDLOADR and STDSINGL; .COM files for AUTOLOAD, BACKUP, BOOT, BUFFERS, COPY, DATE, DELETE, DIR, DO, DRIVE, DUMP, ERASEDIR, FIXMAP, FORMAT, GEN, LABEL, LOGOFF, LOGON, MONITOR, PRINT, RENAME, SET, SHOW, TYPE, USER, and VERIFY; and .REL files for all necessary driver modules.

single-user with spooling: .REL files for STDLOADR, STDSINGL, and STDSPOOL; .COM files for AUTOLOAD, BACKUP, BOOT, BUFFERS, COPY, DATE, DELETE, DIR, DO, DRIVE, DUMP, ERASEDIR, FIXMAP, FORMAT, GEN, LABEL, LOGOFF, LOGON, MONITOR, PRINT, PRINTER, QUEUE, RENAME, SET, SHOW, TYPE, USER, and VERIFY; and .REL files for all necessary driver modules.

multi-user networking: .REL files for STDLOADR, STDSINGL, STDSPOOL, STDMASTR, and STDSLAVE; .COM files for AUTOLOAD, BACKUP, BATCH, BOOT, BUFFERS, CHANGE, COPY, DATE, DELETE, DIR, DO, DRIVE, DUMP, ERASEDIR, FIFO, FIXMAP, FORMAT, GEN, LABEL, LOGOFF, LOGON, MASTER, MONITOR, PRINT, PRINTER, QUEUE, RECEIVE, RENAME, SEND, SET, SHOW, TYPE, USER, and VERIFY; and .REL files for all necessary driver modules.

Important Note: Be certain that the new diskette does not contain unserialized modules or SERIAL.COM.

4. Using the new serialized diskette, generate an executable loader and operating system, using the system generation procedure described earlier in this section.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Generation

5. In addition to the serialized diskette, the dealer or end-user should receive a TurboDOS start-up PROM (if applicable) and copies of the User's Guide and Configuration Guide.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.
System Implementation

SYSTEM IMPLEMENTATION

TurboDOS has been designed to run on any Z80-based microcomputer with at least 48K of RAM, a random-access mass storage device, and a full-duplex character-oriented console device (or on an interconnected network of such microcomputers). The process-level and kernel-level modules of TurboDOS do not depend upon the specific peripheral devices to be used. Rather, a set of hardware-dependent device driver modules must be included in each TurboDOS configuration in order to adapt the operating system to a particular hardware environment. Device drivers are typically required for consoles, printers, disk controllers, network interfaces, real-time clock, and communications.

Although Software 2000 Inc. can supply TurboDOS pre-configured for certain specific hardware configurations, most OEMs and many dealers and end-users will want to implement their own hardware-dependent drivers. Driver modules may be readily written by any programmer competent in Z80 assembly-language. This section provides detailed instructions to programmers for implementing such driver modules, and the Appendix includes assembly listings of various sample drivers.

Assembler Requirements

Drivers must be written using a Z80 assembler capable of producing relocatable modules with symbolic linkage information in the industry-standard Microsoft relocatable module format. Both Microsoft's MACRO-80 and Digital Research's RMAC assemblers have these characteristics, and are well suited for implementing TurboDOS drivers.

Phoenix Software Associates' (PSA) assembler (formerly TDL and Xitan) is an excellent relocatable Z80 assembler, but it produces object modules in a non-standard format. To alleviate this problem, a conversion utility (RELCVT.COM) is available from Software 2000 Inc. for converting PSA-format object modules to standard Microsoft format. The command

```
RELCVT filename
```

converts the PSA-format .REL file specified by "filename" into standard Microsoft .REL format. Wherever the characters "." and "%" appear in names in the PSA-format module, they are replaced by the characters "?" and "@" (respectively) in the Microsoft-format module.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Programming Conventions

Assembly-language examples in this section and in the Appendix are all coded for the PSA assembler. In the examples, the name suffix "#" is used to reference an external name that is defined in another module. The label suffix "::" is used to define a public name that is available for reference in other modules. Some assemblers require that such names be declared in an EXTERN or PUBLIC statement. Program, data, and common segments are introduced with a .LOC statement in the examples. Some assemblers use different statements (e.g., CSEG, DSEG, COMMON) to accomplish the same thing. Also, the symbol "." represents the current location counter value; some assemblers use "\$" or "*" instead.

Dynamic Memory Allocation

The resident portion of TurboDOS resides in the topmost portion of system memory. TurboDOS uses a common memory management module (MEMMGR) to provide dynamic allocation and de-allocation of memory space required for disk buffers, de-spool requests, file interlocks, DO-file nesting, etc. Dynamic memory segments are allocated downward from the base of the TurboDOS resident area, thereby reducing the space available for the transient program area (TPA). Deallocated segments are concatenated with any neighbors and threaded on a free list. A best-fit algorithm is used to reduce memory fragmentation.

Allocation and de-allocation of memory segments is accomplished in this manner:

LXI	H,36	;get size of requested segment in HL
CALL	ALLOC#	;allocate segment
ORA	A	;was segment allocated successfully?
JNZ	ERROR	;if not, error
PUSH	H	;else, segment base address in HL
.		
.		
.		
POP	H	;get address of memory segment in HL
CALL	DEALOC#	;de-allocate segment

ALLOC# prefixes each dynamic memory segment with a word containing the segment length, so that DEALOC# can tell how much memory is to be de-allocated. ALLOC# does not zero the newly allocated segment.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Threaded Lists

All dynamic structures in TurboDOS are maintained as threaded lists with bidirectional linkages. This technique permits a node to be easily added or deleted anywhere in a threaded list without searching. The list head and each list node must contain a two-word linkage (forward pointer and backward pointer).

Manipulation of threaded lists is accomplished in this manner:

```

LSTHED:          ;list head (initialized to empty
    .WORD   .
    .WORD   .-2   ;forward pointer
;                                ;backward pointer

;LSTNOD:          ;list node
    .WORD   0   ;forward pointer
    .WORD   0   ;backward pointer
    .BLKB   128 ;node body
    .
    .
    .
    LXI    H,LSTHED ;get list head address in HL
    LXI    D,LSTNOD ;get new node address in DE
    CALL   LNKEND#;link node to end of list
    .
    .
    .
    LXI    H,LSTNOD ;get node address in HL
    CALL   UNLINK#;unlink node from list
    .
    .
    .
    LXI    H,LSTHED ;get list head address in HL
    LXI    D,LSTNOD ;get new node address in DE
    CALL   LNKBEGL#;link node to beginning of list

```

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Dispatching

TurboDOS incorporates an extremely efficient and flexible mechanism for dispatching the Z80 microprocessor among various competing processes. In writing device drivers for TurboDOS, the programmer must take extreme care to use the dispatcher correctly in order to attain maximum performance.

Basically, the dispatcher enables one process to wait for some event (e.g., character available, operation complete) while allowing other processes to utilize the microprocessor. For each such event, the programmer must define a three-word structure called an "event semaphore". A semaphore consists of a count-word followed by a two-word list head. The count-word is used by the dispatcher to keep track of the status of the event, while the list head defines a threaded list of processes waiting for the event.

There are two fundamental operations which affect an event semaphore: waiting for the event to occur (WAIT#), and signalling that the event has occurred (SIGNAL#). These are coded in the following manner:

EVENT:		
.WORD 0		;event semaphore
.WORD .		;semaphore count
.WORD -.2		;semaphore list forward pointer
.		
.		
LXI H,EVENT		;get event semaphore address
CALL WAIT#		;wait until event occurs
.		
.		
LXI H,EVENT		;get event semaphore address
CALL SIGNAL#		;signal that event has occurred

Whenever a process waits on an event semaphore, WAIT# decrements the count-word of the semaphore. Thus, a negative count of -N signifies that there are N processes waiting for that event to occur. Whenever the occurrence of an event is signalled, SIGNAL# increments the count-word of the semaphore and awakens the process that has been waiting longest.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

If the occurrence of an event is signalled but no process is waiting for it, then SIGNAL# simply increments the count-word to a positive value. Thus, a positive count N signifies that there have been N occurrences of the event for which no process was waiting. In this case, the next N calls to WAIT# on that semaphore will return immediately without waiting.

Sometimes it is necessary for a process to wait for a specific time interval (e.g., head-settle delay, carriage-return delay) rather than for the occurrence of a specific event. The TurboDOS dispatcher provides a delay facility (DELAY#) which permits other processes to use the microprocessor while one process is waiting for such a time interval to expire. Delay intervals are measured in an implementation-defined unit called a "tick"; in most implementations, ticks occur 50 or 60 times per second. Delays may be coded in the following manner:

```
•  
•  
•  
LXI    H,6      ;get number of ticks to delay  
CALL   DELAY#  ;delay for specified interval  
•  
•
```

A delay of zero ticks may be specified to effect a very short delay, or simply to relinquish the processor to other processes on a "courtesy" basis.

For best performance, all driver delays should be accomplished by means of WAIT# (wait for an event to be signalled) or DELAY# (wait for a given interval of time to elapse). Drivers should never be coded to spin in a wait loop.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Interrupt Service Routines

The TurboDOS dispatching mechanism is especially efficient when used with interrupt-driven peripheral devices. In most situations, the interrupt service routine simply calls SIGNAL# to indicate that the event associated with the interrupt has occurred.

Service routines for low-frequency interrupts (no more than 100 times per second) should exit by means of the standard interrupt service routine exit ISRXIT# in order to provide frequent time-slicing of processes. Service routines for high-frequency interrupts (occurring more than 100 times per second) should simply enable interrupts and return, in order to avoid excessive dispatch overhead.

It is good programming practice for interrupt service routines to set up an auxilliary stack, in order to avoid the possibility of overflowing the stack area of a user's program. TurboDOS provides a standard interrupt stack area (INTSTK#) and stack pointer save location (INTSP#) for this purpose.

A simple interrupt service routine for a low-frequency interrupt could be coded in this manner:

DEVISR:	SSPD	INTSP#	;save user's stack pointer
	LXI	SP,INTSTK#	;set up auxilliary stack
	PUSH	PSW	;save all registers
	PUSH	B	
	PUSH	D	
	PUSH	H	
	IN	STATUS	;reset the interrupt condition
	LXI	H,EVENT	;get event semaphore address
	CALL	SIGNAL#	;signal that event has occured
	POP	H	;restore all registers
	POP	D	
	POP	B	
	POP	PSW	
	LSPD	INTSP#	;restore user's stack pointer
	JMP	ISRXIT#	;exit through dispatcher

In more complex interrupt situations, it may be necessary for an interrupt service routine to determine which of several possible events occurred, and to signal one of several alternative semaphores. Sometimes it may be desirable for an interrupt service routine to perform a data buffering function (e.g., to provide keyboard type-ahead).

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Poll Routines

Peripheral devices which are not capable of interrupting the processor must be polled by the device driver. To facilitate this, the TurboDOS dispatcher maintains a threaded list of poll routines, and executes the routines on the list at every dispatch. The function of each poll routine is to check the status of its peripheral device, and to signal the occurrence of an event (e.g., character available, operation complete) when it occurs. The routine LNKPOL# can be called at any time to link a new poll routine onto the poll list.

The only tricky thing about a poll routine is that it must be coded in such a fashion that it will not signal the occurrence a particular event more than once. This can be accomplished in various ways, but a most efficient method is for the poll routine to simply unlink itself from the dispatcher's poll list as soon as it has signalled the occurrence of an event. This can be accomplished in the following manner:

EVENT:	.WORD 0	;event semaphore
	.WORD .	;semaphore count
	.WORD .-2	;semaphore list forward pointer
	.	;semaphore list backward pointer
	.	
	.	
LXI	D,POLNOD	;get poll routine node address
CALL	LNKPOL#	;link poll routine onto poll list
CALL	POLRTN	;pre-test peripheral status (optional)
LXI	H,EVENT	;get event semaphore address
CALL	WAIT#	;wait until event occurs
	.	
	.	
	.	
POLNOD:	.WORD 0	;poll routine node linkage
	.WORD 0	
POLRTN:	IN STATUS	;get peripheral status
	ANI MASK	;is input character available?
	RZ	;if not, exit
LXI	H,EVENT	;else, get event semaphore address
CALL	SIGNAL#	;signal that event has occurred
LXI	H,POLNOD	;get poll routine node address
CALL	UNLINK#	;unlink poll routine from poll list
RET		;done

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Re-Entrancy and Mutual Exclusion

All TurboDOS process-level and kernel-level modules permit re-entrant execution by multiple processes. However, most driver-level modules are not coded re-entrantly (since most peripheral devices can only do one thing at a time). Consequently, most drivers must make use of a mutual-exclusion interlock to prevent re-entrant execution.

Using the TurboDOS event semaphore mechanism, such a mutual-exclusion interlock can be implemented very simply in the following manner:

```
MXLOCK:           ;mutual-exclusion interlock semaphore
    .WORD   1      ;semaphore count (initialized to 1)
    .WORD   .
    .WORD   .-2     ;semaphore list head forward pointer
    ;semaphore list head backward pointer
;
DRIVER: LXI     H, MXLOCK ;get interlock semaphore address
CALL    WAIT#    ;wait if driver is already in use
        .
        .
        .
LXI     H, MXLOCK ;get interlock semaphore address
CALL    SIGNAL#   ;signal driver no longer in use
RET     ;done
```

Note that the interlock semaphore count-word must be initialized to 1 (instead of 0) for this scheme to work properly.

Configuration Guide to TurboDOS 1.2
 Copyright (C) 1982 by Software 2000, Inc.
 System Implementation

Sample Interrupt-Driven Device Driver

The following is a simple device driver for an interrupt-driven serial input device. It illustrates the coding techniques described previously:

```

MXLOCK:
    .WORD   1          ;mutual-exclusion interlock semaphore
    .WORD   .           ;semaphore count (initialized to 1!)
    .WORD   .-2         ;semaphore list head forward pointer
                      ;semaphore list head backward pointer
;
EVENT:
    .WORD   0          ;event semaphore
    .WORD   .           ;semaphore count
    .WORD   .-2         ;semaphore list forward pointer
                      ;semaphore list backward pointer
;
CHRSAV: .BYTE 0          ;input character save location
;
DRIVER: LXI      H,MXLOCK ;get interlock semaphore address
        CALL     WAIT#    ;wait if driver is already in use
        EI       .          ;ensure that interrupts are enabled
        LXI      H,EVENT   ;get event semaphore
        CALL     WAIT#    ;wait for event to occur
        LDA      CHRSAV   ;get input character
        PUSH    PSW       ;save on stack
        LXI      H,MXLOCK ;get interlock semaphore address
        CALL     SIGNAL#  ;signal driver no longer in use
        POP     PSW       ;return input character in A-register
        RET     .          ;done
;
DEVISR: SSPD    INTSP#   ;save user's stack pointer
        LXI      SP,INTSTK#;set up auxilliary stack
        PUSH    PSW       ;save all registers
        PUSH    B          .
        PUSH    D          .
        PUSH    H          .
        IN      STATUS   ;get peripheral status
        ANI     MASK     ;is input character available?
        JRZ     ..X       ;if not, exit
        IN      DATA     ;else, get input character
        STA     CHRSAV   ;save input character
        LXI      H,EVENT   ;get event semaphore address
        CALL    SIGNAL#  ;signal that event has occured
        ..X:
        POP     H          ;restore all registers
        POP     D          .
        POP     B          .
        POP     PSW       ;
        LSDP    INTSP#   ;restore user's stack pointer
        JMP     ISRXIT#  ;exit through dispatcher
;
```

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Sample Polled Device Driver

The following is a simple device driver for a polled serial input device. It illustrates the coding techniques described previously:

```
MXLOCK:
    .WORD    1          ;mutual-exclusion interlock semaphore
    .WORD    .           ;semaphore count (initialized to 1!)
    .WORD    .-2         ;semaphore list head forward pointer
    .WORD    .-2         ;semaphore list head backward pointer
;
EVENT:
    .WORD    0          ;event semaphore
    .WORD    .           ;semaphore count
    .WORD    .-2         ;semaphore list forward pointer
    .WORD    .-2         ;semaphore list backward pointer
;
CHRSAV: .BYTE   0          ;input character save location
;
DRIVER: LXI     H,MXLOCK  ;get interlock semaphore address
        CALL    WAIT#    ;wait if driver is already in use
        LXI     D,POLNOD ;get poll routine node address
        CALL    LNKPOL#   ;link poll routine onto poll list
        CALL    POLRTN   ;pre-test peripheral status (optional)
        LXI     H,EVENT   ;get event semaphore address
        CALL    WAIT#    ;wait until event occurs
        LDA     CHRSAV   ;get input character
        PUSH   PSW       ;save on stack
        LXI     H,MXLOCK  ;get interlock semaphore address
        CALL    SIGNAL#   ;signal driver no longer in use
        POP    PSW       ;return input character in A-register
        RET
;
POLNOD: .WORD   0          ;done
        .WORD   0
;
POLRTN: IN      STATUS   ;poll routine node linkage
        ANI    MASK
        RZ
        IN      DATA
        STA    CHRSAV
        LXI     H,EVENT
        CALL   SIGNAL#
        LXI     H,POLNOD
        CALL   UNLINK#
        RET
```

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Initialization Segments

In programming hardware-dependent driver modules, it is frequently necessary to include a considerable amount of initialization code which is executed only once (at system start-up) and never needed again. TurboDOS provides a space-saving mechanism whereby such initialization code may be loaded and executed in lower memory (TPA), instead of becoming part of the resident operating system. To use this feature, each initialization segment must be assembled under a special location counter (i.e., common block) named ?INIT? (or .INIT.# if PSA assembler and RELCVT are used):

```
.LOC      .INIT.#      ;initialization segment follows
;
HDWNIT:: XRA      A      ;start of initialization code
.
.
.
RET          ;end of initialization code
;
```

Page-Oriented Segments

Sometimes, a programmer must force a segment of code or data to begin on a 256-byte page boundary. Examples are interrupt vectors for Z80 IM2, and the simulated CP/M BIOS branch table. To do this, a page-oriented segment must be assembled under a special location counter (i.e., common block) named ?PAGE? (or .PAGE.# if PSA assembler and RELCVT are used). If several modules utilize the ?PAGE? location counter, then a separate page is allocated for each such module.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Inter-Process Messages

For passing messages from one process to another, TurboDOS makes use of a five-word structure called a "message node". A message node consists of a three-word event semaphore followed by a two-word message list head. Subroutines are provided for sending messages to a message node (SNDMSG#), and receiving messages from a message node (RCVMSG#). Typically, the sending process allocates a segment of dynamic memory in which to build the message, and the receiving process deallocates the segment after making use of the message:

MSGNOD:	.WORD 0	;message node
	.WORD .	;semaphore count
	.WORD .-2	;semaphore list forward pointer
	.WORD .	;semaphore list backward pointer
	.WORD .-2	;message list forward pointer
		;message list backward pointer
SEND:	LXI H,12	;get size of message to send
	CALL ALLOC#	;allocate message packet
	PUSH H	;save message packet address
	.	
	.	
	.	
	POP D	;get address of message packet in DE
	LXI H,MSGNOD	;get address of message node in HL
	CALL SNDMSG#	;send inter-process message
	.	
	.	
	.	
REC:	LXI H,MSGNOD	;get address of message node in HL
	CALL RCVMSG#	;receive inter-process message
	PUSH H	;save message packet address
	.	
	.	
	.	
	POP H	;read message in packet
	CALL DEALOC#	;get address of message packet in HL
	.	
	.	
	.	

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Console Subroutines

The following illustrates the use of various console-related subroutines which may be called from within driver modules:

	CALL CONST#	;returns console status in A-reg
	ORA A	;is console input available?
	RZ	;if not, exit
	CALL CONIN#	;returns console input in A-reg
	CALL UPRCAS#	;convert lower-case letters to upper-case
	MOV C,A	;move character to C-reg
	CALL CONOUT#	;displays character passed in C-reg
..MSG:	CALL DMS#	;display following message
	.ASCIS "Message"	;last byte of message has sign-bit set
	LXI H,..MSG	;HL -> sign-bit-terminated message
	CALL DMSHL#	;display message pointed-to by HL
	LXI H,31416	;HL has any 16-bit value
	CALL DECOUT#	;displays HL value in decimal

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Creating a Resident Process

In some circumstances, it may be desirable to activate a resident process which runs in the background concurrent with other system activities. The create-process subroutine CRPROC# may be called to create such a process at system initialization time as illustrated below:

```
.LOC    .INIT.#      ;initialization segment follows
;
; HDWNIT::
LXI    D,BACKGR    ;hardware-dependent initialization
CALL   CRPROC#     ;get process entrypoint address
          ;create process
.
.
.

.LOC    .PROG.#      ;program segment follows
;
; BACKGR:
LXI    D,60*60      ;background process starts here
MVI    C,125        ;number of ticks in one minute
CALL   OSNTRY#     ;number of "delay process" function
LXI    D,..FCB       ;delay for one minute
MVI    C,15         ;get FCB address
CALL   OSNTRY#     ;number of "open file" function
OR     A             ;open the file
JRNZ   BACKGR      ;was file opened successfully?
          ;if not, try again in a minute
          ;otherwise, ...
.
.

..FCB:  .BYTE   0       ;file control block
        .ASCII  "FILENAME"
        .ASCII  "TYP"
        .BYTE  [24]0
```

The CRPROC# routine automatically assigns a TurboDOS work area whose address appears to the new process in the X-register, and a 64-word stack area whose address appears in the SP-register. If the process requires a re-entrant work area (usually dynamically allocated), its address should be passed to CRPROC# in the HL-register and will appear to the new process in the Y-register.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Note that the resident process must make all its operating system requests in exactly the same fashion as a transient program would, except that the operating system entrypoint OSNTRY# is used instead of location 0005H. This is very important. A resident process must not make direct calls to kernel-level subroutines such as WAIT#, SIGNAL#, DELAY#, SNDMSG#, RCVMSG#, ALLOC#, DEALOC#, DMS#, etc. Also, a resident process is not attached to a console, so any console input/output operations it issues will be ignored.

A resident process must preserve index register X, but may use other registers as desired.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Driver Interface Specifications

The interface specifications for various kinds of device drivers are described below. Drivers may be packaged into as many or few separate modules as desired by the programmer. In general, it is easier to reconfigure TurboDOS for a wide variety of peripheral devices if the driver for each device is packaged as a separate module.

TurboDOS may be configured with multiple disk, console, printer and network drivers. The disk driver entrypoint table refers to disk driver entrypoints DSKDRA#, DSKDRB#, DSKDRC#, etc. Each disk driver should be coded with a public entrypoint DSKDR@:: (or DSKDR%:: if PSA assembler and RELCVT are used). The GEN command automatically maps successive definitions of such names by replacing the trailing @ by A, B, C, etc. The same technique should be used for console, printer, and network drivers.

To allow various TurboDOS modules to be included or omitted at will, the GEN command automatically resolves all undefined external references to the default symbol ?UND?#. The TurboDOS common subroutine module COMSUB contains the following stub routine:

?UND?::	NOP	;	single- or double-length load
	NOP	;	of undefined returns zero
	XRA	A	;call of undefined returns A=0
	RET		;done

Thus, it is always safe to load or call an external name, whether or not it is defined.

Driver routines must preserve the stack and the index registers X and Y, but may use other registers as desired.

Initialization

All necessary hardware initialization and interrupt vector setup should be performed by an initialization routine that begins with the public entry name HDWNIT::. This routine is called by TurboDOS at system start-up with interrupts disabled. The hardware initialization procedure must not enable interrupts or make calls to WAIT# or DELAY#. In most cases, the HDWNIT:: routine should contain a series of calls to individual driver initialization subroutines. All initialization code which is not needed again should be assembled under the location counter (i.e., common block) ?INIT?.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Console Drivers

Each console driver routine should begin with the public entry name CONDR@::, and should perform a console operation in accordance with the operation code (0, 1, 2, 8 or 9) passed by TurboDOS in the E-register. A console number is passed in the B-register (obtained from the least-significant nibble of the console assignment table entry CONAST#).

If E=0, the driver must determine if a console input character is available. It must return with A=-1 if a character is available, or with A=0 if no character is available. If a character is available, the driver must return it in the C-register, but must not "consume" the character. (This look-ahead capability is used by TurboDOS to detect attention requests.)

If E=1, the driver must obtain a console input character (waiting for one if necessary), and return it in the A-register.

If E=2, the driver must output to the console the character passed by TurboDOS in the C-register.

If E=8, the driver should prepare to display a TurboDOS error message; if E=9, the driver should revert to normal display. Error message displays issued by TurboDOS are always preceded by an E=8 call and followed by an E=9 call. This gives the console driver the opportunity to take special action for system error messages (e.g., 25th line, reverse video). For simple console devices, the driver should perform a carriage-return and line-feed in response to E=8 and E=9 calls.

Printer Drivers

Each printer driver routine should begin with the public entry name LSTDRA@::, and should perform a printer operation in accordance with the operation code (2 or 7) passed by TurboDOS in the E-register. A printer number is passed in the B-register (obtained from the least-significant nibble of the printer assignment table entry LSTAST#).

If E=2, the driver must output to the printer the character passed by TurboDOS in the C-register.

If E=7, the driver should take any appropriate end-of-print-job action (e.g., re-align forms, drop ribbon, home print head).

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Network Circuit Drivers

Each network circuit driver should begin with the public entry name CKTDR@::, and should send or receive a network message, according to the operation code (0 or 1) passed by TurboDOS in the C-register.

If C=0, the driver must receive a network message into the message buffer whose address is passed by TurboDOS in the DE-registers. If a message is received successfully, the driver must return with A=0. On the other hand, a malfunction of any remote processor is detected, the driver must return with A=-1 and must return the network address of the crashed processor in the DE-registers.

If C=1, the driver must send the network message from the message buffer whose address is passed by TurboDOS in the DE-registers. If a message is sent successfully, the driver must return with A=0. On the other hand, if the message could not be sent because of a malfunction of the destination processor, the driver must return with A=-1 and must return the network address of the crashed processor in the DE-registers.

The format of a network message buffer is:

Linkage:	.WORD	.	;buffer linkage
	.WORD	:	
Header:	.BYTE	MSGLEN	;message length (excludes linkage)
	.WORD	MSGDID	;network address of message destination
	.BYTE	MSGPID	;process ID
	.WORD	MSGSID	;network address of message source
	.WORD	MSGOID	;network address of originator
	.BYTE	MSGOPR	;process ID of originator
	.BYTE	MSGLVL	;forwarding level number
	.BYTE	MSGFCD	;message format code
Body:	.BLKB	7	;registers: A,C,B,E,D,L,H
	.BLKB	38	;FCB data and related info (optional)
	.BLKB	128	;record data (optional)

The first four bytes of a message buffer contains a linkage used by TurboDOS, and should not be sent or received by the driver. The eleven-byte header and variable-length body should be passed over the network. The driver should only need to look at the message length and destination ID in order to do its job. On a receive request (C=0), TurboDOS presets the message length byte to the maximum allowable message length, and expects that byte to contain the actual message length upon return. On a send request (C=1), TurboDOS presets the message length byte to the actual length

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

of the message to be sent (header plus body).

In simple master-slave network situations, it is often desirable for the circuit driver in the master processor to periodically "poll" the slave processors on its circuit in order to detect any slave malfunctions in a timely fashion and to effect recovery. If the circuit driver reports that a slave has crashed (by returning A=-1 and DE=net-address), then the circuit driver must not accept any further messages from that slave until TurboDOS has completed its recovery for that slave. TurboDOS signals the driver that such recovery is complete by sending a dummy message destined for that slave with a length of zero. The driver should not actually send such a message to the slave, but could initiate whatever action is appropriate to reset the slave and initiate a new down-load of the slave operating system.

For a slave processor to have its operating system downloaded over the network, it must send a special download-request message consisting of a standard eleven-byte header (with MSGPID, MSGOID and MSGFCD set to zero) followed by a one-byte body containing a "download suffix" character. The master processor specified by MSGDID will return a reply message whose body contains the first 128-byte record of the file OSSLAVEx.SYS (where "x" is the specified download suffix). The slave should continue to send download-request messages and receive successive records of the .SYS file until it receives a "short" reply message signifying end-of-file. The first word of the OSSLAVEx.SYS file specifies the base address to which the system should be moved, and the second word specifies the total length of the system. The single byte passed as the body of the "short" reply message identifies the system disk, and should be passed to the system in the A-register.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Disk Drivers

Each disk driver routine should begin with the public entry name DSKDR@::, and should perform a physical disk operation as specified by the physical disk request packet whose address is passed by TurboDOS in the X-register. The format of the physical disk request packet is:

X+0:	.BYTE	OPCODE	;disk operation code
X+1:	.BYTE	DRIVE	;drive number on controller (base 0)
X+2:	.WORD	TRACK	;physical track number (base 0)
X+4:	.WORD	SECTOR	;physical sector number (base 0)
X+6:	.WORD	SECCNT	;number of sectors to read or write
X+8:	.WORD	BYTCNT	;number of bytes to read or write
X+10:	.WORD	DMAADR	;DMA address for read or write
X+12:	.WORD	DSTADR	;disk specification table address
;			
;copy of disk specification table follows			
;			
X+14:	.BYTE	BLKSIZ	;block size (3=1K, 4=2K,..., 7=16K)
X+15:	.WORD	NMBLKS	;number of blocks, total
X+17:	.BYTE	NMBDIR	;number of directory blocks
X+18:	.BYTE	SECSIZ	;sector size (0=128, 1=256, 2=512,..., 7=16K)
X+19:	.WORD	SECTRK	;sectors per track
X+21:	.WORD	TRKDSK	;total tracks on disk
X+23:	.WORD	RESTRK	;reserved tracks on disk

If OPCODE=0, then the driver must read SECCNT physical sectors (or BYTCNT bytes) into DMAADR, starting at TRACK and SECTOR on DRIVE. Return with A=-1 if an unrecoverable error occurs, otherwise return with A=0. Although TurboDOS may request many consecutive sectors to be read, it will never request an operation which extends past the end of the specified track.

If OPCODE=1, then the driver must write SECCNT physical sectors (or BYTCNT bytes) from DMAADR, starting at TRACK and SECTOR on DRIVE. Return with A=-1 if an unrecoverable error occurs, otherwise return with A=0. Although TurboDOS may request many consecutive sectors to be written, it will never request an operation which extends past the end of the specified track.

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

If OPCODE=2, then the driver must determine the type of disk mounted in the specified drive, and must return in DSTADR the address of an 11-byte disk specification table structured as follows:

DST:	.BYTE	BLKSIZ	;block size (3=1K, 4=2K,..., 7=16K)
	.WORD	NMBLKS	;number of blocks, total
	.BYTE	NMBDIR	;number of directory blocks
	.BYTE	SECSIZ	;sector size (0=128, 1=256, 2=512,..., 7=16K)
	.WORD	SECTRK	;sectors per track
	.WORD	TRKDSK	;total tracks on disk
	.WORD	RESTRK	;reserved tracks on disk

On return, TurboDOS moves a copy of the disk specification table into X+14 through X+24, where it is available for subsequent read and write operations on that drive. If the drive is not ready or the type is unrecognizable, the driver must return A=0, otherwise it must return A=-1.

If OPCODE=3, then the driver must determine whether or not the specified drive is ready. Return A=-1 if the drive is ready, otherwise return A=0.

If OPCODE=4, then the driver must format (i.e., initialize) the specified TRACK on DRIVE. Hardware-dependent formatting information will be provided at DMAADR. Return with A=-1 if an unrecoverable error occurs, otherwise return with A=0.

Configuration Guide to TurboDOS 1.2

Copyright (C) 1982 by Software 2000, Inc.

System Implementation

Real-Time Clock Driver

The real-time clock driver normally consists of an interrupt service routine which responds to interrupts from a periodic interrupt source (preferably 50 to 60 times per second). The interrupt service routine should call DLYTIC# once per system tick to synchronize process delay requests. It should also call RTCSEC# once per second (i.e., every 50 or 60 ticks) to update the system time and date. Finally, it should exit through ISRXT# to provide a periodic system time-slice.

Excluding necessary initialization code, a typical real-time clock driver might look like this:

RTCCNT: .BYTE	1	;divide-by-60 counter
;		
RTCISR: SSPD	INTSP#	;save user's stack pointer
LXI	SP,INTSTK#	;set up auxilliary stack
PUSH	PSW	;save all registers
PUSH	B	
PUSH	D	
PUSH	H	
IN	STATUS	;reset the interrupt condition
CALL	DLYTIC#	;signal one tick elapsed time
LXI	H,RTCCNT	;get divide-by-60 counter
DCR	M	;decrement counter
JRNZ	.X	;not 60 ticks yet, exit
MVI	M,60	;else, reset counter to 60 ticks
CALL	RTCSEC#	;signal one second elapsed time
.X:	POP H	;restore all registers
POP	D	
POP	B	
POP	PSW	
LSPD	INTSP#	;restore user's stack pointer
JMP	ISRXT#	;exit through dispatcher

If it is possible to determine the date and/or time-of-day at cold-start (e.g., by means of a battery-powered clock board), then the driver may initialize the following public symbols in RTCMGR:

SECS:: .BYTE	0	;0...59
MINS:: .BYTE	0	;0...59
HOURS:: .BYTE	0	;0...23
JDATE:: .WORD	8001H	;Julian date, based 31 Dec 47

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Comm Channel Drivers

The comm channel driver supports the TurboDOS communications extensions (functions 87...93), and is not required if these functions are not used. The comm channel driver routine should begin with the public entry name COMDRV::, and should perform a comm channel operation in accordance with the operation code passed by TurboDOS in the E-register. A channel number is passed in the B-register.

If E=0, the driver must determine if an input character is available on the specified channel. It must return with A=-1 if a character is available, or with A=0 if no character is available.

If E=1, the driver must obtain an input character from the specified channel (waiting for one if necessary), and return it in the A-register.

If E=2, the driver must output to the specified channel the character passed by TurboDOS in the C-register.

If E=3, the driver must set the baud rate of the specified channel according to the baud rate code passed by TurboDOS in the C-register. (See function 90 in the User's Guide for definition of the codes.)

If E=4, the driver must obtain the current baud rate code for the specified channel, and return it in the A-register.

If E=5, the driver must set the modem controls of the specified channel according to the modem control vector passed by TurboDOS in the C-register. (See function 92 in the User's Guide for definition of the vector.)

If E=6, the driver must obtain the current modem status vector for the specified channel, and return it in the A-register. (See function 93 in the User's Guide for definition of the vector.)

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
System Implementation

Bootstrap ROM

Implementation of a TurboDOS bootstrap ROM involves linking the standard bootstrap module OSBOOT with a hardware-dependent driver OSBDRV. This should be accomplished with the GEN command, using the ";Lxxxx" option to establish the desired ROM base address. Since the OSBOOT module requires only 0.4K, the completed bootstrap can fit in a 1K ROM (e.g., 2708) if the driver is kept simple enough. The driver module OSBDRV must define five public entry names: INIT::, SELECT::, READ::, XFER::, and RAM::.

INIT:: is called at the beginning of the bootstrap process, and performs any required hardware initialization (e.g., of the disk controller). It must return with the load base address in the HL-registers. The load base address determines the RAM where loading of the file OSLOAD.COM will begin. It should normally be 0100H, but may have to be a higher address if low RAM cannot be written while the ROM is enabled.

SELECT:: selects the disk drive according to the drive number 0...15 passed in the A-register. If the selected drive is not ready or non-existent, then this routine must return A=0. Otherwise, it must return A=-1, and must return the address of an appropriate disk specification table in the HL-registers. The disk specification table is an 11-byte table whose format is the same as described earlier for the normal disk driver.

READ:: reads one physical sector from the last selected drive into RAM. On entry, the physical track is passed in the BC-registers, the physical sector is passed in the DE-registers, and the starting RAM address is passed in the HL-registers. The routine must return with A=0 if the operation was successful, or with A=-1 if an unrecoverable error occurred.

XFER:: is executed at the end of the bootstrap process, and transfers control to the loader program OSLOAD.COM which has been loaded into RAM. In most cases, this involves simply setting location 0080H to zero (to simulate a null command tail), and jumping to 0100H. However, if INIT returned a loader base other than 0100H, then XFER should move the loader program down to 0100H prior to execution.

RAM:: defines the beginning of a 64-byte area of RAM that OSBOOT can use as working storage. Obviously, it should not be located in the area in which OSLOAD.COM will be loaded!

Configuration Guide to TurboDOS 1.2
Copyright (C) 1982 by Software 2000, Inc.
Sample Driver Listings

APPENDIX — SAMPLE DRIVER LISTINGS



EQUATE - TURBODOS OPERATING SYSTEM --COMMON SYMBOLIC EQUATES FOR DRIVERS
PYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```
; ****
; *
; * The following are common symbolic equates used in
; * the various drivers which follow. They are refer-
; * enced by a .INSERT DREQUATE in each driver module.
; *
; ****
; COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

; AUTHORS: RONALD E. RAIKES
; MICHAEL D. BUSCH

; VERSION: EXAMPLE

; IDENT   EQUATE      ;MODULE ID
; ASCII EQUIVALENCES
;
0000    ANUL    == 00H  ;NULL
0001    ASOH    == 01H  ;SOH
0002    ASTX    == 02H  ;STX
0003    AETX    == 03H  ;ETX
0004    AEOT    == 04H  ;EOT
0005    AENQ    == 05H  ;ENQ
0006    AACK    == 06H  ;ACK
0007    ABEL    == 07H  ;BELL
0008    ABS     == 08H  ;BS
0009    AHT     == 09H  ;HT
000A    ALF     == 0AH  ;LF
000B    AVT     == 0BH  ;VT
000C    AFF     == 0CH  ;FF
000D    ACR     == 0DH  ;CR
000E    ASO     == 0EH  ;SO
000F    ASI     == 0FH  ;SI
0010    ADLE    == 10H  ;DLE
0011    ADC1    == 11H  ;DC1
0012    ADC2    == 12H  ;DC2
0013    ADC3    == 13H  ;DC3
0014    ADC4    == 14H  ;DC4
0015    ANAK    == 15H  ;NAK
0016    ASYN    == 16H  ;SYN
0017    AETB    == 17H  ;ETB
0018    ACAN    == 18H  ;CAN
0019    AEM     == 19H  ;EM
001A    ASUB    == 1AH  ;SUB
001B    AESC    == 1BH  ;ESC
001C    AFS     == 1CH  ;FS
001D    AGS     == 1DH  ;GS
001E    ARS     == 1EH  ;RS
001F    AUS     == 1FH  ;US
0020    ASP     == 20H  ;SPACE
007F    ARUB    == 7FH  ;RUBOUT (DEL)
```

EQUATE - TURBODOS OPERATING SYSTEM --COMMON SYMBOLIC EQUATES FOR DRIVERS
 COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

;          ;WBOOT    == 0000H      ;WARM START ENTRYPOINT
0000      IOBYTE   == 0003H      ;I/O CONFIGURATION BYTE
0003      CURDRV   == 0004H      ;CURRENT DEFAULT DRIVE
0004      OPSYS    == 0005H      ;OPERATING SYSTEM ENTRYPOINT
0005      TFCB     == 005CH      ;DEFAULT FILE CONTROL BLOCK
005C      TBUF     == 0080H      ;DEFAULT DISK BUFFER ADDRESS
0080      TPA      == 0100H      ;TRANSIENT PROGRAM AREA BASE
0100      ;          ;LOC    0      ;WORKING STORAGE RELATIVE TO 0
0000      ;          ;PDRDP:      ;PD REQUEST DESCRIPTOR PACKET
0000      PDRFCN: .BLKB    1      ;PD REQUEST FUNCTION NUMBER
0001      PDRDRV: .BLKB    1      ;PD REQUEST DRIVE NUMBER
0002      PDRTRK: .BLKW    1      ;PD REQUEST TRACK NUMBER
0004      PDRSEC: .BLKW    1      ;PD REQUEST SECTOR NUMBER
0006      PDRSC:  .BLKW    1      ;PD REQUEST SECTOR COUNT
0008      PDRTC:  .BLKW    1      ;PD REQUEST TRANSFER COUNT
000A      PDRDMA: .BLKW    1      ;PD REQUEST DMA ADDRESS
000C      PDRDST: .BLKW    1      ;PD REQUEST DRIVE SPEC TABLE ADDR
000E      PDRLEN == .-PDRDP      ;PD REQUEST DESCRIPTOR PACKET LEN
000E      ;          ;DSKNFO:      ;DISK TYPE INFORMATION
000E      BLKSIZ: .BLKB    1      ;BLOCK SIZE
000F      NMBLKS: .BLKW    1      ;NUMBER OF BLOCKS
0011      NMBDIR: .BLKB    1      ;NUMBER OF DIRECTORY BLOCKS
0012      SECSIZ: .BLKB    1      ;PHYSICAL SECTOR SIZE (2^N*128)
0013      SECTRK: .BLKW    1      ;PHYSICAL SECTORS PER TRACK
0015      TRKDSK: .BLKW    1      ;PHYSICAL TRACKS PER DISK
0017      RESTRK: .BLKW    1      ;NUMBER OF RESERVED TRACKS
000B      DNFOL   == .-DSKNFO      ;DISK INFO LENGTH
;          ;END

```

ENIT - TURBODOS OPERATING SYSTEM MEMORY PARITY INITIALIZATION
PYRIGHT (C) 1982, SOFTWARE 2000, INC.

```
;*****  
;  
; This module initializes the parity of the RAM on  
; an IMS 64K RAM board or an IMS 740 slave processor board.  
; The procedure is to do a 64K block move of all memory which causes parity generation  
; to take place in all memory locations.  
;  
;*****  
;  
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.  
;  
; AUTHORS: RONALD E. RAIKES  
; MICHAEL D. BUSCH  
;  
; VERSION: EXAMPLE  
;  
.IDENT MPENIT ;MODULE ID  
;  
.INSERT DREQUATE ;DRIVER SYMBOLIC EQUIVALENCES  
;  
0000:04 .LOC .INIT.# ;LOCATE IN INITIALIZATION AREA  
;  
0000:04 21 0000 MPENIT::LXI H,0 ;INITIALIZE MEMORY PARITY  
0003:04 11 0000 LXI D,0  
0006:04 01 0000 LXI B,0  
0009:04 EDB0 LDIR  
000B:04 AF XRA A ;CLEAR START-UP PARITY ERROR  
000C:04 D300 OUT 0  
000E:04 C9 RET ;DONE  
;  
.END
```

NITIMS - TURBODOS OPERATING SYSTEM HARDWARE INITIALIZATION (IMS)
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```
; ****
; ****
; * This is the hardware initialization routine for
; * an IMS 8000 master processor. It consists only
; * of calls to the initialization entrypoints of
; * other driver modules.
; ****
; ****
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
; VERSION: EXAMPLE
; IDENT NITIMS          ;MODULE ID
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
0000:04
;      .LOC    .INIT.# ;LOCATE IN INITIALIZATION AREA
; 0000:04 CD 0000:05   HDWNIT::CALL    MPENIT# ;INITIALIZE MEMORY PARITY
0003:04 CD .0000:06   CALL      SPINIT# ;INITIALIZE SERIAL/PARALLEL I/O
0006:04 CD 0000:07   CALL      RTCNIT# ;INITIALIZE REAL TIME CLOCK
0009:04 CD 0000:08   CALL      DSKINA# ;INITIALIZE DISK DRIVER A
000C:04 CD 0000:09   CALL      DSKINB# ;INITIALIZE DISK DRIVER B
000F:04 CD 0000:0A   CALL      DSKINC# ;INITIALIZE DISK DRIVER C
0012:04 CD 0000:0B   CALL      DSKIND# ;INITIALIZE DISK DRIVER D
0015:04 CD 0000:0C   CALL      CKTINA# ;INITIALIZE CIRCUIT DRIVER A
0018:04 CD 0000:0D   CALL      CKTINB# ;INITIALIZE CIRCUIT DRIVER B
001B:04 CD 0000:0E   CALL      CKTINC# ;INITIALIZE CIRCUIT DRIVER C
001E:04 C3 0000:0F   JMP     CKTIND# ;INITIALIZE CIRCUIT DRIVER D
; END
```

SK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

; ****
;
; * This is a disk driver for the IMS 401 eight-inch *
; * floppy disk controller board. This board makes *
; * use of a NEC uPD-765 floppy disk controller chip *
; * coupled with an Intel 8257 DMA controller chip. *
;
; * This driver is fairly long and complex because: *
;
; * (1) The NEC uPD-765 is not as easy to get along *
; * with as other chips (such as the Western *
; * Digital 1791 or 1793). *
;
; * (2) The driver accomodates a wide variety of *
; * disk formats, including both TurboDOS non- *
; * interleaved and CP/M interleaved formats. *
; * The various formats are defined in a separate *
; * module DST8F. *
;
; ****
;
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT   DSK401          ;MODULE ID
;
; INSERT  DREQUATE        ;DRIVER SYMBOLIC EQUIVALENCES
;
0082    CH1DMA  = 82H      ;CHANNEL 1 DMA REGISTER (FDC)
0083    CH1TC   = 83H      ;CHANNEL 1 TERMINAL COUNT (FDC)
0088    DMACTL  = 88H      ;DMA COMMAND AND STATUS REGISTERS
008A    DSKSEL  = 8AH      ;DISK SELECT PORT
008C    DSKCTL  = 8CH      ;STATUS AND INT MASK (BOARD)
008E    FDCST   = 8EH      ;DISK CONTROLLER STATUS (uPD-765)
008F    FDCCDAT = 8FH      ;DISK CONTROLLER DATA (uPD-765)
;
0042    CH1ENA  = 42H      ;DMA CHANNEL 1 ENABLE COMMAND
0000    DMAVFY  = 00H      ;DMA VERIFY COMMAND
0040    DMARD   = 40H      ;DMA READ COMMAND
0080    DMAWR   = 80H      ;DMA WRITE COMMAND
;
0003    FDCCSFY = 03H      ;FDC SPECIFY COMMAND
0004    FDCCSDS  = 04H     ;FDC SENSE DRIVE STATUS COMMAND
0007    FDCCRCL  = 07H     ;FDC RECALIBRATE COMMAND
0008    FDCCSIS  = 08H     ;FDC SENSE INTERRUPT STATUS COMMAND
000A    FDCCRID  = 0AH     ;FDC READ ID COMMAND
000D    FDCCFMT  = 0DH     ;FDC FORMAT TRACK COMMAND
000F    FDCCSK   = 0FH     ;FDC SEEK COMMAND
0005    FDCCWR   = 05H     ;FDC WRITE COMMAND
;
```

DSK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0006	FDCRD = 06H	;FDC READ COMMAND
	;	
0000	DSKENI = 0	;DISK CONTROLLER ENABLE INTERRUPT
0007	DSKDLC = 7	;DISK CONTROLLER DELAY COMPLETE
	;	
0006	FDCMF M = 6	;FDC DOUBLE-DENSITY BIT
0007	FDCMT = 7	;FDC MULTI-TRACK BIT
	;	
0004	FDCBSY = 4	;FDC BUSY STATUS
0005	FDCSE = 5	;FDC SEEK END
0006	FDCOUT = 6	;FDC OUTPUT MODE
0007	FDCRDY = 7	;FDC READY FOR DATA
	;	
00C3	SRT8Q = 3	;8 INCH FDD STEP RATE (3 MS-QUME)
0008	SRT8S = 8	;8 INCH FDD STEP RATE (8 MS-SHUG)
	;	
0024	HDLT = 18*2	;FDD HEAD LOAD TIME (36 MS)
0001	HDUT = 1	;FDD HEAD UNLOAD TIME (16 MS)
	;	
0003	STONR = 3	;STATUS REGISTER 0 NOT READY
0004	STOEC = 4	;STATUS REGISTER 0 EQUIP CHECK
0005	STOSE = 5	;STATUS REGISTER 0 SEEK END
	;	
0000	ST1MA = 0	;STATUS REGISTER 1 MISSING ADDR M
0001	ST1NW = 1	;STATUS REGISTER 1 NOT WRITABLE
0002	ST1ND = 2	;STATUS REGISTER 1 NO DATA
0004	ST1OR = 4	;STATUS REGISTER 1 OVER RUN
0005	ST1DE = 5	;STATUS REGISTER 1 DATA ERROR
	;	
0003	ST3TS = 3	;STATUS REGISTER 3 TWO-SIDED
0004	ST3TO = 4	;STATUS REGISTER 3 TRACK 0
0005	ST3RDY = 5	;STATUS REGISTER 3 READY
0006	ST3WP = 6	;STATUS REGISTER 3 WRITE PROTECTE
	;	
000A	MAXTRY = 10	;MAX DISK TRY COUNT
	;	
0002	TSD = 2	;TWO-SIDED DISK BIT (TYPE CODE)
0003	DDD = 3	;DOUBLE DENSITY DISK BIT (TYPE CO
	;	
0004	MINI = 4	;MINI-FLOPPY DISK BIT (TYPE CODE)
	;	
0000"	.LOC .DATA.#	;LOCATE IN DATA AREA
	;	
0000" 08	SRT401:::BYTE	SRT8S ;STEP RATE
0001" 00	TRYCNT: .BYTE	0 ;TRY COUNT
0002" 00	CALTBLC: .BYTE	0 ;DRIVE CALIBRATED TABLE
0003" 00	FLAGS: .BYTE	0 ;FLAGS
0004" 00	IOWRC: .BYTE	0 ;I/O READ/WRITE COMMAND
0005" 00	IODMAC: .BYTE	0 ;I/O DMA COMMAND
0006" 0000	RETSP: .WORD	0 ;ERROR RETURN STACK POINTER
0008" 00	RIDDSK: .BYTE	0 ;READ ID DISK
0009" 00	CURSEC: .BYTE	0 ;CURRENT SECTOR NUMBER
000A" 0000	CURADR: .WORD	0 ;CURRENT DMA ADDRESS
000C" 00	CURSC: .BYTE	0 ;CURRENT SECTOR COUNT

SK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

000D"	00	IOERR:	.BYTE	0	;I/O ERROR STATUS
		;			
000E"		DMXSPH:			;MUTUAL EXCLUSION SEMAPHORE
000E"	0001		.WORD	1	;SEMAPHORE COUNT
0010"	0010"	..DMXH:	.WORD	..DMXH	;SEMAPHORE P/D HEAD
0012"	0010"		.WORD	..DMXH	
		;			
0014"		DWTSPH:			;DISK WAIT SEMAPHORE
0014"	0000		.WORD	0	;SEMAPHORE COUNT
0016"	0016"	..DWTH:	.WORD	..DWTH	;SEMAPHORE P/D HEAD
0018"	0016"		.WORD	..DWTH	
		;			
001A"		IDINFO:			;SECTOR ID INFO LIST
001A"	00	CYL:	.BYTE	0	;DISK CYLINDER NUMBER
001B"	00	HEAD:	.BYTE	0	;DISK HEAD NUMBER
001C"	00	REC:	.BYTE	0	;DISK RECORD NUMBER
001D"	00	SIZE:	.BYTE	0	;DISK SECTOR SIZE
001E"	00	EOT:	.BYTE	0	;END OF TRACK SECTOR NUMBER
001F"	00	GPL:	.BYTE	0	;DISK GAP 3 SIZE
0020"	00	DTL:	.BYTE	0	;DISK SECTOR SIZE WHEN SIZE=0
		;			
0021"		RESULT:			;RESULT PHASE LIST
0021"	00	ST0:	.BYTE	0	;STATUS REGISTER 0
0022"	00	ST1:	.BYTE	0	;STATUS REGISTER 1
0023"	00	ST2:	.BYTE	0	;STATUS REGISTER 2
0024"	00	RCYL:	.BYTE	0	;DISK CYLINDER NUMBER
0025"	00	RHEAD:	.BYTE	0	;DISK HEAD NUMBER
0026"	00	RREC:	.BYTE	0	;DISK RECORD NUMBER
0027"	00	RSIZE:	.BYTE	0	;DISK SECTOR SIZE
0028"	00	MAINST:	.BYTE	0	;MAIN STATUS REGISTER
0029"	00	ST3:	.BYTE	0	;STATUS REGISTER 3
		;			
0000:04			.LOC	.INIT.#	;LOCATE IN INITIALIZATION AREA
		;			
0000:04	DB8E	DSKIN%::IN	FDCST		;GET FDC STATUS
0002:04	3C	INR	A		;CONTROLLER PRESENT?
0003:04	C8	RZ			;IF NOT, DONE
0004:04	3EC3	MVI	A,JMP		;ELSE, INITIALIZE INTERRUPT VECTOR
0006:04	32 0028	STA	5*8		; (VECTORED INTERRUPT-5)
0009:04	21 0303'	LXI	H,DSKISR		
000C:04	22 0029	SHLD	(5*8)+1		
000F:04	AF	XRA	A		
0010:04	D388	OUT	DMACTL		;DISABLE DMA CONTROLLER
0012:04	3E03	MVI	A,FDCSFY		;GET FDC SPECIFY COMMAND
0014:04	CD 038E'	CALL	CMDRDY		;OUTPUT COMMAND TO FDC
0017:04	3A 0000"	LDA	SRT401		;GET STEP RATE
001A:04	ED44	NEG			;CALC FDC STEP RATE VALUE
001C:04	C610	ADI	16		
001E:04	87	ADD	A		
001F:04	87	ADD	A		
0020:04	87	ADD	A		
0021:04	87	ADD	A		
0022:04	F601	ORI	HDUT		;COMBINE STEP RATE WITH HEAD UNLOAD
0024:04	CD 0394'	CALL	DATOUT		;OUTPUT IT TO FDC

DSK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0027:04 3E24      MVI     A,HDLT ;GET HEAD LOAD TIME/NON-DMA BIT
0029:04 CD 0394'   CALL    DATOUT ;OUTPUT IT TO FDC
002C:04 3E01      MVI     A,1<DSKENI
002E:04 D38C      OUT    DSKCTL ;ENABLE CONTROLLER INTERRUPTS
0030:04 C9        RET    ;DONE

; .LOC .PROG.# ;LOCATE IN PROGRAM AREA

0000' 21 000E"    DSKDR%::LXI H,DMXSPH ;GET MUTUAL EXCLUSION SEMAPHORE
0003' CD 0000:05   CALL    WAIT# ;DISPATCH IF NECESSARY
0006' CD 0012'     CALL    ..DD ;CALL DISK DRIVER
0009' F5          PUSH   PSW ;SAVE RETURN CODE
000A' 21 000E"    LXI    H,DMXSPH ;GET MUTUAL EXCLUSION SEMAPHORE
000D' CD 0000:06   CALL    SIGNAL# ;SIGNAL PROCESS AS READY
0010' F1          POP    PSW ;RESTORE RETURN CODE
0011' C9          RET    ;DONE

; ..DD: SSPD
0012' ED73 0006"   MOV    RETSP ;SAVE ERROR RETURN STACK POINTER
0016' DD7E00       ORA    A,PDRFCN(X) ;GET PD REQ FUNCTION NUMBER
0019' B7          JRZ   A ;PD REQ FUNCTION NUMBER=0?
001A' 280F        DCR   RDDSK ;IF SO, CONTINUE
001C' 3D          DCR   A ;PD REQ FUNCTION NUMBER=1?
001D' 281E        JRZ   WRDSK ;IF SO, CONTINUE
001F' 3D          DCR   A ;PD REQ FUNCTION NUMBER=2?
0020' CA 0206'     JZ    RETDST ;IF SO, CONTINUE
0023' 3D          DCR   A ;PD REQ FUNCTION NUMBER=3?
0024' CA 027F'     JZ    RETRDY ;IF SO, CONTINUE
0027' 3D          DCR   A ;PD REQ FUNCTION NUMBER=4?
0028' 282E        JRZ   FMTDSK ;IF SO, CONTINUE
002A' C9          RET    ;ELSE, DONE

; RDDSK:
002B' 3EOA         MVI   A,MAXTRY ;GET MAX TRY COUNT
002D' 32 0001"     STA   TRYCNT ;SET TRY COUNT
0030' 3E06         ..RD: MVI   A,FDCRD ;GET FDC READ COMMAND
0032' 0E40         MVI   C,DMARD ;GET DMA READ COMMAND
0034' CD 00C4'     CALL  DSKCOM ;CALL COMMON CODE
0037' C8          RZ    ;NO ERRORS, RET A=0
0038' CD 011B'     CALL  RETRY ;ERRORS, RECALIBRATE
003B' 18F3         JMPR ..RD ;TRY AGAIN

; WRDSK:
003D' 3EOA         MVI   A,MAXTRY ;GET MAX TRY COUNT
003F' 32 0001"     STA   TRYCNT ;SET TRY COUNT
0042' 3E05         ..WR: MVI   A,FDCWR ;GET FDC WRITE COMMAND
0044' 0E80         MVI   C,DMAWR ;GET DMA WRITE COMMAND
0046' CD 00C4'     CALL  DSKCOM ;CALL COMMON CODE
0049' 2008         JRNZ ..RT ;IF ERRORS, RETRY
004B' 3E06         MVI   A,FDCRD ;ELSE, GET FDC READ COMMAND
004D' 0E00         MVI   C,DMAVFY ;GET DMA VERIFY COMMAND
004F' CD 00C4'     CALL  DSKCOM ;CALL COMMON CODE
0052' C8          RZ    ;NO ERRORS, RET A=0
0053' CD 011B'     ..RT: CALL  RETRY ;ERRORS, RECALIBRATE
0056' 18EA         JMPR ..WR ;TRY AGAIN

; FMTDSK:
0058' DD7E02       FMTDSK: MOV  A,PDRTRK(X) ;GET PD REQ TRACK NUMBER

```

SK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
)PYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

005B' B7          ORA     A      ;PD REQUEST TRACK NUMBER=0?
005C' 2006        JRNZ    ..NTRO  ;IF NOT, CONTINUE
005E' CD 02CC'    CALL    SELCUR ;ELSE, SELECT I/O DISK
0061' CD 01CB'    CALL    RECAL   ;RECALIBRATE DRIVE
0064' 3EOA        ..NTRO: MVI    A,MAXTRY ;GET MAX TRY COUNT
0066' 32 0001"    STA     TRYCNT ;SET TRY COUNT
0069' CD 01A6'    ..FMT:  CALL   SEEK   ;SELECT DISK AND SEEK
006C' 3E80        MVI    A,DMAWR ;GET DMA WRITE COMMAND
006E' 32 0005"    STA     IODMAC ;SET DMA COMMAND
0071' DD6E08      MOV    L,PDRTC(X) ;GET PD REQ TRANSFER COUNT
0074' DD6609      MOV    H,PDRTC+1(X)
0077' DD5E0A      MOV    E,PDRDMA(X) ;GET PD REQUEST DMA ADDRESS
007A' DD560B      MOV    D,PDRDMA+1(X)
007D' CD 013D'    CALL   DMANIT ;INITIALIZE DMA CONTROLLER
0080' 3E0D        MVI    A,FDCFMT ;GET FORMAT TRACK COMMAND
0082' DDCB047E    BIT    7,PDRSEC(X) ;DOUBLE DENSITY FLAG SET?
0086' 2802        JRZ    ..SD   ;IF NOT, CONTINUE
0088' CBF7        SET    FDCMF, A ;ELSE, SET DOUBLE DENSITY BIT
008A' CD 038E'    ..SD:  CALL   CMDRDY ;SEND FORMAT COMMAND TO FDC
008D' DD7E01      MOV    A,PDRDRV(X) ;GET PD REQUEST DRIVE NUMBER
0090' DDCB057E    BIT    7,PDRSEC+1(X) ;HEAD NUMBER ONE FLAG SET?
0094' 2802        JRZ    ..HDO  ;IF NOT, CONTINUE
0096' CBD7        SET    2,A   ;ELSE, SET HEAD ONE BIT
0098' CD 0394'    ..HDO: CALL   DATOUT ;OUTPUT UNIT NUMBER TO FDC
009B' DD7E04      MOV    A,PDRSEC(X) ;GET PD REQUEST SECTOR (LSB)
009E' E603        ANI    3      ;EXTRACT FORMAT SECTOR SIZE
00A0' CD 0394'    CALL   DATOUT ;OUTPUT FORMAT SECTOR SIZE TO FDC
00A3' DD7E06      MOV    A,PDRSC(X) ;GET PD REQUEST SECTOR COUNT
00A6' CD 0394'    CALL   DATOUT ;OUTPUT SECTORS/TRACK TO FDC
00A9' DD7E05      MOV    A,PDRSEC+1(X) ;GET PD REQUEST SECTOR (MSB)
00AC' E67F        ANI    7FH   ;EXTRACT FORMAT GAP LENGTH
00AE' CD 0394'    CALL   DATOUT ;OUTPUT FORMAT GAP LENGTH TO FDC
00B1' 3EE5        MVI    A,0E5H ;GET FORMAT FILLER BYTE
00B3' CD 0394'    CALL   DATOUT ;OUTPUT FORMAT FILLER BYTE TO FDC
00B6' CD 02FC'    CALL   WTINT  ;WAIT FOR INTERRUPT
00B9' 3A 0021"    LDA    STO   ;GET STATUS REGISTER 0
00BC' E6C0        ANI    0COH  ;ANY ERRORS?
00BE' C8          RZ    ;NO ERRORS, RET A=0
00BF' CD 011B'    CALL   RETRY ;ERRORS, RECALIBRATE
00C2' 18A5        JMPR  ..FMT  ;TRY AGAIN

;DSKCOM: STA     IORWC ;SET FDC READ/WRITE COMMAND
00C4' 32 0004"    ;DSKCOM: STA     A,C   ;GET DMA COMMAND
00C7' 79          MOV    IODMAC ;SET DMA COMMAND
00C8' 32 0005"    STA     A,PDRSEC(X) ;GET PD REQ SECTOR NUMBER
00CB' DD7E04      MOV    CURSEC ;SET CURRENT SECTOR
00CE' 32 0009"    STA     L,PDRDMA(X) ;GET PD REQUEST DMA ADDRESS
00D1' DD6E0A      MOV    H,PDRDMA+1(X)
00D4' DD660B      MOV    SHLD   CURADR ;SET CURRENT DMA ADDRESS
00D7' 22 000A"    SHLD   A,PDRSC(X) ;GET PD REQ SECTOR COUNT
00DA' DD7E06      MOV    STA     CURSC  ;SET CURRENT SECTOR COUNT
00DD' 32 000C"    STA     SEEK   ;SELECT DISK AND SEEK
00E0' CD 01A6'    CALL   AF    A
00E3' AF          XRA   IOERR  ;CLEAR I/O ERROR STATUS
00E4' 32 000D"

```

DSK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

00E7'	CD 0155'	..RWL:	CALL	SETID	;SET UP SECTOR ID INFO
00EA'	CD 012B'		CALL	SETUP	;SETUP READ/WRITE DMA
00ED'	CD 035D'		CALL	CMDOUT	;SEND SECTOR ID INFO TO FDC
00FO'	CD 02FC'		CALL	WTINT	;WAIT FOR INTERRUPT
00F3'	21 000D"		LXI	H,IOERR	;GET I/O ERROR STATUS
00F6'	3A 0021"		LDA	STO	;GET STATUS REGISTER 0
00F9'	B6		ORA	M	;ADD NEW STATUS
00FA'	77		MOV	M,A	;UPDATE I/O ERROR STATUS
00FB'	CD 03CF'		CALL	GETXLT	;GET TRANSLATION TABLE ADDRESS
00FE'	2815		JRZ	..NI	;IF TRANSLATION NOT REQUIRED, CO
0100'	21 0009"		LXI	H,CURSEC	;ELSE, GET CURRENT SECTOR NUMB
0103'	34		INR	M	;INCREMENT CURRENT SECTOR
0104'	CD 03C4'		CALL	CALCSS	;CALC SECTOR SIZE
0107'	EB		XCHG		;SECTOR SIZE TO DE-REG
0108'	2A 000A"		LHLD	CURADR	;GET CURRENT DMA ADDRESS
010B'	19		DAD	D	;CALC NEXT DMA ADDRESS
010C'	22 000A"		SHLD	CURADR	;UPDATE CURRENT DMA ADDRESS
010F'	21 000C"		LXI	H,CURSC	;GET CURRENT SECTOR COUNT
0112'	35		DCR	M	;DECREMENT CURRENT SECTOR COUNT
0113'	20D2		JRNZ	..RWL	;IF TRANSFER NOT COMPLETE, CONTI
0115'	3A 000D"	..NI:	LDA	IOERR	;GET I/O ERROR STATUS
0118'	E6C0		ANI	OCOH	;EXTRACT COMPLETION STATUS
011A'	C9		RET		;DONE
<hr/>					
011B'	OE07	RETRY:	MVI	C,ABEL	;GET BELL CHARACTER
011D'	CD 0000:07		CALL	CONOUT#	;OUTPUT TO CONSOLE
0120'	CD 01CB'		CALL	RECAL	;RECALIBRATE DRIVE
0123'	21 0001"		LXI	H,TRYCNT	;GET RETRY COUNT
0126'	35		DCR	M	;DECREMENT RETRY COUNT
0127'	C0		RNZ		;IF COUNT NOT EXHAUSTED, TRY AGA
0128'	C3 03EC'		JMP	FATAL	;CONTINUE
<hr/>					
012B'	CD 03CF'	SETUP:	CALL	GETXLT	;GET TRANSLATION TABLE ADDRESS
012E'	DD6E08		MOV	L,PDRTC(X)	;GET PD REQ TRANSFER COUNT
0131'	DD6609		MOV	H,PDRTC+1(X)	
0134'	2803		JRZ	..NI	;IF NO TRANSLATION RQRD, CONTINU
0136'	CD 03C4'		CALL	CALCSS	;ELSE, CALC SECTOR SIZE
0139'	ED5B 000A"	..NI:	LDED	CURADR	;GET CURRENT DMA ADDRESS
<hr/>					
013D'	AF	DMANIT:	XRA	A	
013E'	D388		OUT	DMACTL	;RESET DMA CONTROLLER
0140'	2B		DCX	H	;TERMINAL COUNT-1 FOR 8257
0141'	7D		MOV	A,L	;GET LSB OF TERMINAL COUNT
0142'	D383		OUT	CH1TC	;SEND LSB OF TERMINAL COUNT
0144'	3A 0005"		LDA	IODMAC	;GET I/O DMA COMMAND
0147'	B4		ORA	H	;ADD TO MSB OF TERMINAL COUNT
0148'	D383		OUT	CH1TC	;SEND MSB OF TERMINAL COUNT
014A'	7B		MOV	A,E	;GET LSB
014B'	D382		OUT	CH1DMA	;OUTPUT IT TO DMA CONTROLLER
014D'	7A		MOV	A,D	;GET MSB
014E'	D382		OUT	CH1DMA	;OUTPUT IT TO DMA CONTROLLER
0150'	3E42		MVI	A,CH1ENA	;GET CHANNEL 1 ENABLE COMMAND
0152'	D388		OUT	DMACTL	;ENABLE DMA CONTROLLER
0154'	C9		RET		;DONE

SK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;                               ;SETID: MOV    A,PDRTRK(X) ;GET PD REQ TRACK NUMBER
0155'  DD7E02          STA    CYL    ;SET CYLINDER
0158'  32 001A"        LDA    CURSEC ;GET CURRENT SECTOR
015B'  3A 0009"        MOV    C,A    ;SECTOR NUMBER TO C-REG
015E'  4F              CALL   GETXLT ;GET TRANSLATION TABLE ADDRESS
015F'  CD 03CF'        JRZ   ..NI   ;IF TRANSLATION NOT REQUIRED, CONT
0162'  2804            MVI    B,0    ;ELSE, MAKE SECTOR DOUBLE LENGTH
0164'  0600            DAD    B      ;INDEX INTO TRANSLATION TABLE
0166'  09              MOV    C,M    ;GET TRANSLATED SECTOR NUMBER
0167'  4E              INR   C      ;CONVERT SECTOR TO BASE 1
0168'  OC              ..NI:  MOV    B,SECTRK(X) ;GET NUMBER OF SECTORS/TRACK
0169'  DD4613          CALL   GETTCA ;GET DISK TYPE CODE ADDRESS
016C'  CD 03DD'        CB56   BIT    TSD,M  ;TWO SIDED DISK?
016F'  CB56            2802   JRZ   ..SSD  ;IF NOT, CONTINUE
0171'  2802            CB38   SRLR   B      ;ELSE, CALC NUMBER OF SECTORS/SIDE
0173'  CB38            78     ..SSD: MOV    A,B    ;GET NUMBER OF SECTORS/SIDE
0176'  32 001E"        B9     STA    EOT    ;SET END OF TRACK SECTOR NUMBER
0179'  B9              CMP    C      ;FRONT SIDE OF DISK?
017A'  3E00            MVI    A,0    ;PRESET FOR FRONT SIDE
017C'  3005            3E00   JRNC   ..FS   ;IF FRONT SIDE, CONTINUE
017E'  79              3005   MOV    A,C    ;GET SECTOR NUMBER
017F'  90              79     SUB    B      ;SUBTRACT ONE SIDES WORTH
0180'  4F              90     MOV    C,A    ;TO C-REG
0181'  3E01            4F     MVI    A,1    ;GET HEAD #1
0183'  32 001B"        3E01   ..FS:  STA    HEAD   ;SET HEAD NUMBER
0186'  79              32 001C"  MOV    A,C    ;GET SECTOR NUMBER
0187'  32 001C"        3E80   STA    REC    ;SET RECORD NUMBER
018A'  DD7E12          32 001D"  MOV    A,SECSIZ(X) ;GET SECTOR SIZE
018D'  32 001D"        B7     STA    SIZE   ;SET RECORD SIZE
0190'  B7              3E80   ORA    A      ;N=0?
0191'  3E80            2802   MVI    A,128  ;PRESET DTL=128
0193'  2802            3EFF   JRZ   ..NO   ;IF N=0, CONTINUE
0195'  3EFF            3EFF   MVI    A,OFFH ;ELSE, DTL=OFFH
0197'  32 0020"        32 0020" ..NO:  STA    DTL    ;SET DATA LENGTH
019A'  CD 03E5'        11 0000:08 CALL   GETDST ;GET DST ADDRESS
019D'  11 0000:08      LXI   D,GAPLEN# ;GET OFFSET TO GAP LENGTH
01A0'  19              19     DAD    D      ;CALC GAP LENGTH ADDRESS
01A1'  7E              7E     MOV    A,M    ;GET GAP LENGTH
01A2'  32 001F"        32 001F" STA    GPL    ;SET GAP LENGTH
01A5'  C9              8F     RET    ;DONE
;
01A6'  CD 02CC'        SEEK: CALL   SELCUR ;SELECT I/O DISK
01A9'  DD7E01          3C     MOV    A,PDRDRV(X) ;GET PD REQ DISK NUMBER
01AC'  3C              INR   A      ;INCREMENT IT
01AD'  47              47     MOV    B,A    ;TO B-REG
01AE'  AF              AF     XRA   A      ;CLEAR DRIVE VECTOR
01AF'  37              37     STC    ;SET CARRY FLAG
01B0'  8F              8F     ADC   A      ;SHIFT CARRY FLAG LEFT
01B1'  10FD            10FD   ..SL:  DJNZ   ..SL   ;GET DRIVE CALIBRATED TABLE
01B3'  21 0002"        LXI   H,CALTBLC ;COMBINE VECTOR W/CALIBRATED TABLE
01B6'  B6              B6     ORA   M      ;DRIVE ALREADY CALIBRATED?
01B7'  BE              BE     CMP   M      ;UPDATE DRIVE CALIBRATED TABLE
01B8'  77

```

DSK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

01B9'	C4 01CB'	CNZ	RECAL ;RE-CALIBRATE DRIVE, IF NECESSARY
01BC'	DD7E01	MOV	A, PDRDRV(X) ;GET PD REQ DISK NUMBER
01BF'	47	MOV	B, A ;CONTROLLER DISK TO B-REG
01C0'	DD7E02	MOV	A, PDRTRK(X) ;GET PD REQ TRACK NUMBER
01C3'	4F	MOV	C, A ;CYLINDER TO C-REG
01C4'	CD 01EA'	CALL	SEKCMD ;SEND SEEK COMMAND
01C7'	C8	RZ	;IF NO ERRORS, DONE
01C8'	C3 03EC'	JMP	FATAL ;CONTINUE
;			
01CB'	DD7E01	RECAL:	MOV A, PDRDRV(X) ;GET PD REQ DISK NUMBER
01CE'	CD 01D5'	CALL RECCMD	;SEND RECALIBRATE COMMAND
01D1'	C8	RZ	;IF NO ERRORS, DONE
01D2'	C3 03EC'	JMP	FATAL ;CONTINUE
;			
01D5'	F5	RECCMD:	PUSH PSW ;SAVE CONTROLLER DISK
01D6'	3E07	MVI	A, FDCRCL ;GET FDC RECALIBRATE COMMAND
01D8'	CD 038E'	CALL	CMDRDY ;OUTPUT COMMAND TO FDC
01DB'	F1	POP	PSW ;RESTORE CONTROLLER DISK
01DC'	CD 0394'	CALL	DATOUT ;OUTPUT IT TO FDC
01DF'	CD 02FC'	CALL	WTINT ;WAIT FOR INTERRUPT
01E2'	3A 0021"	LDA	STO ;GET STATUS REGISTER 0
01E5'	E6E0	ANI	OCOH!1<FDCSE ;EXTRACT COMPLETION STATUS
01E7'	FE20	CPI	1<FDCSE ;ANY ERRORS?
01E9'	C9	RET	;DONE
;			
01EA'	C5	SEKCMD:	PUSH B ;SAVE DISK/TRACK
01EB'	3EOF	MVI	A, FDCKS ;GET FDC SEEK COMMAND
01ED'	CD 038E'	CALL	CMDRDY ;OUTPUT COMMAND TO FDC
01F0'	C1	POP	B ;RESTORE DISK/TRACK
01F1'	C5	PUSH	B ;SAVE DISK/TRACK
01F2'	78	MOV	A, B ;GET CONTROLLER DISK
01F3'	CD 0394'	CALL	DATOUT ;OUTPUT IT TO FDC
01F6'	C1	POP	B ;RESTORE DISK/TRACK
01F7'	79	MOV	A, C ;GET CYLINDER NUMBER
01F8'	CD 0394'	CALL	DATOUT ;OUTPUT IT TO FDC
01FB'	CD 02FC'	CALL	WTINT ;WAIT FOR INTERRUPT
01FE'	3A 0021"	LDA	STO ;GET STATUS REGISTER 0
0201'	E6E0	ANI	OCOH!1<FDCSE ;EXTRACT COMPLETION STATUS
0203'	FE20	CPI	1<FDCSE ;ANY ERRORS?
0205'	C9	RET	;DONE
;			
0206'	CD 027F'	RETDST:	CALL RETRDY ;RETURN READY STATUS
0209'	B7	ORA	A ;DRIVE READY?
020A'	C8	RZ	;IF NOT, DONE
020B'	0E00	MVI	C, 0 ;ELSE, GET INITIAL TYPE VALUE
020D'	3A 0029"	LDA	ST3 ;GET STATUS REGISTER 3
0210'	CB5F	BIT	ST3TS, A ;ONE-SIDED DISK?
0212'	2802	JRZ	..OS ;YES
0214'	CBD1	SET	TSD, C ;SET TWO-SIDED DISK BIT
0216'	DD7E01	..OS:	MOV A, PDRDRV(X) ;GET PD REQ DISK NUMBER
0219'	32 0008"	STA	RIDDSK ;SET READ ID DISK
021C'	CD 026A'	CALL	..FD ;FIND DISK DENSITY
021F'	280F	JRZ	..DF ;IF DENSITY FOUND, CONTINUE
0221'	C5	PUSH	B ;ELSE, SAVE DISK TYPE CODE

SK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0222' DD7E01      MOV    A,PDRDRV(X) ;GET PD REQ DISK NUMBER
0225' CD 01D5'     CALL   RECCMD ;RECALIBRATE DRIVE
0228' C1          POP    B      ;RESTORE DISK TYPE CODE
0229' 2032        JRNZ   .NR    ;IF UNABLE TO RECALIBRATE, CONTINUE
022B' CD 026A'     CALL   .FD    ;ELSE, ATTEMPT TO FIND DISK DENSITY
022E' 202D        JRNZ   .NR    ;IF DENSITY NOT FOUND, CONTINUE
0230' B1          ..DF: ORA    C      ;ADD SECTOR SIZE TO TYPE CODE
0231' 4F          MOV    C,A    ;TWO SIDED BIT SET?
0232' CB51        BIT    TSD,C ;IF NOT, CONTINUE
0234' 2814        JRZ    .FDI   ;IF READABLE, CONTINUE
0236' 21 0008"    LXI    H,RIDDSK ;GET READ ID DISK
0239' CBD6        SET    2,M    ;SET HEAD BIT
023B' 3E4A        MVI    A,FDCRID!1<FDCMFM ;GET READ ID CMD (DD)
023D' CB59        BIT    DDD,C ;DOUBLE DENSITY BIT SET?
023F' 2002        JRNZ   .DD    ;IF SO, CONTINUE
0241' CBB7        RES    FDCMFM,A ;ELSE, RESET MFM BIT
0243' CD 0279'     ..DD: CALL   .RID   ;ATTEMPT TO READ ID ON BACK SIDE
0246' 2802        JRZ    .FDI   ;IF READABLE, CONTINUE
0248' CB91        RES    TSD,C ;ELSE, RESET TWO SIDED BIT
024A' 11 0000:09  ..FDI: LXI    D,DSTBLS# ;GET DISK SPEC TABLES
024D' 79          ..SL2: MOV    A,C    ;GET DISK TYPE CODE
024E' 21 0000:0A  LXI    H,DTCO# ;GET OFFSET TO DISK TYPE CODE
0251' 19          DAD    D      ;CALC DISK TYPE CODE ADDRESS
0252' BE          CMP    M      ;DISK SPEC TABLE FOUND?
0253' 280A        JRZ    .DSTF  ;IF SO, CONTINUE
0255' EB          XCHG   E,M    ;DISK SPEC TABLE ADDRESS TO HL-REG
0256' 5E          MOV    E,M    ;GET DISK SPEC TABLE LINK POINTER
0257' 23          INX    H
0258' 56          MOV    D,M
0259' 7A          MOV    A,D
025A' B3          ORA    E      ;END OF LIST?
025B' 20F0        JRNZ   .SL2   ;IF NOT, CONTINUE
025D' AF          ..NR:  XRA    A      ;ELSE, SET RETURN CODE=0
025E' C9          RET    ;DONE
025F' 13          ..DSTF: INX   D      ;ADVANCE PAST LINK POINTER
0260' 13          INX   D
0261' DD730C      MOV    PDRDST(X),E ;SET DISK SPEC TABLE ADDRESS
0264' DD720D      MOV    PDRDST+1(X),D
0267' 3EFF        MVI    A,OFFH ;SET RETURN CODE=OFFH
0269' C9          RET    ;DONE
026A' 3E0A        ..FD:  MVI    A,FDCRID ;GET FDC READ ID COMMAND (SD)
026C' CD 0279'     CALL   ..RID  ;ATTEMPT TO READ SINGLE-DENSITY
026F' C8          RZ    ;IF SINGLE-DENSITY, DONE
0270' 3E4A        MVI    A,FDCRID!1<FDCMFM ;GET READ ID CMD (DD)
0272' CD 0279'     CALL   ..RID  ;ATTEMPT TO READ DOUBLE-DENSITY
0275' C0          RNZ   ;IF UNABLE, DONE
0276' CBD9        SET    DDD,C ;SET DOUBLE-DENSITY DISK BIT
0278' C9          RET    ;DONE
0279' C5          ..RID: PUSH   B      ;SAVE BC
027A' CD 02A2'     CALL   READID ;READ DISK ID
027D' C1          POP    B      ;RESTORE BC
027E' C9          RET    ;DONE
027F' DD7E01      ;RETRDY: MOV    A,PDRDRV(X) ;GET PD REQ DISK NUMBER

```

DSK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0282' FE04          CPI    4      ;TEST FOR VALID DRIVE NUMBER
0284' 3E00          MVI    A,0    ;PRESET RETURN CODE=0
0286' DO             RNC    ;IF INVALID DRIVE, RETURN NOT REA
0287' DB8E          IN     FDCST  ;GET FDC STATUS
0289' 3C             INR    A      ;CONTROLLER PRESENT?
028A' C8             RZ    ;IF NOT, DONE
028B' CD 02CC'       CALL   SELCUR ;ELSE, SELECT REQUESTED DRIVE
028E' CD 0298'       CALL   ..RDY  ;CHECK IF DRIVE READY
0291' CO             RNZ    ;IF SO, DONE
0292' 21 0001        LXI   H,1    ;ELSE, DELAY ONE TICK...
0295' CD 0000:0B     CALL   DELAY# ;...SO 765 CAN SCAN
0298' CD 02E9'       ..RDY: CALL   SENSDS ;SENSE DRIVE STATUS
029B' CB6F          BIT    ST3RDY,A ;DRIVE READY?
029D' 3E00          MVI   A,0    ;PRESET RETURN CODE=0
029F' C8             RZ    ;IF DRIVE NOT READY, DONE
02A0' 2F             CMA    ;ELSE, SET RETURN CODE=0FFH
02A1' C9             RET    ;DONE

; READID: CALL CMDRDY ;OUTPUT COMMAND TO FDC
02A2' CD 038E'       READID: CALL LDA RIDDSK ;GET READ ID DISK
02A5' 3A 0008"       LDA    DATOUT ;OUTPUT IT TO FDC
02A8' CD 0394'       CALL   WTINT  ;WAIT FOR INTERRUPT
02AB' CD 02FC'       CALL   LDA    ;GET STATUS REGISTER 0
02AE' 3A 0021"       LDA    STO    ;EXTRACT COMPLETION STATUS
02B1' E6C0          ANI    OCOH   ;RETURN SECTOR SIZE
02B3' 3A 0027"       LDA    RSIZE  ;DINE
02B6' C9             RET    ;DELAY COMPLETE POLL ROUTINE
02B7' 0000          .WORD  0
02B9' 0000          .WORD  0

; DLCPR: IN DSKCTL ;GET DISK CONTROLLER STATUS
02BB' DB8C          DLCPR: IN  DSKDLC,A ;DELAY COMPLETE (MOTORS RUNNING
02BD' CB7F          BIT    ;IF NOT, DONE
02BF' C8             RZ    ;ELSE, GET POLL ROUTINE
02C0' 21 02B7'       LXI   H,DLCPOL ;UNLINK POLL ROUTINE FROM POLL LI
02C3' CD 0000:0C     CALL   UNLINK# ;GET DISK WAIT SEMAPHORE
02C6' 21 0014"       LXI   H,DWTSPH ;CONTINUE
02C9' C3 0000:06     JMP    SIGNAL# ;SELECTED DRIVE
02CC' DB8C          SELCUR: IN  DSKCTL ;GET DISK CONTROLLER STATUS
02CE' 0F             RRC    ;EXTRACT SELECTED DRIVE
02CF' E603          ANI    3
02D1' 4F             MOV    C,A    ;TO C-REG
02D2' DD7E01         MOV    A,PDRDRV(X) ;GET PD REQ DISK NUMBER
02D5' B9             CMP    C     ;DRIVE ALREADY SELECTED?
02D6' 2802          JRZ    ..DAS  ;IF SO, CONTINUE
02D8' D38A          OUT   DSKSEL ;ELSE, SELECT CONTROLLER DISK
02DA' 11 02B7'       ..DAS: LXI   D,DLCPOL ;GET POLL ROUTINE
02DD' CD 0000:0D     CALL   LNKPOL# ;CREATE POLL ROUTINE
02E0' CD 02BB'       CALL   DLCPR  ;EXECUTE POLL ROUTINE
02E3' 21 0014"       LXI   H,DWTSPH ;GET DISK WAIT SEMAPHORE
02E6' C3 0000:05     JMP    WAIT# ;DISPATCH IF NECESSARY
02E9' 3E04          SENSDS: MVI   A,FDCSDS ;GET FDC SENSE DRIVE STATUS CME

```

SK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

02EB' CD 038E'          CALL    CMDRDY ;OUTPUT COMMAND TO FDC
02EE' DD7E01            MOV     A,PDRDRV(X) ;GET PD REQ DISK NUMBER
02F1' CD 0394"          CALL    DATOUT ;OUTPUT IT TO FDC
02F4' CD 039B"          CALL    DATAIN ;GET STATUS REGISTER 3
02F7' 32 0029"          STA     ST3   ;SAVE STATUS REGISTER 3
02FA' FB                EI      ;ENABLE INTERRUPTS
02FB' C9                RET    ;DONE

;WTINT: EI ;ENABLE INTERRUPTS
02FC' FB                LXI    H,DWTSPH ;GET DISK WAIT SEMAPHORE
02FD' 21 0014"          JMP    WAIT# ;DISPATCH IF NECESSARY

;DSKISR: SSPD
0300' C3 0000:05        ;INTSP# ;SAVE INTERRUPT STACK PCINTER
0303' ED73 0000:0E       DSXISR: LXI    SP,INTSTK# ;SET UP AUX STACK
0307' 31 0000:0F        PUSH   PSW   ;SAVE REGISTERS
030A' F5                PUSH   B
030B' C5                PUSH   D
030C' D5                PUSH   H
030D' E5                PUSH   H

030E' DB8E              ..RQML: IN    FDCST  ;GET FDC STATUS
0310' CB7F              BIT    FDCRDY,A ;FDC READY FOR CONVERSATION?
0312' 28FA              JRZ   ..RQML ;IF NOT, WAIT
0314' 32 0028"          STA    MAINST ;SAVE MAIN STATUS REGISTER
0317' CB77              BIT    FDCOUT,A ;FDC IN OUTPUT MODE?
0319' 2020              JRNZ  ..RW   ;IF SO, PROCESS
031B' 3E08              MVI    A,FDCSIS ;GET SENSE INTERRUPT STATUS CMD
031D' D38F              OUT   FDCDAT ;OUTPUT IT TO FDC DATA REGISTER
031F' CD 039B"          CALL  DATAIN ;GET STATUS REGISTER 0
0322' 4F                MOV    C,A   ;SAVE IT IN C-REG
0323' E6C0              ANI    OCOH  ;EXTRACT COMPLETION STATUS
0325' FE80              CPI    80H   ;INTERRUPT STACK EMPTY?
0327' 2829              JRZ   ..X   ;IF SO, DONE
0329' CD 039B"          CALL  DATAIN ;GET PRESENT CYLINDER NUMBER
032C' CB69              BIT    STOSE,C ;READY LINE CHANGE STATE?
032E' 28DE              JRZ   ..RQML ;IF SO, IGNORE
0330' 32 0024"          STA    RCYL  ;ELSE, SAVE PCN
0333' 79                MOV    A,C   ;GET STATUS REGISTER 0
0334' 32 0021"          STA    STO   ;SAVE IT
0337' 3E01              MVI    A,1   ;SET INTERRUPT COMPLETION STATUS
0339' 180F              JMPR  ..SIGC ;CONTINUE
033B' 21 0021"          ..RW: LXI    H,RESULT ;GET RESULT TABLE
033E' 0607              MVI    B,7   ;GET LENGTH OF RESULT PHASE
0340' CD 039B"          ..RL: CALL  DATAIN ;GET RESULT BYTE FROM FDC
0343' 77                MOV    M,A   ;STORE IN RESULT AREA
0344' 23                INX   H      ;INCREMENT POINTER
0345' 10F9              DJNZ  ..RL   ;READ ALL SEVEN BYTES
0347' AF                XRA   A
0348' D388              OUT   DMACTL ;DISABLE DMA CONTROLLER
034A' 21 0014"          ..SIGC: LXI    H,DWTSPH ;GET DISK WAIT SEMAPHORE
034D' CD 0000:06        CALL  SIGNAL# ;SIGNAL PROCESS AS READY
0350' 18BC              JMPR  ..RQML ;FLUSH ANY REMAINING INTERRUPTS
0352' E1                POP    H      ;REGISTERS
0353' D1                POP    D
0354' C1                POP    B
0355' F1                POP    PSW

```

DSK401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0356'	ED7B 0000:0E	LSPD	INTSP#	; RESTORE STACK POINTER
035A'	C3 0000:10	JMP	ISRxit#	;CONTINUE
		;		
035D'	CD 03DD'	CMDOUT:	CALL	GETTCA ;GET DISK TYPE CODE ADDRESS
0360'	3A 0004"		LDA	IOWC ;GET READ/WRITE COMMAND
0363'	CB5E		BIT	DDD,M ;DOUBLE DENSITY DISK?
0365'	2802		JRZ	..SD ;IF NOT, SINGLE DENSITY
0367'	CBF7		SET	FDCMF, A ;ELSE, SET DOUBLE DENSITY BIT
0369'	CB56	..SD:	BIT	TSD,M ;TWO-SIDED DISK?
036B'	2802		JRZ	..SS ;IF NOT, SINGLE SIDED
036D'	CBFF		SET	FDCMT, A ;ELSE, SET MULTI-TRACK BIT
036F'	CD 038E'	..SS:	CALL	CMDRDY ;SEND COMMAND TO FDC
0372'	DD7E01		MOV	A, PDRDRV(X) ;GET PD REQ DISK NUMBER
0375'	21 001B"		LXI	H, HEAD ;GET HEAD NUMBER
0378'	CB46		BIT	0, M ;HEAD #0?
037A'	2802		JRZ	..FS ;IF SO, CONTINUE
037C'	CBD7		SET	2, A ;ELSE, SET HEAD #1 BIT IN I/O DI
037E'	CD 0394'	..FS:	CALL	DATOUT ;OUTPUT IT TO FDC
0381'	21 001A"		LXI	H, IDINFO ;GET SECTOR ID INFO
0384'	0607		MVI	B, 7 ;B=LENGTH OF ID INFO
0386'	7E	..IDL:	MOV	A, M ;GET BYTE FROM LIST
0387'	23		INX	H ;INCREMENT POINTER
0388'	CD 0394'		CALL	DATOUT ;OUTPUT BYTE TO FDC
038B'	10F9		DJNZ	..IDL ;SEND ENTIRE LIST
038D'	C9		RET	;DONE
		;		
038E'	CD 03A6'	CMDRDY:	CALL	OUTRDY ;WAIT FOR FDC READY
0391'	F3		DI	;DISABLE INTERRUPTS
0392'	1803		JMPR	OUTCOM ;JOIN COMMON CODE
		;		
0394'	CD 03A6'	DATOUT:	CALL	OUTRDY ;WAIT FOR FDC READY
		;		
0397'	79	OUTCOM:	MOV	A, C ;RESTORE OUTPUT BUTE
0398'	D38F		OUT	FDCDAT ;OUTPUT BYTE TO FDC DATA REGISTE
039A'	C9		RET	;DONE
		;		
039B'	DB8E	DATAIN:	IN	FDCST ;GET FDC STATUS
039D'	07		RLC	;TEST FDC FOR READY
039E'	30FB		JRNC	DATAIN ;IF NOT READY, WAIT
03A0'	07		RLC	;TEST FDC DIRECTION
03A1'	300B		JRNC	FDCERR ;IF WRONG DIRECTION, DIAGNOSE
03A3'	DB8F		IN	FDCDAT ;GET FDC DATA BYTE
03A5'	C9		RET	;DONE
		;		
03A6'	4F	OUTRDY:	MOV	C, A ;SAVE OUTPUT BYTE
03A7'	DB8E	..RW:	IN	FDCST ;GET FDC STATUS
03A9'	07		RLC	;TEST FDC FOR READY
03AA'	30FB		JRNC	..RW ;IF NOT READY, WAIT
03AC'	07		RLC	;TEST FDC DIRECTION
03AD'	DO		RNC	;IF DIRECTION CORRECT, DONE
		;		
03AE'	CD 0000:11	FDCERR:	CALL	DMS# ;SOUND BELL
03B1'	87		.ASCIS	[ABEL]
03B2'	CD 0000:12		CALL	CONSO# ;SHIFT CONSOLE TO ERROR LINE

K401 - TURBODOS OPERATING SYSTEM IMS 8-INCH FLOPPY DISK DRIVER
 PYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

03B5' CD 0000:11          CALL   DMS#    ;DISPLAY ERROR MESSAGE
03B8' 464443204572       .ASCIS "FDC Error"
03C1' C3 03C1'           JMP    .
                                         ;HALT

03C4' 21 0080             ;CALCSS: LXI   H,128   ;GET 128 BYTE SECTOR LENGTH
03C7' DD7E12               MOV    A,SECSIZ(X) ;GET SECTOR SIZE
03CA' 3D                 ..SL:  DCR    A        ;DECREMENT SECTOR SIZE
03CB' F8                 RM     .
                                         ;IF UNDERFLOW, DONE
03CC' 29                 DAD    H        ;ELSE, SHIFT SECTOR SIZE LEFT
03CD' 18FB               JMPR   ..SL   ;CONTINUE

03CF' CD 03E5'            ;GETXLT: CALL  GETDST ;GET DST ADDRESS
03D2' 11 0000:13          LXI   D,XLTBL# ;GET OFFSET TO TRANSLATION TABLE
03D5' 19                 DAD    D        ;CALC TRANSLATION TABLE ADDRESS
03D6' 5E                 MOV    E,M    ;GET TRANSLATION TABLE ADDRESS
03D7' 23                 INX    H        ;
03D8' 56                 MOV    D,M    ;
03D9' EB                 XCHG   .
                                         ;TRANSLATION TABLE ADDRESS TO HL-R

03DA' 7C                 MOV    A,H    ;
03DB' B5                 ORA    L        ;TRANSLATION REQUIRED?
03DC' C9                 RET    .
                                         ;DONE

03DD' CD 03E5'            ;GETTCA: CALL  GETDST ;GET DST ADDRESS
03E0' 11 0000:14          LXI   D,TYPcod# ;GET OFFSET TO DISK TYPE CODE
03E3' 19                 DAD    D        ;CALC DISK TYPE CODE ADDRESS
03E4' C9                 RET    .
                                         ;DONE

03E5' DD6EOC              ;GETDST: MOV   L,PDRDST(X) ;GET PD REQUEST DST ADDRESS
03E8' DD660D              MOV   H,PDRDST+1(X)
03EB' C9                 RET    .
                                         ;DONE

03EC' ED7B 0006"          ;FATAL:  LSPD   RETSP  ;RESTORE STACK POINTER
03F0' 3EFF                MVI   A,OFFH ;RETURN ERROR CODE
03F2' C9                 RET    .
                                         ;DONE

;END

```

DSKFMT - TURBODOS OPERATING SYSTEM 8-INCH FLOPPY DISK SPECIFICATION TABLES
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

; **** This is a list of disk specification tables for
; all of the 8-inch floppy disk formats supported
; by the DSK401 disk driver module and the MPB401
; boot prom driver module.
; ****

; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

; AUTHORS: RONALD E. RAIKES
;          MICHAEL D. BUSCH

; VERSION: EXAMPLE

; IDENT DSKFMT           ;MODULE ID
; INSERT DREQUATE        ;DRIVER SYMBOLIC EQUIVALENCES
;
0002    TSD    = 2           ;TWO-SIDED DISK BIT (TYPE CODE)
0003    DDD    = 3           ;DOUBLE DENSITY DISK BIT (TYPE CO

;
0000'      ; .LOC   .PROG.# ;LOCATE IN PROGRAM AREA
;
;          1024 BYTE SECTOR, DOUBLE-DENSITY, TWO-SIDED
;
0000'  0011'  DSTBLS:: .WORD  .+DSTL  ;DISK SPEC TABLE LINK POINTER
0002'  04      .BYTE   4       ;BLOCK SIZE
0003'  0268   .WORD   (77*(16*(1<3)))/(1<4) ;NUMBER OF BLOCKS
0005'  04      .BYTE   4       ;NUMBER OF DIRECTORY BLOCKS
0006'  03      .BYTE   3       ;PHYSICAL SECTOR SIZE (2^N*128)
0007'  0010   .WORD   16      ;PHYSICAL SECTORS PER TRACK
0009'  004D   .WORD   77      ;PHYSICAL TRACKS PER DISK
000B'  0000   .WORD   0       ;NUMBER OF RESERVED TRACKS
000D'  0000   .WORD   0       ;TRANSLATION TABLE ADDRESS
000F'  0F      .BYTE   1<DDD!1<TSD!3 ;DISK TYPE CODE
0010'  35      .BYTE   35H    ;GAP LENGTH

;
;          1024 BYTE SECTOR, DOUBLE-DENSITY, ONE-SIDED
;
0011'  0022'  .WORD   .+DSTL  ;DISK SPEC TABLE LINK POINTER
0013'  04      .BYTE   4       ;BLOCK SIZE
0014'  0134   .WORD   (77*(8*(1<3)))/(1<4) ;NUMBER OF BLOCKS
0016'  03      .BYTE   3       ;NUMBER OF DIRECTORY BLOCKS
0017'  03      .BYTE   3       ;PHYSICAL SECTOR SIZE (2^N*128)
0018'  0008   .WORD   8       ;PHYSICAL SECTORS PER TRACK
001A'  004D   .WORD   77      ;PHYSICAL TRACKS PER DISK
001C'  0000   .WORD   0       ;RESERVED TRACKS
001E'  0000   .WORD   0       ;TRANSLATION TABLE ADDRESS
0020'  0B      .BYTE   1<DDD!3 ;DISK TYPE CODE
0021'  35      .BYTE   35H    ;GAP LENGTH

```

KFMT - TURBODOS OPERATING SYSTEM 8-INCH FLOPPY DISK SPECIFICATION TABLES
 PYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;      512 BYTE SECTOR, SINGLE-DENSITY, TWO-SIDED
;
0022' 0033'      .WORD  .+DSTL ;DISK SPEC TABLE LINK POINTER
0024' 04          .BYTE  4   ;BLOCK SIZE
0025' 0134        .WORD  (77*(16*(1<2)))/(1<4) ;NUMBER OF BLOCKS
0027' 03          .BYTE  3   ;NUMBER OF DIRECTORY BLOCKS
0028' 02          .BYTE  2   ;PHYSICAL SECTOR SIZE (2^N*128)
0029' 0010        .WORD  16  ;PHYSICAL SECTORS PER TRACK
002B' 004D        .WORD  77  ;PHYSICAL TRACKS PER DISK
002D' 0000        .WORD  0   ;RESERVED TRACKS
002F' 0000        .WORD  0   ;TRANSLATION TABLE ADDRESS
0031' 06          .BYTE  1<TSD!2 ;DISK TYPE CODE
0032' 1B          .BYTE  1BH ;GAP LENGTH
;

;      512 BYTE SECTOR, SINGLE-DENSITY, ONE-SIDED
;
0033' 0044'      .WORD  .+DSTL ;DISK SPEC TABLE LINK POINTER
0035' 04          .BYTE  4   ;BLOCK SIZE
0036' 009A        .WORD  (77*(8*(1<2)))/(1<4) ;NUMBER OF BLOCKS
0038' 02          .BYTE  2   ;NUMBER OF DIRECTORY BLOCKS
0039' 02          .BYTE  2   ;PHYSICAL SECTOR SIZE (2^N*128)
003A' 0008        .WORD  8   ;PHYSICAL SECTORS PER TRACK
003C' 004D        .WORD  77  ;PHYSICAL TRACKS PER DISK
003E' 0000        .WORD  0   ;RESERVED TRACKS
0040' 0000        .WORD  0   ;TRANSLATION TABLE ADDRESS
0042' 02          .BYTE  2   ;DISK TYPE CODE
0043' 1B          .BYTE  1BH ;GAP LENGTH
;

;      128 BYTE SECTOR, SINGLE-DENSITY, ONE-SIDED
;
0044' 0000        DSTA:  .WORD  0   ;DISK SPEC TABLE LINK POINTER
0046' 03          DSTB:  .BYTE  3   ;BLOCK SIZE
0047' 00F3        .WORD  (75*(26*(1<0)))/(1<3) ;NUMBER OF BLOCKS
0049' 02          .BYTE  2   ;NUMBER OF DIRECTORY BLOCKS
004A' 00          .BYTE  0   ;PHYSICAL SECTOR SIZE (2^N*128)
004B' 001A        .WORD  26  ;PHYSICAL SECTORS PER TRACK
004D' 004D        .WORD  77  ;PHYSICAL TRACKS PER DISK
004F' 0002        .WORD  2   ;RESERVED TRACKS
;

000B            XLTBL =: .-DSTB ;TRANSLATION TABLE ADDRESS OFFSET
;
0051' 0055'      ;
                  .WORD  TRTBL ;TRANSLATION TABLE ADDRESS
;
000F            DTCO  =: .-DSTA ;DISK TYPE CODE OFFSET
000D            TYPCOD =: .-DSTB ;DISK TYPE CODE OFFSET
;
0053' 00          ;
                  .BYTE  0   ;DISK TYPE CODE
;
000E            GAPLEN =: .-DSTB ;GAP LENGTH OFFSET
;
0054' 07          ;
                  .BYTE  7   ;GAP LENGTH
;
0011            DSTL  = .-DSTA ;DISK SPEC TABLE LENGTH
;
```

DSKFMT - TURBODOS OPERATING SYSTEM 8-INCH FLOPPY DISK SPECIFICATION TABLES
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```
; SINGLE-DENSITY/SINGLE-SIDED SECTOR TRANSLATION TABLE
; TRTBL: .BYTE 0,6,12,18,24,4,10,16,22
0055' 00060C121804      .BYTE 2,8,14,20,1,7,13,19,25
005E' 02080E140107      .BYTE 5,11,17,23,3,9,15,21
0067' 050B11170309
;
.END
```

DN192 - TURBODOS OPERATING SYSTEM 19.2KB CONSOLE DRIVER
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;***** This is a trivial console driver for a 19.2KB
;***** console device connected to serial channel zero.
;***** This module is hardware-independent. All access
;***** to the serial interface hardware is accomplished
;***** via calls to the entrypoint SERIAL:: in the hard-
;***** ware dependent serial driver modules SPD442 or
;***** SPD740.
;
;***** COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT CON192          ;MODULE ID
;
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
0000"          .LOC    .DATA.# ;LOCATE IN DATA AREA
;
0000" 8F        CONBR:: .BYTE  8FH   ;CONSOLE BAUD RATE CODE (19200 BAU
;
0001" 0C        FFCHR:: .BYTE  AFF   ;FORM FEED CHARACTER
0002" 00        INITC: .BYTE  0      ;INITIALIZATION COMPLETE FLAG
;
0000'          .LOC    .PROG.# ;LOCATE IN PROGRAM AREA
;
0000' 21 0002"  CONDR%::LXI H,INITC ;GET INITIALIZATION COMPLETE FLAG
0003' 7E        MOV     A,M
0004' B7        ORA     A
0005' CC 0013'  CZ      ..INIT  ;IF NOT, INITIALIZE CONSOLE BAUD R
;
0008' 7B        ..CDRV: MOV    A,E   ;GET FUNCTION NUMBER
0009' D608      SUI    8      ;FUNCTION NUMBER=8?
000B' 2823      JRZ    CONSO ;IF SO, ERROR SHIFT OUT
000D' 3D        DCR    A      ;FUNCTION NUMBER=9?
000E' 2820      JRZ    CONSI ;IF SO, ERROR SHIFT IN
0010' C3 0000:04 JMP    SERIAL# ;ELSE, CONTINUE
0013' 35        ..INIT: DCR    M      ;SET INITIALIZATION COMPLETE FLAG
0014' D5        PUSH   D      ;SAVE FUNCTION NUMBER
0015' C5        PUSH   B      ;SAVE CHANNEL NUMBER/CHARACTER
0016' 3A 0000"  LDA    CONBR ;GET CONSOLE BAUD RATE CODE
0019' 4F        MOV    C,A   ;TELEVIDEO BAUD RATE CODE TO C-REG
001A' 1E03      MVII   E,3   ;SET FUNCTION NUMBER=3
001C' CD 0000:04 CALL   SERIAL# ;SET CHANNEL BAUD RATE
001F' 3A 0001"  LDA    FFCHR ;GET FORM FEED CHARACTER
0022' B7        ORA    A      ;FORM FEED CHARACTER=0?
0023' 2808      JRZ    ..NITX ;IF SO, CONTINUE
;
```

CON192 - TURBODOS OPERATING SYSTEM 19.2KB CONSOLE DRIVER
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```
0025' C1          POP    B      ;ELSE, RESTORE CHANNEL NUMBER
0026' C5          PUSH   B      ;SAVE CHANNEL NUMBER
0027' 4F          MOV    C,A    ;FORM FEED CHARACTER TO C-REG
0028' 1E02         MVI    E,2    ;SET FUNCTION NUMBER=2
002A' CD 0000:04   CALL   SERIAL# ;OUTPUT FORM FEED
002D' C1          ..NITX: POP    B      ;RESTORE CHANNEL NUMBER/CHARACTER
002E' D1          POP    D      ;RESTORE FUNCTION NUMBER
002F' C9          RET     ;DONE
;
0030'             CONSO: CALL   DMS#    ;POSITION TO NEXT LINE
0030' CD 0000:05   CONSI: CALL   .ASCIS  [ACR] [ALF]
0033' OD8A         RET     ;DONE
;
.END
```

ST300 - TURBODOS OPERATING SYSTEM 300 BAUD LIST DRIVER
 COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```
*****  

* This is a printer driver for a 300 baud TTY-like  

* printer device connected to a serial channel 0-15.  

* It is coded to support up to 16 channels at once.  

* This module is hardware-independent. All access  

* to the serial interface hardware is accomplished  

* via calls to the entrypoint SERIAL:: in the hard-  

* ware dependent serial driver modules SPD442 or  

* SPD740.  

*****  

; COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.  

; AUTHORS: RONALD E. RAIKES  

; MICHAEL D. BUSCH  

; VERSION: EXAMPLE  

; IDENT LST300 ;MODULE ID  

; INSERT DREQUATE ;DRIVER SYMBOLIC EQUIVALENCES  

; 0000" .LOC .DATA.# ;LOCATE IN DATA AREA  

; 0000" 25 LST3BR:::BYTE 25H ;BAUD RATE CODE (300 BAUD).  

; 0001" 0C LST3FF:::BYTE AFF ;FORM FEED CHARACTER  

; 0002" 000000000000 INITC: .BYTE [16]0 ;INITIALIZATION COMPLETE FLAGS  

; 0000" .LOC .PROG.# ;LOCATE IN PROGRAM AREA  

; 0000" 21 0002" LSTDRA%::LXI H,INITC ;GET INITIALIZATION COMPLETE FLAGS  

; 0003" D5 PUSH D ;SAVE FUNCTION NUMBER  

; 0004" 58 MOV E,B ;CHANNEL NUMBER TO DE-REG  

; 0005" 1600 MVI D,0 ;DOUBLE LENGTH  

; 0007" 19 DAD D ;INDEX INTO FLAGS TABLE  

; 0008" D1 POP D ;RESTORE FUNCTION NUMBER  

; 0009" 7E MOV A,M ;GET INITIALIZATION COMPLETE FLAG  

; 000A" B7 ORA A ;INITIALIZATION COMPLETE FLAG SET?  

; 000B" CC 0018" CZ ..INIT ;IF NOT, INITIALIZE LIST CHANNEL  

; 000E" 7B MOV A,E ;GET FUNCTION NUMBER  

; 000F" FE02 CPI 2 ;FUNCTION NUMBER=2?  

; 0011" 281A JRZ LSTOUT ;IF SO, CONTINUE  

; 0013" FE07 CPI 7 ;FUNCTION NUMBER=7?  

; 0015" 2810 JRZ LSTWSR ;IF SO, CONTINUE  

; 0017" C9 RET ;ELSE, DONE  

; 0018" 35 ..INIT: DCR M ;SET INITIALIZATION COMPLETE FLAG  

; 0019" D5 PUSH D ;SAVE FUNCTION NUMBER  

; 001A" C5 PUSH B ;SAVE CHANNEL NUMBER/CHARACTER  

; 001B" 3A 0000" LDA LST3BR ;GET BAUD RATE CODE  

; 001E" 4F MOV C,A ;BAUD RATE CODE TO C-REG  

; 001F" 1E03 MVI E,3 ;SET FUNCTION NUMBER=3
```

LST300 - TURBODOS OPERATING SYSTEM 300 BAUD LIST DRIVER
COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

0021'	CD 0000:04	CALL	SERIAL#	;SET CHANNEL BUAD RATE
0024'	C1	POP	B	;RESTORE CHANNEL NUMBER/CHARACTER
0025'	D1	POP	D	;RESTORE FUNCTION NUMBER
0026'	C9	RET		;DONE
		;		
0027'	3A 0001"	LSTWSR:	LDA	LST3FF ;GET FORM FEED CHARACTER
002A'	4F		MOV	C,A ;FORM FEED CHARACTER TO C-REG
002B'	1E02		MVI	E,2 ;SET FUNCTION NUMBER=2
		;		
002D'	C3 0000:04	LSTOUT:	JMP	SERIAL# ;CONTINUE
		;		
		END		

TCTS - TURBODOS OPERATING SYSTEM CLEAR-TO-SEND PRINTER DRIVER
 PYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

;*****#
;
; This is a printer driver for 9600 baud printers
; using clear-to-send handshaking (e.g. TI-810).
; It is coded to support up to 16 channels at once.
; This module is hardware-independent. All access
; to the serial interface hardware is accomplished
; via calls to the entrypoint SERIAL:: in the hard-
; ware dependent serial driver modules SPD442 or
; SPD740.
;
;*****#
;

COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

AUTHORS: RONALD E. RAIKES
MICHAEL D. BUSCH

VERSION: EXAMPLE

.IDENT LSTCTS ;MODULE ID
.INSERT DREQUATE ;DRIVER SYMBOLIC EQUIVALENCES
; .LOC .DATA.# ;LOCATE IN DATA AREA
0000" 6E CTSBR:: .BYTE 6EH ;BAUD RATE CODE (9600 BAUD)
0001" 0C CTSFF:: .BYTE AFF ;FORM FEED CHARACTER
0002" 000000000000 INITC: .BYTE [16]0 ;INITIALIZATION COMPLETE FLAGS
; .LOC .PROG.# ;LOCATE IN PROGRAM AREA
0000' 21 0002" LSTDRC:::LXI H,INITC ;GET INITIALIZATION COMPLETE FLAGS
0003' D5 PUSH D ;SAVE FUNCTION NUMBER
0004' 58 MOV E,B ;CHANNEL NUMBER TO DE-REG
0005' 1600 MVI D,O ;DOUBLE LENGTH
0007' 19 DAD D ;INDEX INTO FLAGS TABLE
0008' D1 POP D ;RESTORE FUNCTION NUMBER
0009' 7E MOV A,M ;GET INITIALIZATION COMPLETE FLAG
000A' B7 ORA A ;INITIALIZATION COMPLETE FLAG SET?
000B' CC 0018' CZ ..INIT ;IF NOT, INITIALIZE LIST CHANNEL
000E' 7B MOV A,E ;GET FUNCTION NUMBER
000F' FE02 CPI 2 ;FUNCTION NUMBER=2?
0011' 281A JRZ LSTOUT ;IF SO, CONTINUE
0013' FE07 CPI 7 ;FUNCTION NUMBER=7?
0015' 2810 JRZ LSTWSR ;IF SO, CONTINUE
0017' C9 RET ;ELSE, DONE
0018' 35 ..INIT: DCR M ;SET INITIALIZATION COMPLETE FLAG
0019' D5 PUSH D ;SAVE FUNCTION NUMBER
001A' C5 PUSH B ;SAVE CHANNEL NUMBER/CHARACTER
001B' 3A 0000" LDA CTSBR ;GET BAUD RATE CODE
001E' 4F MOV C,A ;BAUD RATE CODE TO C-REG
001F' 1E03 MVI E,3 ;SET FUNCTION NUMBER=3

```

LSTCTS - TURBODOS OPERATING SYSTEM CLEAR-TO-SEND PRINTER DRIVER
COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

0021'	CD 0000:04	CALL	SERIAL#	;SET CHANNEL BUAD RATE
0024'	C1	POP	B	;RESTORE CHANNEL NUMBER/CHARACTER
0025'	D1	POP	D	;RESTORE FUNCTION NUMBER
0026'	C9	RET		;DONE
		;		
0027'	3A 0001"	LSTWSR:	LDA	CTSFF ;GET FORM FEED CHARACTER
002A'	4F		MOV	C,A ;FORM FEED CHARACTER TO C-REG
002B'	1E02		MVI	E,2 ;SET FUNCTION NUMBER=2
		;		
002D'	C3 0000:04	LSTOUT:	JMP	SERIAL# ;CONTINUE
		;		
		•END		

TETX - TURBODOS OPERATING SYSTEM ETX/ACK PRINTER DRIVER
 PYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

; ****
;
; This is a printer driver for 1200 baud printers
; using ETX/ACK protocol (e.g., Diablo or NEC daisy).
; It is coded to support up to 16 channels at once.
; This module is hardware-independent. All access
; to the serial interface hardware is accomplished
; via calls to the entrypoint SERIAL:: in the hard-
; ware dependent serial driver modules SPD442 or
; SPD740.
;

; ****
;
; COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH

; VERSION: EXAMPLE

; IDENT LSTETX      ;MODULE ID
; INSERT DREQUATE   ;DRIVER SYMBOLIC EQUIVALENCES
;

0000"          .LOC    .DATA.# ;LOCATE IN DATA AREA
;

0000"  07        ETXBR:: .BYTE   7      ;BAUD RATE CODE (1200 BAUD)
0001"  8C        ETXLEN:: .BYTE  140    ;CHARACTER COUNT BETWEEN ETX'S
0002"  03        ETXSEQ:: .BYTE  3      ;MAX ESCAPE SEQUENCE LENGTH
0003"  0C        ETXFF:: .BYTE  AFF    ;FORM FEED CHARACTER
0004"  000000000000 CHRCNT: .BYTE [16]0 ;CHARACTER COUNT
0014"  000000000000 SEQCNT: .BYTE [16]0 ;SEQUENCE COUNT
0024"  000000000000 INITC:  .BYTE [16]0 ;INITIALIZATION COMPLETE FLAGS
;

0000'          .LOC    .PROG.# ;LOCATE IN PROGRAM AREA
;

0000'  21 0024"  LSTDRL%::LXI H,INITC ;GET INITIALIZATION COMPLETE FLAGS
0003'  CD 0084'    CALL INDEX  ;INDEX INTO FLAGS TABLE
0006'  7E          MOV A,M   ;GET INITIALIZATION COMPLETE FLAG
0007'  B7          ORA A     ;INITIALIZATION COMPLETE FLAG SET?
0008'  CC 0015'    CZ ..INIT ;IF NOT, INITIALIZE LIST CHANNEL
000B'  7B          MOV A,E   ;GET FUNCTION NUMBER
000C'  FE02         CPI 2    ;FUNCTION NUMBER=2?
000E'  281A         JRZ LSTOUT ;IF SO, CONTINUE
0010'  FE07         CPI 7    ;FUNCTION NUMBER=7?
0012'  2810         JRZ LSTWSR ;IF SO, CONTINUE
0014'  C9          RET      ;ELSE, DONE
0015'  35          ..INIT: DCR M    ;SET INITIALIZATION COMPLETE FLAG
0016'  D5          PUSH D   ;SAVE FUNCTION NUMBER
0017'  C5          PUSH B   ;SAVE CHANNEL NUMBER/CHARACTER
0018'  3A 0000"    LDA ETXBR ;GET BAUD RATE CODE
001B'  4F          MOV C,A  ;BAUD RATE CODE TO C-REG
001C'  1E03        MVI E,3   ;SET FUNCTION NUMBER=3
;
```

LSTETX - TURBODOS OPERATING SYSTEM ETX/ACK PRINTER DRIVER
 COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

001E' CD 0000:04          CALL    SERIAL# ;SET CHANNEL BUAD RATE
0021' C1                  POP     B      ;RESTORE CHANNEL NUMBER/CHARACTER
0022' D1                  POP     D      ;RESTORE FUNCTION NUMBER
0023' C9                  RET      ;DONE

;LSTWSR: LDA ETXFF ;GET FORM FEED CHARACTER
0024' 3A 0003"           MOV   C,A   ;FORM FEED CHARACTER TO C-REG
0027' 4F                  MVI   E,2   ;SET FUNCTION NUMBER=2

;LSTOUT: CALL ..GCCA ;GET CHARACTER COUNT ADDRESS
002A' CD 007C'           MOV   A,M   ;GET CHARACTER COUNT
002D' 7E                  LXI   H,ETXLEN ;GET CHARACTER COUNT BETWEEN EI

0031' B7                  CMP   M      ;MAX CHARACTER COUNT OUTSTANDING?
0032' 381B                JRC   ..OUT  ;IF NOT, CONTINUE
0034' CD 0081'             CALL  ..GSCA ;ELSE, GET SEQUENCE COUNT ADDRESS
0037' 7E                  MOV   A,M   ;GET SEQUENCE COUNT
0038' B7                  ORA   A      ;IN ESCAPE SEQUENCE?
0039' 2014                JRNZ  ..OUT  ;IF SO, CONTINUE
003B' C5                  PUSH  B      ;ELSE, SAVE OUTPUT CHARACTER
003C' 0E03                MVI   C,AETX ;GET ETX CHARACTER
003E' CD 0074'             CALL  ..SOUT ;OUTPUT ETX CHARACTER
0041' CD 006B'             ..WAIT: CALL ..SIN   ;ELSE, GET SERIAL INPUT
0044' E67F                ANI   7FH   ;STRIP SIGN BIT
0046' D606                SUI   AACK  ;CHARACTER=ACK?
0048' 20F7                JRNZ  ..WAIT  ;IF NOT, WAIT
004A' CD 007C'             CALL  ..GCCA ;ELSE, GET CHARACTER COUNT ADDRESS
004D' 77                  MOV   M,A   ;RESET CHARACTER COUNT
004E' C1                  POP   B      ;RESTORE OUTPUT CHARACTER
004F' 79                  ..OUT:  MOV   A,C   ;GET OUTPUT CHARACTER
0050' E67F                ANI   7FH   ;STRIP SIGN BIT
0052' FE1B                CPI   AESC  ;CHARACTER=ESCAPE?
0054' 2007                JRNZ  ..NESC  ;IF NOT, CONTINUE
0056' CD 0081'             CALL  ..GSCA ;ELSE, GET SEQUENCE COUNT ADDRESS
0059' 3A 0002"             LDA   ETXSEQ ;GET MAX ESCAPE SEQUENCE LENGTH
005C' 77                  MOV   M,A   ;SET SEQUENCE COUNT
005D' CD 0074'             ..NESC: CALL ..SOUT ;OUTPUT CHARACTER
0060' CD 007C'             CALL  ..GCCA ;GET CHARACTER COUNT ADDRESS
0063' 34                  INR   M      ;INCREMENT CHARACTER COUNT
0064' CD 0081'             CALL  ..GSCA ;GET SEQUENCE COUNT ADDRESS
0067' 35                  DCR   M      ;DECREMENT SEQUENCE COUNT
0068' F0                  RP    ;IF POSITIVE, DONE
0069' 34                  INR   M      ;ELSE, RESTORE COUNT TO 0
006A' C9                  RET    ;DONE
006B' C5                  ..SIN: PUSH  B      ;SAVE CHANNEL NUMBER/CHARACTER
006C' D5                  PUSH  D      ;SAVE FUNCTION NUMBER
006D' 1E01                MVI   E,1   ;SET FUNCTION NUMBER=1
006F' CD 0000:04             CALL  SERIAL# ;GET SERIAL INPUT
0072' 1805                JMPR  ..SIOC ;CONTINUE
0074' C5                  ..SOUT: PUSH  B      ;SAVE CHANNEL NUMBER/CHARACTER
0075' D5                  PUSH  D      ;SAVE FUNCTION NUMBER
0076' CD 0000:04             CALL  SERIAL# ;OUTPUT CHARACTER
0079' D1                  ..SIOC: POP   D      ;RESTORE FUNCTION NUMBER
007A' C1                  POP   B      ;RESTORE CHANNEL NUMBER/CHARACTER

```

STETX - TURBODOS OPERATING SYSTEM ETX/ACK PRINTER DRIVER
COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```
007B' C9          RET      ;DONE
007C' 21 0004"    ..GCCA: LXI    H,CHRCNT ;GET CHARACTER COUNT TABLE
007F' 1803        JMPR    INDEX  ;CONTINUE
0081' 21 0014"    ..GSCA: LXI    H,SEQCNT ;GET SEQUENCE COUNT TABLE
0084' D5          ;INDEX: PUSH   D       ;SAVE FUNCTION NUMBER
0085' 58          MOV     E,B     ;CHANNEL NUMBER TO DE-REG
0086' 1600        MVI     D,0     ;DOUBLE LENGTH
0088' 19          DAD     D       ;INDEX INTO TABLE
0089' D1          POP     D       ;RESTORE FUNCTION NUMBER
008A' C9          RET      ;DONE
;
.END
```

LSTXON - TURBODOS OPERATING SYSTEM XON/XOFF PRINTER DRIVER
 COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

; **** This is a printer driver for 1200 baud printers
; **** using XON/XOFF protocol (e.g., Diablo, Okidata).
; **** It is coded to support up to 16 channels at once.
; **** This module is hardware-independent. All access
; **** to the serial interface hardware is accomplished
; **** via calls to the entrypoint SERIAL:: in the hard-
; **** ware dependent serial driver modules SPD442 or
; **** SPD740.
;
; ****
;
; COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
; MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT LSTXON          ;MODULE ID
;
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
0000"           .LOC    .DATA.# ;LOCATE IN DATA AREA
;
0000"   07      XONBR:: .BYTE  7      ;BAUD RATE CODE (1200 BAUD)
0001"   0C      XONFF:: .BYTE  AFF    ;FORM FEED CHARACTER
0002" 000000000000 INITC:  .BYTE  [16]0 ;INITIALIZATION COMPLETE FLAGS
;
0000'           .LOC    .PROG.# ;LOCATE IN PROGRAM AREA
;
0000' 21 0002"  LSTDRL%::LXI  H,INITC ;GET INITIALIZATION COMPLETE FLAG
0003'  D5      PUSH   D      ;SAVE FUNCTION NUMBER
0004'  58      MOV    E,B    ;CHANNEL NUMBER TO DE-REG
0005'  1600    MVI    D,0    ;DOUBLE LENGTH
0007'  19      DAD    D      ;INDEX INTO FLAGS-TABLE
0008'  D1      POP    D      ;RESTORE FUNCTION NUMBER
0009'  7E      MOV    A,M    ;GET INITIALIZATION COMPLETE FLAG
000A'  B7      ORA    A      ;INITIALIZATION COMPLETE FLAG SET
000B'  CC 0018' CZ     ..INIT  ;IF NOT, INITIALIZE LIST CHANNEL
000E'  7B      MOV    A,E    ;GET FUNCTION NUMBER
000F'  FE02    CPI    2      ;FUNCTION NUMBER=2?
0011'  281A    JRZ    LSTOUT ;IF SO, CONTINUE
0013'  FE07    CPI    7      ;FUNCTION NUMBER=7?
0015'  2810    JRZ    LSTWSR ;IF SO, CONTINUE
0017'  C9      RET
0018'  35      ..INIT: DCR    M      ;SET INITIALIZATION COMPLETE FLAG
0019'  D5      PUSH   D      ;SAVE FUNCTION NUMBER
001A'  C5      PUSH   B      ;SAVE CHANNEL NUMBER/CHARACTER
001B'  3A 0000" LDA    XONBR ;GET BAUD RATE CODE
001E'  4F      MOV    C,A    ;BAUD RATE CODE TO C-REG
001F'  1E03    MVI    E,3    ;SET FUNCTION NUMBER=3

```

TXON - TURBO DOS OPERATING SYSTEM XON/XOFF PRINTER DRIVER
PYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

0021' CD 0000:04      CALL    SERIAL# ;SET CHANNEL BUAD RATE
0024' C1              POP     B      ;RESTORE CHANNEL NUMBER/CHARACTER
0025' D1              POP     D      ;RESTORE FUNCTION NUMBER
0026' C9              RET    ;DONE

;          ;
0027' 3A 0001"        LSTWSR: LDA     XONFF  ;GET FORM FEED CHARACTER
002A' 4F              MOV     C,A    ;FORM FEED CHARACTER TO C-REG
002B' 1E02             MVI     E,2    ;SET FUNCTION NUMBER=2

;          ;
002D' CD 0048'        LSTOUT: CALL   ..SST   ;GET SERIAL STATUS
0030' B7              ORA     A      ;CHARACTER AVAILABLE?
0031' 2812            JRZ     ..OUT   ;IF NOT, CONTINUE
0033' CD 0051'        CALL   ..SIN   ;ELSE, GET SERIAL INPUT
0036' E67F            ANI     7FH    ;STRIP SIGN BIT
0038' FE13            CPI     ADC3   ;CHARACTER=DC3 (XOFF)?
003A' 20F1            JRNZ   LSTOUT ;IF NOT, WAIT
003C' CD 0051'        ..WAIT: CALL   ..SIN   ;GET SERIAL INPUT
003F' E67F            ANI     7FH    ;STRIP SIGN BIT
0041' FE11            CPI     ADC1   ;CHARACTER=DC1 (XON)?
0043' 20F7            JRNZ   ..WAIT  ;IF NOT, WAIT
0045' C3 0000:04      ..OUT:  JMP    SERIAL# ;OUTPUT CHARACTER
0048' C5              ..SST:  PUSH   B      ;SAVE CHANNEL NUMBER/CHARACTER
0049' D5              PUSH   D      ;SAVE FUNCTION NUMBER
004A' 1E00            MVI     E,0    ;SET FUNCTION NUMBER=0
004C' CD 0000:04      CALL   SERIAL# ;GET SERIAL STATUS
004F' 1807            JMPR   ..SSIC  ;CONTINUE
0051' C5              ..SIN:  PUSH   B      ;SAVE CHANNEL NUMBER/CHARACTER
0052' D5              PUSH   D      ;SAVE FUNCTION NUMBER
0053' 1E01            MVI     E,1    ;SET FUNCTION NUMBER=1
0055' CD 0000:04      CALL   SERIAL# ;GET SERIAL STATUS
0058' D1              ..SSIC: POP    D      ;RESTORE FUNCTION NUMBER
0059' C1              POP    B      ;RESTORE CHANNEL NUMBER/CHARACTER
005A' C9              RET    ;DONE

;
.END

```

MCD740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```
;;
; **** This is a fairly complex network circuit driver
; which runs in an IMS 8000 master processor and
; which communicates with a simple circuit driver
; (SCD740) running in an IMS 740 slave processor
; board. This driver accomodates up to sixteen
; IMS 740 slave boards.
;
; The IMS 740 slave communicates with the master
; processor over the S-100 bus via a byte-parallel
; transfer which is handled by programmed I/O by
; both processors. The IMS 740 slave appears to the
; master processor as an ordinary port-addressed
; peripheral device. The interface on the 740 board
; is an Intel 8255 parallel I/O controller chip,
; and coordination between the master and slave is
; handled by the status bits of the 8255. The
; master processor may interrupt the slave to see
; if it is still healthy, and can also reset and
; download the slave.
;
; This driver maintains a "watchdog timer" for each
; of the slave processors. If it has not received
; any messages from a particular slave processor
; after a one-second interval, it polls that slave
; by interrupting it and looking for an acknowledgement
; from the slave's interrupt service routine.
; If no acknowledgement is received within a brief
; timeout interval, then this driver concludes that
; the slave has crashed. The driver informs Turbo-
; DOS of the crash (so TurboDOS can take its re-
; covery action), and then the driver resets and
; downloads a fresh copy of the operating system
; into the failed slave.
;
; The IMS 740 slave board has a start-up ROM which
; is programmed with the contents of the module
; SPB740 to handle the slave-end of the download
; procedure. At the start of a download, this dri-
; ver sends (and the SPB740 slave ROM receives) a
; loader module LOD740 to the slave. This loader
; module handles the remainder of the downloading
; task by making standard TurboDOS network download
; requests to load the full slave operating system
; from a file OSSLAVE.SYS on the master's disk.
;
; ****
;
; COPYRIGHT (C) 1982. SOFTWARE 2000. INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
```

CD740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

;          ; VERSION: EXAMPLE
;          ;.IDENT MCD740           ;MODULE ID
;          ;.INSERT DREQUATE      ;DRIVER SYMBOLIC EQUIVALENCES
;
0005      IBF     = 5           ;INPUT BUFFER FULL BIT
0007      OBFN    = 7           ;INPUT BUFFER FULL (NOT) BIT
;
0000      RESPC0 = 00H          ;RESET PC0 COMMAND
0001      SETPC0 = 01H          ;SET PC0 COMMAND
0002      RESPC1 = 02H          ;RESET PC1 COMMAND
0003      SETPC1 = 03H          ;SET PC1 COMMAND
0008      RESPC4 = 08H          ;RESET PC4 COMMAND
0009      SETPC4 = 09H          ;SET PC4 COMMAND
000A      RESPC5 = 0AH          ;RESET PC5 COMMAND
000B      SETPC5 = 0BH          ;SET PC5 COMMAND
000C      RESPC6 = 0CH          ;RESET PC6 COMMAND
000D      SETPC6 = 0DH          ;SET PC6 COMMAND
000C      RESPC7 = 0CH          ;RESET PC7 COMMAND
000D      SETPC7 = 0DH          ;SET PC7 COMMAND
;
00C0      PPMODE  = 0COH         ;PARALLEL PORT MODE WORD
                                ;(MODE 2/MODE 0 OUT)
;
0000"      ;          .LOC    .DATA.# ;LOCATE IN DATA AREA
0000" 02      NMB740:::BYTE   2           ;NUMBER OF IMS 740 SLAVES
;
0001" 00      CKT740:::BYTE   00H          ;IMS 740 CIRCUIT NUMBER
;
0002"      PAT740:::          ;IMS 740 SLAVE PORT ADDRESS TABLE
0002" 40      .BYTE   40H
0003" 44      .BYTE   44H
0004" 48      .BYTE   48H
0005" 4C      .BYTE   4CH
0006" 50      .BYTE   50H
0007" 54      .BYTE   54H
0008" 58      .BYTE   58H
0009" 5C      .BYTE   5CH
000A" 60      .BYTE   60H
000B" 64      .BYTE   64H
000C" 68      .BYTE   68H
000D" 6C      .BYTE   6CH
000E" 70      .BYTE   70H
000F" 74      .BYTE   74H
0010" 78      .BYTE   78H
0011" 7C      .BYTE   7CH
;
0012"      SST740:::          ;IMS 740 SLAVE SUFFIX LETTER TABLE
0012" 20      .BYTE   ASP
0013" 20      .BYTE   ASP
0014" 20      .BYTE   ASP

```

MCD740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

0015" 20          .BYTE  ASP
0016" 20          .BYTE  ASP
0017" 20          .BYTE  ASP
0018" 20          .BYTE  ASP
0019" 20          .BYTE  ASP
001A" 20          .BYTE  ASP
001B" 20          .BYTE  ASP
001C" 20          .BYTE  ASP
001D" 20          .BYTE  ASP
001E" 20          .BYTE  ASP
001F" 20          .BYTE  ASP
0020" 20          .BYTE  ASP
0021" 20          .BYTE  ASP

;                                ;MAXLEN: .BYTE 0      ;MAXIMUM MESSAGE LENGTH
0022" 00          MAXLEN: .BYTE 0      ;MAXIMUM MESSAGE LENGTH
0023" 000F        CURSLV: .WORD 000FH ;CURRENT SLAVE PROCESSOR NUMBER
;
0025" 0000        RCVSPH: .WORD 0      ;RECEIVE MESSAGE SEMAPHORE
0027" 0027        ..RCVH: .WORD ..RCVH ;RECEIVE MESSAGE SEMAPHORE
0029" 0027        .WORD ..RCVH

002B" 000000000000 ;POLCNT: .BYTE [16]0 ;POLL ROUTINE TICK COUNTS
;
0000:04          ;.LOC   .INIT.# ;LOCATE IN INITIALIZATION AREA
;
0000:04 C9        CKTIN%::RET           ;DONE
;
0000'             ;.LOC   .PROG.# ;LOCATE IN PROGRAM AREA
;
0000' 79          CKTDR%::MOV A,C    ;GET FUNCTION NUMBER
0001' B7          ORA A      ;FUNCTION NUMBER=0?
0002' 2805        JRZ RCVMSG ;IF SO, CONTINUE
0004' 3D          DCR A      ;FUNCTION NUMBER=1?
0005' CA 0060'    JZ SNDMSG ;IF SO, CONTINUE
0008' C9          RET         ;ELSE, DONE

;                                ;RCVMSG: INX D      ;ADVANCE PAST LINK POINTERS
0009' 13          INX D
000A' 13          INX D
000B' 13          INX D
000C' 13          INX D
000D' D5          PUSH D     ;SAVE MESSAGE BUFFER ADDRESS
000E' 1A          LDAX D     ;GET MAXIMUM MESSAGE LENGTH
000F' 32 0022"    STA MAXLEN ;SAVE MAXIMUM MESSAGE LENGTH
0012' 11 00FO'    ..RCVL: LXI D, POL740 ;GET IMS 740 POLL ROUTINE
0015' CD 0000:05  CALL LNKPOL# ;LINK POLL ROUTINE ON POLL LIST
0018' 21 0025"    LXI H, RCVSPH ;GET RECEIVE MESSAGE SEMAPHORE
001B' CD 0000:06  CALL WAIT#  ;WAIT FOR REQUEST
001E' CD 0170'    CALL RMCOM ;DO COMMON SETUP
0021' D5          PUSH D     ;SAVE SLAVE PROCESSOR NUMBER
0022' 200C        JRNZ ..RIP ;IF REQUEST IN PROGRESS, CONTINUE
0024' CBC6        SET O,M    ;ELSE, SET REQUEST IN PROGRESS FL
0026' 0C          INR C      ;CALC CONTROL PORT
0027' 3E01        MVI A, SETPCO ;SET PC0 (INTERRUPT)
0029' ED79        OUTP A     ;ASSERT INTERRUPT

```

740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
 YRIGHT (C) 1982. SOFTWARE 2000. INC.

```

002B' 3E00      MVI    A, RESPCO ;RESET PC0 (INTERRUPT)
002D' ED79      OUTP   A     ;RELEASE INTERRUPT
002F' OD         DCR    C     ;CALC PORT C ADDRESS
0030' CD 013A'   ..RIP: CALL   INBYT  ;INPUT BYTE FROM SLAVE PROCESSOR
0033' D1         POP    D     ;RESTORE SLAVE PROCESSOR NUMBER
0034' 380D      JRC    ..IERR ;IF ERROR, CONTINUE
0036' FE06      CPI    AACK   ;RESPONSE=ACK?
0038' 280C      JRZ    ..RCV   ;IF SO, CONTINUE
003A' FE15      CPI    ANAK   ;RESPONSE=NACK?
003C' 2005      JRNZ   ..IERR ;IF NOT, CONTINUE
003E' CD 0168'   CALL   SETTC  ;ELSE, SET TICK COUNT
0041' 18CF      JMPR   ..RCVL ;CONTINUE
0043' E1         ..IERR: POP    H     ;RESTORE MESSAGE BUFFER ADDRESS
0044' 1842      JMPR   ERRCOM ;CONTINUE
0046' E1         ..RCV:  POP    H     ;RESTORE MESSAGE BUFFER ADDRESS
0047' 0601      MVI    B,1    ;GET LENGTH OF MESSAGE LENGTH
0049' CD 0130'   CALL   RCV740 ;RECEIVE MESSAGE LENGTH
004C' 383A      JRC    ERRCOM ;IF ERROR, CONTINUE
004E' 2B         DCX    MAXLEN ;GET MAXIMUM MESSAGE LENGTH
004F' 3A 0022"   LDA    MAXLEN ;MAXIMUM MESSAGE LENGTH EXCEEDED?
0052' BE         CMP    M     ;MAXIMUM MESSAGE LENGTH EXCEEDED?
0053' 3833      JRC    ERRCOM ;IF SO, CONTINUE
0055' 46         MOV    B,M    ;ELSE, GET MESSAGE LENGTH
0056' 23         INX    H     ;RESTORE MESSAGE BUFFER ADDRESS
0057' 05         DCR    B     ;DECREMENT MESSAGE LENGTH
0058' 282E      JRZ    ERRCOM ;IF MESSAGE LENGTH=0, CONTINUE
005A' CD 0130'   CALL   RCV740 ;ELSE, RECEIVE REMAINDER OF MESSAG
005D' D0         RNC    ERRCOM ;IF NO ERROR, DONE
005E' 1828      JMPR   ERRCOM ;ELSE, CONTINUE

; SNDMSG: XCHG      ;MESSAGE BUFFER ADDRESS TO HL-REG
0060' EB          INX    H     ;ADVANCE PAST LINK POINTERS
0061' 23          INX    H
0062' 23          INX    H
0063' 23          INX    H
0064' 23          INX    H
0065' E5          PUSH   H     ;SAVE MESSAGE BUFFER ADDRESS
0066' 23          INX    H     ;ADVANCE TO MESSAGE DESTINATION ID
0067' 5E          MOV    E,M    ;GET MESSAGE DESTINATION ID
0068' 1600      MVI    D,0    ;DOUBLE LENGTH
006A' 1D          DCR    E     ;DECREMENT MESSAGE DESTINATION ID
006B' CD 0174'   CALL   SMCOM ;DO COMMON SETUP
006E' E1          POP    H     ;RESTORE MESSAGE BUFFER ADDRESS
006F' 7E          MOV    A,M    ;GET MESSAGE LENGTH
0070' B7          ORA    A     ;MESSAGE LENGTH=0?
0071' 2810      JRZ    ..X    ;IF SO, CONTINUE
0073' D5          PUSH   D     ;ELSE, SAVE SLAVE PROCESSOR NUMBER
0074' 46          MOV    B,M    ;GET MESSAGE LENGTH
0075' 05          DCR    B     ;DECREMENT MESSAGE LENGTH
0076' C5          PUSH   B     ;SAVE MESSAGE LENGTH
0077' 0601      MVI    B,1    ;GET LENGTH OF MESSAGE LENGTH
0079' CD 0126'   CALL   SND740 ;SEND MESSAGE LENGTH TO SLAVE
007C' C1          POP    B     ;RESTORE MESSAGE LENGTH
007D' D4 0126'   CNC    SND740 ;IF NO ERROR, SEND MESSAGE
0080' D1          POP    D     ;RESTORE SLAVE PROCESSOR NUMBER

```

MCD740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

0081' 3805          JRC      ERRCOM ;IF ERROR, CONTINUE
0083' CD 0168'       ..X:    CALL    SETTC ;ELSE, SET TICK COUNT
0086' AF             XRA     A        ;SET RETURN CODE=0
0087' C9             RET     ;DONE

0088' CD 0092'       ;ERRCOM: CALL    RESSLV ;RESET SLAVE PROCESSOR
008B' ED5B 0000:07   LDED    SID740# ;GET SLAVE PROCESSOR SOURCE ID
008F' 3EFF           MVI     A,OFFH ;SET RETURN CODE=OFFH
0091' C9             RET     ;DONE

0092' 3A 0001"       ;RESSLV: LDA     CKT740 ;GET IMS 740 CIRCUIT NUMBER
0095' 67              MOV     H,A    ;IMS 740 CIRCUIT NUMBER TO H-REG
0096' 2E00            MVI     L,0    ;SET CIRCUIT NODE ADDRESS TO 0
0098' 22 0000:08     SHLD    DID740# ;SET SLAVE PPROCESSOR DESTINATION
009B' 3A 0023"       LDA     CURSLV ;GET CURRENT SLAVE PROCESSOR NUMB
009E' 3C              INR     A      ;INCREMENT SLAVE PROCESSOR NUMBER
009F' 6F              MOV     L,A    ;SLAVE PROCESSOR NUMBER TO L-REG
00A0' 22 0000:07     SHLD    SID740# ;SET SLAVE PROCESSOR SOURCE ID
00A3' 22 0000:09     SHLD    ORG740# ;SET SLAVE PROCESSOR ORIGIN
00A6' 2A 0023"       LHLD    CURSLV ;GET CURRENT SLAVE PROCESSOR NUMB
00A9' 11 0012"       LXI    D,SST740 ;GET SLAVE SUFFIX LETTER TABLE
00AC' 19              DAD     D      ;INDEX INTO SLAVE SUFFIX TABLE
00AD' 7E              MOV     A,M    ;GET SLAVE O/S SUFFIX LETTER
00AE' 32 0000:0A     STA     SSL740# ;SET SLAVE SUFFIX LETTER
00B1' 0C              INR     C      ;CALC CONTROL PORT ADDRESS
00B2' 3EC0            MVI     A,PPMODE ;GET PARALLEL PORT MODE WORD
00B4' ED79            OUTP   A      ;INITIALIZE 8255
00B6' 3E03            MVI     A,SETPC1 ;SET PC1 (RESET)
00B8' ED79            OUTP   A      ;ASSERT RESET
00BA' 0D              DCR     C      ;CALC PORT A ADDRESS
00BB' 0D              DCR     C
00BC' 0D              DCR     C
00BD' ED78            INP     A      ;CLEAR PORT A INPUT
00BF' 0C              INR     C      ;CALC CONTROL PORT ADDRESS
00C0' 0C              INR     C
00C1' 0C              INR     C
00C2' CD 00EB'        CALL   ..DLY  ;DELAY
00C5' 3E02            MVI     A,RESPC1 ;RESET PC1 (RESET)
00C7' ED79            OUTP   A      ;RELEASE RESET
00C9' CD 00EB'        CALL   ..DLY  ;DELAY
00CC' 0D              DCR     C      ;CALC PORT C ADDRESS
00CD' 21 0000:0B     LXI    H,LAD740# ;GET LOAD ADDRESS/LENGTH
00D0' 0604            MVI     B,4    ;GET LENGTH OF LOAD ADDRESS/LENGT
00D2' CD 0126'        CALL   SND740 ;SEND LOAD ADDRESS/LENGTH
00D5' D8              RC     D      ;IF ERROR, DONE
00D6' ED5B 0000:0C   LDED   LEN740# ;GET LOAD LENGTH
00DA' 43              MOV     B,E    ;LSB OF LOAD LENGTH TO B-REG
00DB' 7B              MOV     A,E    ;GET LSB OF LOAD LENGTH
00DC' B7              ORA     A      ;LSB OF LOAD LENGTH=0?
00DD' 2001            JRNZ   ..LDL  ;IF NOT, CONTINUE
00DF' 15              DCR     D      ;ELSE, DECREMENT MSB OF LOAD LENG
00E0' D5              PUSH   D      ;SAVE LOAD LENGTH
00E1' CD 0126'        CALL   SND740 ;SEND UP TO 256 BYTES OF BOOT COD
00E4' D1              POP    D      ;RESTORE LOAD LENGTH
  ..LDL:             CALL

```

CD740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

00E5' D8          RC      ;IF ERROR, DONE
00E6' 15          DCR    ;ELSE, DECREMENT LSB OF LOAD LENGTH
00E7' F2 00E0'    JP     ..LDL   ;IF MORE TO SEND, CONTINUE
00EA' C9          RET    ;ELSE, DONE
00EB' 0600        ..DLY: MVI    B,0    ;INITIALIZE DELAY COUNT
00ED' 10FE        ..DLYL: DJNZ   ..DLYL ;DELAY
00EF' C9          RET    ;DONE

00F0' 0000        ;POL740: .WORD 0      ;SUCCESSOR LINK POINTER
00F2' 0000        .WORD 0      ;PREDECESSOR LINK POINTER
;
00F4' 3A 0000"    LDA    NMB740 ;GET NUMBER OF IMS 740 PROCESSORS
00F7' B7          ORA    A      ;NUMBER OF IMS 740 PROCESSORS=0?
00F8' C8          RZ     ;IF SO, DONE
00F9' 3D          DCR    A      ;DECREMENT NUMBER OF PROCESSORS
00FA' E60F        ANI    OFH   ;LIMIT NUMBER OF PROCESSORS TO 16
00FC' 21 0023"    LXI    H,CURSLV ;GET CURRENT SLAVE NUMBER
00FF' 34          INR    M      ;INCREMENT CURRENT SLAVE NUMBER
0100' BE          CMP    M      ;VALID SLAVE PROCESSOR NUMBER?
0101' 3002        JRNC   ..VSPN ;IF SO, CONTINUE
0103' 3600        MVI    M,0    ;ELSE, SET SLAVE PROCESSOR NUMBER=
0105' CD 0170'    ..VSPN: CALL   RMCOM ;DO COMMON SETUP
0108' C0          RNZ    ;IF REQUEST IN PROGRESS SET, DONE
0109' ED78        INP    A      ;ELSE, GET SLAVE PROCESSOR STATUS
010B' CB6F        BIT    IBF,A ;INPUT BUFFER FULL SET?
010D' 2804        JRZ    ..CTC  ;IF NOT, CONTINUE
010F' CBC6        SET    0,M   ;ELSE, SET REQUEST IN PROGRESS FLAG
0111' 1807        JMPR   ..SIG  ;CONTINUE
0113' CD 0182'    ..CTC: CALL   GETCTC ;GET CURRENT TICK COUNT
0116' 96          SUB    M      ;CALC ELAPSED NUMBER OF TICKS
0117' FE3C        CPI    60    ;MINIMUM NUMBER OF TICKS ELAPSED?
0119' D8          RC     ;IF NOT, DONE
011A' 21 00F0'    ..SIG:  LXI    H,POL740 ;ELSE, GET IMS 740 POLL ROUTINE
011D' CD 0000:0D  CALL   UNLINK# ;UNLINK POLL ROUTINE FROM POLL LIST
0120' 21 0025"    LXI    H,RCVSPH ;GET RECEIVE MESSAGE SEMAPHORE
0123' C3 0000:0E  JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
0126' 7E          ;SND740: MOV    A,M   ;GET BYTE FROM BUFFER
0127' 23          INX    H     ;OUTPUT BYTE
0128' CD 0151'    CALL   OUTBYT ;IF TIME-OUT, DONE
012B' D8          RC     SND740 ;ELSE, CONTINUE
012C' 10F8        DJNZ   SND740 ;SET RETURN CODE=0
012E' AF          XRA    A     ;DONE
012F' C9          RET    ;DONE

0130' CD 013A'    ;RCV740: CALL   INBYT ;INPUT BYTE
0133' D8          RC     ;IF TIME-OUT, DONE
0134' 77          MOV    M,A   ;ELSE, STORE BYTE IN BUFFER
0135' 23          INX    H     ;CONTINUE
0136' 10F8        DJNZ   RCV740 ;SET RETURN CODE=0
0138' AF          XRA    A     ;DONE
0139' C9          RET    ;INITIALIZE TIME OUT COUNTER
013A' 1E00        ;INBYT: MVI    E,0    ;INITIALIZE TIME OUT COUNTER

```

MCD740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

013C' ED50      ..WTL: INP    D      ;GET SLAVE PROCESSOR STATUS
013E' CB6A      BIT    IBF,D   ;INPUT BUFFER FULL SET?
0140' 2007      JRNZ   ..IBF   ;IF SO, CONTINUE
0142' 1D         DCR    E      ;ELSE, DECREMENT TIME OUT COUNT
0143' 20F7      JRNZ   ..WTL   ;CONTINUE
0145' 3EFF      MVI    A,OFFH ;SET RETURN CODE=OFFH
0147' 37         STC    ;SET CARRY FLAG
0148' C9         RET    ;DONE
0149' 0D         . .IBF: DCR    C      ;CALC PORT A ADDRESS
014A' 0D         DCR    C
014B' ED78      INP    A      ;INPUT BYTE FROM PORT A
014D' 0C         INR    C      ;CALC PORT C ADDRESS
014E' 0C         INR    C
014F' B7         ORA    A      ;CLEAR CARRY FLAG
0150' C9         RET    ;DONE

;          ;OUTBYT: MVI    E,0    ;INITIALIZE TIME OUT COUNTER
0151' 1E00      ..WTL: INP    D      ;GET SLAVE PROCESSOR STATUS
0153' ED50      BIT    OBFN,D  ;OUTPUT BUFFER FULL (NOT) SET?
0155' CB7A      JRNZ   ..NOBF  ;IF SO, CONTINUE
0157' 2007      DCR    E      ;ELSE, DECREMENT TIME OUT COUNT
0159' 1D         JRNZ   ..WTL   ;CONTINUE
015A' 20F7      MVI    A,OFFH ;SET RETURN CODE=OFFH
015C' 3EFF      STC    ;SET CARRY FLAG
015E' 37         RET    ;DONE
015F' C9         . .NOBF: DCR    C      ;CALC PORT A ADDRESS
0160' 0D         DCR    C
0161' 0D         OUTP   A      ;OUTPUT BYTE TO PORT A
0162' ED79      INR    C      ;CALC PORT C ADDRESS
0164' 0C         INR    C
0165' 0C         INR    C
0166' B7         ORA    A      ;CLEAR CARRY FLAG
0167' C9         RET    ;DONE

;          ;SETTC: CALL   SMCOM ;GET TICK COUNT ADDRESS
0168' CD 0174'   CALL   GETCTC ;GET CURRENT TICK COUNT
016B' CD 0182'   MOV    M,A    ;SET TICK COUNT
016E' 77         RET    ;DONE

;          ;RMCOM: LDED  CURSLV ;GET CURRENT SLAVE PROCESSOR NUMB
0170' ED5B 0023" SMCOM: LXI    H,PAT740 ;GET IMS 740 PORT ADDRESS TABLE
;          ;SMCOM: DAD    D      ;CALC IMS 740 PORT ADDRESS
0174' 21 0002"   MOV    C,M    ;DATA PORT ADDRESS TO C-REG
0177' 19         INR    C      ;CALC PORT C ADDRESS
0178' 4E         INR    C
0179' 0C         INR    C
017A' 0C         INR    C
017B' 21 002B"   LXI    H,POLCNT ;GET POLL ROUTINE TICK COUNTS
017E' 19         DAD    D      ;INDEX INTO TICK COUNTS
017F' CB46      BIT    O,M    ;REQUEST IN PROGRESS FLAG SET?
0181' C9         RET    ;DONE

;          ;GETCTC: LDA    TICCNT# ;GET CURRENT TICK COUNT
0182' 3A 0000:0F  ANI    OFEH   ;STRIP BIT 0
0185' E6FE      RET    ;DONE
0187' C9         ;
```

Macro Assembler [C12011-0102]

Page 8

740 - TURBODOS OPERATING SYSTEM MASTER CIRCUIT DRIVER (IMS 740)
RIGHT (C) 1982. SOFTWARE 2000. INC.

.PRGEND

LOD740 - TURBODOS OPERATING SYSTEM INTERMEDIATE BOOTSTAP (IMS 740)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

; ****
;
; * At the start of a download of an IMS 740 slave
; * processor board, the master circuit driver MCD740
; * sends this loader to the slave. It is loaded into
; * slave memory by the slave ROM module SPB740. This
; * loader module handles the remainder of the down-
; * loading task by making standard TurboDOS network
; * download requests to load the full slave operating
; * system from a file OSSLAVE.SYS on the master's
; * disk.
;
; ****
;
; COPYRIGHT (C) 1982. SOFTWARE 2000. INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT LOD740          ;MODULE ID
;
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
0000    PIOVEC = 00H      ;PIO INTERRUPT VECTOR ADDRESS
;
0020    PORTAD = 20H      ;8255 PORT A DATA REGISTER
0024    PIOADR = 24H      ;PIO PORT A DATA REGISTER
0025    PIOBDR = 25H      ;PIO PORT B DATA REGISTER
0026    PIOACR = 26H      ;PIO PORT A CONTROL REGISTER
0027    PIOBCR = 27H      ;PIO PORT B CONTROL REGISTER
;
0004    PORTCO = 4        ;PORT C DATA BIT 0 (INT)
0005    PORTC5 = 5        ;PORT C DATA BIT 5 (IBF)
0006    PORTC7 = 6        ;PORT C DATA BIT 7 (OBF)
0007    RAMPER = 7        ;RAM PARITY ERROR
;
0006    ROMENA = 6        ;ROM ENABLE BIT
0007    PERRES = 7        ;PARITY ERROR RESET
;
0000'          .LOC     .PROG.# ;LOCATE IN PROGRAM AREA
;
0000'    0A00    LAD740::WORD  0AO0H   ;SLAVE PROCESSOR BOOT LOAD ADDRESS
0002'    00CF    LEN740::WORD   SPBLEN  ;SLAVE PROCESSOR BOOT LOAD LENGTH
;
; DEFINE RELOC[ADDR]=[(ADDR-SPB740)+0AO0H] ;RELOCATION MACRO
;
0004'    F3      SPB740: DI          ;DISABLE INTERRUPTS
0005'    31 0900  LXI      SP,900H ;INITIALIZE STACK POINTER
0008'    3E09      MVI      A,09H   ;GET INTERRUPT VECTOR PAGE
000A'    ED47      STAI     IM2      ;SET INTERRUPT PAGE REGISTER
000C'    ED5E

```

740 - TURBODOS OPERATING SYSTEM INTERMEDIATE BOOTSTAP (IMS 740)
 YRIGHT (C) 1982, SOFTWARE 2000, INC.

000E'	21 0A8E	LXI	H, RELOC[PIOISR] ;GET PIO INT SERVICE ADDR
0011'	22 0900	SHLD	0900H ;SET INTERRUPT VECTOR ADDRESS
0014'	3E00	MVI	A, PIOVEC ;GET PIO INTERRUPT SERVICE VECTO
0016'	D326	OUT	PIOACR ;OUTPUT INTERRUPT SERVICE VECTOR
0018'	3ECF	MVI	A, OCFH ;GET PIO A MODE WORD (MODE 3)
001A'	D326	OUT	PIOACR ;OUTPUT PIO A MODE WORD
001C'	3EFF	MVI	A, OFFH ;GET PIO A MODE 3 MODE WORD
001E'	D326	OUT	PIOACR ;OUTPUT PIO A MODE 3 MODE WORD
0020'	3EB7	MVI	A, OB7H ;GET PIO A INTERRUPT CONTROL WORD
0022'	D326	OUT	PIOACR ;OUTPUT INTERRUPT CONTROL WORD
0024'	3EEF	MVI	A, OEFH ;GET PIO A INTERRUPT MASK
0026'	D326	OUT	PIOACR ;OUTPUT INTERRUPT MASK
0028'	3EF0	MVI	A, OFOH ;GET PIO B DATA DATA WORD
002A'	D325	OUT	PIOBDR ;OUTPUT PIO B DATA WORD
002C'	3EOF	MVI	A, OFH ;GET PIO B MODE WORD (MODE 0)
002E'	D327	OUT	PIOBCR ;OUTPUT PIO B MODE WORD
0030'	DB20	IN	PORTAD ;CLEAR INPUT PORT A
0032'	FB	EI	;ENABLE INTERRUPTS
0033'	21 0000	LXI	H, 0 ;INITIALIZE MEMORY PARITY
0036'	11 0000	LXI	D, 0
0039'	01 0000	LXI	B, 0
003C'	EDBO	LDIR	
003E'	3E30	MVI	A, 30H ;GET PIO B DATA BYTE
0040'	D325	OUT	PIOBDR ;RELEASE PARITY ERROR RESET
0042'	3E06	..SPBL:	MVI A, AACK ;GET ACK
0044'	CD 0A86	CALL	RELOC[OUTBYT] ;OUTPUT ACK
0047'	21 0AC3	LXI	H, RELOC[REQMSG] ;GET REQUEST MESSAGE
004A'	46	MOV	B, M ;GET MESSAGE LENGTH
004B'	CD 0A9D	CALL	RELOC[SND740] ;SEND MESSAGE
004E'	21 0ACF	LXI	H, RELOC[REPMMSG] ;GET REPLY MESSAGE BUFFER
0051'	0601	MVI	B, 1 ;GET LENGTH OF MESSAGE LENGTH
0053'	CD 0AA5	CALL	RELOC[RCV740] ;RECEIVE MESSAGE LENGTH
0056'	2B	DCX	H ;BACK UP TO MESSAGE LENGTH
0057'	46	MOV	B, M ;GET MESSAGE LENGTH
0058'	23	INX	H ;RESTORE MESSAGE BUFFER ADDRESS
0059'	05	DCR	B ;DECREMENT MESSAGE LENGTH
005A'	CD 0AA5	CALL	RELOC[RCV740] ;RECEIVE MESSAGE
005D'	3A 0ACF	LDA	RELOC[REPMMSG] ;GET REPLY MESSAGE LENGTH
0060'	FE0C	CPI	MSGHL+1 ;MESSAGE LENGTH=HEADER LENGTH+1?
0062'	2812	JRZ	..EOF ;IF SO, CONTINUE
0064'	21 0ADA	LXI	H, RELOC[REPMMSG+MSGHL] ;GET DATA ADDRESS
0067'	ED5B 0AC1	LDED	RELOC[DMADDR] ;GET DMA ADDRESS
006B'	01 0080	LXI	B, 128 ;GET DATA RECORD LENGTH
006E'	EDBO	LDIR	;MOVE DOWNLOAD RECORD INTO DMA ADD
0070'	ED53 0AC1	SDED	RELOC[DMADDR] ;UPDATE DMA ADDRESS
0074'	18CC	JMPR	..SPBL ;CONTINUE
0076'	2B	DCX	H ;BACK UP TO O/S ID
0077'	7E	MOV	A, M ;GET SYSTEM DISK
0078'	21 0B5A	LXI	H, RELOC[OSLOAD] ;GET SLAVE PROCESSOR O/S
007B'	5E	MOV	E, M ;GET O/S LOAD ADDRESS
007C'	23	INX	H
007D'	56	MOV	D, M
007E'	23	INX	H
007F'	4E	MOV	C, M ;GET SLAVE PROCESSOR O/S LENGTH

LOD740 - TURBODOS OPERATING SYSTEM INTERMEDIATE BOOTSTAP (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0080'	23	INX	H	
0081'	46	MOV	B, M	
0082'	09	DAD	B	; CALC LAST BYTE OF O/S
0083'	EB	XCHG		; O/S LOAD ADDRESS TO HL-REG
0084'	09	DAD	B	; CALC LAST BYTE LOAD ADDRESS
0085'	2B	DCX	H	
0086'	EB	XCHG		; HL=END OF O/S-HL=LAST LOAD ADDRE
0087'	EDB8	LDDR		; MOVE O/S INTO LOAD ADDRESS
0089'	13	INX	D	; ADVANCE TO O/S ENTRYPPOINT
008A'	2A 0AC7	LHLD		RELOC[SID740] ;GET IMS 740 SOURCE ID
008D'	22 0080	SHLD	TBUF	;STORE ID IN DEFAULT BUFFER
0090'	EB	XCHG		;O/S ENTRYPPOINT TO HL-REG
0091'	E9	PCHL		;TRANSFER TO SLAVE PROCESSOR O/S
 ;				
0092'	F5	PIOISR:	PUSH	PSW ;SAVE AF-REG
0093'	DB24		IN	PIOADR ;GET PIO A DATA REGISTER
0095'	CB6F		BIT	PORTC5,A ;PORT C BIT 5 SET? (IBF)
0097'	2004		JRNZ	.X ;IF SO, CONITNUE
0099'	3E15		MVI	A,ANAK ;ELSE, GET NACK
009B'	D320		OUT	PORTAD ;OUTPUT NACK TO PORT A
009D'	F1	..X:	POP	PSW ;RESTORE AF-REG
009E'	FB		EI	;ENABLE INTERRUPTS
009F'	ED4D		RETI	;DONE
 ;				
00A1'	7E	SND740:	MOV	A, M ;GET BYTE FROM MESSAGE
00A2'	23		INX	H
00A3'	CD 0AB6		CALL	RELOC[OUTBYT] ;OUTPUT BYTE
00A6'	10F9		DJNZ	SND740 ;CONTINUE
00A8'	C9		RET	;DONE
 ;				
00A9'	CD 0AAD	RCV740:	CALL	RELOC[INBYT] ;INPUT BYTE
00AC'	77		MOV	M, A ;SAVE BYTE IN MESSAGE
00AD'	23		INX	H
00AE'	10F9		DJNZ	RCV740 ;CONTINUE
00B0'	C9		RET	;DONE
 ;				
00B1'	DB24	INBYT:	IN	PIOADR ;GET PIO A DATA REGISTER
00B3'	CB77		BIT	PORTC7,A ;PORT C BIT 7 SET? (OBF)
00B5'	20FA		JRNZ	INBYT ;IF NOT, WAIT
00B7'	DB20		IN	PORTAD ;INPUT BYTE FROM PORT A
00B9'	C9		RET	;DONE
 ;				
00BA'	4F	OUTBYT:	MOV	C, A ;SAVE OUTPUT BYTE IN C-REG
00BB'	DB24	..WTL:	IN	PIOADR ;GET PIO A DATA REGISTER
00BD'	CB6F		BIT	PORTC5,A ;PORT C BIT 5 SET? (IBF)
00BF'	20FA		JRNZ	.WTL ;IF SO, WAIT
00C1'	79		MOV	A, C ;GET OUTPUT BYTE
00C2'	D320		OUT	PORTAD ;OUTPUT BYTE TO PORT A
00C4'	C9		RET	;DONE
 ;				
00C5'	0B5A	DMADDR:	.WORD	RELOC[OSLOAD] ;DMA ADDRESS
 ;				
00C7'		REQMSG:		; DOWNLOAD REQUEST MESSAGE
00C7'		MSGHDR:		; MESSAGE HEADER

D740 - TURBODOS OPERATING SYSTEM INTERMEDIATE BOOTSTAP (IMS 740)
PYRIGHT (C) 1982. SOFTWARE 2000. INC.

```
00C7' 0C      MSGLEN: .BYTE   MSGHBL ;MESSAGE LENGTH
00C8'          DID740::: ;SLAVE PROCESSOR DESTINATION ID
00C8' 0000    MSGDID: .WORD    0 ;MESSAGE DESTINATION ID
00CA' 00      MSGPID: .BYTE    0 ;MESSAGE PROCESS ID
00CB'          SID740::: ;SLAVE PROCESSOR SOURCE ID
00CB' 0000    MSGSID: .WORD    0 ;MESSAGE SOURCE ID
00CD'          ORG740::: ;SLAVE PROCESSOR ORIGIN
00CD' 000000  MSGORG: .BYTE   [3]0 ;MESSAGE ORIGIN
00D0' 00      MSGLVL: .BYTE   0 ;MESSAGE LEVEL
00D1' 00      MSGFCD: .BYTE   0 ;MESSAGE FORMAT CODE
;
000B          MSGHL = .-MSGHDR ;MESSAGE HEADER LENGTH
;
00D2' 20      SSL740:::.BYTE  ASP ;SLAVE PROCESSOR O/S SUFFIX LETTER
;
000C          MSGHBL = .-MSGHDR ;MESSAGE HEADER/BUFFER LENGTH
;
00CF          SPBLEN = .-SPB740 ;SLAVE PROCESSOR BOOT CODE LENGTH
;
00D3'          REPMMSG: .BLKB   MSGHL+128 ;REPLY MESSAGE BUFFER
;
015E'          OSLOAD = . ;O/S LOAD ADDRESS
;
.END
```

CKTSER - TURBODOS OPERATING SYSTEM CIRCUIT DRIVER (SERIAL ASYNC)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

; **** This is a trivial network circuit driver which
; **** may be used for master-to-master networking over
; **** an ordinary RS232 serial channel. It performs
; **** absolutely no handshaking, error checking, or
; **** error recovery, and consequently is suitable only
; **** for very short links which are considered to be
; **** completely error-free. It could easily be en-
; **** hanced to include such features, however.
;

; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH

; VERSION: EXAMPLE

; IDENT CKTSER          ;MODULE ID
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
;      .LOC   .DATA.# ;LOCATE IN DATA AREA
;
;      CKTSBR:::BYTE    OFH    ;NETWORK BAUD RATE
;      CKTSCH:::BYTE    1      ;NETWORK SERIAL CHANNEL
;
;      .LOC   .INIT.# ;LOCATE IN INITIALIZATION AREA
;
;      CKTIN%::MVI      E,3    ;E = SET BAUD RATE FCN
;      LBCD             CKTSBR ;C = BAUD RATE, B = CHANNEL NUMBER
;      JMP              SERIAL# ;SET SERIAL CHANNEL BAUD RATE
;
;      .LOC   .PROG.# ;LOCATE IN PROGRAM AREA
;
;      CKTDR%::MOV      A,C    ;GET FUNCTION NUMBER
;      ORA               A      ;FUNCTION NUMBER=0?
;      JRZ               RCVMSG ;IF SO, CONTINUE
;      DCR               A      ;FUNCTION NUMBER=1?
;      JRZ               SNDMSG ;IF SO, CONTINUE
;      RET               ,      ;ELSE, DONE
;
;      RCVMSG: XCHG      ,      ;ADDRESS OF BUFFER IN HL-REGISTER:
;      ..L1: MVI         B,3    ;LOOK FOR THREE SYNC CHARACTERS
;      ..L2: CALL        RCVA   ;RECEIVE SYNC BYTE (?)
;      CPI               ASYN   ;SYNC?
;      JRNZ              ..L1   ;NO, RESET COUNT
;      DJNZ              ..L2   ;ELSE, CONTINUE FOR COUNT
;      INX               H      ;ADVANCE PAST BUFFER LINKAGE
;      INX               H
;      INX               H

```

TSER - TURBODOS OPERATING SYSTEM CIRCUIT DRIVER (SERIAL ASYNC)
 PYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

0017' 23           INX   H
0018' CD 0027'     CALL  RCVA ;RECEIVE MESSAGE LENGTH BYTE
001B' 47           MOV   B,A  ;B = ACTUAL MESSAGE LENGTH
001C' 1803          JMPR  ..L4 ;JOIN COMMON
001E' CD 0027'     ..L3:  CALL  RCVA ;RECEIVE MESSAGE BYTE
0021' 77           ..L4:  MOV   M,A  ;STORE IN BUFFER
0022' 23           INX   H    ;INCREMENT BUFFER POINTER
0023' 10F9          DJNZ  ..L3 ;CONTINUE FOR THE COUNT
0025' AF            XRA   A    ;SET RETURN CODE = SUCCESS
0026' C9            RET
;
0027' E5            RCVA: PUSH  H    ;SAVE REGISTERS
0028' C5            PUSH  B
0029' 3A 0001"       LDA   CKTSCH ;B = GET CHANNEL NUMBER
002C' 47           MOV   B,A
002D' 1E01          MVI   E,1  ;E = SERIAL IN FCN
002F' CD 0000:05    CALL  SERIAL# ;INPUT CHARACTER
0032' C1            POP   B    ;RESTORE REGISTERS
0033' E1            POP   H
0034' C9            RET
;
0035' EB            SNDMSG: XCHG  ;ADDRESS OF BUFFER IN HL-REGISTERS
0036' 01 0316        LXI   T    B,3<8!ASYN ;SEND THREE SYNC CHARACTERS FI
T
0039' CD 004C'     ..L1:  CALL  SNDC
003C' 10FB          DJNZ  ..L1
003E' 23           INX   H    ;ADVANCE PAST BUFFER LINKAGE
003F' 23           INX   H
0040' 23           INX   H
0041' 23           INX   H
0042' 46           MOV   B,M  ;B = MESSAGE LENGTH
0043' 4E            ..L2:  MOV   C,M  ;GET NEXT MESSAGE BYTE
0044' 23           INX   H    ;ADVANCE BUFFER POINTER
0045' CD 004C'     CALL  SNDC ;SEND MESSAGE BYTE
0048' 10F9          DJNZ  ..L2 ;CONTINUE FOR THE COUNT
004A' AF            XRA   A    ;SET RETURN CODE = SUCCESS
004B' C9            RET
;
004C' E5            SNDC: PUSH  H    ;SAVE REGISTERS
004D' C5            PUSH  B
004E' 3A 0001"       LDA   CKTSCH ;B = GET CHANNEL NUMBER
0051' 47           MOV   B,A
0052' 1E02          MVI   E,2  ;E = SERIAL OUT FCN
0054' CD 0000:05    CALL  SERIAL# ;OUTPUT CHARACTER
0057' C1            POP   B    ;RESTORE REGISTERS
0058' E1            POP   H
0059' C9            RET
;
.END

```

SPD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

; ****
;
; **** This module handles all serial and parallel I/O
; **** for the IMS 442 I/O board. Serial channels 0 and
; **** 1 are handled directly by this module, and cor-
; **** respond to the two serial ports on the IMS 442
; **** board. Serial channels 2, 3, 4 and 5 are passed
; **** to another module, SER480, and correspond to the
; **** four serial ports on the IMS 480 four-channel
; **** serial board. Thus, six serial channels can be
; **** supported if both boards are installed.
;
; **** Serial input is handled via interrupts and buf-
; **** fered in a separate circular buffer for each chan-
; **** nel. Serial output is handled on a polled basis
; **** and is not buffered.
;
; ****
;
; COPYRIGHT (C) 1982. SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT SPD442          ;MODULE ID
;
; INSERT DREQUATE        ;DRIVER SYMBOLIC EQUIVALENCES
;
0010   IOBASE = 10H          ;SERIAL/PARALLEL I/O PORT BASE
;
0010   SOCTRL  = IOBASE+00H    ;SERIAL 0 CONTROL/STATUS REGISTER
0011   SODATA  = IOBASE+01H    ;SERIAL 0 DATA REGISTER
0012   S1CTRL  = IOBASE+02H    ;SERIAL 1 CONTROL/STATUS REGISTER
0013   S1DATA  = IOBASE+03H    ;SERIAL 1 DATA REGISTER
0014   TIM0    = IOBASE+04H    ;TIMER 0 DATA REGISTER
0015   TIM1    = IOBASE+05H    ;TIMER 1 DATA REGISTER
0016   TIM2    = IOBASE+06H    ;TIMER 2 DATA REGISTER
0017   TIMCTL  = IOBASE+07H    ;TIMER CONTROL REGISTER
0018   SINTE   = IOBASE+08H    ;SERIAL INTERRUPT ENABLE REGISTER
0019   T2RES   = IOBASE+09H    ;TIMER 2 INTERRUPT RESET
001C   PODATA  = IOBASE+0CH    ;PARALLEL 0 DATA REGISTER
001D   P1DATA  = IOBASE+0DH    ;PARALLEL 1 DATA REGISTER
001E   P2DATA  = IOBASE+0EH    ;PARALLEL 2 DATA REGISTER
001F   PPCTL   = IOBASE+0FH    ;PARALLEL PORT CONTROL REGISTER
;
0000   RDA     = 0            ;RECEIVED DATA AVAILABLE BIT
0001   TBE     = 1            ;TRANSMIT BUFFER EMPTY BIT
0007   CTSN    = 7            ;CLEAR TO SEND (NOT) BIT
;
0000   ROMDIS  = 0            ;ROM DISABLE BIT
0001   RTCENA  = 1            ;REAL TIME CLOCK ENABLE BIT

```

P442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
)PYRIGHT (C) 1982. SOFTWARE 2000. INC.

0002	S1TXIE	= 2	;SERIAL 1 TX INTERRUPT ENABLE BIT
0003	S1RXIE	= 3	;SERIAL 1 RX INTERRUPT ENABLE BIT
0004	S1RTSN	= 4	;SERIAL 1 REQ TO SEND (NOT) BIT
0005	S0TXIE	= 5	;SERIAL 0 TX INTERRUPT ENABLE BIT
0006	S0RXIE	= 6	;SERIAL 0 RX INTERRUPT ENABLE BIT
0007	SORTSN	= 7	;SERIAL 0 REQ TO SEND (NOT) BIT
	;		
0036	TOCMD	= 36H	;TIMER 0 COMMAND
0076	T1CMD	= 76H	;TIMER 1 COMMAND
00B6	T2CMD	= 0B6H	;TIMER 2 COMMAND
	;		
0089	PPMODE	= 89H	;PARALLEL PORT MODE WORD
0019	SPMODE	= 19H	;SERIAL PORT MODE WORD ;PARITY INHIBIT/1 STOP BIT/8 BITS
	;		
0000"		.LOC	.DATA.# ;LOCATE IN DATA AREA
	;		
0000" 0040	SOIBSZ:	.WORD 64	;SERIAL 0 INPUT BUFFER SIZE
0002" 0000	SOIBUF:	.WORD 0	;SERIAL 0 INPUT BUFFER ADDRESS
0004" 0000	SOIPTR:	.WORD 0	;SERIAL 0 INPUT POINTER
0006" 0000	SOOPTR:	.WORD 0	;SERIAL 0 OUTPUT POINTER
0008" 0000	SOICNT:	.WORD 0	;SERIAL 0 INPUT COUNT
000A" 00	SOOCHR:	.BYTE 0	;SERIAL 0 OUTPUT CHARACTER
000B" 00	SOBR:	.BYTE 0	;SERIAL 0 BAUD RATE CODE
	;		
000C" 0000	SOISPH:		;SERIAL 0 INPUT SEMAPHORE
000C" 0000		.WORD 0	;SEMAPHORE COUNT
000E" 000E"	..SOIH:	.WORD ..SOIH	;SEMAPHORE P/D HEAD
0010" 000E"		.WORD ..SOIH	
	;		
0012" 0000	SOOSPH:	.WORD 0	;SERIAL 0 OUTPUT SEMAPHORE
0014" 0014"	..SOOH:	.WORD ..SOOH	;SEMAPHORE COUNT
0016" 0014"		.WORD ..SOOH	;SEMAPHORE P/D HEAD
	;		
0018" 0001	SOXSPH:	.WORD 1	;SERIAL 0 OUTPUT SEMAPHORE
001A" 001A"	..SOXH:	.WORD ..SOXH	;SEMAPHORE COUNT
001C" 001A"		.WORD ..SOXH	;SEMAPHORE P/D HEAD
	;		
001E" 0010	S1IBSZ:	.WORD 16	;SERIAL 1 INPUT BUFFER SIZE
0020" 0000	S1IBUF:	.WORD 0	;SERIAL 1 INPUT BUFFER ADDRESS
0022" 0000	S1IPTR:	.WORD 0	;SERIAL 1 INPUT POINTER
0024" 0000	S1OPTR:	.WORD 0	;SERIAL 1 OUTPUT POINTER
0026" 0000	S1ICNT:	.WORD 0	;SERIAL 1 INPUT COUNT
0028" 00	S1OCHR:	.BYTE 0	;SERIAL 1 OUTPUT CHARACTER
0029" 00	S1BR:	.BYTE 0	;SERIAL 1 BAUD RATE CODE
	;		
002A" 0000	S1ISPH:	.WORD 0	;SERIAL 1 INPUT SEMAPHORE
002C" 002C"	..S1IH:	.WORD ..S1IH	;SEMAPHORE COUNT
002E" 002C"		.WORD ..S1IH	;SEMAPHORE P/D HEAD
	;		
	;SERIAL 1 OUTPUT SEMAPHORE		

SPD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0030" 0000      S1OSPH: .WORD   0       ;SEMAPHORE COUNT
0032" 0032"      ..S1OH: .WORD   ..S1OH  ;SEMAPHORE P/D HEAD
0034" 0032"      .WORD     ..S1OH
;
;                                ;SERIAL 1 OUTPUT SEMAPHORE
0036" 0001      S1XSPH: .WORD   1       ;SEMAPHORE COUNT
0038" 0038"      ..S1XH: .WORD   ..S1XH  ;SEMAPHORE P/D HEAD
003A" 0038"      .WORD     ..S1XH
;
003C" 49        INTMSK::BYTE  1<ROMDIS!1<SORXIE!1<S1RXIE ;INTERRUPT MAS
;
0000:04          .LOC      .INIT.# ;LOCATE IN INITIALIZATION AREA
;
0000:04 3E89    SPTNIT::MVI   A,PPMODE ;INITIALIZE 8255
0002:04 D31F    OUT      PPCTL
0004:04 3EFF    MVI      A,OFFH  ;CLEAR PARALLEL PORTS
0006:04 D31C    OUT      PODATA
0008:04 D31D    OUT      P1DATA
000A:04 3E19    MVI      A,SPMODE ;INITIALIZE UARTS
000C:04 D310    OUT      SOCTRL
000E:04 D312    OUT      S1CTRL
0010:04 3EC3    MVI      A,JMP   ;SET UP SERIAL INTERRUPT VECTOR
0012:04 32 0018  STA      3#8
0015:04 21 0131' LXI      H,SERISR
0018:04 22 0019  SHLD     (3#8)+1
001B:04 3A 003C" LDA      INTMSK ;GET INTERRUPT MASK
001E:04 D318    OUT      SINTE   ;ENABLE INTERRUPT MASKS
0020:04 2A 0000" LHLD     SOIBSZ ;GET SERIAL 0 INPUT BUFFER SIZE
0023:04 CD 0000:05 CALL     ALLOC# ;ALLOCATE PACKET FOR SERIAL BUFFER
0026:04 22 0002" SHLD     SOIBUF ;SAVE SERIAL 0 INPUT BUFFER ADDRES
0029:04 22 0004" SHLD     SOIPTR ;SET SERIAL 0 INPUT POINTER
002C:04 22 0006" SHLD     SOOPTR ;SET SERIAL 0 OUTPUT POINTER
002F:04 2A 001E" LHLD     S1IBSZ ;GET SERIAL 1 INPUT BUFFER SIZE
0032:04 CD 0000:05 CALL     ALLOC# ;ALLOCATE PACKET FOR SERIAL BUFFER
0035:04 22 0020" SHLD     S1IBUF ;SAVE SERIAL 1 INPUT BUFFER ADDRES
0038:04 22 0022" SHLD     S1IPTR ;SET SERIAL 1 INPUT POINTER
003B:04 22 0024" SHLD     S1OPTR ;SET SERIAL 1 OUTPUT POINTER
003E:04 C3 0000:06 JMP     NIT480# ;INITIALIZE IMS 480 SERIAL PORTS
;
0000'           .LOC      .PROG.# ;LOCATE IN PROGRAM AREA
;
0000'           SERIAL:::
0000'   7B      COMDRV::MOV   A,E    ;GET FUNCTION NUMBER
0001'   B7      ORA      A      ;FUNCTION NUMBER=0?
0002'   2818    JRZ      SERST  ;IF SO, CONTINUE
0004'   3D      DCR      A      ;FUNCTION NUMBER=1?
0005'   2834    JRZ      SERIN  ;IF SO, CONTINUE
0007'   3D      DCR      A      ;FUNCTION NUMBER=2?
0008'   CA 00A4' JZ       SEROUT ;IF SO, CONTINUE
000B'   3D      DCR      A      ;FUNCTION NUMBER=3?
000C'   CA 0200' JZ       SERSBR ;IF SO, CONTINUE
000F'   3D      DCR      A      ;FUNCTION NUMBER=4?
0010'   CA 0235' JZ       SERRBR ;IF SO, CONTINUE
0013'   3D      DCR      A      ;FUNCTION NUMBER=5?

```

PD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

0014' CA 0246' JZ SERSMC ;IF SO, CONTINUE
0017' 3D DCR A ;FUNCTION NUMBER=6?
0018' CA 026A' JZ SERRMC ;IF SO, CONTINUE
001B' C9 RET ;ELSE, DONE

001C' 78 ;SERST: MOV A,B ;GET CHANNEL NUMBER
001D' FE02 CPI 2 ;CHANNEL NUMBER=0/1?
001F' D2 0000:07 JNC ST480# ;IF NOT, CONTINUE

0022' ED5B 0008" ST442: LDED SOICNT ;GET SERIAL 0 INPUT BUFFER COUNT
0026' 2A 0006" LHLD SOOPTR ;GET SERIAL 0 OUTPUT POINTER
0029' 78 MOV A,B ;GET CHANNEL NUMBER
002A' B7 ORA A ;CHANNEL NUMBER=0
002B' 280/ JRZ ..STC ;IF SO, CONTINUE
002D' ED5B 0026" LDED S1ICNT ;GET SERIAL 1 INPUT BUFFER COUNT
0031' 2A 0024" LHLD S1OPTR ;GET SERIAL 1 OUTPUT POINTER
0034' 7A ..STC: MOV A,D ;SERIAL INPUT BUFFER COUNT=0?
0035' B3 ORA E ;IF SO, DONE
0036' C8 RZ ;ELSE, SET RETURN CODE=OFFH
0037' 3EFF MVI A,OFFH ;GET SERIAL INPUT CHARACTER
0039' 4E MOV C,M ;DONE
003A' C9 RET

003B' 78 ;SERIN: MOV A,B ;GET CHANNEL NUMBER
003C' FE02 CPI 2 ;CHANNEL NUMBER=0/1?
003E' D2 0000:08 JNC IN480# ;IF NOT, CONTINUE
0041' CD 0022' ..SINL: CALL ST442 ;ELSE, GET SERIAL STATUS
0044' B7 ORA A ;CHARACTER AVAILABLE?
0045' 200F JRNZ ..SIN ;IF SO, CONTINUE
0047' 78 MOV A,B ;ELSE, GET CHANNEL NUMBER
0048' 21 000C" LXI H,SOISPH ;GET SERIAL 0 INPUT SEMAPHORE
004B' B7 ORA A ;CHANNEL NUMBER=0?
004C' 2803 JRZ ..INC ;IF SO, CONTINUE
004E' 21 002A" LXI H,S1ISPH ;GET SERIAL 1 INPUT SEMAPHORE
0051' CD 0000:09 ..INC: CALL WAIT# ;WAIT FOR CONSOLE INPUT
0054' 18EB JMPR ..SINL ;CONTINUE
0056' 78 ..SIN: MOV A,B ;GET CHANNEL NUMBER
0057' B7 ORA A ;CHANNEL NUMBER=0?
0058' 2025 JRNZ ..S1I ;IF NOT, CONTINUE
005A' F3 DI ;ELSE, DISABLE INTERRUPTS
005B' 2A 0008" LHLD SOICNT ;GET SERIAL 0 INPUT COUNT
005E' 2B DCX H ;DECREMENT SERIAL 0 INPUT COUNT
005F' 22 0008" SHLD SOICNT ;UPDATE SERIAL 0 INPUT COUNT
0062' 2A 0006" LHLD SOOPTR ;GET SERIAL 0 OUTPUT POINTER
0065' 7E MOV A,M ;GET CHARACTER FROM BUFFER
0066' 23 INX H ;INCREMENT SERIAL 0 OUTPUT POINTER
0067' EB XCHG ;SERIAL 0 OUTPUT POINTER TO DE-REG
0068' 2A 0002" LHLD SOIBUF ;GET SERIAL 0 INPUT BUFFER ADDRESS
006B' ED4B 0000" LBCD SOIBSZ ;GET SERIAL 0 INPUT BUFFER SIZE
006F' 0B DCX B ;DECREMENT INPUT BUFFER SIZE
0070' 09 DAD B ;CALC LAST INPUT BUFFER ADDRESS
0071' ED52 DSBC D ;BUFFER WRAP-AROUND?
0073' 3004 JRNC ..NWA0 ;IF NOT, CONTINUE
0075' ED5B 0002" LDED SOIBUF ;GET SERIAL 0 INPUT BUFFER ADDRESS

```

SPD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0079' ED53 0006" ..NWA0: SDED SOOPTR ;UPDATE SERIAL 0 OUTPUT POINTER
007D' FB EI ;ENABLE INTERRUPTS
007E' C9 RET ;DONE
007F' F3 ..S1I: DI ;DISABLE INTERRUPTS
0080' 2A 0026" LHLD S1ICNT ;GET SERIAL 1 INPUT COUNT
0083' 2B DCX H ;DECREMENT SERIAL 1 INPUT COUNT
0084' 22 0026" SHLD S1ICNT ;UPDATE SERIAL 1 INPUT COUNT
0087' 2A 0024" LHLD S1OPTR ;GET SERIAL 1 OUTPUT POINTER
008A' 7E MOV A,M ;GET CHARACTER FROM BUFFER
008B' 23 INX H ;INCREMENT SERIAL 1 OUTPUT POINTER
008C' EB XCHG ;SERIAL 1 OUTPUT POINTER TO DE-REG
008D' 2A 0020" LHLD S1IBUF ;GET SERIAL 1 INPUT BUFFER ADDRESS
0090' ED4B 001E" LBCD S1IBSZ ;GET SERIAL 1 INPUT BUFFER SIZE
0094' 0B DCX B ;DECREMFNT INPUT BUFFER SIZE
0095' 09 DAD B ;CALC LAST INPUT BUFFER ADDRESS
0096' ED52 DSBC D ;BUFFER WRAP-AROUND?
0098' 3004 JRNC ..NWA1 ;IF NOT, CONTINUE
009A' ED5B 0020" LDED S1IBUF ;GET SERIAL 1 INPUT BUFFER ADDRESS
009E' ED53 0024" ..NWA1: SDED S1OPTR ;UPDATE SERIAL 1 OUTPUT POINTER
00A2' FB EI ;ENABLE INTERRUPTS
00A3' C9 RET ;DONE

; SEROUT: MOV A,B ;GET CHANNEL NUMBER
00A4' 78 CPI 2 ;CHANNEL NUMBER=0/1?
00A5' FE02 JNC OUT480# ;IF NOT, CONTINUE
00A7' D2 0000:0A ORA A ;CHANNEL NUMBER=1?
00AA' B7 JRNZ ..S10 ;IF SO, CONTINUE
00AB' 201E LXI H,SOXSPH ;GET SERIAL 0 OUT SEMAPHORE
00AD' 21 0018" PUSH H ;SAVE SERIAL 0 OUT SEMAPHORE
00B0' E5 CALL WAIT# ;WAIT ON MUTUAL EXCLUSION
00B1' CD 0000:09 CALL H,SOOCHR ;GET SERIAL 0 OUTPUT CHARACTER
00B4' 21 000A" LXI M,C ;SAVE OUTPUT CHARACTER
00B7' 71 MOV D,SOOPOL ;GET SERIAL 0 OUT POLL ROUTINE
00B8' 11 00E9' LXI LNKPOL# ;CREATE POLL ROUTINE
00BB' CD 0000:0B CALL SOOPR ;EXECUTE POLL ROUTINE
00BE' CD 00ED' LXI H,SOOSPH ;GET SERIAL 0 OUT SEMAPHORE
00C1' 21 0012" CALL WAIT# ;DISPATCH IF NECESSARY
00C4' CD 0000:09 POP H ;GET MUTUAL EXCLUSION SEMAPHORE
00C7' E1 JMP SIGNAL# ;SIGNAL PROCESS AS READY
00C8' C3 0000:0C ..S10: LXI H,S1XSPH ;GET MUTUAL EXCLUSION SEMAPHORE
00CB' 21 0036" PUSH H ;SAVE MUTUAL EXCLUSION SEMAPHORE
00CE' E5 CALL WAIT# ;WAIT ON MUTUAL EXCLUSION
00CF' CD 0000:09 LXI H,S1OCHR ;GET SERIAL 1 OUTPUT CHARACTER
00D2' 21 0028" MOV M,C ;SAVE OUTPUT CHARACTER
00D5' 71 LXI D,S1OPOL ;GET SERIAL 1 OUT POLL ROUTINE
00D6' 11 010D' CALL LNKPOL# ;CREATE POLL ROUTINE
00D9' CD 0000:0B CALL S1OPR ;EXECUTE POLL ROUTINE
00DC' CD 0111' LXI H,S10SPH ;GET SERIAL 1 OUT SEMAPHORE
00DF' 21 0030" POP H ;DISPATCH IF NECESSARY
00E2' CD 0000:09 JMP SIGNAL# ;SIGNAL PROCESS AS READY
00E5' E1 WORD 0 ;SERIAL 0 OUTPUT POLL ROUTINE
00E6' C3 0000:0C .WORD 0 ;SUCCESSOR LINK POINTER

00E9' SOOPOL: ;SIGNAL# ;SIGNAL PROCESS AS READY
00E9' 0000

```

PD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

00EB'	0000	.WORD	0	;PREDECESSOR LINK POINTER
		;		
00ED'	DB10	SOOPR:	IN	SOCtrl ;GET SERIAL 0 STATUS
00EF'	CB4F		BIT	TBE,A ;TRANSMIT BUFFER EMPTY?
00F1'	C8		RZ	;IF NOT, DONE
00F2'	21 000B"		LXI	H,SOBR ;ELSE, GET SERIAL 0 BAUD RATE CODE
00F5'	CB76		BIT	6,M ;CTS HANDSHAKING REQUESTED?
00F7'	2803		JRZ	..NCTS ;IF NOT, CONTINUE
00F9'	CB7F		BIT	CTSN,A ;CHECK CLEAR TO SEND (NOT) STATUS
00FB'	CO		RNZ	;IF CLEAR TO SEND FALSE, DONE
00FC'	3A 000A"	..NCTS:	LDA	SOOCHR ;GET SERIAL 0 OUTPUT CHARACTER
00FF'	D311		OUT	SODATA ;OUTPUT CHARACTER
0101'	21 00E9'		LXI	H,SOOPOL ;GET SERIAL 0 OUT POLL ROUTINE
0104'	CD 0000:0D		CALL	UNLINK# ;UNLINK POLL ROUTINE
0107'	21 0012"		LXI	H,SOOSPH ;GET SERIAL 0 OUT SEMAPHORE
010A'	C3 0000:0C		JMP	SIGNAL# ;SIGNAL PROCESS AS READY
		;		
010D'		S1OPOL:		;SERIAL 1 OUTPUT POLL ROUTINE
010D'	0000		.WORD	0 ;SUCCESSOR LINK POINTER
010F'	0000		.WORD	0 ;PREDECESSOR LINK POINTER
		;		
0111'	DB12	S1OPR:	IN	S1CTRL ;GET SERIAL 1 STATUS
0113'	CB4F		BIT	TBE,A ;TRANSMIT BUFFER EMPTY?
0115'	C8		RZ	;IF NOT, DONE
0116'	21 0029"		LXI	H,S1BR ;ELSE, GET SERIAL 1 BAUD RATE CODE
0119'	CB76		BIT	6,M ;CTS HANDSHAKING REQUESTED?
011B'	2803		JRZ	..NCTS ;IF NOT, CONTINUE
011D'	CB7F		BIT	CTSN,A ;CHECK CLEAR TO SEND (NOT) STATUS
011F'	CO		RNZ	;IF CLEAR TO SEND FALSE, DONE
0120'	3A 0028"	..NCTS:	LDA	S1OCHR ;GET SERIAL 1 OUTPUT CHARACTER
0123'	D313		OUT	S1DATA ;OUTPUT CHARACTER
0125'	21 010D'		LXI	H,S1OPOL ;GET SERIAL 1 OUT POLL ROUTINE
0128'	CD 0000:0D		CALL	UNLINK# ;UNLINK POLL ROUTINE
012B'	21 0030"		LXI	H,S1OSPH ;GET SERIAL 1 OUT SEMAPHORE
012E'	C3 0000:0C		JMP	SIGNAL# ;SIGNAL PROCESS AS READY
		;		
0131'	ED73 0000:0E	SERISR:	SSPD	INTSP# ;SAVE STACK POINTER
0135'	31 0000:0F		LXI	SP,INTSTK# ;SET UP AUX STACK POINTER
0138'	F5		PUSH	PSW ;SAVE REGISTERS
0139'	C5		PUSH	B
013A'	D5		PUSH	D
013B'	E5		PUSH	H
013C'	CD 0150'		CALL	..SOI ;CHECK FOR SERIAL 0 INPUT
013F'	CD 01A6'		CALL	..S1I ;CHECK FOR SERIAL 1 INPUT
0142'	CD 0000:10		CALL	ISR480# ;CHECK FOR IMS 480 INPUT
0145'	E1		POP	H ;RESTORE REGISTERS
0146'	D1		POP	D
0147'	C1		POP	B
0148'	F1		POP	PSW
0149'	ED7B 0000:0E		LSPD	INTSP# ;RESTORE STACK POINTER
014D'	C3 0000:11		JMP	ISRxit# ;CONTINUE
0150'	DB10	..SOI:	IN	SOCtrl ;GET SERIAL 0 STATUS
0152'	CB47		BIT	RDA,A ;CHARACTER AVAILABLE
0154'	C8		RZ	;IF NOT, DONE

SPD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

0155'	DB11	IN	SODATA	;ELSE, GET SERIAL 0 DATA CHARACTE	
0157'	21 000B"	LXI	H,SOBR	;GET SERIAL 0 BAUD RATE CODE	
015A'	CB6E	BIT	5,M	;INHIBIT INPUT FLAG SET?	
015C'	CO	RNZ		;IF SO, DONE	
015D'	4F	MOV	C,A	;SERIAL 0 DATA CHARACTER TO C-REG	
015E'	CB7E	BIT	7,M	;ATTENTION DETECTION FLAG SET?	
0160'	2814	JRZ	.NADO	;IF NOT, CONTINUE	
0162'	CBB9	RES	7,C	;STRIP SIGN BIT ON INPUT CHARACTE	
0164'	3A 0000:12	LDA	ATNCHR#	;GET ATTENTION CHARACTER	
0167'	B9	CMP	C	;CHARACTER=ATTENTION CHARACTER?	
0168'	200C	JRNZ	.NADO	;IF NOT, CONTINUE	
016A'	2A 0004"	LHLD	SOIPTR	;ELSE, GET SERIAL 0 INPUT POINTER	
016D'	22 0006"	SHLD	SOOPTR	;RESET SERIAL 0 OUTPUT POINTER	
0170'	21 0000	LXI	H,O		
0173'	22 0008"	SHLD	SOICNT	;SET SERIAL 0 INPUT COUNT=0	
0176'	2A 0000"	..NADO:	LHLD	SOIBSZ	;GET SERIAL 0 INPUT BUFFER SIZE
0179'	ED5B 0008"	LDED	SOICNT	;GET SERIAL 0 INPUT COUNT	
017D'	13	INX	D	;INCREMENT SERIAL 0 INPUT COUNT	
017E'	B7	ORA	A	;CLEAR CARRY FLAG	
017F'	ED52	DSBC	D	;SERIAL 0 INPUT BUFFER FULL?	
0181'	D8	RC		;IF SO, DONE	
0182'	ED53 0008"	SDED	SOICNT	;ELSE, UPDATE SERIAL 0 INPUT COUN	
0186'	2A 0004"	LHLD	SOIPTR	;GET SERIAL 0 INPUT POINTER	
0189'	71	MOV	M,C	;STORE INPUT CHARACTER IN BUFFER	
018A'	23	INX	H	;INCREMENT INPUT POINTER	
018B'	EB	XCHG		;INPUT BUFFER POINTER TO DE-REG	
018C'	2A 0000"	LHLD	SOIBSZ	;GET SERIAL 0 INPUT BUFFER SIZE	
018F'	2B	DCX	H	;DECREMENT INPUT BUFFER SIZE	
0190'	ED4B 0002"	LBCD	SOIBUF	;GET SERIAL 0 INPUT BUFFER ADDRES	
0194'	09	DAD	B	;CALC LAST INPUT BUFFER ADDRESS	
0195'	ED52	DSBC	D	;BUFFER WRAP-AROUND?	
0197'	3004	JRNC	.NWA0	;IF NOT, CONTINUE	
0199'	ED5B 0002"	LDED	SOIBUF	;GET SERIAL 0 INPUT BUFFER ADDRES	
019D'	ED53 0004"	..NWA0:	SDED	SOIPTR	;UPDATE SERIAL 0 INPUT POINTER
01A1'	21 000C"	LXI	H,SOISPH	;GET SERIAL 0 INPUT SEMAPHORE	
01A4'	1854	JMPR	.X	;CONTINUE	
01A6'	DB12	..S1I:	IN	S1CTRL	;GET SERIAL 1 STATUS
01A8'	CB47	BIT		RDA,A	;CHARACTER AVAILABLE
01AA'	C8	RZ			;IF NOT, DONE
01AB'	DB13	IN	S1DATA	;ELSE, GET SERIAL 1 DATA CHARACTE	
01AD'	21 0029"	LXI	H,S1BR	;GET SERIAL 1 BAUD RATE CODE	
01B0'	CB6E	BIT	5,M	;INHIBIT INPUT FLAG SET?	
01B2'	CO	RNZ		;IF SO, DONE	
01B3'	4F	MOV	C,A	;SERIAL 1 DATA CHARACTER TO C-REG	
01B4'	CB7E	BIT	7,M	;ATTENTION DETECTION FLAG SET?	
01B6'	2814	JRZ	.NAD1	;IF NOT, CONTINUE	
01B8'	CBB9	RES	7,C	;STRIP SIGN BIT ON INPUT CHARACTE	
01BA'	3A 0000:12	LDA	ATNCHR#	;GET ATTENTION CHARACTER	
01BD'	B9	CMP	C	;CHARACTER=ATTENTION CHARACTER?	
01BE'	200C	JRNZ	.NAD1	;IF NOT, CONTINUE	
01C0'	2A 0022"	LHLD	S1IPTR	;ELSE, GET SERIAL 1 INPUT POINTER	
01C3'	22 0024"	SHLD	S1OPTR	;RESET SERIAL 1 OUTPUT POINTER	
01C6'	21 0000	LXI	H,O		
01C9'	22 0026"	SHLD	S1ICNT	;SET SERIAL 1 INPUT COUNT=0	

D442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
)PYRIGHT (C) 1982. SOFTWARE 2000. INC.

01CC'	2A 001E"	..NAD1:	LHLD	S1IBSZ	;GET SERIAL 1 INPUT BUFFER SIZE
01CF'	ED5B 0026"		LDED	S1ICNT	;GET SERIAL 1 INPUT COUNT
01D3'	13		INX	D	;INCREMENT SERIAL 1 INPUT COUNT
01D4'	B7		ORA	A	;CLEAR CARRY FLAG
01D5'	ED52		DSBC	D	;SERIAL 1 INPUT BUFFER FULL?
01D7'	D8		RC		;IF SO, DONE
01D8'	ED53 0026"		SDED	S1ICNT	;ELSE, UPDATE SERIAL 1 INPUT COUNT
01DC'	2A 0022"		LHLD	S1IPTR	;GET SERIAL 1 INPUT POINTER
01DF'	71		MOV	M,C	;STORE INPUT CHARACTER IN BUFFER
01E0'	23		INX	H	;INCREMENT INPUT POINTER
01E1'	EB		XCHG		;INPUT BUFFER POINTER TO DE-REG
01E2'	2A 001E"		LHLD	S1IBSZ	;GET SERIAL 1 INPUT BUFFER SIZE
01E5'	2B		DCX	H	;DECREMENT INPUT BUFFER SIZE
01E6'	ED4B 0020"		LBCD	S1IBUF	;GET SERIAL 1 INPUT BUFFER ADDRESS
01EA'	09		DAD	B	;CALC LAST INPUT BUFFER ADDRESS
01EB'	ED52		DSBC	D	;BUFFER WRAP-AROUND?
01ED'	3004		JRNC	.NWA1	;IF NOT, CONTINUE
01EF'	ED5B 0020"		LDED	S1IBUF	;GET SERIAL 1 INPUT BUFFER ADDRESS
01F3'	ED53 0022"	..NWA1:	SDED	S1IPTR	;UPDATE SERIAL 1 INPUT POINTER
01F7'	21 002A"		LXI	H,S1ISPH	;GET SERIAL 1 INPUT SEMAPHORE
01FA'	7E	..X:	MOV	A,M	;GET SEMAPHORE COUNT
01FB'	B7		ORA	A	;SEMAPHORE COUNT=0?
01FC'	C8		RZ		;IF SO, DONE
01FD'	C3 0000:OC		JMP	SIGNAL#	;ELSE, SIGNAL PROCESS AS READY
<hr/>					
0200'	78	SERSBR:	MOV	A,B	;GET CHANNEL NUMBER
0201'	FE02		CPI	2	;CHANNEL NUMBER=0/1?
0203'	D2 0000:13		JNC	SBR480#	;IF NOT, CONTINUE
0206'	21 000B"		LXI	H,SOBR	;ELSE, GET SERIAL 0 BAUD RATE CODE
0209'	B7		ORA	A	;CHANNEL NUMBER=0?
020A'	2803		JRZ	.COM1	;IF SO, CONTINUE
020C'	21 0029"		LXI	H,S1BR	;ELSE, GET SERIAL 1 BAUD RATE CODE
020F'	71	..COM1:	MOV	M,C	;SAVE BAUD RATE CODE
0210'	CD 0226'		CALL	GETBTW	;GET BAUD RATE TIMER VALUE
0213'	78		MOV	A,B	;GET CHANNEL NUMBER
0214'	B7		ORA	A	;CHANNEL NUMBER=0?
0215'	3E36		MVI	A,TOCMD	;GET TIMER 0 COMMAND
0217'	0E14		MVI	C,TIMO	;GET TIMER 0 DATA REGISTER
0219'	2804		JRZ	.COM2	;IF CHANNEL NUMBER=0, CONTINUE
021B'	3E76		MVI	A,T1CMD	;ELSE, GET TIMER 1 COMMAND
021D'	0E15		MVI	C,TIM1	;GET TIMER 1 DATA REGISTER
021F'	D317	..COM2:	OUT	TIMCTL	;SELECT TIMER
0221'	ED59		OUTP	E	;OUTPUT LSB OF TIMER VALUE
0223'	ED51		OUTP	D	;OUTPUT MSB OF TIMER VALUE
0225'	C9		RET		;DONE
<hr/>					
0226'	79	GETBTW:	MOV	A,C	;GET REQUESTED BAUD RATE CODE
0227'	E60F		ANI	OFH	;EXTRACT RELEVANT BITS
0229'	87		ADD	A	;X2
022A'	5F		MOV	E,A	;TO E-REG
022B'	1600		MVI	D,O	;MAKE IT DOUBLE LENGTH
022D'	21 0000:14		LXI	H,BRTBL#	;GET BAUD RATE TABLE
0230'	19		DAD	D	;INDEX INTO TABLE
0231'	5E		MOV	E,M	;GET TIMER VALUE

SPD442 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL I/O DRIVER (IMS 442)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

0232' 23           INX      H
0233' 56           MOV      D, M
0234' C9           RET      ;DONE

;SERRBR: MOV A,B ;GET CHANNEL NUMBER
0235' 78           CPI      2 ;CHANNEL NUMBER=0/1?
0236' FE02          JNC     RBR480# ;IF NOT, CONTINUE
0238' D2 0000:15    LXI     H,SOBR ;ELSE, GET SERIAL 0 BAUD RATE COD
023B' 21 000B"       ORA     A ;CHANNEL NUMBER=0?
023E' B7           JRZ     ..COM ;IF SO, CONTINUE
023F' 2803          LXI     H,S1BR ;ELSE, GET SERIAL 1 BAUD RATE COD
0241' 21 0029"       ..COM: MOV   A,M ;GET CURRENT BAUD RATE CODE
0244' 7E           RET      ;DONE

;SERSMC: MOV A,B ;GET CHANNEL NUMBER
0246' 78           CPI      2 ;CHANNEL NUMBER=0/1?
0247' FE02          JNC     SMC480# ;IF NOT, CONTINUE
0249' D2 0000:16    ORA     A ;CHANNEL NUMBER=0?
024C' B7           LDA     INTMSK ;GET INT MASK
024D' 3A 003C"       JRNZ    ..CH1 ;IF CHANNEL NUMBER NOT=0, CONTINUE
0250' 200A          RES     SORTSN,A ;CLEAR SERIAL 0 REQ TO SEND (NO'
0252' CBBF          BIT     7,C ;SERIAL 0 REQ TO SEND TO BE ON?
0254' CB79          SET     ..COM ;IF SO, CONTINUE
0256' 200C          JRNZ    SORTSN,A ;ELSE, SET SERIAL 0 RTS (NOT)
0258' CBFF          JMPR   ..COM ;CONTINUE
025A' 1808          CBA7   RES     S1RTSN,A ;CLEAR SERIAL 1 REQ TO SEND (NO'
025C' CB79          BIT     7,C ;SERIAL 1 REQ TO SEND TO BE ON?
0260' 2002          JRNZ    ..COM ;IF SO, CONTINUE
0262' CBE7          SET     S1RTSN,A ;ELSE, SET SERIAL 1 RTS (NOT)
0264' 32 003C"       ..COM: STA   INTMSK ;UPDATE INT MASK
0267' D318          OUT    SINTE ;SET SERIAL 1 REQUEST TO SEND
0269' C9           RET      ;DONE

;SERRMC: MOV A,B ;GET CHANNEL NUMBER
026A' 78           CPI      2 ;CHANNEL NUMBER=0/1?
026B' FE02          JNC     RMC480# ;IF NOT, CONTINUE
026D' D2 0000:17    ORA     A ;CHANNEL NUMBER=0?
0270' B7           IN      S1CTRL ;GET SERIAL 0 STATUS
0271' DB12          JRZ     ..COM ;IF CHANNEL NUMBER=0, CONTINUE
0273' 2802          IN      S1CTRL ;ELSE, GET SERIAL 1 STATUS
0275' DB12          ..COM: ANI   1<CTSN ;EXTRACT CLEAR TO SEND (NOT)
0277' E680          XRI   1<CTSN ;COMPLIMENT IT
0279' EE80          RET      ;DONE

;POOUT:: OUT    PODATA ;OUTPUT BYTE TO PARALLEL 0
027C' D31C          RET      ;DONE

;P1OUT:: OUT    P1DATA ;OUTPUT BYTE TO PARALLEL 1
027F' D31D          RET      ;DONE

;P2IN:: IN     P2DATA ;INPUT BYTE FROM PARALLEL 2
0281' C9           RET      ;DONE

;.END

```

R480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 PYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

; ****
;
; * This module is called by SPD442, and handles the *
; * four serial ports on the IMS 480 four-port serial *
; * board. Input is handled on an interrupt-driven *
; * basis and buffered via a circular buffer. Output *
; * is handled on a polled basis and not buffered. *
;
; ****
;
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT SER480          ;MODULE ID
;
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
00E0    IOBASE = 0EOH      ;I/O PORT BASE
;
00E0    S2DATA = IOBASE+00H   ;SERIAL 2 DATA REGISTER
00E1    S2IER = IOBASE+01H   ;SERIAL 2 INTERRUPT ENABLE REGISTE
00E2    S2IIDR = IOBASE+02H  ;SERIAL 2 INTERRUPT ID REGISTER
00E3    S2LCR = IOBASE+03H  ;SERIAL 2 LINE CONTROL REGISTER
00E4    S2MCR = IOBASE+04H  ;SERIAL 2 MODEM CONTROL REGISTER
00E5    S2LSR = IOBASE+05H  ;SERIAL 2 LINE STATUS REGISTER
00E6    S2MSR = IOBASE+06H  ;SERIAL 2 MODEM STATUS REGISTER
;
00E8    S3DATA = IOBASE+08H   ;SERIAL 3 DATA REGISTER
00E9    S3IER = IOBASE+09H   ;SERIAL 3 INTERRUPT ENABLE REGISTE
00EA    S3IIDR = IOBASE+0AH  ;SERIAL 3 INTERRUPT ID REGISTER
00EB    S3LCR = IOBASE+0BH  ;SERIAL 3 LINE CONTROL REGISTER
00EC    S3MCR = IOBASE+0CH  ;SERIAL 3 MODEM CONTROL REGISTER
00ED    S3LSR = IOBASE+0DH  ;SERIAL 3 LINE STATUS REGISTER
00EE    S3MSR = IOBASE+0EH  ;SERIAL 3 MODEM STATUS REGISTER
;
00F0    S4DATA = IOBASE+10H   ;SERIAL 4 DATA REGISTER
00F1    S4IER = IOBASE+11H   ;SERIAL 4 INTERRUPT ENABLE REGISTE
00F2    S4IIDR = IOBASE+12H  ;SERIAL 4 INTERRUPT ID REGISTER
00F3    S4LCR = IOBASE+13H  ;SERIAL 4 LINE CONTROL REGISTER
00F4    S4MCR = IOBASE+14H  ;SERIAL 4 MODEM CONTROL REGISTER
00F5    S4LSR = IOBASE+15H  ;SERIAL 4 LINE STATUS REGISTER
00F6    S4MSR = IOBASE+16H  ;SERIAL 4 MODEM STATUS REGISTER
;
00F8    S5DATA = IOBASE+18H   ;SERIAL 5 DATA REGISTER
00F9    S5IER = IOBASE+19H   ;SERIAL 5 INTERRUPT ENABLE REGISTE
00FA    S5IIDR = IOBASE+1AH  ;SERIAL 5 INTERRUPT ID REGISTER
00FB    S5LCR = IOBASE+1BH  ;SERIAL 5 LINE CONTROL REGISTER
00FC    S5MCR = IOBASE+1CH  ;SERIAL 5 MODEM CONTROL REGISTER
;
```

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

00FD	S5LSR	= IOBASE+1DH	;SERIAL 5 LINE STATUS REGISTER
00FE	S5MSR	= IOBASE+1EH	;SERIAL 5 MODEM STATUS REGISTER
	;		
0001	IERCW	= 01H	;INT ENABLE REGISTER CONTROL WORD
0003	LCRCW	= 03H	;LINE CONTROL REGISTER CONTROL WORD
0003	MCRCW	= 03H	;MODEM CONTROL REGISTER CTRL WORD
	;		
0000	RDA	= 0	;RECEIVED DATA AVAILABLE BIT
0005	TBE	= 5	;TRANSMIT BUFFER EMPTY BIT
0004	CTS	= 4	;CLEAR TO SEND BIT
	;		
0000"		.LOC	.DATA.# ;LOCATE IN DATA AREA
	;		
0000" 0010	S2IBSZ::WORD	16	;SERIAL 2 INPUT BUFFER SIZE
0002" 0000	S2IBUF:WORD	0	;SERIAL 2 INPUT BUFFER ADDRESS
0004" 0000	S2IPTR:WORD	0	;SERIAL 2 INPUT POINTER
0006" 0000	S2OPTR:WORD	0	;SERIAL 2 OUTPUT POINTER
0008" 0000	S2ICNT:WORD	0	;SERIAL 2 INPUT COUNT
000A" 00	S2OCHR:.BYTE	0	;SERIAL 2 OUTPUT CHARACTER
000B" 00	S2BR:.BYTE	0	;SERIAL 2 BAUD RATE CODE
	;		
000C"	S2ISPH:		;SERIAL 2 INPUT SEMAPHORE
000C" 0000	.WORD	0	;SEMAPHORE COUNT
000E" 000E"	..S2IH:WORD	..S2IH	;SEMAPHORE P/D HEAD
0010" 000E"	.WORD	..S2IH	
	;		
0012" 0000	S2OSPH:WORD	0	;SERIAL 2 OUTPUT SEMAPHORE
0014" 0014"	..S2OH:WORD	..S2OH	;SEMAPHORE COUNT
0016" 0014"	.WORD	..S2OH	;SEMAPHORE P/D HEAD
	;		
0018" 0001	S2XSPH:WORD	1	;SERIAL 2 OUTPUT SEMAPHORE
001A" 001A"	..S2XH:WORD	..S2XH	;SEMAPHORE COUNT
001C" 001A"	.WORD	..S2XH	;SEMAPHORE P/D HEAD
	;		
001E" 0010	S3IBSZ::WORD	16	;SERIAL 3 INPUT BUFFER SIZE
0020" 0000	S3IBUF:WORD	0	;SERIAL 3 INPUT BUFFER ADDRESS
0022" 0000	S3IPTR:WORD	0	;SERIAL 3 INPUT POINTER
0024" 0000	S3OPTR:WORD	0	;SERIAL 3 OUTPUT POINTER
0026" 0000	S3ICNT:WORD	0	;SERIAL 3 INPUT COUNT
0028" 00	S3OCHR:.BYTE	0	;SERIAL 3 OUTPUT CHARACTER
0029" 00	S3BR:.BYTE	0	;SERIAL 3 BAUD RATE CODE
	;		
002A" 0000	S3ISPH:WORD	0	;SERIAL 3 INPUT SEMAPHORE
002C" 002C"	..S3IH:WORD	..S3IH	;SEMAPHORE COUNT
002E" 002C"	.WORD	..S3IH	;SEMAPHORE P/D HEAD
	;		
0030" 0000	S3OSPH:WORD	0	;SERIAL 3 OUTPUT SEMAPHORE
0032" 0032"	..S3OH:WORD	..S3OH	;SEMAPHORE COUNT
0034" 0032"	.WORD	..S3OH	;SEMAPHORE P/D HEAD
	;		

R480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 PYRIGHT (C) 1982. SOFTWARE 2000. INC.

0036"	0001	S3XSPH:	.WORD	1	;SERIAL 3 OUTPUT SEMAPHORE
0038"	0038"	..S3XH:	.WORD	..S3XH	;SEMAPHORE COUNT
003A"	0038"		.WORD	..S3XH	;SEMAPHORE P/D HEAD
<hr/>					
003C"	0010	S4IBSZ:	.WORD	16	;SERIAL 4 INPUT BUFFER SIZE
003E"	0000	S4IBUF:	.WORD	0	;SERIAL 4 INPUT BUFFER ADDRESS
0040"	0000	S4IPTR:	.WORD	0	;SERIAL 4 INPUT POINTER
0042"	0000	S4OPTR:	.WORD	0	;SERIAL 4 OUTPUT POINTER
0044"	0000	S4ICNT:	.WORD	0	;SERIAL 4 INPUT COUNT
0046"	00	S4OCHR:	.BYTE	0	;SERIAL 4 OUTPUT CHARACTER
0047"	00	S4BR:	.BYTE	0	;SERIAL 4 BAUD RATE CODE
<hr/>					
0048"		S4ISPH:			;SERIAL 4 INPUT SEMAPHORE
0048"	0000		.WORD	0	;SEMAPHORE COUNT
004A"	004A"	..S4IH:	.WORD	..S4IH	;SEMAPHORE P/D HEAD
004C"	004A"		.WORD	..S4IH	<hr/>
<hr/>					
004E"	0000	S4OSPH:	.WORD	0	;SERIAL 4 OUTPUT SEMAPHORE
0050"	0050"	..S4OH:	.WORD	..S4OH	;SEMAPHORE COUNT
0052"	0050"		.WORD	..S4OH	;SEMAPHORE P/D HEAD
<hr/>					
0054"	0001	S4XSPH:	.WORD	1	;SERIAL 4 OUTPUT SEMAPHORE
0056"	0056"	..S4XH:	.WORD	..S4XH	;SEMAPHORE COUNT
0058"	0056"		.WORD	..S4XH	;SEMAPHORE P/D HEAD
<hr/>					
005A"	0010	S5IBSZ:	.WORD	16	;SERIAL 5 INPUT BUFFER SIZE
005C"	0000	S5IBUF:	.WORD	0	;SERIAL 5 INPUT BUFFER ADDRESS
005E"	0000	S5IPTR:	.WORD	0	;SERIAL 5 INPUT POINTER
0060"	0000	S5OPTR:	.WORD	0	;SERIAL 5 OUTPUT POINTER
0062"	0000	S5ICNT:	.WORD	0	;SERIAL 5 INPUT COUNT
0064"	00	S5OCHR:	.BYTE	0	;SERIAL 5 OUTPUT CHARACTER
0065"	00	S5BR:	.BYTE	0	;SERIAL 5 BAUD RATE CODE
<hr/>					
0066"	0000	S5ISPH:	.WORD	0	;SERIAL 5 INPUT SEMAPHORE
0068"	0068"	..S5IH:	.WORD	..S5IH	;SEMAPHORE COUNT
006A"	0068"		.WORD	..S5IH	;SEMAPHORE P/D HEAD
<hr/>					
006C"	0000	S5OSPH:	.WORD	0	;SERIAL 5 OUTPUT SEMAPHORE
006E"	006E"	..S5OH:	.WORD	..S5OH	;SEMAPHORE COUNT
0070"	006E"		.WORD	..S5OH	;SEMAPHORE P/D HEAD
<hr/>					
0072"	0001	S5XSPH:	.WORD	1	;SERIAL 5 OUTPUT SEMAPHORE
0074"	0074"	..S5XH:	.WORD	..S5XH	;SEMAPHORE COUNT
0076"	0074"		.WORD	..S5XH	;SEMAPHORE P/D HEAD
<hr/>					
0000:04		.	LOC	.	INIT.# ;LOCATE IN INITIALIZATION AREA
<hr/>					

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982. SOFTWARE 2000, INC.

0000:04	3E03	NIT480::MVI	A,LCRCW	;GET LINE CONTROL REGISTER VALUE
0002:04	D3E3	OUT	S2LCR	;SET LINE CONTROL REGISTER 0
0004:04	D3EB	OUT	S3LCR	;SET LINE CONTROL REGISTER 1
0006:04	D3F3	OUT	S4LCR	;SET LINE CONTROL REGISTER 2
0008:04	D3FB	OUT	S5LCR	;SET LINE CONTROL REGISTER 3
000A:04	3E03	MVI	A,MCRCW	;GET MODEM CONTROL REGISTER VALU
000C:04	D3E4	OUT	S2MCR	;SET MODEM CONTROL REGISTER 0
000E:04	D3EC	OUT	S3MCR	;SET MODEM CONTROL REGISTER 1
0010:04	D3F4	OUT	S4MCR	;SET MODEM CONTROL REGISTER 2
0012:04	D3FC	OUT	S5MCR	;SET MODEM CONTROL REGISTER 3
0014:04	3E01	MVI	A,IERCW	;GET INT ENABLE REGISTER VALUE
0016:04	D3E1	OUT	S2IER	;SET INT ENABLE REGISTER 0
0018:04	D3E9	OUT	S3IER	;SET INT ENABLE REGISTER 1
001A:04	D3F1	OUT	S4IER	;SET INT ENABLE REGISTER 2
001C:04	D3F9	OUT	S5IER	;SET INT ENABLE REGISTER 3
001E:04	2A 0000"	LHLD	S2IBSZ	;GET SERIAL 2 INPUT BUFFER SIZE
0021:04	CD 0000:05	CALL	ALLOC#	;ALLOCATE PACKET FOR SERIAL BUFF
0024:04	22 0002"	SHLD	S2IBUF	;SAVE SERIAL 2 INPUT BUFFER ADDRE
0027:04	22 0004"	SHLD	S2IPTR	;SET SERIAL 2 INPUT POINTER
002A:04	22 0006"	SHLD	S2OPTR	;SET SERIAL 2 OUTPUT POINTER
002D:04	2A 001E"	LHLD	S3IBSZ	;GET SERIAL 3 INPUT BUFFER SIZE
0030:04	CD 0000:05	CALL	ALLOC#	;ALLOCATE PACKET FOR SERIAL BUFF
0033:04	22 0020"	SHLD	S3IBUF	;SAVE SERIAL 3 INPUT BUFFER ADDRE
0036:04	22 0022"	SHLD	S3IPTR	;SET SERIAL 3 INPUT POINTER
0039:04	22 0024"	SHLD	S3OPTR	;SET SERIAL 3 OUTPUT POINTER
003C:04	2A 003C"	LHLD	S4IBSZ	;GET SERIAL 4 INPUT BUFFER SIZE
003F:04	CD 0000:05	CALL	ALLOC#	;ALLOCATE PACKET FOR SERIAL BUFF
0042:04	22 003E"	SHLD	S4IBUF	;SAVE SERIAL 4 INPUT BUFFER ADDRE
0045:04	22 0040"	SHLD	S4IPTR	;SET SERIAL 4 INPUT POINTER
0048:04	22 0042"	SHLD	S4OPTR	;SET SERIAL 4 OUTPUT POINTER
004B:04	2A 005A"	LHLD	S5IBSZ	;GET SERIAL 5 INPUT BUFFER SIZE
004E:04	CD 0000:05	CALL	ALLOC#	;ALLOCATE PACKET FOR SERIAL BUFF
0051:04	22 005C"	SHLD	S5IBUF	;SAVE SERIAL 5 INPUT BUFFER ADDRE
0054:04	22 005E"	SHLD	S5IPTR	;SET SERIAL 5 INPUT POINTER
0057:04	22 0060"	SHLD	S5OPTR	;SET SERIAL 5 OUTPUT POINTER
005A:04	C9	RET		;DONE
		;	.LOC	.PROG.# ;LOCATE IN PROGRAM AREA
0000'		;		
0000'	78	ST480:: MOV	A,B	;GET CHANNEL NUMBER
0001'	D602	SUI	2	;CHANNEL NUMBER=2?
0003'	2808	JRZ	..ST2	;IF SO, CONTINUE
0005'	3D	DCR	A	;CHANNEL NUMBER=3?
0006'	280E	JRZ	..ST3	;IF SO, CONTINUE
0008'	3D	DCR	A	;CHANNEL NUMBER=4?
0009'	2814	JRZ	..ST4	;IF SO, CONTINUE
000B'	181B	JMPR	..ST5	;CONTINUE
		;		
000D'	ED5B 0008"	..ST2:	LDED	S2ICNT ;GET SERIAL 2 INPUT BUFFER COUNT
0011'	2A 0006"		LHLD	S2OPTR ;GET SERIAL 2 OUTPUT POINTER
0014'	1819		JMPR	..COM ;CONTINUE
0016'	ED5B 0026"	..ST3:	LDED	S3ICNT ;GET SERIAL 3 INPUT BUFFER COUNT
001A'	2A 0024"		LHLD	S3OPTR ;GET SERIAL 3 OUTPUT POINTER
001D'	1810		JMPR	..COM ;CONTINUE

R480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
PYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

001F' ED5B 0044" ..ST4: LDED S4ICNT ;GET SERIAL 4 INPUT BUFFER COUNT
0023' 2A 0042" LHLD S4OPTR ;GET SERIAL 4 OUTPUT POINTER
0026' 1807 JMPR ..COM ;CONTINUE
0028' ED5B 0062" ..ST5: LDED S5ICNT ;GET SERIAL 5 INPUT BUFFER COUNT
002C' 2A 0060" LHLD S5OPTR ;GET SERIAL 5 OUTPUT POINTER
002F' 7A ..COM: MOV A,D
0030' B3 ORA E ;SERIAL INPUT BUFFER COUNT=0?
0031' C8 RZ
0032' 3EFF MVI A,OFFH ;ELSE, SET RETURN CODE=OFFH
0034' 4E MOV C,M ;GET SERIAL INPUT CHARACTER
0035' C9 RET ;DONE

;IN480:: CALL ST480 ;GET SERIAL STATUS
0036' CD 0000' ORA A ;CHARACTER AVAILABLE?
0039' B7 JRNZ ..SIN ;IF SO, CONTINUE
003A' 201C MOV A,B ;ELSE, GET CHANNEL NUMBER
003C' 78 LXI H,S2ISPH ;GET SERIAL 2 INPUT SEMAPHORE
003D' 21 000C" SUI 2 ;CHANNEL NUMBER=2?
0040' D602 JRZ ..INC ;IF SO, CONTINUE
0042' 280F LXI H,S3ISPH ;GET SERIAL 3 INPUT SEMAPHORE
0044' 21 002A" DCR A ;CHANNEL NUMBER=3?
0047' 3D JRZ ..INC ;IF SO, CONTINUE
0048' 2809 LXI H,S4ISPH ;GET SERIAL 4 INPUT SEMAPHORE
004A' 21 0048" DCR A ;CHANNEL NUMBER=4?
004D' 3D JRZ ..INC ;IF SO, CONTINUE
004E' 2803 LXI H,S5ISPH ;GET SERIAL 5 INPUT SEMAPHORE
0050' 21 0066" ;IN480:: CALL ST480 ;GET SERIAL STATUS

0053' CD 0000:06 ..INC: CALL WAIT# ;WAIT FOR INPUT CHARACTER
0056' 18DE JMPR IN480 ;CONTINUE
0058' 78 ..SIN: MOV A,B ;GET CHANNEL NUMBER
0059' D602 SUI 2 ;CHANNEL NUMBER=2?
005B' 2808 JRZ ..IN2 ;IF SO, CONTINUE
005D' 3D DCR A ;CHANNEL NUMBER=3?
005E' 282A JRZ ..IN3 ;IF SO, CONTINUE
0060' 3D DCR A ;CHANNEL NUMBER=4?
0061' 284C JRZ ..IN4 ;IF SO, CONTINUE
0063' 186F JMPR ..IN5 ;ELSE, CONTINUE

;IN2: DI ;DISABLE INTERRUPTS
0065' F3 LHLD S2ICNT ;GET SERIAL 2 INPUT COUNT
0066' 2A 0008" DCX H ;DECREMENT SERIAL 2 INPUT COUNT
0069' 2B SHLD S2ICNT ;UPDATE SERIAL 2 INPUT COUNT
006A' 22 0008" LHLD S2OPTR ;GET SERIAL 2 OUTPUT POINTER
006D' 2A 0006" MOV A,M ;GET CHARACTER FROM BUFFER
0070' 7E INX H ;INCREMENT SERIAL 2 OUTPUT POINTER
0071' 23 XCHG ;SERIAL 2 OUTPUT POINTER TO DE-REG
0072' EB LHLD S2IBUF ;GET SERIAL 2 INPUT BUFFER ADDRESS
0073' 2A 0002" LBCD S2IBSZ ;GET SERIAL 2 INPUT BUFFER SIZE
0076' ED4B 0000" DAD B ;DECREMENT INPUT BUFFER SIZE
007A' 0B DSBC B ;CALC LAST INPUT BUFFER ADDRESS
007B' 09 ..NWA2 D ;BUFFER WRAP-AROUND?
007C' ED52 JRNC ..NWA2 ;IF NOT, CONTINUE
007E' 3004 LDDED S2IBUF ;GET SERIAL 2 INPUT BUFFER ADDRESS
0080' ED5B 0002" SDED S2OPTR ;UPDATE SERIAL 2 OUTPUT POINTER
0084' ED53 0006" ;NWA2: SDED S2OPTR ;UPDATE SERIAL 2 OUTPUT POINTER

```

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

0088'	FB		EI	;ENABLE INTERRUPTS
0089'	C9		RET	;DONE
 ;				
008A'	F3	..IN3:	DI	;DISABLE INTERRUPTS
008B'	2A 0026"		LHLD	S3ICNT ;GET SERIAL 3 INPUT COUNT
008E'	2B		DCX	H ;DECREMENT SERIAL 3 INPUT COUNT
008F'	22 0026"		SHLD	S3ICNT ;UPDATE SERIAL 3 INPUT COUNT
0092'	2A 0024"		LHLD	S3OPTR ;GET SERIAL 3 OUTPUT POINTER
0095'	7E		MOV	A,M ;GET CHARACTER FROM BUFFER
0096'	23		INX	H ;INCREMENT SERIAL 3 OUTPUT POINTE
0097'	EB		XCHG	;SERIAL 3 OUTPUT POINTER TO DE-RE
0098'	2A 0020"		LHLD	S3IBUF ;GET SERIAL 3 INPUT BUFFER ADDRES
009B'	ED4B 001E"		LBCD	S3IBSZ ;GET SERIAL 3 INPUT BUFFER SIZE
009F'	OB		DCX	B ;DECREMENT INPUT BUFFER SIZE
00A0'	09		DAD	B ;CALC LAST INPUT BUFFER ADDRESS
00A1'	ED52		DSBC	D ;BUFFER WRAP-AROUND?
00A3'	3004		JRNC	.NWA3 ;IF NOT, CONTINUE
00A5'	ED5B 0020"		LDED	S3IBUF ;GET SERIAL 3 INPUT BUFFER ADDRES
00A9'	ED53 0024"	.NWA3:	SDED	S3OPTR ;UPDATE SERIAL 3 OUTPUT POINTER
00AD'	FB		EI	;ENABLE INTERRUPTS
00AE'	C9		RET	;DONE
 ;				
00AF'	F3	..IN4:	DI	;DISABLE INTERRUPTS
00B0'	2A 0044"		LHLD	S4ICNT ;GET SERIAL 4 INPUT COUNT
00B3'	2B		DCX	H ;DECREMENT SERIAL 4 INPUT COUNT
00B4'	22 0044"		SHLD	S4ICNT ;UPDATE SERIAL 4 INPUT COUNT
00B7'	2A 0042"		LHLD	S4OPTR ;GET SERIAL 4 OUTPUT POINTER
00BA'	7E		MOV	A,M ;GET CHARACTER FROM BUFFER
00BB'	23		INX	H ;INCREMENT SERIAL 4 OUTPUT POINTE
00BC'	EB		XCHG	;SERIAL 4 OUTPUT POINTER TO DE-RE
00BD'	2A 003E"		LHLD	S4IBUF ;GET SERIAL 4 INPUT BUFFER ADDRES
00C0'	ED4B 003C"		LBCD	S4IBSZ ;GET SERIAL 4 INPUT BUFFER SIZE
00C4'	OB		DCX	B ;DECREMENT INPUT BUFFER SIZE
00C5'	09		DAD	B ;CALC LAST INPUT BUFFER ADDRESS
00C6'	ED52		DSBC	D ;BUFFER WRAP-AROUND?
00C8'	3004		JRNC	.NWA4 ;IF NOT, CONTINUE
00CA'	ED5B 003E"		LDED	S4IBUF ;GET SERIAL 4 INPUT BUFFER ADDRES
00CE'	ED53 0042"	.NWA4:	SDED	S4OPTR ;UPDATE SERIAL 4 OUTPUT POINTER
00D2'	FB		EI	;ENABLE INTERRUPTS
00D3'	C9		RET	;DONE
 ;				
00D4'	F3	..IN5:	DI	;DISABLE INTERRUPTS
00D5'	2A 0062"		LHLD	S5ICNT ;GET SERIAL 5 INPUT COUNT
00D8'	2B		DCX	H ;DECREMENT SERIAL 5 INPUT COUNT
00D9'	22 0062"		SHLD	S5ICNT ;UPDATE SERIAL 5 INPUT COUNT
00DC'	2A 0060"		LHLD	S5OPTR ;GET SERIAL 5 OUTPUT POINTER
00DF'	7E		MOV	A,M ;GET CHARACTER FROM BUFFER
00E0'	23		INX	H ;INCREMENT SERIAL 5 OUTPUT POINTE
00E1'	EB		XCHG	;SERIAL 5 OUTPUT POINTER TO DE-RE
00E2'	2A 005C"		LHLD	S5IBUF ;GET SERIAL 5 INPUT BUFFER ADDRES
00E5'	ED4B 005A"		LBCD	S5IBSZ ;GET SERIAL 5 INPUT BUFFER SIZE
00E9'	OB		DCX	B ;DECREMENT INPUT BUFFER SIZE
00EA'	09		DAD	B ;CALC LAST INPUT BUFFER ADDRESS
00EB'	ED52		DSBC	D ;BUFFER WRAP-AROUND?

R480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 PYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

00ED' 3004          JRNC   ..NWA5 ;IF NOT, CONTINUE
00EF' ED5B 005C"    LDED   S5IBUF ;GET SERIAL 5 INPUT BUFFER ADDRESS
00F3' ED53 0060"    ..NWA5: SDED   S5OPTR ;UPDATE SERIAL 5 OUTPUT POINTER
00F7' FB             EI      ;ENABLE INTERRUPTS
00F8' C9             RET     ;DONE
;
00F9' D602          OUT480::SUI 2       ;CHANNEL NUMBER=2?
00FB' 2808          JRZ    ..OUT2 ;IF SO, CONTINUE
00FD' 3D             DCR    A       ;CHANNEL NUMBER=3?
00FE' 2823          JRZ    ..OUT3 ;IF SO, CONTINUE
0100' 3D             DCR    A       ;CHANNEL NUMBER=4?
0101' 283E          JRZ    ..OUT4 ;IF SO, CONTINUE
0103' 185A          JMPR   ..OUT5 ;ELSE, CONTINUE
;
0105' 21 0018"       ..OUT2: LXI   H,S2XSPH ;GET SERIAL 2 OUT SEMAPHORE
0108' E5             PUSH   H       ;SAVE SERIAL 2 OUT SEMAPHORE
0109' CD 0000:06     CALL   WAIT#  ;WAIT ON MUTUAL EXCLUSION
010C' 21 000A"       LXI   H,S2OCHR ;GET SERIAL 2 OUTPUT CHARACTER
010F' 71             MOV    M,C    ;SAVE OUTPUT CHARACTER
0110' 11 017D'       LXI   D,S2OPOL ;GET SERIAL 2 OUT POLL ROUTINE
0113' CD 0000:07     CALL   LNKPOL# ;CREATE POLL ROUTINE
0116' CD 0181'       CALL   S2OPR  ;EXECUTE POLL ROUTINE
0119' 21 0012"       LXI   H,S2OSPH ;GET SERIAL 2 OUT SEMAPHORE
011C' CD 0000:06     CALL   WAIT#  ;DISPATCH IF NECESSARY
011F' E1             POP    H       ;GET MUTUAL EXCLUSION SEMAPHORE
0120' C3 0000:08     JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
0123' 21 0036"       ..OUT3: LXI   H,S3XSPH ;GET SERIAL 3 OUT SEMAPHORE
0126' E5             PUSH   H       ;SAVE SERIAL 3 OUT SEMAPHORE
0127' CD 0000:06     CALL   WAIT#  ;WAIT ON MUTUAL EXCLUSION
012A' 21 0028"       LXI   H,S3OCHR ;GET SERIAL 3 OUTPUT CHARACTER
012D' 71             MOV    M,C    ;SAVE OUTPUT CHARACTER
012E' 11 01A3'       LXI   D,S3OPOL ;GET SERIAL 3 OUT POLL ROUTINE
0131' CD 0000:07     CALL   LNKPOL# ;CREATE POLL ROUTINE
0134' CD 01A7'       CALL   S3OPR  ;EXECUTE POLL ROUTINE
0137' 21 0030"       LXI   H,S3OSPH ;GET SERIAL 3 OUT SEMAPHORE
013A' CD 0000:06     CALL   WAIT#  ;DISPATCH IF NECESSARY
013D' E1             POP    H       ;GET MUTUAL EXCLUSION SEMAPHORE
013E' C3 0000:08     JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
0141' 21 0054"       ..OUT4: LXI   H,S4XSPH ;GET SERIAL 4 OUT SEMAPHORE
0144' E5             PUSH   H       ;SAVE SERIAL 4 OUT SEMAPHORE
0145' CD 0000:06     CALL   WAIT#  ;WAIT ON MUTUAL EXCLUSION
0148' 21 0046"       LXI   H,S4OCHR ;GET SERIAL 4 OUTPUT CHARACTER
014B' 71             MOV    M,C    ;SAVE OUTPUT CHARACTER
014C' 11 01C9'       LXI   D,S4OPOL ;GET SERIAL 4 OUT POLL ROUTINE
014F' CD 0000:07     CALL   LNKPOL# ;CREATE POLL ROUTINE
0152' CD 01CD'       CALL   S4OPR  ;EXECUTE POLL ROUTINE
0155' 21 004E"       LXI   H,S4OSPH ;GET SERIAL 4 OUT SEMAPHORE
0158' CD 0000:06     CALL   WAIT#  ;DISPATCH IF NECESSARY
015B' E1             POP    H       ;GET MUTUAL EXCLUSION SEMAPHORE
015C' C3 0000:08     JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
015F' 21 0072"       ..OUT5: LXI   H,S5XSPH ;GET SERIAL 5 OUT SEMAPHORE

```

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0162' E5          PUSH    H      ;SAVE SERIAL 5 OUT SEMAPHORE
0163' CD 0000:06 CALL    WAIT#   ;WAIT ON MUTUAL EXCLUSION
0166' 21 0064"    LXI     H,S50CHR ;GET SERIAL 5 OUTPUT CHARACTER
0169' 71          MOV     M,C    ;SAVE OUTPUT CHARACTER
016A' 11 01EF'    LXI     D,S50POL ;GET SERIAL 5 OUT POLL ROUTINE
016D' CD 0000:07 CALL    LNKPOL# ;CREATE POLL ROUTINE
0170' CD 01F3'    CALL    S50PR   ;EXECUTE POLL ROUTINE
0173' 21 006C"    LXI     H,S50SPH ;GET SERIAL 5 OUT SEMAPHORE
0176' CD 0000:06 CALL    WAIT#   ;DISPATCH IF NECESSARY
0179' E1          POP    H      ;GET MUTUAL EXCLUSION SEMAPHORE
017A' C3 0000:08 JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
017D'           S2OPOL:          ;SERIAL 2 OUTPUT POLL ROUTINE
017D' 0000          .WORD   0      ;SUCCESSOR LINK POINTER
017F' 0000          .WORD   0      ;PREDECESSOR LINK POINTER
;
0181' DBE5         S2OPR:  IN     S2LSR   ;GET SERIAL 2 LINE STATUS REGIST
0183' CB6F         BIT    TBE,A   ;TRANSMIT BUFFER EMPTY?
0185' C8          RZ
0186' 21 000B"    LXI     H,S2BR   ;ELSE, GET SERIAL 2 BAUD RATE COD
0189' CB76         BIT    6,M    ;CLEAR TO SEND HANDSHAKING?
018B' 2805         JRZ    ..NCTS  ;IF NOT, CONTINUE
018D' DBE6         IN     S2MSR   ;GET SERIAL 2 MODEM STATUS REGIST
018F' CB67         BIT    CTS,A  ;CLEAR TO SEND STATUS TRUE?
0191' C8          RZ
0192' 3A 000A"    ..NCTS: LDA    S20CHR ;GET SERIAL 2 OUTPUT CHARACTER
0195' D3E0         OUT    S2DATA  ;OUTPUT CHARACTER
0197' 21 017D'    LXI     H,S2OPOL ;GET SERIAL 2 OUT POLL ROUTINE
019A' CD 0000:09 CALL    UNLINK# ;UNLINK POLL ROUTINE
019D' 21 0012"    LXI     H,S20SPH ;GET SERIAL 2 OUT SEMAPHORE
01A0' C3 0000:08 JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
01A3'           S3OPOL:          ;SERIAL 3 OUTPUT POLL ROUTINE
01A3' 0000          .WORD   0      ;SUCCESSOR LINK POINTER
01A5' 0000          .WORD   0      ;PREDECESSOR LINK POINTER
;
01A7' DBED         S3OPR:  IN     S3LSR   ;GET SERIAL 3 LINE STATUS REGIST
01A9' CB6F         BIT    TBE,A   ;TRANSMIT BUFFER EMPTY?
01AB' C8          RZ
01AC' 21 0029"    LXI     H,S3BR   ;ELSE, GET SERIAL 3 BAUD RATE COD
01AF' CB76         BIT    6,M    ;CLEAR TO SEND HANDSHAKING?
01B1' 2805         JRZ    ..NCTS  ;IF NOT, CONTINUE
01B3' DBEE         IN     S3MSR   ;GET SERIAL 3 MODEM STATUS REGIST
01B5' CB67         BIT    CTS,A  ;CLEAR TO SEND STATUS TRUE?
01B7' C8          RZ
01B8' 3A 0028"    ..NCTS: LDA    S30CHR ;GET SERIAL 3 OUTPUT CHARACTER
01BB' D3E8         OUT    S3DATA  ;OUTPUT CHARACTER
01BD' 21 01A3'    LXI     H,S3OPOL ;GET SERIAL 3 OUT POLL ROUTINE
01C0' CD 0000:09 CALL    UNLINK# ;UNLINK POLL ROUTINE
01C3' 21 0030"    LXI     H,S30SPH ;GET SERIAL 3 OUT SEMAPHORE
01C6' C3 0000:08 JMP    SIGNAL# ;SIGNAL PROCESS AS READY
;
01C9'           S4OPOL:          ;SERIAL 4 OUTPUT POLL ROUTINE
01C9' 0000          .WORD   0      ;SUCCESSOR LINK POINTER

```

R480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 PYRIGHT (C) 1982. SOFTWARE 2000, INC.

01CB'	0000	.WORD	0	;PREDECESSOR LINK POINTER
<hr/>				
01CD'	DBF5	S4OPR:	IN	S4LSR ;GET SERIAL 4 LINE STATUS REGISTER
01CF'	CB6F		BIT	TBE,A ;TRANSMIT BUFFER EMPTY?
01D1'	C8		RZ	;IF NOT, DONE
01D2'	21 0047"		LXI	H,S4BR ;ELSE, GET SERIAL 4 BAUD RATE CODE
01D5'	CB76		BIT	6,M ;CLEAR TO SEND HANDSHAKING?
01D7'	2805		JRZ	..NCTS ;IF NOT, CONTINUE
01D9'	DBF6		IN	S4MSR ;GET SERIAL 4 MODEM STATUS REGISTE
01DB'	CB67		BIT	CTS,A ;CLEAR TO SEND STATUS TRUE?
01DD'	C8		RZ	;IF NOT, DONE
01DE'	3A C046"	..NCTS:	LDA	S4OCHR ;GET SERIAL 4 OUTPUT CHARACTER
01E1'	D3F0		OUT	S4DATA ;OUTPUT CHARACTER
01E3'	21 01C9'		LXI	H,S4OPOL ;GET SERIAL 4 OUT POLL ROUTINE
01E6'	CD 0000:09		CALL	UNLINK# ;UNLINK POLL ROUTINE
01E9'	21 004E"		LXI	H,S4OSPH ;GET SERIAL 4 OUT SEMAPHORE
01EC'	C3 0000:08		JMP	SIGNAL# ;SIGNAL PROCESS AS READY
<hr/>				
01EF'	0000	S5OPOL:		;SERIAL 5 OUTPUT POLL ROUTINE
01EF'	0000		.WORD	0 ;SUCCESSOR LINK POINTER
01F1'	0000		.WORD	0 ;PREDECESSOR LINK POINTER
<hr/>				
01F3'	DBFD	S5OPR:	IN	S5LSR ;GET SERIAL 5 LINE STATUS REGISTER
01F5'	CB6F		BIT	TBE,A ;TRANSMIT BUFFER EMPTY?
01F7'	C8		RZ	;IF NOT, DONE
01F8'	21 0065"		LXI	H,S5BR ;ELSE, GET SERIAL 5 BAUD RATE CODE
01FB'	CB76		BIT	6,M ;CLEAR TO SEND HANDSHAKING?
01FD'	2805		JRZ	..NCTS ;IF NOT, CONTINUE
01FF'	DBFE		IN	S5MSR ;GET SERIAL 5 MODEM STATUS REGISTE
0201'	CB67		BIT	CTS,A ;CLEAR TO SEND STATUS TRUE?
0203'	C8		RZ	;IF NOT, DONE
0204'	3A 0064"	..NCTS:	LDA	S5OCHR ;GET SERIAL 5 OUTPUT CHARACTER
0207'	D3F8		OUT	S5DATA ;OUTPUT CHARACTER
0209'	21 01EF'		LXI	H,S5OPOL ;GET SERIAL 5 OUT POLL ROUTINE
020C'	CD 0000:09		CALL	UNLINK# ;UNLINK POLL ROUTINE
020F'	21 006C"		LXI	H,S5OSPH ;GET SERIAL 5 OUT SEMAPHORE
0212'	C3 0000:08		JMP	SIGNAL# ;SIGNAL PROCESS AS READY
<hr/>				
0215'	CD 0222'	ISR480::CALL	..S2I	;CHECK FOR SERIAL 2 INPUT
0218'	CD 0276'		..S3I	;CHECK FOR SERIAL 3 INPUT
021B'	CD 02CA'		..S4I	;CHECK FOR SERIAL 4 INPUT
021E'	CD 0319'		..S5I	;CHECK FOR SERIAL 5 INPUT
0221'	C9		RET	;DONE
<hr/>				
0222'	DBE5	..S2I:	IN	S2LSR ;GET SERIAL 2 STATUS
0224'	CB47		BIT	RDA,A ;CHARACTER AVAILABLE
0226'	C8		RZ	;IF NOT, DONE
0227'	DBE0		IN	S2DATA ;ELSE, GET SERIAL 2 DATA CHARACTER
0229'	21 000B"		LXI	H,S2BR ;GET SERIAL 2 BAUD RATE CODE
022C'	CB6E		BIT	5,M ;INHIBIT INPUT FLAG SET?
022E'	C0		RNZ	;IF SO, DONE
022F'	4F		MOV	C,A ;SERIAL 2 DATA CHARACTER TO C-REG
0230'	CB7E		BIT	-7,M ;ATTENTION DETECTION FLAG SET?
0232'	2814		JRZ	..NAD2 ;IF NOT, CONTINUE

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982. SOFTWARE 2000, INC.

0234'	CBB9	RES	7,C	;STRIP SIGN BIT ON INPUT CHARACTE	
0236'	3A 0000:0A	LDA	ATNCHR#	;GET ATTENTION CHARACTER	
0239'	B9	CMP	C	;CHARACTER=ATTENTION CHARACTER?	
023A'	200C	JRNZ	..NAD2	;IF NOT, CONTINUE	
023C'	2A 0004"	LHLD	S2IPTR	;ELSE, GET SERIAL 2 INPUT POINTER	
023F'	22 0006"	SHLD	S2OPTR	;RESET SERIAL 2 OUTPUT POINTER	
0242'	21 0000	LXI	H,0		
0245'	22 0008"	SHLD	S2ICNT	;SET SERIAL 2 INPUT COUNT=0	
0248'	2A 0000"	..NAD2:	LHLD	S2IBSZ	;GET SERIAL 2 INPUT BUFFER SIZE
024B'	ED5B 0008"	LDED	S2ICNT	;GET SERIAL 2 INPUT COUNT	
024F'	13	INX	D	;INCREMENT SERIAL 2 INPUT COUNT	
0250'	B7	ORA	A	;CLEAR CARRY FLAG	
0251'	ED52	DSBC	D	;SERIAL 2 INPUT BUFFER FULL?	
0253'	DO	RNC		;IF SO, DONE	
0254'	ED53 0008"	SDED	S2ICNT	;ELSE, UPDATE SERIAL 2 INPUT COUN	
0258'	2A 0004"	LHLD	S2IPTR	;GET SERIAL 2 INPUT POINTER	
025B'	71	MOV	M,C	;STORE INPUT CHARACTER IN BUFFER	
025C'	23	INX	H	;INCREMENT INPUT POINTER	
025D'	EB	XCHG		;INPUT BUFFER POINTER TO DE-REG	
025E'	2A 0000"	LHLD	S2IBSZ	;GET SERIAL 2 INPUT BUFFER SIZE	
0261'	2B	DCX	H	;DECREMENT INPUT BUFFER SIZE	
0262'	ED4B 0002"	LBCD	S2IBUF	;GET SERIAL 2 INPUT BUFFER ADDRES	
0266'	09	DAD	B	;CALC LAST INPUT BUFFER ADDRESS	
0267'	ED52	DSBC	D	;BUFFER WRAP-AROUND?	
0269'	3004	JRNC	..NWA2	;IF NOT, CONTINUE	
026B'	ED5B 0002"	LDED	S2IBUF	;GET SERIAL 2 INPUT BUFFER ADDRES	
026F'	ED53 0004"	..NWA2:	SDED	;UPDATE SERIAL 2 INPUT POINTER	
0273'	C3 036D'	JMP	..X	;CONTINUE	
		;			
0276'	DBED	..S3I:	IN	S3LSR ;GET SERIAL 3 STATUS	
0278'	CB47		BIT	RDA,A ;CHARACTER AVAILABLE	
027A'	C8		RZ		
027B'	DBE8		IN	S3DATA ;ELSE, GET SERIAL 3 DATA CHARACTE	
027D'	21 0029"		LXI	H,S3BR ;GET SERIAL 3 BAUD RATE CODE	
0280'	CB6E		BIT	5,M ;INHIBIT INPUT FLAG SET?	
0282'	CO		RNZ		
0283'	4F		MOV	C,A ;SERIAL 3 DATA CHARACTER TO C-REG	
0284'	CB7E		BIT	7,M ;ATTENTION DETECTION FLAG SET?	
0286'	2814		JRZ	..NAD3 ;IF NOT, CONTINUE	
0288'	CBB9		RES	7,C ;STRIP SIGN BIT ON INPUT CHARACTE	
028A'	3A 0000:0A		LDA	ATNCHR# ;GET ATTENTION CHARACTER	
028D'	B9		CMP	C ;CHARACTER=ATTENTION CHARACTER?	
028E'	200C		JRNZ	..NAD3 ;IF NOT, CONTINUE	
0290'	2A 0022"		LHLD	S3IPTR ;ELSE, GET SERIAL 3 INPUT POINTER	
0293'	22 0024"		SHLD	S3OPTR ;RESET SERIAL 3 OUTPUT POINTER	
0296'	21 0000		LXI	H,0	
0299'	22 0026"		SHLD	S3ICNT ;SET SERIAL 3 INPUT COUNT=0	
029C'	2A 001E"	..NAD3:	LHLD	S3IBSZ ;GET SERIAL 3 INPUT BUFFER SIZE	
029F'	ED5B 0026"		LDED	S3ICNT ;GET SERIAL 3 INPUT COUNT	
02A3'	13		INX	D ;INCREMENT SERIAL 3 INPUT COUNT	
02A4'	B7		ORA	A ;CLEAR CARRY FLAG	
02A5'	ED52		DSBC	D ;SERIAL 3 INPUT BUFFER FULL?	
02A7'	DO		RNC	;IF SO, DONE	
02A8'	ED53 0026"		SDED	S3ICNT ;ELSE, UPDATE SERIAL 3 INPUT COUN	

ER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 PYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

02AC' 2A 0022"           LHLD   S3IPTR ;GET SERIAL 3 INPUT POINTER
02AF' 71                 MOV     M,C    ;STORE INPUT CHARACTER IN BUFFER
02B0' 23                 INX     H      ;INCREMENT INPUT POINTER
02B1' EB                 XCHG    ;INPUT BUFFER POINTER TO DE-REG
02B2' 2A 001E"           LHLD   S3IBSZ ;GET SERIAL 3 INPUT BUFFER SIZE
02B5' 2B                 DCX     H      ;DECREMENT INPUT BUFFER SIZE
02B6' ED4B 0020"         LBCD   S3IBUF ;GET SERIAL 3 INPUT BUFFER ADDRESS
02BA' 09                 DAD     B      ;CALC LAST INPUT BUFFER ADDRESS
02BB' ED52                DSBC    D      ;BUFFER WRAP-AROUND?
02BD' 3004               JRNC   ..NWA3 ;IF NOT, CONTINUE
02BF' ED5B 0020"         LDED   S3IBUF ;GET SERIAL 3 INPUT BUFFER ADDRESS
02C3' ED53 0022"         ..NWA3: SDED   S3IPTR ;UPDATE SERIAL 3 INPUT POINTER
02C7' C3 036D'           JMP    ..X    ;CONTINUE

;
02CA' DBF5               ..S4I:  IN     S4LSR  ;GET SERIAL 4 STATUS
02CC' CB47               BIT    RDA,A  ;CHARACTER AVAILABLE
02CE' C8                 RZ    ;IF NOT, DONE
02CF' DBF0               IN     S4DATA ;ELSE, GET SERIAL 4 DATA CHARACTER
02D1' 21 0047"           LXI    H,S4BR ;GET SERIAL 4 BAUD RATE CODE
02D4' CB6E               BIT    5,M    ;INHIBIT INPUT FLAG SET?
02D6' C0                 RNZ    ;IF SO, DONE
02D7' 4F                 MOV    C,A    ;SERIAL 4 DATA CHARACTER TO C-REG
02D8' CB7E               BIT    7,M    ;ATTENTION DETECTION FLAG SET?
02DA' 2814               JRZ    ..NAD4 ;IF NOT, CONTINUE
02DC' CBB9               RES    7,C    ;STRIP SIGN BIT ON INPUT CHARACTER
02DE' 3A 0000:0A          LDA    ATNCHR# ;GET ATTENTION CHARACTER
02E1' B9                 CMP    C      ;CHARACTER=ATTENTION CHARACTER?
02E2' 200C               JRNZ   ..NAD4 ;IF NOT, CONTINUE
02E4' 2A 0040"           LHLD   S4IPTR ;ELSE, GET SERIAL 4 INPUT POINTER
02E7' 22 0042"           SHLD   S4OPTR ;RESET SERIAL 4 OUTPUT POINTER
02EA' 21 0000             LXI    H,0    ;SET SERIAL 4 INPUT COUNT=0
02ED' 22 0044"           SHLD   S4ICNT ;GET SERIAL 4 INPUT BUFFER SIZE
02F0' 2A 003C"           ..NAD4: LHLD   S4IBSZ ;GET SERIAL 4 INPUT COUNT
02F3' ED5B 0044"         LDED   S4ICNT ;INCREMENT SERIAL 4 INPUT COUNT
02F7' 13                 INX    D      ;CLEAR CARRY FLAG
02F8' B7                 ORA    A      ;SERIAL 4 INPUT BUFFER FULL?
02F9' ED52                DSBC    D    ;IF SO, DONE
02FB' D0                 RNC    ;ELSE, UPDATE SERIAL 4 INPUT COUNT
02FC' ED53 0044"          SDED   S4ICNT ;GET SERIAL 4 INPUT POINTER
0300' 2A 0040"           LHLD   S4IPTR ;STORE INPUT CHARACTER IN BUFFER
0303' 71                 MOV    M,C    ;INCREMENT INPUT POINTER
0304' 23                 INX    H      ;DECREMENT INPUT BUFFER SIZE
0305' 2B                 DCX    H      ;GET SERIAL 4 INPUT BUFFER ADDRESS
0306' ED4B 003E"          LBCD   S4IBUF ;CALC LAST INPUT BUFFER ADDRESS
030A' 09                 DAD    B      ;BUFFER WRAP-AROUND?
030B' ED52                DSBC    D    ;IF NOT, CONTINUE
030D' 3004               JRNC   ..NWA4 ;GET SERIAL 4 INPUT BUFFER ADDRESS
030F' ED5B 003E"          LDED   S4IBUF ;UPDATE SERIAL 4 INPUT POINTER
0313' ED53 0040"          ..NWA4: SDED   S4IPTR ;CONTINUE

;
0319' DBFD               ..S5I:  IN     S5LSR  ;GET SERIAL 5 STATUS
031B' CB47               BIT    RDA,A  ;CHARACTER AVAILABLE
031D' C8                 RZ    ;IF NOT, DONE

```

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

031E' DBF8      IN     S5DATA ;ELSE, GET SERIAL 5 DATA CHARACTE
0320' 21 0065" LXI    H,S5BR ;GET SERIAL 5 BAUD RATE CODE
0323' CB6E      BIT    5,M   ;INHIBIT INPUT FLAG SET?
0325' C0        RNZ    C,A   ;IF SO, DONE
0326' 4F        MOV    7,M   ;SERIAL 5 DATA CHARACTER TO C-REG
0327' CB7E      BIT    7,M   ;ATTENTION DETECTION FLAG SET?
0329' 2814      JRZ    ..NAD5 ;IF NOT, CONTINUE
032B' CBB9      RES    7,C   ;STRIP SIGN BIT ON INPUT CHARACTE
032D' 3A 0000:0A LDA    ATNCHR#;GET ATTENTION CHARACTER
0330' B9        CMP    C     ;CHARACTER=ATTENTION CHARACTER?
0331' 200C      JRNZ   ..NAD5 ;IF NOT, CONTINUE
0333' 2A 005E" LHLD   S5IPTR ;ELSE, GET SERIAL 5 INPUT POINTER
0336' 22 0060" SHLD   S5OPTR ;RESET SERIAL 5 OUTPUT POINTER
0339' 21 0000    LXI    H,0   ;
033C' 22 0062" SHLD   S5ICNT ;SET SERIAL 5 INPUT COUNT=0
033F' 2A 005A" ..NAD5: LHLD   S5IBSZ ;GET SERIAL 5 INPUT BUFFER SIZE
0342' ED5B 0062" LDED   S5ICNT ;GET SERIAL 5 INPUT COUNT
0346' 13        INX    D     ;INCREMENT SERIAL 5 INPUT COUNT
0347' B7        ORA    A     ;CLEAR CARRY FLAG
0348' ED52      DSBC   D     ;SERIAL 5 INPUT BUFFER FULL?
034A' DO        RNC    ;IF SO, DONE
034B' ED53 0062" SDED   S5ICNT ;ELSE, UPDATE SERIAL 5 INPUT COUN
034F' 2A 005E" LHLD   S5IPTR ;GET SERIAL 5 INPUT POINTER
0352' 71        MOV    M,C   ;STORE INPUT CHARACTER IN BUFFER
0353' 23        INX    H     ;INCREMENT INPUT POINTER
0354' EB        XCHG   ;INPUT BUFFER POINTER TO DE-REG
0355' 2A 005A" LHLD   S5IBSZ ;GET SERIAL 5 INPUT BUFFER SIZE
0358' 2B        DCX    H     ;DECREMENT INPUT BUFFER SIZE
0359' ED4B 005C" LBCD   S5IBUF ;GET SERIAL 5 INPUT BUFFER ADDRES
035D' 09        DAD    B     ;CALC LAST INPUT BUFFER ADDRESS
035E' ED52      DSBC   D     ;BUFFER WRAP-AROUND?
0360' 3004      JRNC   ..NWA5 ;IF NOT, CONTINUE
0362' ED5B 005C" LDED   S5IBUF ;GET SERIAL 5 INPUT BUFFER ADDRES
0366' ED53 005E" ..NWA5: SDED   S5IPTR ;UPDATE SERIAL 5 INPUT POINTER
036A' 21 0066" LXI    H,S5ISPH ;GET SERIAL 5 INPUT SEMAPHORE
036D' 7E        ;.X:    MOV    A,M   ;GET SEMAPHORE COUNT
036E' B7        ORA    A     ;SEMAPHORE COUNT=0?
036F' C8        RZ    ;IF SO, DONE
0370' C3 0000:08 JMP    SIGNAL# ;ELSE, SIGNAL PROCESS AS READY
0373' CD 0000:0B SBR480::CALL GETBTW# ;GET BAUD RATE TIMER VALUE
0376' 78        MOV    A,B   ;GET CHANNEL NUMBER
0377' D602      SUI    2     ;REMOVE CHANNEL NUMBER BIAS
0379' F5        PUSH   PSW   ;SAVE CHANNEL NUMBER
037A' C5        PUSH   B     ;SAVE BAUD RATE CODE
037B' 87        ADD    A     ;X2
037C' 87        ADD    A     ;X2=X4
037D' 87        ADD    A     ;X2=X8
037E' F6E3      ORI    IOBASE+3 ;CALC LINE CONTROL REGISTER
0380' 4F        MOV    C,A   ;LINE CONTROL REGISTER TO C-REG
0381' 3E83      MVI    A,LCRCW!80H ;GET DIVISOR LATCH ACCESS BI
0383' ED79      OUTP   A     ;SELECT DIVISOR LATCH
0385' OD        DCR    C     ;CALC DATA REGISTER

```

IR480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0386' 0D          DCR    C
0387' 0D          DCR    C
0388' ED59        OUTP   E      ;OUTPUT LSB OF TIMER VALUE
038A' 0C          INR    C      ;CALC DATA REGISTER+1
038B' ED51        OUTP   D      ;OUTPUT MSB OF TIMER VALUE
038D' 0C          INR    C      ;CALC LINE CONTROL REGISTER
038E' 0C          INR    C
038F' 3E03        MVI    A,LCRCW ;GET LINE CONTROL REGISTER VALUE
0391' ED79        OUTP   A      ;DE-SELECT DIVISOR LATCH
0393' C1          POP    B      ;RESTORE BAUD RATE CODE
0394' F1          POP    PSW   ;RESTORE CHANNEL NUMBER
0395' 2808        JRZ    ..SBR2 ;IF CHANNEL NUMBER=2, CONTINUE
0397' 3D          DCR    A      ;CHANNEL NUMBER=3?
0398' 280A        JRZ    ..SBR3 ;IF SO, CONTINUE
039A' 3D          DCR    A      ;CHANNEL NUMBER=4?
039B' 280C        JRZ    ..SBR4 ;IF SO, CONTINUE
039D' 180F        JMPR   ..SBR5 ;ELSE, CONTINUE

039F' 79          ..SBR2: MOV    A,C   ;GET SERIAL 2 BAUD RATE CODE
03A0' 32 000B"     STA    S2BR  ;SET SERIAL 2 BAUD RATE CODE
03A3' C9          RET
;
03A4' 79          ..SBR3: MOV    A,C   ;GET SERIAL 3 BAUD RATE CODE
03A5' 32 0029"     STA    S3BR  ;SET SERIAL 3 BAUD RATE CODE
03A8' C9          RET
;
03A9' 79          ..SBR4: MOV    A,C   ;GET SERIAL 4 BAUD RATE CODE
03AA' 32 0047"     STA    S4BR  ;SET SERIAL 4 BAUD RATE CODE
03AD' C9          RET
;
03AE' 79          ..SBR5: MOV    A,C   ;GET SERIAL 5 BAUD RATE CODE
03AF' 32 0065"     STA    S5BR  ;SET SERIAL 5 BAUD RATE CODE
03B2' C9          RET
;
03B3' D602        RBR480:SUI 2      ;CHANNEL NUMBER=2?
03B5' 2808        JRZ    ..RBR2 ;IF SO, CONTINUE
03B7' 3D          DCR    A      ;CHANNEL NUMBER=3?
03B8' 2809        JRZ    ..RBR3 ;IF SO, CONTINUE
03BA' 3D          DCR    A      ;CHANNEL NUMBER=4?
03BB' 280A        JRZ    ..RBR4 ;IF SO, CONTINUE
03BD' 180C        JMPR   ..RBR5 ;ELSE, CONTINUE

03BF' 3A 000B"     ..RBR2: LDA    S2BR  ;GET SERIAL 2 BAUD RATE CODE
03C2' C9          RET
;
03C3' 3A 0029"     ..RBR3: LDA    S3BR  ;GET SERIAL 3 BAUD RATE CODE
03C6' C9          RET
;
03C7' 3A 0047"     ..RBR4: LDA    S4BR  ;GET SERIAL 4 BAUD RATE CODE
03CA' C9          RET
;
03CB' 3A 0065"     ..RBR5: LDA    S5BR  ;GET SERIAL 5 BAUD RATE CODE
03CE' C9          RET
;
```

SER480 - TURBODOS OPERATING SYSTEM SERIAL DRIVER (IMS 480)
 COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

03CF' 78          SMC480::MOV   A,B      ;GET CHANNEL NUMBER
03D0' D602        SUI    2       ;REMOVE CHANNEL NUMBER BIAS
03D2' 87          ADD    A       ;X2
03D3' 87          ADD    A       ;X2=X4
03D4' 87          ADD    A       ;X2=X8
03D5' F6E4        ORI   IOBASE+4 ;CALC MODEM CONTROL REGISTER
03D7' 4F          MOV    C,A     ;MODEM CONTROL REGISTER TO C-REG
03D8' 79          MOV    A,C     ;GET REQUESTED MODEM CONTROLS
03D9' 0F          RRC
03DA' 0F          RRC
03DB' ED79        OUTP   A       ;OUTPUT MODEM CONTROLS
03DD' C9          RET
;
03DE' 78          RMC480::MOV   A,B      ;GET CHANNEL NUMBER
03DF' D602        SUI    2       ;REMOVE CHANNEL NUMBER BIAS
03E1' 87          ADD    A       ;X2
03E2' 87          ADD    A       ;X2=X4
03E3' 87          ADD    A       ;X2=X8
03E4' F6E6        ORI   IOBASE+6 ;CALC MODEM STATUS REGISTER
03E6' 4F          MOV    C,A     ;MODEM STATUS REGISTER TO C-REG
03E7' ED50        INP    D       ;GET MODEM STATUS REGISTER
03E9' AF          XRA
03EA' CB62        BIT    4,D     ;CLEAR TO SEND BIT SET?
03EC' 2802        JRZ   ..NCTS  ;IF NOT, CONTINUE
03EE' CBFF        SET    7,A     ;ELSE, SET CLEAR TO SEND BIT
03F0' CB6A        ..NCTS: BIT  5,D     ;DATA SET READY BIT SET?
03F2' 2802        JRZ   ..NDSR  ;IF NOT, CONTINUE
03F4' CBF7        SET    6,A     ;ELSE, SET DATA SET READY BIT
03F6' CB7A        ..NDSR: BIT  7,D     ;DATA CARRIER DETECT BIT SET?
03F8' 2802        JRZ   ..NDCCD ;IF NOT, CONTINUE
03FA' CBEF        SET    5,A     ;ELSE, SET DATA CARRIER DETECT BIT1
03FC' CB72        ..NDCCD: BIT 6,D     ;RING INDICATOR BIT SET?
03FE' C8          RZ
03FF' CBE7        SET    4,A     ;IF NOT, DONE
0401' C9          RET
;
.END

```

T442 - TURBODOS OPERATING SYSTEM BAUD RATE TABLE (IMS 442 OPTIONAL OSC)
 COPYRIGHT (C) 1982 BY SOFTWARE 2000. INC.

```

; ****
;
; * This module contains the table of baud-rate divisor values used by the IMS 442 and IMS 480 I/O boards. It is used by the SPD442, SER480, and RTC442 modules.
;
; ****
;
; COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE2
;
; IDENT     BRT442          ;MODULE ID
;
; INSERT    DREQUATE        ;DRIVER SYMBOLIC EQUIVALENCES
;
0600      BR50    = 1536      ;50 BAUD TIMER VALUE
0400      BR75    = 1024      ;75 BAUD TIMER VALUE
02BA      BR110   = 698       ;110 BAUD TIMER VALUE
023B      BR1345  = 571       ;134.5 BAUD TIMER VALUE
0200      BR150   = 512       ;150 BAUD TIMER VALUE
0100      BR300   = 256       ;300 BAUD TIMER VALUE
0080      BR600   = 128       ;600 BAUD TIMER VALUE
0040      BR1200  = 64        ;1200 BAUD TIMER VALUE
002B      BR1800  = 43        ;1800 BAUD TIMER VALUE
0026      BR2000  = 38        ;2000 BAUD TIMER VALUE
0020      BR2400  = 32        ;2400 BAUD TIMER VALUE
0015      BR3600  = 21        ;3600 BAUD TIMER VALUE
0010      BR4800  = 16        ;4800 BAUD TIMER VALUE
000B      BR7200  = 11        ;7200 BAUD TIMER VALUE
0008      BR9600  = 8         ;9600 BAUD TIMER VALUE
0004      BR192K  = 4         ;19200 BAUD TIMER VALUE
;
5000      RTCCNT  =: 20480    ;RTC COUNT (1/60 SECOND TICK)
003C      TICSEC  =: 60       ;RTC TICKS PER SECOND
;
0000'      .LOC    .PROG.# ;LOCATE IN PROGRAM AREA
;
0000'      0600      BRTBL:: .WORD   BR50    ;50 BAUD TIMER VALUE
0002'      0400      .WORD   BR75    ;75 BAUD TIMER VALUE
0004'      02BA      .WORD   BR110   ;110 BAUD TIMER VALUE
0006'      023B      .WORD   BR1345  ;134.5 BAUD TIMER VALUE
0008'      0200      .WORD   BR150   ;150 BAUD TIMER VALUE
000A'      0100      .WORD   BR300   ;300 BAUD TIMER VALUE
000C'      0080      .WORD   BR600   ;600 BAUD TIMER VALUE
000E'      0040      .WORD   BR1200  ;1200 BAUD TIMER VALUE
0010'      002B      .WORD   BR1800  ;1800 BAUD TIMER VALUE
0012'      0026      .WORD   BR2000  ;2000 BAUD TIMER VALUE
0014'      0020      .WORD   BR2400  ;2400 BAUD TIMER VALUE

```

BRT442 - TURBODOS OPERATING SYSTEM BAUD RATE TABLE (IMS 442 OPTIONAL OSC)
COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

0016'	0015	.WORD	BR3600	;3600 BAUD TIMER VALUE
0018'	0010	.WORD	BR4800	;4800 BAUD TIMER VALUE
001A'	000B	.WORD	BR7200	;7200 BAUD TIMER VALUE
001C'	0008	.WORD	BR9600	;9600 BAUD TIMER VALUE
001E'	0004	.WORD	BR192K	;19200 BAUD TIMER VALUE

;END

FC442 - TURBODOS OPERATING SYSTEM IMS REAL TIME CLOCK ROUTINES
COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

```

; **** This is a real-time clock driver, which utilizes
; **** a counter on the IMS 442 I/O board to provide a
; **** periodic "tick" interrupt at 60 hertz.
;

; COPYRIGHT (C) 1982 BY SOFTWARE 2000, INC.

; AUTHORS: RONALD E. RAIKES
; MICHAEL D. BUSCH

; VERSION: EXAMPLE

; IDENT RTC442 ;MODULE ID
; INSERT DREQUATE ;DRIVER SYMBOLIC EQUIVALENCES
; IOBASE = 10H ;SERIAL/PARALLEL I/O PORT BASE
; 0010
; 0016 TIM2 = IOBASE+06H ;TIMER 2 DATA REGISTER
; 0017 TIMCTL = IOBASE+07H ;TIMER CONTROL REGISTER
; 0018 SINTE = IOBASE+08H ;SERIAL INTERRUPT ENABLE REGISTER
; 0019 T2RES = IOBASE+09H ;TIMER 2 INTERRUPT RESET
; 0001
; RTCENA = 1 ;REAL TIME CLOCK ENABLE BIT
; 00B6 T2CMD = 0B6H ;TIMER 2 COMMAND
; 0000" .LOC .DATA.# ;LOCATE IN DATA AREA
; 0000" 00 TICCTR: .BYTE 0 ;TICK COUNTER
; 0000:04 .LOC .INIT.# ;LOCATE IN INITIALIZATION AREA
; 0000:04 3EC3 RTCNIT: :MVI A,JMP ;INIT RTC INTERRUPT VECTOR ADDR
; 0002:04 32 0008 STA 1*8
; 0005:04 21 0000' LXI H, RTCISR
; 0008:04 22 0009 SHLD (1*8)+1
; 000B:04 3EB6 MVI A,T2CMD ;GET TIMER 2 COMMAND
; 000D:04 D317 OUT TIMCTL ;SELECT TIMER 2
; 000F:04 21 0000:05 LXI H, RTCCNT# ;GET RTC COUNTER VALUE
; 0012:04 7D MOV A,L ;GET LSB OF TIMER VALUE
; 0013:04 D316 OUT TIM2 ;OUTPUT IT TO TIMER 2 DATA REGISTE
; 0015:04 7C MOV A,H ;GET MSB OF TIMER VALUE
; 0016:04 D316 OUT TIM2 ;OUTPUT IT TO TIMER 2 DATA REGISTE
; 0018:04 21 0000:06 LXI H, INTMSK# ;GET INTERRUPT MASK
; 001B:04 CBCE SET RTCENA,M ;SET RTC INTERRUPT ENABLE BIT
; 001D:04 3A 0000:06 LDA INTMSK ;GET INTERRUPT MASK
; 0020:04 D318 OUT SINTE ;ENABLE RTC INTERRUPT MASK
; 0022:04 C9 RET ;DONE
;
```

RTC442 - TURBODOS OPERATING SYSTEM IMS REAL TIME CLOCK ROUTINES
 COPYRIGHT (C) 1982 BY SOFTWARE 2000. INC.

0000'		.LOC	.PROG.# ;LOCATE IN PROGRAM AREA
0000'	ED73 0000:07	RTCISR: SSPD	INTSP# ;SAVE STACK POINTER
0004'	31 0000:08	LXI	SP, INTSTK# ;SET UP AUX STACK POINTER
0007'	F5	PUSH	PSW ;SAVE REGISTERS
0008'	C5	PUSH	B
0009'	D5	PUSH	D
000A'	E5	PUSH	H
000B'	D319	OUT	T2RES ;RESET RTC INTERRUPT
000D'	21 0000"	LXI	H,TICCTR ;GET TICK COUNTER
0010'	34	INR	M ;INCREMENT TICK COUNTER
0011'	7E	MOV	A,M ;GET TICK COUNT
0012'	01 0000:09	LXI	B,TICSEC# ;GET NUMBER OF TICKS PER SECONI
0015'	B9	CMP	C ;SECONDS COUNT REACHED?
0016'	3805	JRC	.NSEC ;IF NOT, CONTINUE
0018'	3600	MVI	M,0 ;ELSE, RESET TICK COUNTER
001A'	CD 0000:0A	CALL	RTCSEC# ;SERVICE REAL TIME CLOCK MANAGER
001D'	CD 0000:0B	..NSEC: CALL	DLYTIC# ;SERVICE DISPATCHER DELAY MANAGER
0020'	E1	POP	H ;RESTORE REGISTERS
0021'	D1	POP	D
0022'	C1	POP	B
0023'	F1	POP	PSW
0024'	ED7B 0000:07	LSPD	INTSP# ;RESTORE STACK POINTER
0028'	C3 0000:0C	JMP	ISRxit# ;CONTINUE
		;	
		END	

IT740 - TURBODOS OPERATING SYSTEM HARDWARE INITIALIZATION (IMS 740)
COPYRIGHT (C) 1982, SOFTWARE 2000. INC.

```
;*****  
;  
; * This is the hardware initialization routine for  
; * an IMS 740 slave processor board. It consists  
; * of calls to the initialization entrypoints of  
; * other driver modules.  
;  
;*****  
;  
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.  
;  
; AUTHORS: RONALD E. RAIKES  
; MICHAEL D. BUSCH  
;  
; VERSION: EXAMPLE  
;  
.IDENT NIT740 ;MODULE ID  
;  
.INSERT DREQUATE ;DRIVER SYMBOLIC EQUIVALENCES  
;  
0000:04 ;LOC .INIT.# ;LOCATE IN INITIALIZATION AREA  
;  
0000:04 CD 0000:05 HDWNIT::CALL SPINIT# ;INITIALIZE SERIAL/PARALLEL I/O  
0003:04 C3 0000:06 JMP CKTINA# ;INITIALIZE CIRCUIT DRIVER A  
;  
.END
```

SCD740 - TURBODOS OPERATING SYSTEM SLAVE CIRCUIT DRIVER (IMS 740)
COPYRIGHT (C) 1982. SOFTWARE 2000. INC.

```

; ****
;
; * This is a simple network circuit driver which runs
; * in an IMS 740 slave processor board, and communi-
; * cates with a similar but more complex driver
; * MCD740 running in the master processor.
;
; * The IMS 740 slave communicates with the master
; * processor over the S-100 bus via a byte-parallel
; * transfer, using programmed I/O at both ends. The
; * IMS 740 board appears to the master as an ordinary
; * port-addressed peripheral device. The interface
; * is accomplished using an Intel 8255 PIO (on the
; * master side) connected to a Zilog Z80 PIO (on the
; * slave side). The master can interrupt the 740
; * slave processor to see if it is still healthy, and
; * this driver must service the interrupt and send an
; * acknowledgement to the master.
;
; ****
;
; COPYRIGHT (C) 1982. SOFTWARE 2000. INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT SCD740          ;MODULE ID
;
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
0010  PIOVEC = 10H        ;PIO INTERRUPT VECTOR ADDRESS
;
0020  PORTAD = 20H        ;8255 PORT A DATA REGISTER
0024  PIOADR = 24H        ;PIO PORT A DATA REGISTER
0025  PIOBDR = 25H        ;PIO PORT B DATA REGISTER
0026  PIOACR = 26H        ;PIO PORT A CONTROL REGISTER
0027  PIOBCR = 27H        ;PIO PORT B CONTROL REGISTER
;
0004  PORTCO = 4          ;PORT C DATA BIT 0 (INT)
0005  PORTC5 = 5          ;PORT C DATA BIT 5 (IBF)
0006  PORTC7 = 6          ;PORT C DATA BIT 7 (OBF)
0007  RAMPER = 7          ;RAM PARITY ERROR
;
0006  ROMENA = 6          ;ROM ENABLE BIT
0007  PERRES = 7          ;PARITY ERROR RESET
;
0000"               .LOC    .DATA.# ;LOCATE IN DATA AREA
;
0000"   0000  RCVSPH: .WORD  0      ;RECEIVE MESSAGE SEMAPHORE
0002"   0002" ..RCVH: .WORD    ..RCVH
0004"   0002"             .WORD    ..RCVH

```

CD740 - TURBODOS OPERATING SYSTEM SLAVE CIRCUIT DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;           .LOC    .INIT.# ;LOCATE IN INITIALIZATION AREA
;
0000:04      CKTIN%::LXI H,PIOISR ;GET PIO A INTERRUPT SERVICE ADD
0003:04 21 0041' SHLD  PIOVEC ;SET INTERRUPT VECTOR ADDRESS
0006:04 3E10   MVI   A,PIOVEC ;GET PIO A INTERRUPT VECTOR
0008:04 D326   OUT  PIOACR ;OUTPUT INTERRUPT SERVICE VECTOR
000A:04 3ECF   MVI   A,OCFH ;GET PIO A MODE WORD (MODE 3)
000C:04 D326   OUT  PIOACR ;OUTPUT PIO A MODE WORD
000E:04 3EFF   MVI   A,OFFH ;GET PIO A MODE 3 MODE WORD
0010:04 D326   OUT  PIOACR ;OUTPUT PIO A MODE 3 MODE WORD
0012:04 3EB7   MVI   A,OB7H ;GET PIO A INTERRUPT CONTROL WORD
0014:04 D326   OUT  PIOACR ;OUTPUT INTERRUPT CONTROL WORD
0016:04 3EEF   MVI   A,OEFH ;GET PIO A INTERRUPT MASK
0018:04 D326   OUT  PIOACR ;OUTPUT INTERRUPT MASK
001A:04 3E30   MVI   A,30H  ;GET PIO B DATA DATA WORD
001C:04 D325   OUT  PIOBDR ;OUTPUT PIO B DATA WORD
001E:04 3EOF   MVI   A,OFH  ;GET PIO B MODE WORD (MODE 0)
0020:04 D327   OUT  PIOBCR ;OUTPUT PIO B MODE WORD
0022:04 DB20   IN   PORTAD ;CLEAR INPUT PORT A
0024:04 3A 0000:05 LDA   NMBCKT# ;GET NUMBER OF CIRCUITS
0027:04 47     MOV   B,A   ;NUMBER OF CIRCUITS TO B-REG
0028:04 21 0001:06 LXI   H,CKTAST#+1 ;GET CIRCUIT ASSIGNMENT TABLE
002B:04 3A 0081 LDA   TBUF+1 ;GET MSB OF PASSED DESTINATION ID
002E:04 BE     ..SL:  CMP   M   ;CIRCUIT NUMBERS EQUAL?
002F:04 2807   JRZ   ..DIDF ;IF SO, CONTINUE
0031:04 23     INX   H   ;ELSE, ADVANCE TO NEXT TABLE ENTRY
0032:04 23
0033:04 23
0034:04 23
0035:04 10F7   DJNZ  ..SL  ;CONTINUE
0037:04 C9     RET   ;DONE
0038:04 2B     ..DIDF: DCX   H   ;BACK UP TO LSB OF DESTINATION ID
0039:04 3A 0080 LDA   TBUF  ;GET LSB OF PASSED DESTINATION ID
003C:04 77     MOV   M,A  ;SET LSB OF DESTINATION ID
003D:04 C9     RET   ;DONE
;
0000'          .LOC    .PROG.# ;LOCATE IN PROGRAM AREA
;
0000' 79       CKTDR%::MOV A,C   ;GET FUNCTION NUMBER
0001' B7       ORA   A   ;FUNCTION NUMBER=0?
0002' 2804   JRZ   SLVRCV ;IF SO, CONTINUE
0004' 3D       DCR   A   ;FUNCTION NUMBER=1?
0005' 281C   JRZ   SLVSND ;IF SO, CONTINUE
0007' C9       RET   ;ELSE, DONE
;
0008' 21 0000"  SLVRCV: LXI H,RCVSPH ;GET RECEIVE MESSAGE SEMAPHORE
000B' CD 0000:07 CALL  WAIT# ;WAIT FOR RECEIVE MESSAGE
000E' CD 003B'  CALL  SRMCOM ;DO COMMON SETUP
0011' 0601   MVI   B,1   ;GET LENGTH OF MESSAGE LENGTH
0013' CD 001A'  CALL  ..RCVL ;RECEIVE MESSAGE LENGTH
0016' 2B       DCX   H   ;BACK UP TO MESSAGE LENGTH
0017' 46       MOV   B,M  ;GET MESSAGE LENGTH
0018' 23       INX   H   ;RESTORE MESSAGE BUFFER ADDRESS

```

SCD740 - TURBODOS OPERATING SYSTEM SLAVE CIRCUIT DRIVER (IMS 740)
 COPYRIGHT (C) 1982. SOFTWARE 2000, INC.

```

0019' 05          DCR      B       ;DECREMENT MESSAGE LENGTH
001A' CD 005B'    ..RCVL: CALL    INBYT   ;INPUT BYTE
001D' 77          MOV      M,A     ;SAVE BYTE IN MESSAGE
001E' 23          INX      H
001F' 10F9        DJNZ    ..RCVL   ;CONTINUE
0021' AF          XRA      A       ;SET RETURN CODE=0
0022' C9          RET
;
0023' CD 003B'    SLVSND: CALL    SRMCOM  ;DO COMMON SETUP
0026' 3E06        MVI      A,AACK  ;GET ACK
0028' CD 0064'    CALL    OUTBYT  ;OUTPUT ACK
002B' 46          MOV      B,M     ;GET MESSAGE LENGTH
002C' 7E          ..SNDL: MOV      A,M     ;GET BYTE FROM MESSAGE
002D' 23          INX      H
002E' CD 0064'    CALL    OUTBYT  ;OUTPUT BYTE
0031' 10F9        DJNZ    ..SNDL   ;CONTINUE
0033' 21 0000"    LXI      H,RCVSPH ;GET RECEIVE MESSAGE SEMAPHORE
0036' CD 0000:08  CALL    SIGNAL#  ;SIGNAL RECEIVE MESSAGE
0039' AF          XRA      A       ;SET RETURN CODE=0
003A' C9          RET
;
003B' EB          SRMCOM: XCHG    ;MESSAGE PACKET ADDRESS TO HL-REG
003C' 23          INX      H       ;ADVANCE PAST LINK POINTERS
003D' 23          INX      H
003E' 23          INX      H
003F' 23          INX      H
0040' C9          RET
;
0041' ED73 0000:09 PIOISR: SSPD    INTSP#  ;SAVE STACK POINTER
0045' 31 0000:0A  LXI      SP,INTSTK# ;SET UP AUX STACK POINTER
0048' F5          PUSH    PSW     ;SAVE AF-REG
0049' DB24        IN      PIOADR  ;GET PIO A DATA REGISTER
004B' CB6F        BIT     PORTC5,A ;PORT C BIT 5 SET? (IBF)
004D' 2004        JRNZ    ..X:    .X      ;IF SO, CONTINUE
004F' 3E15        MVI      A,ANAK  ;ELSE, GET NACK
0051' D320        OUT     PORTAD  ;OUTPUT NACK TO PORT A
0053' F1          ..X:    POP     PSW     ;RESTORE AF-REG
0054' ED7B 0000:09 LSPD    INTSP#  ;RESTORE STACK POINTER
0058' FB          EI      ;ENABLE INTERRUPTS
0059' ED4D        RETI
;
005B' DB24        INBYT:  IN      PIOADR  ;GET PIO A DATA REGISTER
005D' CB77        BIT     PORTC7,A ;PORT C BIT 7 SET? (OBF)
005F' 20FA        JRNZ    INBYT   ;IF NOT, WAIT
0061' DB20        IN      PORTAD  ;INPUT BYTE FROM PORT A
0063' C9          RET
;
0064' 4F          OUTBYT: MOV     C,A     ;SAVE OUTPUT BYTE IN C-REG
0065' DB24        ..WTL:  IN      PIOADR  ;GET PIO A DATA REGISTER
0067' CB6F        BIT     PORTC5,A ;PORT C BIT 5 SET? (IBF)
0069' 20FA        JRNZ    ..WTL   ;IF SO, WAIT
006B' 79          MOV     A,C     ;GET OUTPUT BYTE
006C' D320        OUT     PORTAD  ;OUTPUT BYTE TO PORT A
006E' C9          RET
;
```

SA Macro Assembler [C12011-0102]

Page 4

CD740 - TURBODOS OPERATING SYSTEM SLAVE CIRCUIT DRIVER (IMS 740)
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

;
.END

SPD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

; ****
;
; * This module handles all serial and parallel I/O
; * for the IMS 740 slave processor board. The IMS
; * has two serial ports. One is generally used for
; * a console, and the other can be used for a local
; * printer or a modem.
;
; * Serial input is handled via interrupts and buf-
; * fered in a separate circular buffer for each chan-
; * nel. Serial output is handled on a polled basis
; * and is not buffered.
;
; ****
;
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT SPD740          ;MODULE ID
;
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;
0010  PIOVEC = 10H          ;PIO INTERRUPT VECTOR ADDRESS
0012  SIOVEC = 12H          ;SIO INTERRUPT VECTOR ADDRESS
;
0020  PORTAD = 20H          ;8255 PORT A DATA REGISTER
0024  PIOADR = 24H          ;PIO PORT A DATA REGISTER
0025  PIOBDR = 25H          ;PIO PORT B DATA REGISTER
0026  PIOACR = 26H          ;PIO PORT A CONTROL REGISTER
0027  PIOBCR = 27H          ;PIO PORT B CONTROL REGISTER
0028  CTCCHO = 28H          ;CTC CHANNEL 0 REGISTERS
0029  CTCCH1 = 29H          ;CTC CHANNEL 1 REGISTERS
002A  CTCCH2 = 2AH          ;CTC CHANNEL 2 REGISTERS
002B  CTCCH3 = 2BH          ;CTC CHANNEL 3 REGISTERS
002C  SIOADR = 2CH          ;SIO PORT A DATA REGISTER
002D  SIOBDR = 2DH          ;SIO PORT B DATA REGISTER
002E  SIOACR = 2EH          ;SIO PORT A CONTROL REGISTER
002F  SIOBCR = 2FH          ;SIO PORT B CONTROL REGISTER
;
0004  PORTCO = 4            ;PORT C DATA BIT 0 (INT)
0005  PORTC5 = 5            ;PORT C DATA BIT 5 (IBF)
0006  PORTC7 = 6            ;PORT C DATA BIT 7 (OBF)
0007  RAMPER = 7            ;RAM PARITY ERROR
;
0006  ROMENA = 6            ;ROM ENABLE BIT
0007  PERRES = 7            ;PARITY ERROR RESET
;
0000  RDA = 0               ;RECEIVED DATA AVAILABLE BIT
0002  TBE = 2               ;TRANSMIT BUFFER EMPTY BIT

```

PD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0003		DCD	= 3	; DATA CARRIER DETECT BIT
0005		CTS	= 5	; CLEAR TO SEND BIT
		;		
0000"		.LOC	.DATA.#	; LOCATE IN DATA AREA
		;		
0000" 0040		SOIBSZ::WORD	64	; SERIAL 0 INPUT BUFFER SIZE
0002" 0000		SOIBUF: WORD	0	; SERIAL 0 INPUT BUFFER ADDRESS
0004" 0000		SOIPTR: WORD	0	; SERIAL 0 INPUT POINTER
0006" 0000		SOOPTR: WORD	0	; SERIAL 0 OUTPUT POINTER
0008" 0000		SOICNT: WORD	0	; SERIAL 0 INPUT COUNT
000A" 00		SOOCHR: BYTE	0	; SERIAL 0 OUTPUT CHARACTER
000B" 00		SOBR: BYTE	0	; SERIAL 0 BAUD RATE CODE
		;		
000C"		SOISPH:		; SERIAL 0 INPUT SEMAPHORE
000C" 0000		..SOIH: WORD	0	; SEMAPHORE COUNT
000E" 000E"		..SOIH: WORD	..SOIH	; SEMAPHORE P/D HEAD
0010" 000E"		..WORD	..SOIH	
		;		
0012" 0000		SOOSPH: WORD	0	; SERIAL 0 OUTPUT SEMAPHORE
0014" 0014"		..SOOH: WORD	..SOOH	; SEMAPHORE COUNT
0016" 0014"		..WORD	..SOOH	; SEMAPHORE P/D HEAD
		;		
0018" 0001		SOXSPH: WORD	1	; SERIAL 0 OUTPUT SEMAPHORE
001A" 001A"		..SOXH: WORD	..SOXH	; SEMAPHORE COUNT
001C" 001A"		..WORD	..SOXH	; SEMAPHORE P/D HEAD
		;		
001E" 0010		S1IBSZ::WORD	16	; SERIAL 1 INPUT BUFFER SIZE
0020" 0000		S1IBUF: WORD	0	; SERIAL 1 INPUT BUFFER ADDRESS
0022" 0000		S1IPTR: WORD	0	; SERIAL 1 INPUT POINTER
0024" 0000		S1OPTR: WORD	0	; SERIAL 1 OUTPUT POINTER
0026" 0000		S1ICNT: WORD	0	; SERIAL 1 INPUT COUNT
0028" 00		S1OCHR: BYTE	0	; SERIAL 1 OUTPUT CHARACTER
0029" 00		S1BR: BYTE	0	; SERIAL 1 BAUD RATE CODE
		;		
002A" 0000		S1ISPH: WORD	0	; SERIAL 1 INPUT SEMAPHORE
002C" 002C"		..S1IH: WORD	..S1IH	; SEMAPHORE COUNT
002E" 002C"		..WORD	..S1IH	; SEMAPHORE P/D HEAD
		;		
0030" 0000		S1OSPH: WORD	0	; SERIAL 1 OUTPUT SEMAPHORE
0032" 0032"		..S1OH: WORD	..S1OH	; SEMAPHORE COUNT
0034" 0032"		..WORD	..S1OH	; SEMAPHORE P/D HEAD
		;		
0036" 0001		S1XSPH: WORD	1	; SERIAL 1 OUTPUT SEMAPHORE
0038" 0038"		..S1XH: WORD	..S1XH	; SEMAPHORE COUNT
003A" 0038"		..WORD	..S1XH	; SEMAPHORE P/D HEAD
		;		
0000:04		.LOC	.INIT.#	; LOCATE IN INITIALIZATION AREA
0000:04 AF		SPINIT::XRA	A	

SPD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0001:04 ED47	STAI	;SET INTERRUPT PAGE REGISTER=0
0003:04 ED5E	IM2	;SET INTERRUPT MODE 2
0005:04 3ECF	MVI A,OCFH	;GET PIO A MODE WORD (MODE 3)
0007:04 D326	OUT PIOACR	;OUTPUT PIO A MODE WORD
0009:04 3EFF	MVI A,OFFH	;GET PIO A MODE 3 MODE WORD
000B:04 D326	OUT PIOACR	;OUTPUT PIO A MODE 3 MODE WORD
000D:04 3E30	MVI A,30H	;GET PIO B DATA BYTE
000F:04 D325	OUT PIOBDR	;OUTPUT PIO B DATA BYTE
0011:04 3EOF	MVI A,OFH	;GET PIO B MODE WORD (MODE 0)
0013:04 D327	OUT PIOBCR	;OUTPUT PIO B MODE WORD
0015:04 21 0127'	LXI H,SIOISR	;GET SIO INTERRUPT SERVICE ADDR
0018:04 22 0012	SHLD SIOVEC	;SET SIO INTERRUPT VECTOR ADDRESS
001B:04 21 004A:04	LXI H,SIOPGM	;GET SIO PROGRAM LIST
001E:04 01 092E	LXI B,SIOAPL<8!SIOACR ;B=LENGTH/C=CONTROL RE	;PROGRAM SIO PORT A
0021:04 EDB3	OUTIR	
0023:04 21 004A:04	LXI H,SIOPGM	;GET SIO PROGRAM LIST
0026:04 01 0B2F	LXI B,SIOBPL<8!SIOBCR ;B=LENGTH/C=CONTROL RE	;PROGRAM SIO PORT B
0029:04 EDB3	OUTIR	
002B:04 2A 0000"	LHLD SOIBSZ	;GET SERIAL 0 INPUT BUFFER SIZE
002E:04 CD 0000:05	CALL ALLOC#	;ALLOCATE PACKET FOR SERIAL BUFFE
0031:04 22 0002"	SHLD SOIBUF	;SAVE SERIAL 0 INPUT BUFFER ADDRE
0034:04 22 0004"	SHLD SOIPTR	;SET SERIAL 0 INPUT POINTER
0037:04 22 0006"	SHLD SOOptr	;SET SERIAL 0 OUTPUT POINTER
003A:04 2A 001E"	LHLD S1IBSZ	;GET SERIAL 1 INPUT BUFFER SIZE
003D:04 CD 0000:05	CALL ALLOC#	;ALLOCATE PACKET FOR SERIAL BUFFE
0040:04 22 0020"	SHLD S1IBUF	;SAVE SERIAL 1 INPUT BUFFER ADDRE
0043:04 22 0022"	SHLD S1IPTR	;SET SERIAL 1 INPUT POINTER
0046:04 22 0024"	SHLD S1OPTR	;SET SERIAL 1 OUTPUT POINTER
0049:04 C9	RET	;DONE
;		
004A:04 18	SIOPGM: .BYTE 18H	;RESET CHANNEL
004B:04 04	.BYTE 4	;SELECT WR4
004C:04 C4	.BYTE 0C4H	;WRITE REGISTER 4 CONTROL WORD
004D:04 05	.BYTE 5	;SELECT WR5
004E:04 EA	.BYTE 0EAH	;WRITE REGISTER 5 CONTROL WORD
004F:04 03	.BYTE 3	;SELECT WR3
0050:04 C1	.BYTE 0C1H	;WRITE REGISTER 3 CONTROL WORD
0051:04 01	.BYTE 1	;SELECT WR1
0052:04 10	.BYTE 10H	;WRITE REGISTER 1 CONTROL WORD
;		
0009	SIOAPL = .-SIOPGM	;SIO PORT A PROGRAM LENGTH
;		
0053:04 02	.BYTE 2	;SELECT WR2
0054:04 12	.BYTE SIOVEC	;WRITE REGISTER 1 CONTROL WORD
;		
000B	SIOBPL = .-SIOPGM	;SIO PORT B PROGRAM LENGTH
;		
0000'	.LOC .PROG.#	;LOCATE IN PROGRAM AREA
;		
0000'	SERIAL::	
0000' 7B	COMDRV::MOV A,E	;GET FUNCTION NUMBER
0001' B7	ORA A	;FUNCTION NUMBER=0?
0002' 2818	JRZ SERST	;IF SO, CONTINUE
0004' 3D	DCR A	;FUNCTION NUMBER=1?

PD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0005' 282E           JRZ    SERIN   ;IF SO, CONTINUE
0007' 3D             DCR    A       ;FUNCTION NUMBER=2?
0008' CA 0097'        JZ     SEROUT  ;IF SO, CONTINUE
000B' 3D             DCR    A       ;FUNCTION NUMBER=3?
000C' CA 01F9'        JZ     SERSBR  ;IF SO, CONTINUE
000F' 3D             DCR    A       ;FUNCTION NUMBER=4?
0010' CA 022B'        JZ     SERRBR  ;IF SO, CONTINUE
0013' 3D             DCR    A       ;FUNCTION NUMBER=5?
0014' CA 0237'        JZ     SERSMC  ;IF SO, CONTINUE
0017' 3D             DCR    A       ;FUNCTION NUMBER=6?
0018' CA 0257'        JZ     SERRMC  ;IF SO, CONTINUE
001B' C9             RET    ;ELSE, DONE

001C' ED5B 0008"      ;SERST: LDED   SOICNT ;GET SERIAL 0 INPUT BUFFER COUNT
0020' 2A 0006"        LHLD   SOOPTR  ;GET SERIAL 0 OUTPUT POINTER
0023' 78              MOV    A,B    ;GET CHANNEL NUMBER
0024' B7              ORA    A      ;CHANNEL NUMBER=0
0025' 2807            JRZ    ..COM   ;IF SO, CONTINUE
0027' ED5B 0026"      LDED   S1ICNT ;GET SERIAL 1 INPUT BUFFER COUNT
002B' 2A 0024"        LHLD   S1OPTR ;GET SERIAL 1 OUTPUT POINTER
002E' 7A              ..COM: MOV    A,D   ;SERIAL INPUT BUFFER COUNT=0?
002F' B3              ORA    E      ;IF SO, DONE
0030' C8              RZ    ;ELSE, SET RETURN CODE=OFFH
0031' 3EFF            MVI    A,OFFH ;GET SERIAL INPUT CHARACTER
0033' 4E              MOV    C,M   ;DONE
0034' C9              RET    ;DONE

0035' CD 001C'         ;SERIN: CALL   SERST  ;GET SERIAL STATUS
0038' B7              ORA    A      ;CHARACTER AVAILABLE?
0039' 78              MOV    A,B   ;GET CHANNEL NUMBER
003A' 200E            JRNZ   ..SIN   ;IF CHARACTER AVAILABLE, CONTINUE
003C' 21 000C"         LXI    H,SOISPH ;GET SERIAL 0 INPUT SEMAPHORE
003F' B7              ORA    A      ;CHANNEL NUMBER=0?
0040' 2803            JRZ    ..INC   ;IF SO, CONTINUE
0042' 21 002A"         LXI    H,S1ISPH ;GET SERIAL 1 INPUT SEMAPHORE
0045' CD 0000:06      ..INC: CALL   WAIT#  ;WAIT FOR INPUT CHARACTER
0048' 18EB            JMPR   SERIN  ;CONTINUE
004A' B7              ..SIN: ORA    A      ;CHANNEL NUMBER=0?
004B' 2025            JRNZ   ..S1I   ;IF NOT, CONTINUE
004D' F3              DI     ;DISABLE INTERRUPTS
004E' 2A 0008"         LHLD   SOICNT ;GET SERIAL 0 INPUT COUNT
0051' 2B              DCX    H      ;DECREMENT SERIAL 0 INPUT COUNT
0052' 22 0008"         SHLD   SOICNT ;UPDATE SERIAL 0 INPUT COUNT
0055' 2A 0006"         LHLD   SOOPTR ;GET SERIAL 0 OUTPUT POINTER
0058' 7E              MOV    A,M   ;GET CHARACTER FROM BUFFER
0059' 23              INX    H      ;INCREMENT SERIAL 0 OUTPUT POINTER
005A' EB              XCHG   ;SERIAL 0 OUTPUT POINTER TO DE-REG
005B' 2A 0002"         LHLD   SOIBUF ;GET SERIAL 0 INPUT BUFFER ADDRESS
005E' ED4B 0000"       LBCD   SOIBSZ ;GET SERIAL 0 INPUT BUFFER SIZE
0062' 0B              DCX    B      ;DECREMENT INPUT BUFFER SIZE
0063' 09              DAD    B      ;CALC LAST INPUT BUFFER ADDRESS
0064' ED52            DSBC   D      ;BUFFER WRAP-AROUND?
0066' 3004            JRNC   ..NWAO  ;IF NOT, CONTINUE
0068' ED5B 0002"       LDED   SOIBUF ;GET SERIAL 0 INPUT BUFFER ADDRESS

```

SPD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

006C' ED53 0006" ..NWA0: SDED SOOPTR ;UPDATE SERIAL 0 OUTPUT POINTER
0070' FB EI ;ENABLE INTERRUPTS
0071' C9 RET ;DONE
0072' F3 ..S1I: DI ;DISABLE INTERRUPTS
0073' 2A 0026" LHLD S1ICNT ;GET SERIAL 1 INPUT COUNT
0076' 2B DCX H ;DECREMENT SERIAL 1 INPUT COUNT
0077' 22 0026" SHLD S1ICNT ;UPDATE SERIAL 1 INPUT COUNT
007A' 2A 0024" LHLD S1OPTR ;GET SERIAL 1 OUTPUT POINTER
007D' 7E MOV A,M ;GET CHARACTER FROM BUFFER
007E' 23 INX H ;INCREMENT SERIAL 1 OUTPUT POINTE
007F' EB XCHG ;SERIAL 1 OUTPUT POINTER TO DE-RE
0080' 2A 0020" LHLD S1IBUF ;GET SERIAL 1 INPUT BUFFER ADDRES
0083' ED4B 001E" LBCD S1IBSZ ;GET SERIAL 1 INPUT BUFFER SIZE
0087' 0B DCX B ;DECREMENT INPUT BUFFER SIZE
0088' 09 DAD B ;CALC LAST INPUT BUFFER ADDRESS
0089' ED52 DSBC D ;BUFFER WRAP-AROUND?
008B' 3004 JRNC ..NWA1 ;IF NOT, CONTINUE
008D' ED5B 0020" LDED S1IBUF ;GET SERIAL 1 INPUT BUFFER ADDRES
0091' ED53 0024" ..NWA1: SDED S1OPTR ;UPDATE SERIAL 1 OUTPUT POINTER
0095' FB EI ;ENABLE INTERRUPTS
0096' C9 RET ;DONE

; SEROUT: MOV A,B ;GET CHANNEL NUMBER
0098' B7 ORA A ;CHANNEL NUMBER=1?
0099' 201E JRNZ ..S1O ;IF SO, CONTINUE
009B' 21 0018" LXI H,SOXSPH ;GET SERIAL 0 OUT SEMAPHORE
009E' E5 PUSH H ;SAVE SERIAL 0 OUT SEMAPHORE
009F' CD 0000:06 CALL WAIT# ;WAIT ON MUTUAL EXCLUSION
00A2' 21 000A" LXI H,SOOCHR ;GET SERIAL 0 OUTPUT CHARACTER
00A5' 71 MOV M,C ;SAVE OUTPUT CHARACTER
00A6' 11 00D7' LXI D,SOOPOL ;GET SERIAL 0 OUT POLL ROUTINE
00A9' CD 0000:07 CALL LNKPOL# ;CREATE POLL ROUTINE
00AC' CD 00DB' CALL SOOPR ;EXECUTE POLL ROUTINE
00AF' 21 0012" LXI H,SOOSPH ;GET SERIAL 0 OUT SEMAPHORE
00B2' CD 0000:06 CALL WAIT# ;DISPATCH IF NECESSARY
00B5' E1 POP H ;GET MUTUAL EXCLUSION SEMAPHORE
00B6' C3 0000:08 JMP SIGNAL# ;SIGNAL PROCESS AS READY
00B9' 21 0036" ..S1O: LXI H,S1XSPH ;GET MUTUAL EXCLUSION SEMAPHORE
00BC' E5 PUSH H ;SAVE MUTUAL EXCLUSION SEMAPHORE
00BD' CD 0000:06 CALL WAIT# ;WAIT ON MUTUAL EXCLUSION
00C0' 21 0028" LXI H,S1OCHR ;GET SERIAL 1 OUTPUT CHARACTER
00C3' 71 MOV M,C ;SAVE OUTPUT CHARACTER
00C4' 11 0OFF' LXI D,S1OPOL ;GET SERIAL 1 OUT POLL ROUTINE
00C7' CD 0000:07 CALL LNKPOL# ;CREATE POLL ROUTINE
00CA' CD 0103' CALL S1OPR ;EXECUTE POLL ROUTINE
00CD' 21 0030" LXI H,S1OSPH ;GET SERIAL 1 OUT SEMAPHORE
00D0' CD 0000:06 CALL WAIT# ;DISPATCH IF NECESSARY
00D3' E1 POP H ;GET MUTUAL EXCLUSION SEMAPHORE
00D4' C3 0000:08 JMP SIGNAL# ;SIGNAL PROCESS AS READY

; SOOPOL: .WORD 0 ;SERIAL 0 OUTPUT POLL ROUTINE
00D7' 0000 .WORD 0 ;SUCCESSOR LINK POINTER
00D9' 0000 .WORD 0 ;PREDECESSOR LINK POINTER
;
```

'D740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
)PYRIGHT (C) 1982, SOFTWARE 2000, INC.

00DB'	3E10	SOOPR:	MVI	A,10H	;GET RESET EXTERNAL STATUS COMMAND
00DD'	D32E		OUT	SIOACR	;RESET EXTERNAL STATUS
00DF'	DB2E		IN	SIOACR	;GET SIO PORT A STATUS
00E1'	CB57		BIT	TBE,A	;TRANSMIT BUFFER EMPTY?
00E3'	C8		RZ		;IF NOT, DONE
00E4'	21 000B"		LXI	H,SOBR	;ELSE, GET SERIAL 0 BAUD RATE CODE
00E7'	CB76		BIT	6,M	;CTS HANDSHAKING REQUESTED?
00E9'	2803		JRZ	.NCTS	;IF NOT, CONTINUE
00EB'	CB6F		BIT	CTS,A	;ELSE, CHECK CLEAR TO SEND STATUS
00ED'	C8		RZ		;IF CLEAR TO SEND FALSE, DONE
00EE'	3A 000A"	..NCTS:	LDA	SOOCHR	;GET SERIAL 0 OUTPUT CHARACTER
00F1'	D32C		OUT	SIOADR	;OUTPUT CHARACTER
00F3'	21 00D7'		LXI	H,SOOPOL	;GET SERIAL 0 OUT POLL ROUTINE
00F6'	CD 0000:09		CALL	UNLINK#	;UNLINK POLL ROUTINE
00F9'	21 0012"		LXI	H,SOOSPH	;GET SERIAL 0 OUT SEMAPHORE
00FC'	C3 0000:08		JMP	SIGNAL#	;SIGNAL PROCESS AS READY
 ;					
00FF'	0000	S10POL:			;SERIAL 1 OUTPUT POLL ROUTINE
00FF'	0000		.WORD	0	;SUCCESSOR LINK POINTER
0101'	0000		.WORD	0	;PREDECESSOR LINK POINTER
 ;					
0103'	3E10	S10PR:	MVI	A,10H	;GET RESET EXTERNAL STATUS COMMAND
0105'	D32F		OUT	SIOBCR	;RESET EXTERNAL STATUS
0107'	DB2F		IN	SIOBCR	;GET SIO PORT B STATUS
0109'	CB57		BIT	TBE,A	;TRANSMIT BUFFER EMPTY?
010B'	C8		RZ		;IF NOT, DONE
010C'	21 0029"		LXI	H,S1BR	;ELSE, GET SERIAL 1 BAUD RATE CODE
010F'	CB76		BIT	6,M	;CTS HANDSHAKING REQUESTED?
0111'	2803		JRZ	.NCTS	;IF NOT, CONTINUE
0113'	CB6F		BIT	CTS,A	;ELSE, CHECK CLEAR TO SEND STATUS
0115'	C8		RZ		;IF CLEAR TO SEND FALSE, DONE
0116'	3A 0028"	..NCTS:	LDA	S10CHR	;GET SERIAL 1 OUTPUT CHARACTER
0119'	D32D		OUT	SIOBDR	;OUTPUT CHARACTER
011B'	21 00FF'		LXI	H,S10POL	;GET SERIAL 1 OUT POLL ROUTINE
011E'	CD 0000:09		CALL	UNLINK#	;UNLINK POLL ROUTINE
0121'	21 0030"		LXI	H,S10SPH	;GET SERIAL 1 OUT SEMAPHORE
0124'	C3 0000:08		JMP	SIGNAL#	;SIGNAL PROCESS AS READY
 ;					
0127'	ED73 0000:0A	SIOISR:	SSPD	INTSP#	;SAVE STACK POINTER
012B'	31 0000:0B		LXI	SP,INTSTK#	;SET UP AUX STACK POINTER
012E'	F5		PUSH	PSW	;SAVE REGISTERS
012F'	C5		PUSH	B	
0130'	D5		PUSH	D	
0131'	E5		PUSH	H	
0132'	CD 0143'		CALL	..SOI	;CHECK FOR SERIAL 0 INPUT
0135'	CD 019C'		CALL	..S1I	;CHECK FOR SERIAL 1 INPUT
0138'	E1		POP	H	;RESTORE REGISTERS
0139'	D1		POP	D	
013A'	C1		POP	B	
013B'	F1		POP	PSW	
013C'	ED7B 0000:0A		LSPD	INTSP#	;RESTORE STACK POINTER
0140'	C3 0000:0C		JMP	ISRXIT#	;CONTINUE
0143'	DB2E	..SOI:	IN	SIOACR	;GET SIO PORT A STATUS
0145'	CB47		BIT	RDA,A	;CHARACTER AVAILABLE

SPD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0147' C8 RZ ;IF NOT, DONE
0148' DB2C IN SIOADR ;GET SIO PORT A DATA CHARACTER
014A' 21 000B" LXI H,SOBR ;GET SERIAL 0 BAUD RATE CODE
014D' CB6E BIT 5,M ;INHIBIT INPUT FLAG SET?
014F' CO RNZ ;IF SO, DONE
0150' 4F MOV C,A ;SERIAL 0 DATA CHARACTER TO C-REG
0151' CB7E BIT 7,M ;SIGN BIT ON BAUD RATE CODE?
0153' 2817 JRZ ..NADO ;IF NOT, CONTINUE
0155' CBB9 RES 7,C ;ELSE, STRIP SIGN BIT ON CHARACTE
0157' CD 0000:0D CALL SLVRES# ;CHECK FOR SLAVE RESET
015A' 3A 0000:0E LDA ATNCHR# ;GET ATTENTION CHARACTER
015D' B9 CMP C ;CHARACTER=ATTENTION CHARACTER?
015E' 200C JRNZ ..NADO ;IF NOT, CONTINUE
0160' 2A 0004" LHLD SOIPTR ;ELSE, GET SERIAL 0 INPUT POINTER
0163' 22 0006" SHLD SOOPTR ;RESET SERIAL 0 OUTPUT POINTER
0166' 21 0000 LXI H,O
0169' 22 0008" SHLD SOICNT ;SET SERIAL 0 INPUT COUNT=0
016C' 2A 0000" ..NADO: LHLD SOIBSZ ;GET SERIAL 0 INPUT BUFFER SIZE
016F' ED5B 0008" LDED SOICNT ;GET SERIAL 0 INPUT COUNT
0173' 13 INX D ;INCREMENT SERIAL 0 INPUT COUNT
0174' B7 ORA A ;CLEAR CARRY FLAG
0175' ED52 DSBC D ;SERIAL 0 INPUT BUFFER FULL?
0177' D8 RC ;IF SO, DONE
0178' ED53 0008" SDED SOICNT ;ELSE, UPDATE SERIAL 0 INPUT COUN
017C' 2A 0004" LHLD SOIPTR ;GET SERIAL 0 INPUT POINTER
017F' 71 MOV M,C ;STORE INPUT CHARACTER IN BUFFER
0180' 23 INX H ;INCREMENT INPUT POINTER
0181' EB XCHG ;INPUT POINTER TO DE-REG
0182' 2A 0000" LHLD SOIBSZ ;GET SERIAL 0 INPUT BUFFER SIZE
0185' 2B DCX H ;DECREMENT INPUT BUFFER SIZE
0186' ED4B 0002" LBCD SOIBUF ;GET SERIAL 0 INPUT BUFFER ADDRES
018A' 09 DAD B ;CALC LAST INPUT BUFFER ADDRESS
018B' ED52 DSBC D ;BUFFER WRAP-AROUND?
018D' 3004 JRNc ..NWAO ;IF NOT, CONTINUE
018F' ED5B 0002" LDED SOIBUF ;GET SERIAL 0 INPUT BUFFER ADDRES
0193' ED53 0004" ..NWAO: SDED SOIPTR ;UPDATE SERIAL 0 INPUT POINTER
0197' 21 000C" LXI H,SOISPH ;GET SERIAL 0 INPUT SEMAPHORE
019A' 1857 JMPR ..X ;CONTINUE
019C' DB2F ..S1I: IN SIOBCR ;GET SIO PORT B STATUS
019E' CB47 BIT RDA,A ;CHARACTER AVAILABLE
01A0' C8 RZ ;IF NOT, DONE
01A1' DB2D IN SIOBDR ;GET SIO PORT B DATA CHARACTER
01A3' 21 0029" LXI H,S1BR ;GET SERIAL 1 BAUD RATE CODE
01A6' CB6E BIT 5,M ;INHIBIT INPUT FLAG SET?
01A8' CO RNZ ;IF SO, DONE
01A9' 4F MOV C,A ;SERIAL 1 DATA CHARACTER TO C-REG
01AA' CB7E BIT 7,M ;ATTENTION DETECTION FLAG SET?
01AC' 2817 JRZ ..NAD1 ;IF NOT, CONTINUE
01AE' CBB9 RES 7,C ;ELSE, STRIP SIGN BIT ON CHARACTE
01B0' CD 0000:0D CALL SLVRES# ;CHECK FOR SLAVE RESET
01B3' 3A 0000:0E LDA ATNCHR# ;GET ATTENTION CHARACTER
01B6' B9 CMP C ;CHARACTER=ATTENTION CHARACTER?
01B7' 200C JRNZ ..NAD1 ;IF NOT, CONTINUE
01B9' 2A 0022" LHLD S1IPT ;ELSE, GET SERIAL 1 INPUT POINTER

```

TPD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

01BC'	22 0024"	SHLD	S1OPTR	;RESET SERIAL 1 OUTPUT POINTER
01BF'	21 0000	LXI	H,0	
01C2'	22 0026"	SHLD	S1ICNT	;SET SERIAL 1 INPUT COUNT=0
01C5'	2A 001E"	..NAD1: LHLD	S1IBSZ	;GET SERIAL 1 INPUT BUFFER SIZE
01C8'	ED5B 0026"	LDED	S1ICNT	;GET SERIAL 1 INPUT COUNT
01CC'	13	INX	D	;INCREMENT SERIAL 1 INPUT COUNT
01CD'	B7	ORA	A	;CLEAR CARRY FLAG
01CE'	ED52	DSBC	D	;SERIAL 1 INPUT BUFFER FULL?
01D0'	D8	RC		;IF SO, DONE
01D1'	ED53 0026"	SDED	S1ICNT	;ELSE, UPDATE SERIAL 1 INPUT COUNT
01D5'	2A 0022"	LHLD	S1IPTR	;GET SERIAL 1 INPUT POINTER
01D8'	71	MOV	M,C	;STORE INPUT CHARACTER IN BUFFER
01D9'	23	INX	H	;INCREMENT INPUT POINTER
01DA'	EB	XCHG		;INPUT POINTER TO DE-REG
01DB'	2A 001E"	LHLD	S1IBSZ	;GET SERIAL 1 INPUT BUFFER SIZE
01DE'	2B	DCX	H	;DECREMENT INPUT BUFFER SIZE
01DF'	ED4B 0020"	LBCD	S1IBUF	;GET SERIAL 1 INPUT BUFFER ADDRESS
01E3'	09	DAD	B	;CALC LAST INPUT BUFFER ADDRESS
01E4'	ED52	DSBC	D	;BUFFER WRAP-AROUND?
01E6'	3004	JRNC	..NWA1	;IF NOT, CONTINUE
01E8'	ED5B 0020"	LDED	S1IBUF	;GET SERIAL 1 INPUT BUFFER ADDRESS
01EC'	ED53 0022"	..NWA1: SDED	S1IPTR	;UPDATE SERIAL 1 INPUT POINTER
01FO'	21 002A"	LXI	H,S1ISPH	;GET SERIAL 1 INPUT SEMAPHORE
01F3'	7E	..X:	MOV	A,M ;GET SEMAPHORE COUNT
01F4'	B7	ORA	A	;SEMAPHORE COUNT=0?
01F5'	C8	RZ		;IF SO, DONE
01F6'	C3 0000:08	JMP	SIGNAL#	;ELSE, SIGNAL PROCESS AS READY
<hr/>				
01F9'	51	SERSBR:	MOV	D,C ;REQUESTED BAUD RATE TO D-REG
01FA'	21 000B"	LXI	H,SOBR	;GET SERIAL 0 BAUD RATE
01FD'	0E28	MVI	C,CTCCHO	;GET CTC CHANNEL 0 REGISTERS
01FF'	78	MOV	A,B	;GET CHANNEL NUMBER
0200'	B7	ORA	A	;CHANNEL NUMBER=0?
0201'	2805	JRZ	..COM	;IF SO, CONTINUE
0203'	21 0029"	LXI	H,S1BR	;ELSE, GET SERIAL 1 BAUD RATE
0206'	0E29	MVI	C,CTCCH1	;GET CTC CHANNEL 1 REGISTERS
0208'	72	..COM:	MOV	M,D ;SAVE BAUD RATE CODE
0209'	3E47	MVI	A,47H	;GET CTC CHANNEL CONTROL WORD
020B'	ED79	OUTP	A	;INITIALIZE CTC CHANNEL
020D'	7A	MOV	A,D	;GET REQUESTED BAUD RATE CODE
020E'	E60F	ANI	OFH	;LIMIT TO 16 BAUD RATES
0210'	5F	MOV	E,A	;TO E-REG
0211'	1600	MVI	D,0	;MAKE IT DOUBLE LENGTH
0213'	21 021B'	LXI	H,BRTBL	;GET BAUD RATE TABLE
0216'	19	DAD	D	;INDEX INTO TABLE
0217'	7E	MOV	A,M	;GET TIMER VALUE
0218'	ED79	OUTP	A	;SET CTC CHANNEL TIME CONSTANT
021A'	C9	RET		;DONE
<hr/>				
021B'	00	BRTBL:	.BYTE	0 ;50 BAUD TIMER VALUE
021C'	00		.BYTE	0 ;75 BAUD TIMER VALUE
021D'	AF		.BYTE	175 ;110 BAUD TIMER VALUE
021E'	8F		.BYTE	143 ;134.5 BAUD TIMER VALUE
021F'	80		.BYTE	128 ;150 BAUD TIMER VALUE

SPD740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

0220' 40          .BYTE 64      ;300 BAUD TIMER VALUE
0221' 20          .BYTE 32      ;600 BAUD TIMER VALUE
0222' 10          .BYTE 16      ;1200 BAUD TIMER VALUE
0223' 0B          .BYTE 11      ;1800 BAUD TIMER VALUE
0224' 0A          .BYTE 10      ;2000 BAUD TIMER VALUE
0225' 08          .BYTE 8       ;2400 BAUD TIMER VALUE
0226' 05          .BYTE 5       ;3600 BAUD TIMER VALUE
0227' 04          .BYTE 4       ;4800 BAUD TIMER VALUE
0228' 03          .BYTE 3       ;7200 BAUD TIMER VALUE
0229' 02          .BYTE 2       ;9600 BAUD TIMER VALUE
022A' 01          .BYTE 1       ;19200 BAUD TIMER VALUE
;
022B' 78          SERRBR: MOV A,B      ;GET CHANNEL NUMBER
022C' 21 000B"    LXI H,SOBR    ;GET SERIAL 0 BAUD RATE
022F' B7          ORA A       ;CHANNEL NUMBER=0?
0230' 2803        JRZ ..COM    ;IF SO, CONTINUE
0232' 21 0029"    LXI H,S1BR    ;ELSE, GET SERIAL 1 BAUD RATE
0235' 7E          ..COM: MOV A,M      ;GET CURRENT BAUD RATE CODE
0236' C9          RET         ;DONE
;
0237' 3EEA        SERSMC: MVI A,0EAH   ;GET WRITE REGISTER 5 CONTROL WORD
0239' E67D        ANI #82H     ;STRIP RTS/CTS CONTROL BITS
023B' CB79        BIT 7,C      ;RTS REQUESTED?
023D' 2802        JRZ ..NRTS   ;IF SO, SET RTS BIT
023F' CBCF        SET 1,A      ;DTR REQUESTED?
0241' CB71        ..NRTS: BIT 6,C      ;IF SO, SET DTR BIT
0243' 2802        JRZ ..NDTR   ;REQUESTED MODEM CONTROLS TO D-REQ
0245' CBFF        SET 7,A      ;GET SIO PORT A CONTROL REGISTER
0247' 57          ..NDTR: MOV D,A      ;REQUESTED MODEM CONTROLS TO D-REQ
0248' 0E2E        MVI C,SIOACR  ;GET SIO PORT A CONTROL REGISTER
024A' 78          MOV A,B      ;GET CHANNEL NUMBER
024B' B7          ORA A       ;CHANNEL NUMBER=0?
024C' 2802        JRZ ..COM    ;IF SO, CONTINUE
024E' 0E2F        MVI C,SIOBCR  ;GET SIO PORT B CONTROL REGISTER
0250' 3E05        ..COM: MVI A,5       ;SELECT WRITE REGISTER 5
0252' ED79        OUTP A      ;OUTPUT WRITE REGISTER 5 CONTROL WORD
0254' ED51        OUTP D      ;OUTPUT WRITE REGISTER 5 CONTROL WORD
0256' C9          D           ;DONE
;
0257' 0E2E        SERRMC: MVI C,SIOACR ;GET SIO PORT A CONTROL REGISTER
0259' 78          MOV A,B      ;GET CHANNEL NUMBER
025A' B7          ORA A       ;CHANNEL NUMBER=0?
025B' 2802        JRZ ..COM    ;IF SO, CONTINUE
025D' 0E2F        MVI C,SIOBCR ;GET SIO PORT B CONTROL REGISTER
025F' 3E10        ..COM: MVI A,10H     ;GET RESET EXTERNAL STATUS COMMAND
0261' ED79        OUTP A      ;RESET EXTERNAL STATUS
0263' ED50        INP D       ;GET SIO MODEM STATUS
0265' AF          XRA A       ;CLEAR RETURN VECTOR
0266' CB6A        BIT CTS,D    ;CTS SET?
0268' 2802        JRZ ..NCTS   ;IF NOT, CONTINUE
026A' CBFF        SET 7,A      ;ELSE, SET CTS BIT
026C' CB5A        ..NCTS: BIT DCD,D    ;DCD SET?
026E' C8          RZ          ;IF NOT, DONE

```

'D740 - TURBODOS OPERATING SYSTEM SERIAL/PARALLEL DRIVER (IMS 740)
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```
026F'    CBEF          SET      5,A      ;ELSE, SET DCD BIT
0271'    C9            RET      ;DONE
;
.END
```

SLVRES - TURBODOS OPERATING SYSTEM SLAVE RESET PROCESSOR
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;
; ***** This is a subroutine called by SPD740 which de-
; ***** tects two consecutive slave reset characters from
; ***** the console keyboard, and forces a crash which
; ***** ultimately causes the slave to be reset by the
; ***** master.
;

; ***** COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH

; VERSION: EXAMPLE

; IDENT SLVRES          ;MODULE ID
; INSERT DREQUATE       ;DRIVER SYMBOLIC EQUIVALENCES
;

0000"               .LOC    .DATA.# ;LOCATE IN DATA AREA
;
0000" 1F             SLRCHR::BYTE   AUS      ;SLAVE RESET CHARACTER
0001" FE             RCCNT:  .BYTE    -2       ;RESET CHARACTER COUNT
;
0000'               .LOC    .PROG.# ;LOCATE IN PROGRAM AREA
;
0000' 21 0001"        SLVRES::LXI   H,RCCNT ;GET RESET CHARACTER COUNT
0003' 3A 0000"        LDA     SLRCHR  ;GET SLAVE RESET CHARACTER
0006' B9              CMP     C        ;CHARACTER=SLAVE RESET CHARACTER?
0007' 2803            JRZ     ..RC    ;IF SO, CONTINUE
0009' 36FE            MVI     M,-2   ;ELSE, RESET CHARACTER COUNT
000B' C9              RET     ;DONE
000C' 34              ..RC:  INR     M      ;INCREMENT RESET CHARACTER COUNT
000D' C0              RNZ     ;IF CHARACTER COUNT NOT=0, DONE
000E' F3              DI      ;ELSE, DISABLE INTERRUPTS
000F' 76              HLT     ;HALT
;
.END
;
```

PB401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;*****;;
;
; * This is a boot ROM driver module which interfaces
; * with the IMS 401 eight-inch floppy disk controller
; * board. This driver is linked together with two
; * other modules, OSBOOT.REL and DST8F.REL, to create
; * a boot ROM for an IMS 8000 system.
;
;*****;;
;
; COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
;           MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
;IDENT MPB401          ;MODULE ID
;
;.INSERT EQUATE         ;DRIVER SYMBOLIC EQUIVALENCES
;
0080      RAM      =: TBUF        ;WORKING STORAGE ADDRESS
0040      RAMLEN   = 64          ;WORKING STORAGE LENGTH
;
0082      CH1DMA   = 82H         ;CHANNEL 1 DMA REGISTER (FDC)
0083      CH1TC    = 83H         ;CHANNEL 1 TERMINAL COUNT (FDC)
0088      DMACTL   = 88H         ;DMA COMMAND AND STATUS REGISTERS
008A      DSKSEL   = 8AH         ;DISK SELECT PORT
008C      DSKCTL   = 8CH         ;STATUS AND INT MASK (BOARD)
008E      FDCST    = 8EH         ;DISK CONTROLLER STATUS (uPD-765)
008F      FDCDAT   = 8FH         ;DISK CONTROLLER DATA (uPD-765)
;
0042      CH1ENA   = 42H         ;DMA CHANNEL 1 ENABLE COMMAND
0000      DMAVFY   = 00H         ;DMA VERIFY COMMAND
0040      DMARD    = 40H         ;DMA READ COMMAND
0080      DMAWR    = 80H         ;DMA WRITE COMMAND
;
0003      FDCSFY   = 03H         ;FDC SPECIFY COMMAND
0004      FDCSDS   = 04H         ;FDC SENSE DRIVE STATUS COMMAND
0007      FDCRCL   = 07H         ;FDC RECALIBRATE COMMAND
0008      FDCSIS   = 08H         ;FDC SENSE INTERRUPT STATUS COMMAND
000A      FDCRID   = 0AH         ;FDC READ ID COMMAND
000F      FDCSK    = 0FH         ;FDC SEEK COMMAND
0085      FDCWR    = 85H         ;FDC WRITE COMMAND
0086      FDCRD    = 86H         ;FDC READ COMMAND
;
0000      DSKENI   = 0           ;DISK CONTROLLER ENABLE INTERRUPTS
0007      DSKDLC   = 7           ;DISK CONTROLLER DELAY COMPLETE
;
0006      FDCMFM   = 6           ;FDC DOUBLE-DENSITY BIT
;
0004      FDCBSY   = 4           ;FDC BUSY STATUS
0005      FDCSE    = 5           ;FDC SEEK END

```

MPB401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0006	FDCOUT	= 6	;FDC OUTPUT MODE
0007	FDCRDY	= 7	;FDC READY FOR DATA
	;		
00C0	SRT5	= (16-4)<4	;5 INCH FDD STEP RATE (4 MS-MINI)
00A0	SRT8S	= (16-6)<4	;8 INCH FDD STEP RATE (6 MS-SHUGA)
	;		
00D0	SRT8R	= (16-3)<4	;8 INCH FDD STEP RATE (3 MS-REMEX)
00F0	SRT8P	= (16-1)<4	;8 INCH FDD STEP RATE (1 MS-PERSC)
	;		
0024	HLT	= 18#2	;FDD HEAD LOAD TIME (36 MS)
0001	HUT	= 1	;FDD HEAD UNLOAD TIME (16 MS)
	;		
0003	STONR	= 3	;STATUS REGISTER 0 NOT READY
0004	STOEC	= 4	;STATUS REGISTER 0 EQUIP CHECK
0005	STOSE	= 5	;STATUS REGISTER 0 SEEK END
	;		
0000	ST1MA	= 0	;STATUS REGISTER 1 MISSING ADDR MK
0001	ST1NW	= 1	;STATUS REGISTER 1 NOT WRITABLE
0002	ST1ND	= 2	;STATUS REGISTER 1 NO DATA
0004	ST1OR	= 4	;STATUS REGISTER 1 OVER RUN
0005	ST1DE	= 5	;STATUS REGISTER 1 DATA ERROR
	;		
0003	ST3TS	= 3	;STATUS REGISTER 3 TWO-SIDED
0004	ST3TO	= 4	;STATUS REGISTER 3 TRACK 0
0005	ST3RDY	= 5	;STATUS REGISTER 3 READY
0006	ST3WP	= 6	;STATUS REGISTER 3 WRITE PROTECTED
	;		
0002	TSD	= 2	;TWO-SIDED DISK BIT (TYPE CODE)
0003	DDD	= 3	;DOUBLE DENSITY DISK BIT (TYPE COD
	;		
000A	MAXTRY	= 10	;MAX TRY COUNT
	;		
00C0	.LOC	RAM+RAMLEN	;LOCATE IN WORKING STORAGE ARE
	;		
00C0	IODSK:	.BLKB	1 ;DISK NUMBER
00C1	IOTRK:	.BLKW	1 ;TRACK NUMBER
00C3	IOSEC:	.BLKW	1 ;SECTOR NUMBER
00C5	IODMA:	.BLKW	1 ;DMA ADDRESS
00C7	ST3REG:	.BLKB	1 ;STATUS REGISTER 3
00C8	TRYCNT:	.BLKB	1 ;TRY COUNT
	;		
00C9	DSKNFO:		;DISK TYPE INFORMATION
00C9	BLKSIZ:	.BLKB	1 ;BLOCK SIZE
00CA	NMBLKS:	.BLKW	1 ;NUMBER OF BLOCKS
00CC	NMBDIR:	.BLKB	1 ;NUMBER OF DIRECTORY BLOCKS
00CD	SECSIZ:	.BLKB	1 ;PHYSICAL SECTOR SIZE ($2^N \cdot 128$)
00CE	SECTRK:	.BLKW	1 ;PHYSICAL SECTORS PER TRACK
00DO	TRKDSK:	.BLKW	1 ;PHYSICAL TRACKS PER DISK
00D2	RESTRK:	.BLKW	1 ;NUMBER OF RESERVED TRACKS
00D4	XLTBL:	.BLKW	1 ;TRANSLATION TABLE ADDRESS
00D6	TYPCOD:	.BLKB	1 ;DISK TYPE CODE
00D7	GAPLEN:	.BLKB	1 ;GAP LENGTH
000F	DNFOL	= .-DSKNFO	;DISK INFO LENGTH

©B401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
©PYRIGHT (C) 1982, SOFTWARE 2000, INC.

		.LOC	.PROG.# ;LOCATE IN PROGRAM AREA
0000'	3E03	INIT:: MVI	A,FDCSFY ;GET FDC SPECIFY COMMAND
0002'	CD 01B3'	CALL	DATOUT ;OUTPUT FDC SPECIFY COMMAND
0005'	3EA1	MVI	A,SRT8S!HUT ;GET STEP RATE/HEAD UNLD TIME
0007'	CD 01B3'	CALL	DATOUT ;OUTPUT STEP RATE/HEAD UNLD TIME
000A'	3E24	MVI	A,HLT ;GET HEAD LOAD TIME/NON-DMA BIT
000C'	CD 01B3'	CALL	DATOUT ;OUTPUT HEAD LOAD TIME/NON-DMA BIT
000F'	21 0100	LXI	H,TPA ;GET LOAD BASE ADDRESS
0012'	C9	RET	;DONE
0013'	FE04	;	
0015'	3061	SELECT:: CPI	4 ;TEST FOR VALID DRIVE
0017'	32 00C0	JRNC	..NR ;IF INVALID DRIVE, CONTINUE
001A'	4F	STA	IODSK ;ELSE, SET DISK NUMBER
001B'	DB8C	MOV	C,A ;DISK NUMBER TO C-REG
001D'	OF	IN	DSKCTL ;GET DISK CONTROLLER STATUS
001E'	E603	RRc	;EXTRACT SELECTED DRIVE
0020'	B9	ANI	3
0021'	2803	CMP	C ;DRIVE ALREADY SELECTED?
0023'	79	JRZ	..DS ;IF SO, CONTINUE
0024'	D38A	MOV	A,C ;ELSE, GET DISK NUMBER
0026'	01 0014	OUT	DSKSEL ;SELECT DISK NUMBER
0029'	10FE	..DS: LXI	B,20 ;DELAY 10 MILLISECONDS
002B'	0D	..DLY: DJNZ	..DLY
002C'	20FB	DCR	C
002E'	3E04	JRNZ	..DLY
0030'	CD 01B3'	MVI	A,FDCSDS ;GET FDC SENSE DRIVE STATUS CMD
0033'	3A 00C0	CALL	DATOUT ;OUTPUT COMMAND TO FDC
0036'	CD 01B3'	LDA	IODSK ;GET DISK NUMBER
0039'	CD 01A7'	CALL	DATOUT ;OUTPUT IT TO FDC
003C'	CB6F	DATAIN	;GET STATUS REGISTER 3
003E'	2838	BIT	ST3RDY,A ;DRIVE READY?
0040'	32 00C7	JRZ	..NR ;IF NOT READY, CONTINUE
0043'	CD 0165'	STA	ST3REG ;ELSE, SAVE STATUS REGISTER 3
0046'	2030	CALL	RECAL ;RECALIBRATE DRIVE
0048'	0E00	JRNZ	..NR ;IF ERRORS, CONTINUE
004A'	21 00C7	MVI	C,0 ;ELSE, GET INITIAL TYPE VALUE
004D'	CB5E	LXI	H,ST3REG ;GET STATUS REGISTER 3
004F'	2802	BIT	ST3TS,M ;ONE-SIDED DISK?
0051'	CBD1	JRZ	..OSD ;YES
0053'	3EOA	SET	TSD,C ;SET TWO-SIDED DISK BIT
0055'	CD 0089'	..OSD: MVI	A,FDCRID ;GET FDC READ ID COMMAND (SD)
0058'	2809	CALL	..RID ;ATTEMPT TO READ SINGLE-DENSITY
005A'	3E4A	JRZ	..TPC ;IF SINGLE-DENSITY, DONE
005C'	CD 0089'	MVI	A,FDCRID!1<FDCMFM ;GET READ ID CMD (DD)
005F'	2017	CALL	..RID ;ATTEMPT TO READ DOUBLE-DENSITY
0061'	CBD9	JRNZ	..NR ;IF NOT DOUBLE-DENSITY, DONE
0063'	B1	SET	DDD,C ;SET DOUBLE-DENSITY DISK BIT
0064'	4F	..TPC: ORA	C ;ADD SECTOR SIZE TO TYPE CODE
0065'	11 0000:04	MOV	C,A ;SAVE TYPE CODE IN C-REG
0068'	79	LXI	D,DSTBLS# ;GET DST BASE ADDRESS
0069'	21 0000:05	..SL: MOV	A,C ;GET DISK TYPE CODE
		LXI	H,DTCO# ;GET OFFSET TO DISK TYPE CODE

MPB401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

006C'	19	DAD	D	;CALC DISK TYPE CODE ADDRESS
006D'	BE	CMP	M	;DST FOUND?
006E'	EB	XCHG		;DST ADDRESS TO HL-REG
006F'	2809	JRZ	..DSTF	;IF DST FOUND, CONTINUE
0071'	5E	MOV	E,M	;ELSE, GET NEXT DST ADDRESS
0072'	23	INX	H	
0073'	56	MOV	D,M	
0074'	7A	MOV	A,D	
0075'	B3	ORA	E	;END OF LIST?
0076'	20F0	JRNZ	..SL	;IF NOT, CONTINUE
0078'	AF	..NR:	XRA	A ;SET RETURN CODE=0
0079'	C9		RET	;DONE
007A'	23	..DSTF:	INX	H ;ADVANCE PAST LINK POINTER
007B'	23		INX	H
007C'	E5		PUSH	H ;SAVE DST ADDRESS
007D'	11 00C9	LXI	D,DSKNFO	;GET DISK INFO WORK AREA
0080'	01 000F	LXI	B,DNFOL	;GET DISK INFO LENGTH
0083'	EDB0	LDI		;COPY DST INTO WORK AREA
0085'	E1	POP	H	;RESTORE DST ADDRESS
0086'	3EFF	MVI	A,OFFH	;SET RETURN CODE=OFFH
0088'	C9	RET		;DONE
0089'	C5	..RID:	PUSH	B ;SAVE BC-REG
008A'	CD 01B3'	CALL	DATOUT	;OUTPUT COMMAND TO FDC
008D'	3A 00C0	LDA	IODSK	;GET DISK NUMBER
0090'	CD 01B3'	CALL	DATOUT	;OUTPUT IT TO FDC
0093'	CD 0170'	CALL	WTINT	;WAIT FOR INTERRUPT
0096'	78	MOV	A,B	;RETURN SECTOR SIZE
0097'	C1	POP	B	;RESTORE BC-REG
0098'	C9	RET		;DONE
0099'	ED43 00C1	READ::	SBCD	IOTRK ;SAVE TRACK NUMBER
009D'	ED53 00C3		SDED	IOSEC ;SAVE SECTOR NUMBER
00A1'	22 00C5		SHLD	IODMA ;SAVE DMA ADDRESS
00A4'	21 00C8	LXI	H,TRYCNT	;GET TRY COUNT
00A7'	360A	MVI	M,MAXTRY	;INITIALIZE TRY COUNT
00A9'	CD 0152'	..RR:	CALL	SEEK ;SEEK TO REQUESTED TRACK
00AC'	C2 0143'		JNZ	..ERR ;IF ERRORS, CONTINUE
00AF'	AF	XRA	A	
00B0'	D388	OUT	DMACTL	;RESET DMA CONTROLLER
00B2'	21 0080	LXI	H,128	;GET SECTOR SIZE=0 SECTOR LENGTH
00B5'	3A 00CD	LDA	SECSIZ	;GET PHYSICAL SECTOR SIZE
00B8'	B7	ORA	A	;PHYSICAL SECTOR SIZE=0?
00B9'	2804	JRZ	..NO1	;IF SO, CONTINUE
00BB'	29	..SL:	DAD	H ;ELSE, SHIFT HL-REG LEFT
00BC'	3D		DCR	A ;SECTOR SIZE TIMES
00BD'	20FC	JRNZ	..SL	
00BF'	2B	..NO1:	DCX	H ;COUNT -1 FOR 8257
00C0'	7D	MOV	A,L	;GET LSB OF TERMINAL COUNT
00C1'	D383	OUT	CH1TC	;OUTPUT LSB OF TERMINAL COUNT
00C3'	7C	MOV	A,H	;GET MSB OF TERMINAL COUNT
00C4'	F640	ORI	DMARD	;ADD DMA READ COMMAND
00C6'	D383	OUT	CH1TC	;OUTPUT MSB OF TERMINAL COUNT
00C8'	2A 00C5	LHLD	IODMA	;GET DMA ADDRESS
00CB'	7D	MOV	A,L	;GET LSB OF DMA ADDRESS

B401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
 PYRIGHT (C) 1982, SOFTWARE 2000, INC.

00CC'	D382	OUT	CH1DMA	;OUTPUT LSB OF DMA ADDRESS	
00CE'	7C	MOV	A,H	;GET MSB OF DMA ADDRESS	
00CF'	D382	OUT	CH1DMA	;OUTPUT MSB OF DMA ADDRESS	
00D1'	3E42	MVI	A,CH1ENA	;GET CHANNEL 1 ENABLE COMMAND	
00D3'	D388	OUT	DMACTL	;ENABLE DMA CONTROLLER	
00D5'	3E86	MVI	A,FDCRD	;GET FDC READ COMMAND	
00D7'	21 00D6	LXI	H,TYPCOD	;GET DISK TYPE CODE	
00DA'	CB5E	BIT	DDD,M	;SINGLE DENSITY DISK?	
00DC'	2802	JRZ	.SD	;IF SO, 'CONTINUE	
00DE'	CBF7	SET	FDCMF, A	;ELSE, SET FDC MFM BIT	
00E0'	CD 01B3'	..SD:	CALL	DATOUT	;OUTPUT FDC READ COMMAND
00E3'	3A 00C3	LDA	IOSEC	;GET SECTOR NUMBER	
00E6'	5F	MOV	E,A	;SECTOR NUMBER TO E-REG	
00E7'	2A 00D4	LHLD	XLTBL	;GET TRANSLATION TABLE ADDRESS	
00EA'	7C	MOV	A,H		
00EB'	B5	ORA	L	;SECTOR TRANSLATION REQUIRED?	
00EC'	2804	JRZ	.NI	;IF NOT, 'CONTINUE	
00EE'	1600	MVI	D,0	;ELSE, MAKE SECTOR DOUBLE LENGTH	
00F0'	19	DAD	D	;INDEX INTO TRANSLATION TABLE	
00F1'	5E	MOV	E,M	;GET TRANSLATED SECTOR NUMBER	
00F2'	1C	..NI:	INR	E	;CONVERT SECTOR TO BASE 1
00F3'	3A 00CE	LDA	SECTRK	;GET NUMBER OF SECTORS/TRACK	
00F6'	21 00D6	LXI	H,TYPCOD	;GET DISK TYPE CODE ADDRESS	
00F9'	CB56	BIT	TSD,M	;TWO SIDED DISK?	
00FB'	2802	JRZ	.SSD	;IF NOT, 'CONTINUE	
00FD'	CB3F	SRLR	A	;ELSE, CALC NUMBER OF SECTORS/SIDE	
00FF'	57	..SSD:	MOV	D,A	;SAVE NUMBER OF SECTORS/SIDE
0100'	0600	MVI	B,0	;PRESET FOR FRONT SIDE	
0102'	BB	CMP	E	;FRONT SIDE OF DISK?	
0103'	3004	JRNC	.FS1	;IF SO, 'CONTINUE	
0105'	7B	MOV	A,E	;ELSE, GET SECTOR NUMBER	
0106'	92	SUB	D	;SUBTRACT ONE SIDES WORTH	
0107'	5F	MOV	E,A	;SECTOR NUMBER TO C-REG	
0108'	04	INR	B	;SET HEAD NUMBER=1	
0109'	3A 00C0	..FS1:	LDA	IODSK	;GET DISK NUMBER
010C'	04	INR	B		
010D'	05	DCR	B	;HEAD=0?	
010E'	2802	JRZ	.FS2	;IF SO, 'CONTINUE	
0110'	CBD7	SET	2,A	;ELSE, SET HEAD BIT	
0112'	CD 01B3'	..FS2:	CALL	DATOUT	;OUTPUT UNIT NUMBER
0115'	3A 00C1	LDA	IOTRK	;GET TRACK NUMBER	
0118'	CD 01B3'	CALL	DATOUT	;OUTPUT TRACK NUMBER	
011B'	78	MOV	A,B	;GET HEAD NUMBER	
011C'	CD 01B3'	CALL	DATOUT	;OUTPUT HEAD NUMBER	
011F'	7B	MOV	A,E	;GET SECTOR NUMBER	
0120'	CD 01B3'	CALL	DATOUT	;OUTPUT SECTOR NUMBER	
0123'	3A 00CD	LDA	SECSIZ	;GET SECTOR SIZE	
0126'	F5	PUSH	PSW	;SAVE SECTOR SIZE	
0127'	CD 01B3'	CALL	DATOUT	;OUTPUT SECTOR SIZE	
012A'	7A	MOV	A,D	;GET EOT	
012B'	CD 01B3'	CALL	DATOUT	;OUTPUT EOT	
012E'	3A 00D7	LDA	GAPLEN	;GET GAP LENGTH	
0131'	CD 01B3'	CALL	DATOUT	;OUTPUT GAP LENGTH	
0134'	F1	POP	PSW	;RESTORE SECTOR SIZE	

MPB401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

0135'	B7		ORA	A	;SECTOR SIZE=0?
0136'	3E80		MVI	A,128	;PRESET DTL=128
0138'	2802		JRZ	..NO	;IF SECTOR SIZE=0, CONTINUE
013A'	3EFF		MVI	A,OFFH	;ELSE, DTL=OFFH
013C'	CD 01B3'	..NO:	CALL	DATOUT	;OUTPUT DTL
013F'	CD 0170'		CALL	WTINT	;WAIT FOR INTERRUPT
0142'	C8		RZ		;IF NO ERRORS, DONE
0143'	CD 0165'	..ERR:	CALL	RECAL	;RECALIBRATE DRIVE
0146'	2007		JRNZ	..X	;IF ERRORS, CONTINUE
0148'	21 00C8		LXI	H,TRYCNT	;ELSE, GET TRY COUNT
014B'	35		DCR	M	;DECREMENT TRY COUNT
014C'	C2 00A9'		JNZ	..RR	;IF COUNT NOT EXH, TRY AGAIN
014F'	3EFF	..X:	MVI	A,OFFH	;ELSE, SET RETURN CODE=OFFH
0151'	C9		RET		;DONE
		;			
0152'	3EOF	SEEK:	MVI	A,FDCSK	;SET FDC SEEK COMMAND
0154'	CD 01B3'		CALL	DATOUT	;OUTPUT FDC SEEK COMMAND
0157'	3A 00C0		LDA	IODSK	;GET DISK NUMBER
015A'	CD 01B3'		CALL	DATOUT	;OUTPUT DISK NUMBER
015D'	3A 00C1		LDA	IOTRK	;GET TRACK NUMBER
0160'	CD 01B3'		CALL	DATOUT	;OUTPUT TRACK NUMBER
0163'	180B		JMPR	WTINT	;WAIT FOR INTERRUPT
		;			
0165'	3E07	RECAL:	MVI	A,FDCRCL	;SET FDC RECALIBRATE COMMAND
0167'	CD 01B3'		CALL	DATOUT	;OUTPUT FDC RECALIBRATE COMMAND
016A'	3A 00C0		LDA	IODSK	;GET DISK NUMBER
016D'	CD 01B3'		CALL	DATOUT	;OUTPUT DISK NUMBER
		;			
0170'	DB8C	WTINT:	IN	DSKCTL	;GET DISK CONTROLLER STATUS
0172'	OF		RRC		;TEST FOR FDC INTERRUPT
0173'	30FB		JRNC	WTINT	;IF NO INTERRUPT, WAIT
0175'	DB8E	..RQML:	IN	FDCST	;GET FDC STATUS
0177'	07		RLC		;FDC READY TO COMMUNICATE?
0178'	30FB		JRNC	..RQML	;IF NOT, WAIT
017A'	07		RLC		;TEST FDC DIRECTION
017B'	3818		JRC	..RW	;IF FDC OUTPUT AVAILABLE, PROCESS
017D'	3E08		MVI	A,FDCSIS	;GET SENSE INTERRUPT STATUS CMI
017F'	D38F		OUT	FDCDAT	;OUTPUT BYTE TO FDC DATA REGISTER
0181'	CD 01A7'		CALL	DATAIN	;GET STATUS REGISTER 0
0184'	4F		MOV	C,A	;SAVE IT IN C-REG
0185'	E6C0		ANI	OCOH	;EXTRACT COMPLETION STATUS
0187'	FE80		CPI	80H	;INTERRUPT STACK EMPTY?
0189'	2818		JRZ	..X	;IF SO, DONE
018B'	CD 01A7'		CALL	DATAIN	;GET PRESENT CYLINDER NUMBER
018E'	CB69		BIT	STOSE,C	;READY LINE CHANGE STATE?
0190'	28E3		JRZ	..RQML	;IF SO, IGNORE
0192'	51		MOV	D,C	;GET STATUS REGISTER 0 IN D-REG
0193'	18E0		JMPR	..RQML	;FLUSH ANY REMAINING INTERRUPTS
0195'	CD 01A7'	..RW:	CALL	DATAIN	;GET STATUS REGISTER 0
0198'	57		MOV	D,A	;TO D-REG
0199'	0606		MVI	B,6	;B=LENGTH OF REMAINING RESULT PH/
019B'	CD 01A7'	..RL:	CALL	DATAIN	;GET RESULT BYTE FROM FDC
019E'	10FB		DJNZ	..RL	;READ ALL SEVEN BYTES
01AO'	47		MOV	B,A	;SAVE SECTOR SIZE IN B-REG

PB401 - TURBODOS OPERATING SYSTEM MASTER PROCESSOR BOOT FOR IMS 401
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

01A1' 18D2      JMPR   ..RQML ;FLUSH ANY REMAINING INTERRUPTS
01A3' 7A          ..X:   MOV    A,D   ;GET STATUS REGISTER
01A4' E6C0        ANI    OCOH  ;EXTRACT COMPLETION STATUS
01A6' C9          RET    ;DONE

01A7' DB8E      DATAIN: IN     FDCST ;GET FDC STATUS
01A9' 07          RLC    ;TEST FDC FOR READY
01AA' 30FB        JRNC   DATAIN ;IF NOT READY, WAIT
01AC' 07          RLC    ;TEST FDC DIRECTION
01AD' D2 0000:06  JNC    .BEG.# ;IF WRONG DIRECTION, CONTINUE
01B0' DB8F      IN     FDCCDAT ;GET FDC DATA BYTE
01B2' C9          RET    ;DONE

01B3' 4F          DATOUT: MOV    C,A   ;SAVE OUTPUT BYTE
01B4' DB8E      ..RW:   IN     FDCST ;GET FDC STATUS
01B6' 07          RLC    ;TEST FDC FOR READY
01B7' 30FB        JRNC   ..RW   ;IF NOT READY, WAIT
01B9' 07          RLC    ;TEST FDC DIRECTION
01BA' DA 0000:06  JC    .BEG.# ;IF WRONG DIRECTION, CONTINUE
01BD' 79          MOV    A,C   ;RESTORE OUTPUT BYTE
01BE' D38F      OUT    FDCCDAT ;OUTPUT BYTE TO FDC DATA REGISTER
01C0' C9          RET    ;DONE

01C1' AF          XFER:: XRA    A
01C2' 32 0080    STA    TBUF  ;MAKE DEFAULT BUFFER EMPTY
01C5' C3 0100    JMP    TPA   ;TRANSFER TO O/S LOADER

; .END

```

SPB740 - TURBODOS OPERATING SYSTEM SLAVE PROCESSOR BOOTSTRAP (IMS 740)
COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

;***** This is a boot ROM for the IMS 740 slave processor
; board. It downloads and executes a block of code
; sent by the master. Normally, the master sends
; the network loader module LOD740, which handles
; the actual downloading of the slave operating sys-
; tem.
;
;***** COPYRIGHT (C) 1982, SOFTWARE 2000, INC.
;
; AUTHORS: RONALD E. RAIKES
; MICHAEL D. BUSCH
;
; VERSION: EXAMPLE
;
; IDENT SPB740 ;MODULE ID
;
; INSERT DREQUATE ;DRIVER SYMBOLIC EQUIVALENCES
;
0020    PORTAD = 20H ;8255 PORT A DATA REGISTER
0024    PIOADR = 24H ;PIO PORT A DATA REGISTER
0025    PIOBDR = 25H ;PIO PORT B DATA REGISTER
0026    PIOACR = 26H ;PIO PORT A CONTROL REGISTER
0027    PIOBCR = 27H ;PIO PORT B CONTROL REGISTER
;
0005    PORTC5 = 5 ;PORT C DATA BIT 5 (IBF)
0006    PORTC7 = 6 ;PORT C DATA BIT 7 (OBF)
;
0000'          .LOC   .PROG.# ;LOCATE IN PROGRAM AREA
;
0000'    F3           SPBOOT: DI      ;DISABLE INTERRUPTS
0001' 31 0900        LXI    SP,900H ;INITIALIZE STACK POINTER
0004' 3ECF          MVII   A,OCFH  ;GET PIO A MODE WORD (MODE 3)
0006' D326          OUT    PIOACR ;OUTPUT PIO A MODE WORD
0008' 3EFF          MVII   A,OFFH  ;GET PIO A MODE 3 MODE WORD
000A' D326          OUT    PIOACR ;OUTPUT PIO A MODE 3 MODE WORD
000C' 3EFO          MVII   A,OFOH  ;GET PIO B DATA DATA WORD
000E' D325          OUT    PIOBDR ;OUTPUT PIO B DATA WORD
0010' 3EOF          MVII   A,OFH   ;GET PIO B MODE WORD (MODE 0)
0012' D327          OUT    PIOBCR ;OUTPUT PIO B MODE WORD
0014' DB20          IN     PORTAD ;CLEAR INPUT PORT A
0016' 21 0900        LXI    H,0900H ;GET INTERMEDIATE BOOT LOAD ADI
0019' 11 0004        LXI    D,4    ;GET LENGTH OF LOAD ADDRESS/LEN
001C' CD 003B'       CALL   RCV740 ;RECEIVE LOAD ADDRESS/LENGTH
001F' 2A 0900        LHLD   0900H ;GET LOAD ADDRESS
0022' ED5B 0902     LDED   0902H ;GET LENGTH
0026' E5             PUSH   H    ;SAVE LOAD ADDRESS
0027' CD 003B'       CALL   RCV740 ;RECEIVE INTERMEDIATE BOOT LOAI
002A' E5             PUSH   H    ;PUSH TRANSFER CODE ADDR ONTO S
002B' EB             XCHG   ;TRANSFER CODE ADDRESS TO DE-RE

```

3740 - TURBODOS OPERATING SYSTEM SLAVE PROCESSOR BOOTSTRAP (IMS 740)
 COPYRIGHT (C) 1982, SOFTWARE 2000, INC.

```

002C' 21 0035' LXI H,XFRCOD ;GET TRANSFER CODE
002F' 01 0006 LXI B,XFRLEN ;GET TRANSFER CODE LENGTH
0032' EDB0 LDIR ;MOVE TRANSFER CODE TO DMA ADDRESS
0034' C9 RET ;TRANSFER TO TRANSFER CODE

0035' F3 XFRCOD: DI ;DISABLE INTERRUPTS
0036' 3EB0 MVI A,OB0H ;GET PIO B DATA BYTE
0038' D325 OUT PIOBDR ;DISABLE BOOTSTRAP EPROM
003A' C9 RET ;DONE

0006 XFRLEN = .-XFRCOD ;TRANSFER CODE LENGTH

003B' CD 0046' RCV740: CALL INBYT ;INPUT BYTE
003E' 77 MOV M,A ;SAVE BYTE IN MESSAGE
003F' 23 INX H
0040' 1B DCX D ;DECREMENT COUNT
0041' 7A MOV A,D
0042' B3 ORA E ;COUNT=0?
0043' 20F6 JRNZ RCV740 ;IF NOT, CONTINUE
0045' C9 RET ;ELSE, DONE

0046' DB24 INBYT: IN PIOADR ;GET PIO A DATA REGISTER
0048' CB77 BIT PORTC7,A ;PORT C BIT 7 SET? (OBF)
004A' 20FA JRNZ INBYT ;IF NOT, WAIT
004C' DB20 IN PORTAD ;INPUT BYTE FROM PORT A
004E' C9 RET ;DONE

0000' .END SPBOOT

```

