

TEXAS INSTRUMENTS

Improving Man's Effectiveness Through Electronics

Model 990/4 Computer System Field Maintenance Manual

MANUAL NO. 945401-9701
ORIGINAL ISSUE 15 JULY 1976
INCLUDES
CHANGE 1 1 APRIL 1977
CHANGE 2 1 APRIL 1979

Digital Systems Division



The information and/or drawings set forth in this document and all rights in and to inventions disclosed herein and patents which might be granted thereon disclosing or employing the materials, methods, techniques or apparatus described herein are the exclusive property of Texas Instruments Incorporated.

INSERT LATEST CHANGED PAGES DESTROY SUPERSEDED PAGES

LIST OF EFFECTIVE PAGES

Note: The portion of the text affected by the changes is indicated by a vertical bar in the outer margins of the page.

Model 990/4 Computer System Field Maintenance Manual (945401-9701)

Original Issue15 July 1976
 Change 1 1 April 1977 (ECN 419772)
 Change 2 1 April 1979 (ECN 449604)

Total number of pages in this publication is 172 consisting of the following:

| PAGE NO. | CHANGE NO. | PAGE NO. | CHANGE NO. | PAGE NO. | CHANGE NO. |
|-----------------|------------|-------------|------------|------------------------|------------|
| Cover | .2 | 1-31 | .1 | 5-1 - 5-12 | .0 |
| Effective Pages | .2 | 1-32 - 1-34 | .0 | 6-1 - 6-6 | .0 |
| iii - x | .1 | 1-35 - 1-38 | .1 | Appendix A Div | .0 |
| 1-1 | .1 | 1-39 | .0 | A-1 - A-6 | .0 |
| 1-2 | .0 | 1-40 | .1 | Appendix B Div | .0 |
| 1-3 - 1-8 | .1 | 1-41 - 1-46 | .0 | B-1 - B-2 | .0 |
| 1-9 | .0 | 1-47/1-48 | .1 | Appendix C Div | .0 |
| 1-10 | .1 | 1-49 - 1-52 | .0 | C-1 - C-4 | .0 |
| 1-11 | .0 | 2-1 - 2-2 | .0 | Appendix D Div | .0 |
| 1-12 - 1-13 | .1 | 2-3 - 2-4 | .1 | D-1 - D-10 | .0 |
| 1-14 - 1-16 | .0 | 2-5 - 2-16 | .0 | Appendix E Div | .0 |
| 1-17 | .2 | 3-1 - 3-3 | .0 | E-1 - E-4 | .0 |
| 1-18 | .0 | 3-4 | .1 | Alphabetical Index Div | .0 |
| 1-19 | .2 | 3-5 - 3-6 | .0 | Index-1 - Index-2 | .0 |
| 1-20 - 1-23 | .1 | 3-7 | .1 | User's Response | .0 |
| 1-24 - 1-27 | .0 | 4-1 | .0 | Business Reply | .0 |
| 1-28 | .1 | 4-2 | .1 | Cover Blank | .0 |
| 1-29 - 1-30 | .0 | 4-3 - 4-10 | .0 | Cover | .0 |



PREFACE

This manual provides field-level operation and maintenance information required to service the Texas Instruments Model 990/4 Microcomputer System. This manual is intended for use by trained Customer Service Engineers or other qualified maintenance personnel assigned to 990/4 field service support.

This manual contains a brief physical and functional description of the 990/4 system and describes all hardware options and system configurations. The manual also contains a description of the Model 990 Maintenance Unit used to load diagnostics and manually control a "down" system not equipped with a programmer panel or operable 733 ASR data terminal. Fault isolation procedures are also provided to permit rapid tracing of system malfunctions down to the replaceable logic board or cable (or replaceable IC level in some cases). Packaging and shipping instructions are also provided to permit safe shipment of the faulty board(s) back to the factory or other authorized depot maintenance facility where board repair is performed.

Field service instructions for the peripheral subsystems in the 990/4 Microcomputer System are covered in a separate manual entitled *Model 990 Computer Peripheral Equipment Field Maintenance Manual*.

This manual is organized into six major sections and four appendixes including:

- I. General Description – Provides an introduction to the Model 990/4 Microcomputer System; describes the physical construction of the system and covers the various hardware options and system configurations which are currently available.
- II. Field Service Test Equipment – Describes the 990 Maintenance Unit controls and indicators and provides test setup cabling diagrams for typical system installations. This section also lists the diagnostic tests that are currently available to support field maintenance and provides a list of recommended tools and test equipment.
- III. Maintenance – Provides preventive and corrective maintenance procedures for the 990/4 system. This section describes the procedures for installing jumper-wire options and custom ROMs on replacement boards prior to substituting a spare board for a faulty board.
- IV. Troubleshooting – Provides a systematic procedure for checking out a system and for tracing system malfunctions down to a replaceable subassembly. After the trouble has been isolated down to a replaceable unit, the unit is replaced in accordance with the instructions in Section III. The system checkout procedures in Section IV should then be repeated to ensure that the system is functioning properly.
- V. Troubleshooting Diagrams – Contains a collection of system-level diagrams useful in performing field maintenance fault isolation and repair on the 990/4 system. This section includes a block diagram of each board type used in the 990/4 microcomputer.
- VI. Packing and Shipping – Contains instructions for repacking faulty assemblies for shipment back to the factory or other authorized depot maintenance facility.



- A. Programming Reference Information — Provides a summary of 990 programming information required for field maintenance of the system.
- B. Interrupt Vector Table — Provides a tabular list of interrupt levels and vector locations.
- C. Device CRU Formats — Lists and describes the CRU formats associated with the card reader, TTY/EIA devices, and the 913 display system.
- D. Hexadecimal to Decimal Conversion Charts
- E. Scoping Loop Programs — Provides a collection of commonly used scoping loop programs which may be entered into program memory via the programmer's panel.

RELATED PUBLICATIONS

The following hardware, software and diagnostics publications are available to support programming, operation and maintenance of 990/4 systems:

PROGRAMMING. The following manual provides a detailed description of the instructions, the form and use of assembly language, plus programming conventions.

| Title | Part Number |
|--|-------------|
| <i>Model 990 Computer TMS 9900 Microprocessor Assembly Language Programmer's Guide</i> | 943441-9701 |

INSTALLATION AND OPERATION. The following series of manuals provide complete information to install and operate 990 peripheral devices including detailed unpacking, installation, operator controls and programming information.

| Title | Part Number |
|---|-------------|
| <i>Model 990 Computer Model 913 CRT Display Terminal Installation and Operation</i> | 943457-9701 |
| <i>Model 990 Computer Floppy Disc Installation and Operation Guide</i> | 945253-9701 |
| <i>Model 990/4 Program Development System Operation Guide</i> | 945254-9701 |
| <i>Model 990 Computer Prototyping System Operation Guide</i> | 945255-9701 |
| <i>Model 990 Computer PROM Programming Model Installation and Operation</i> | 945258-9701 |
| <i>Model 990 Computer 733 ASR/KSR Terminal Installation and Operation</i> | 945259-9701 |
| <i>Model 990 Computer Line Printer Installation and Operation</i> | 945261-9701 |



| Title | Part Number |
|--|-------------|
| <i>Model 990 Computer Card Reader Installation and Operation</i> | 945262-9701 |
| <i>Model 990 Computer Communications System Installation and Operation</i> | 945409-9701 |

HARDWARE. This manual presents a technical description of all hardware components in the processing unit. It includes interface descriptions, installation and operating instructions, electrical characteristics, and other essential data concerning the processor and associated chassis.

| Title | Part Number |
|--|-------------|
| <i>Model 990/4 Computer System Hardware Reference Manual</i> | 945251-9701 |

MAINTENANCE. The following manuals contain troubleshooting procedures for fault isolation to a replaceable assembly for each optional peripheral device. Also included are preventive maintenance requirements, disassembly, repair, and assembly instructions. These manuals are required for maintenance of any peripheral within the system.

| Title | Part Number |
|--|--------------|
| <i>Model 990 Computer Family Peripheral Equipment Field Maintenance Manual</i> | 945419-9701 |
| <i>Model 990 Computer Family Maintenance Drawings Volume I – Processors</i> | 945421-9701* |
| <i>Model 990 Computer Family Maintenance Drawings Volume II – Peripherals</i> | 945421-9702* |

*Manual common to both Field and Depot level maintenance

The following manuals are available to enable qualified personnel to repair (at the component level) the major assemblies.

| Title | Part Number |
|--|-------------|
| <i>Model 990/4 Computer System Depot Maintenance Manual</i> | 945403-9701 |
| <i>Model 990 Computer PROM Programming Module Depot Maintenance Manual</i> | 945405-9701 |
| <i>Model 990 Computer Model 913 CRT Display Terminal Depot Maintenance Manual</i> | 945406-9701 |
| <i>Model 990 Computer 16 Input/Output TTL Data Module Depot Maintenance Manual</i> | 945407-9701 |



| Title | Part Number |
|--|--------------------|
| <i>Model 990 Computer Full Duplex EIA Module Depot Maintenance Manual</i> | 945408-9701 |
| <i>Model 990 Computer 16 Input/Output EIA Data Module Depot Maintenance Manual</i> | 945415-9701 |
| <i>Model 990 Floppy Disc Depot Maintenance Manual</i> | 945418-9701 |
| <i>Model 990 Computer Family Maintenance Drawings Volume I – Processors</i> | 945421-9701* |
| <i>Model 990 Computer Family Maintenance Drawings Volume II – Peripherals</i> | 945421-9702* |

*Manual common to both Field and Depot level maintenance



TABLE OF CONTENTS

| Paragraph | Title | Page |
|---|---|------|
| SECTION I. GENERAL DESCRIPTION | | |
| 1.1 | General | 1-1 |
| 1.2 | 990/4 Microcomputer System Description | 1-1 |
| 1.2.1 | 990/4 Microcomputer | 1-1 |
| 1.2.2 | 990 I/O Expansion Chassis | 1-42 |
| SECTION II. FIELD SERVICE TEST EQUIPMENT | | |
| 2.1 | General | 2-1 |
| 2.2 | Tools, Test Equipment and Spares Required for Field Maintenance | 2-1 |
| 2.3 | 990 Maintenance Unit | 2-1 |
| 2.3.1 | Test Configurations | 2-2 |
| 2.3.2 | Operating Controls and Indicators | 2-7 |
| SECTION III. MAINTENANCE | | |
| 3.1 | General | 3-1 |
| 3.2 | Preventive Maintenance | 3-1 |
| 3.2.1 | Filter Removal/Replacement | 3-1 |
| 3.3 | Corrective Maintenance | 3-1 |
| 3.3.1 | Logic Board Removal and Replacement Procedures | 3-1 |
| 3.3.2 | Operator/Programmer Panel Removal and Replacement | 3-2 |
| 3.3.3 | Power Supply Removal and Replacement | 3-3 |
| 3.3.4 | IC Removal and Replacement | 3-9 |
| SECTION IV. TROUBLESHOOTING | | |
| 4.1 | General | 4-1 |
| 4.2 | Maintenance Philosophy | 4-1 |
| 4.2.1 | Disposition of Faulty Subassembly | 4-1 |
| 4.3 | Troubleshooting Procedures | 4-1 |
| SECTION V. TROUBLESHOOTING DIAGRAMS | | |
| 5.1 | General | 5-1 |
| SECTION VI. PACKING AND SHIPPING | | |
| 6.1 | General | 6-1 |
| 6.2 | Unpacking/Packing (6 and 13-slot Chassis) | 6-1 |
| 6.3 | Unpacking/Packing (OEM Chassis) | 6-5 |
| 6.4 | Board Packing/Unpacking | 6-6 |



APPENDIXES

| Appendix | Title | Page |
|----------|--|------|
| A | Programming Reference Data | A-1 |
| B | Interrupt Vector Table | B-1 |
| C | Device CRU Formats | C-1 |
| D | Hexadecimal to Decimal Conversion Charts | D-1 |
| E | Scoping Loop Programs | E-1 |

LIST OF ILLUSTRATIONS

| Figure | Title | Page |
|--------|--|------|
| 1-1 | Typical 990/4 Microcomputer System | 1-2 |
| 1-2 | 990/4 Microcomputer Assemblies and Subassemblies | 1-4 |
| 1-3 | 990/4 Board Level Organization | 1-5 |
| 1-4 | 990/4 Microcomputer Board, Functional Block Diagram | 1-7 |
| 1-5 | 990/4 Memory Map (General Purpose Computer Configuration) | 1-10 |
| 1-6 | Workspace Pointer and Registers | 1-11 |
| 1-7 | TMS 9900 Single-Bit CRU Address Development | 1-13 |
| 1-8 | TMS 9900 LDCR/STCR Data Transfer | 1-14 |
| 1-9 | 990/4 Microcomputer Board Options | 1-16 |
| 1-10 | 990/4 Microcomputer Board Standard Configurations | 1-17 |
| 1-11 | 990/4 Microcomputer Board ROM Loader Options | 1-19 |
| 1-12 | 990/4 Memory Expansion Board Options | 1-25 |
| 1-13 | EPROM Memory Module Options | 1-27 |
| 1-14 | System Interconnections, Simplified Diagram | 1-28 |
| 1-15 | Factory Prewired Chassis Configurations | 1-29 |
| 1-16 | Interrupt Jumper Wire Installation | 1-30 |
| 1-17 | Chassis Interrupt Jumper Plugs | 1-32 |
| 1-18 | Jumper Plug Daisy Chain Sample Connection | 1-33 |
| 1-19 | OEM Chassis External Connections | 1-34 |
| 1-20 | 990 Power System Schematic Diagram (6- and 13-slot Chassis) | 1-37 |
| 1-21 | Power Supply Assemblies and Subassemblies | 1-39 |
| 1-22 | TTY/EIA Module Options | 1-41 |
| 1-23 | Expansion Interrupt Vector Format | 1-42 |
| 1-24 | CRU Expansion Board Options | 1-43 |
| 1-25 | 990 Interrupt Paths, Simplified Diagram | 1-45 |
| 1-26 | CRU Expansion, Simplified Block Diagram | 1-47 |
| 1-27 | CRU Address Map for Standard Expansion Implementation Using 13-slot Chassis | 1-49 |
| 1-28 | CRU Buffer Board Options | 1-51 |
| 2-1 | Model 990 Maintenance Unit | 2-5 |
| 2-2 | Test Setup for System not Containing Operational 733 ASR Data Terminal | 2-6 |
| 2-3 | Alternate Test Setup Using Programmer Panel Only | 2-8 |
| 2-4 | Maintenance Unit Controls and Indicators | 2-9 |
| 2-5 | Cassette Tape Installation, Simplified Diagram | 2-13 |
| 2-6 | Diagnostic Load From Maintenance Unit, Flowchart | 2-14 |



LIST OF ILLUSTRATIONS (Continued)

| Figure | Title | Page |
|--------|---|------|
| 3-1 | 1A4S1 Switch Connections | 3-3 |
| 3-2 | Programmer/Operator Panel Cabling Diagram | 3-3 |
| 3-3 | IC Installation Diagram | 3-9 |
| 5-1 | OEM Chassis Backpanel Schematic | 5-3 |
| 5-2 | 6-slot Chassis Backpanel Schematic | 5-5 |
| 5-3 | 6-slot Chassis Wiring Diagram | 5-7 |
| 5-4 | 13-slot Chassis Backpanel Schematic | 5-9 |
| 5-5 | 13-slot Chassis Wiring Diagram | 5-11 |
| 5-6 | 990/4 Microcomputer Board Block Diagram | 5-13 |
| 5-7 | 990/4 Memory Expansion Board Block Diagram | 5-15 |
| 5-8 | CRU Expander Board Block Diagram | 5-16 |
| 5-9 | CRU Buffer Board Block Diagram | 5-17 |
| 5-10 | EPR0M Memory Module Block Diagram | 5-18 |
| 5-11 | Main Power Supply Board Block Diagram | 5-19 |
| 5-12 | Ac Power Converter Board Schematic Diagram | 5-21 |
| 5-13 | Standby Power Supply Board Block Diagram | 5-22 |
| 5-14 | Programmer Panel Block Diagram | 5-23 |
| 6-1 | Computer Shipping Packaging | 6-2 |
| 6-2 | Location of Chassis Shipping Pallet Mounting Screws | 6-4 |
| 6-3 | OEM Chassis Shipping Packaging | 6-6 |

LIST OF TABLES

| Table | Title | Page |
|-------|--|------|
| 1-1 | Dedicated Workspace Registers | 1-11 |
| 1-2 | CRU Interface Signals | 1-21 |
| 2-1 | Recommended Tools and Test Equipment for Field-Level Maintenance | 2-1 |
| 2-2 | 990/4 Diagnostic Tests | 2-2 |
| 2-3 | Field Replaceable Components for 990/4 System | 2-5 |
| 2-4 | Maintenance Unit Controls and Indicators | 2-10 |
| 3-1 | Summary of 990/4 Jumper Options | 3-4 |
| 4-1 | 990/4 Microcomputer System Checkout Procedures | 4-2 |
| 4-2 | 990/4 Microcomputer System Fault Isolation Procedures | 4-4 |
| 5-1 | Diagram Index | 5-1 |



SECTION I

GENERAL DESCRIPTION

1.1 GENERAL

This section provides a brief physical and functional description of the 990/4 Microcomputer System manufactured by Texas Instruments Incorporated, Austin, Texas. This section also describes the various system- and board-level options available with the 990/4 system.

1.2 990/4 MICROCOMPUTER SYSTEM DESCRIPTION

The 990/4 Microcomputer System is a modular data processing system (or general purpose hardware controller in some applications) which is constructed around the Texas Instruments Model 990/4 microcomputer and a wide range of supporting peripherals and controllers.

Typically, a system includes one or more 990/4 microcomputers, one or more (maximum of seven) 990 expansion chassis, and a combination of peripherals and terminals including:

- 911 CRT
- 913A video display terminals
- 733 ASR/KSR data terminals
- 745 KSR data terminals
- 804 card readers
- 306, 588, 2230, or 2260 line printers
- 990 floppy discs
- Customer-designed controllers
- Communications network

A simplified block diagram of a typical 990/4 Microcomputer System is shown in figure 1-1. The 990/4 microcomputer and the I/O expansion chassis are described in greater detail in the following paragraphs. For a description of the peripherals and data terminals, refer to the *Model 990 Peripheral Equipment Field Maintenance Manual*.

1.2.1 990/4 MICROCOMPUTER. The 990/4 microcomputer is a general-purpose computer available in three different chassis configurations with a wide-variety of optional memory boards, power supplies and I/O interface boards. Basically, the microcomputer consists of the following assemblies and subassemblies:

- 990/4 microcomputer board – Contains TMS 9900 microprocessor chip, two onboard memories including a 4K RAM and a 1K ROM/RAM and various microprocessor support functions such as clock generator, interrupt encoding logic and CRU interfacing logic.
- Optional 990/4 memory expansion board – Provides additional dynamic RAM memory in sizes ranging from 4K to 20K in 4K increments (factory expandable only).



945401-9701




Figure 1-1. 990/4 Microcomputer System



- Optional EPROM memory module – Contains erasable programmable read only memory (EPROM) in sizes ranging from 1K to 8K in 1K increments (field expandable).
- Optional CRU expansion board – Expands the I/O section of the 990/4 microcomputer board to accommodate up to seven additional I/O chassis.
- Optional I/O interface boards – Matches the interface requirements of the 990/4's serial I/O section (CRU) with the interface requirements of various peripherals and terminals in the system.
- Chassis – Houses the above described logic boards and contains built-in regulated power supplies, cooling fans and control panel for all configurations except the 3-slot OEM chassis.
- Optional standby power supplies

The 990/4 microcomputer assemblies and subassemblies are shown in figure 1-2. A simplified block diagram showing the board-level organization of the 990/4 microcomputer is provided in figure 1-3. A functional description of each of the major assemblies and subassemblies is presented in the following paragraphs.

1.2.1.1 990/4 Microcomputer Board. The 990/4 microcomputer board contains a TMS 9900 microprocessor chip and all necessary support functions such as on-board memory and clock circuits as found in a conventional minicomputer. The board functions include:

- Microprocessor
- Memory bus gating for external DMA controller
- 4-Phase clock generator
- 1K ROM/RAM memory (static RAM)
- 4K MOS RAM Memory (Dynamic RAM)
- Programmer panel interface logic
- CRU interface section (I/O interface)
- Interrupt latches and encoding logic
- Real time clock logic
- External instruction decode (LREX, RSET, IDLE, CKON and CKOF)
- Clock and reset fanout logic
- Load control logic

A functional block diagram of the 990/4 microcomputer board is shown in figure 1-4 and a functional description of the board is provided in the following paragraphs.




945401-9701

Change 1


1-4

Digital Systems Division



(A)135900 (990-576-14-4)


Figure 1-2. 990/4 Microcomputer Assemblies and Subassemblies



(B)133301

Figure 1-3. 990/4 Board Level Organization





(C) 133596

Figure 1-4. 990/4 Microcomputer Board, Functional Block Diagram



Microprocessor. The microprocessor function for the 990/4 microcomputer is provided by the TMS 9900 microprocessor chip. Basically, the chip contains all functions normally found in a minicomputer (with exception of memory which is implemented externally) plus such advanced features as memory-located workspace registers and a directly addressable memory address space of 32K 16-bit words.


The instruction set of the TMS 9900 allows both word and byte operands. Thus, all memory word locations are on even byte address boundaries. Byte instructions can address either the even or odd byte. The memory space is 65536 bytes or 32768 16-bit words.

The TMS 9900 employs an advanced memory-to-memory architecture whereby blocks of 16 memory words designated as workspace registers replace internal hardware registers as program data registers. The TMS 9900 memory map (general purpose computer configuration) is shown in figure 1-5. As shown in this figure, the first 32 words are used for interrupt trap vectors. The next contiguous block of 32 memory words is used by the extended operation (XOP) instruction for trap vectors. The last two memory words ($FFFC_{16}$ and $FFFE_{16}$) are used for the trap vector of the LOAD signal. The remaining memory is then available for programs, data, and workspace registers. If desired, any of the special areas may also be used as general memory.

Three internal registers are accessible to the user including the program counter, status register and workspace pointer register. The program counter (PC) contains the address of the instruction following the current instruction being executed. This address is used by the processor to fetch the next instruction from memory and is then automatically incremented to develop the address of the next instruction in memory. The status register (ST) contains the interrupt mask level and other status information pertaining to the instruction operation. Each bit in the register signifies a particular function or condition that exists in the microprocessor. Some instructions use the status register to check for a prerequisite condition, others affect the values of the bits in the register, and others load the entire status register with a new set of parameters. A description of the instruction set contained in the *Model 990 Computer Assembly Language Programmer's Guide* details the effect of each instruction on the status register.


The workspace pointer register (WP) contains the address of the first word in the currently active set of workspace registers. A workspace register file occupies 16 contiguous memory words in the general memory area as shown in figure 1-6. Each workspace register may be used for data storage or function as operand registers, accumulators, address registers, or index registers. Some workspace registers take on special significance during execution of certain instructions as described in table 1-1. During instruction execution, the processor addresses any of the 16 workspace registers assigned to the program currently being executed by adding the register number to the contents of the workspace pointer as shown in figure 1-6.

The workspace concept is particularly valuable during operations that require a context switch (a change from one program to another or to a subroutine, as in the case of an interrupt). For example, a context switch operation using a conventional multiregister arrangement would require numerous memory cycles to store and reload the contents of the register file. However, in the 990/4 the context switch is accomplished with only three store and three fetch cycles which results in exchanging the contents of the program counter, status register, and workspace pointer. After the switch, the workspace pointer in the microprocessor contains the starting address of a new 16-word workspace in memory for use with the new routine and the contents of the WP, PC, and ST registers from the previous routine are saved in workspace registers 13, 14, and 15, of the new workspace. The data and addresses in the remaining 12 registers of the



(A)133330

Figure 1-5. 990/4 Memory Map (General Purpose Computer Configuration)



(A)133119

Figure 1-6. Workspace Pointer and Registers

Table 1-1. Dedicated Workspace Registers

| Register No. | Contents | Used During |
|--------------|------------------------|--|
| 0 | Shift count (optional) | Shift instructions (SLA, SRA, SRC and SRL) |
| 11 | Return address | Branch and Link (BL) instruction |
| | Effective address | Software implemented Extended Operation (XOP) |
| 12 | CRU base address | CRU instructions (SBO, SBZ, TB, LDCR, and STCR) |
| 13 | Saved WP register | Context switching (BLWP, RTWP, software XOP, recognized interrupt, LOAD and RESET) |
| 14 | Saved PC register | Same as above |
| 15 | Saved ST register | Same as above |



original workspace remain in memory until a switch is made back to the original program. A corresponding saving in time occurs when the original context is restored. The instructions in the microprocessor that result in a context switch include:

- Branch and Load Workspace Pointer (BLWP)
- Return from Subroutine (RTWP)
- Extended Operation (XOP)

Device interrupts, RESET— from the power supply, and LOAD— from the front panel (or LOAD external instruction from the 990/4 board) also cause a context switch by forcing the microprocessor to trap a service subroutine.

The TMS 9900 microprocessor can accommodate up to 16 interrupt levels (0 to 15) but only 8 levels are in the 990/4 configuration. Level 0 is the highest priority and is reserved for the RESET— function. Level 7 is assigned the lowest priority. Interrupt levels 1 through 7 are used for events external to the TMS 9900. Anytime power is applied to the system, the microprocessor continuously compares the interrupt code (IC0 through IC3) with the interrupt mask contained in status register bits 12 through 15. When the level of the pending interrupt is less than or equal to the enabling mask level (higher or equal priority interrupt), the microprocessor recognizes the interrupt and initiates a context switch following completion of the currently executing instruction. The processor fetches the new context WP and PC from the interrupt vector locations. Then, the previous context WP, PC, and ST are stored in workspace registers 13, 14, and 15 of the new workspace. The microprocessor then forces the interrupt mask to a value that is one less than the level of the interrupt being serviced, except for level 0 interrupt that loads 0 into the mask. This allows only interrupts of higher priority to interrupt a service routine. The microprocessor also inhibits interrupts until the first instruction of the service routine has been executed so that program linkage is preserved should a higher priority interrupt occur. All interrupt requests must remain active until recognized by the microprocessor and the device- service routine. The individual service routines then reset the interrupt requests before the routine is complete. If a higher priority interrupt occurs, a second context switch is made to service the higher priority interrupt. When that routine is complete, a return instruction (RTWP) restores the first service routine parameters to the processor to complete processing of the lower priority interrupt. All interrupt subroutines normally terminate with the return instruction which restores original program parameters.

The TMS 9900 microprocessor uses a versatile direct command-driven I/O interface designated as the Communications Register Unit (CRU). The CRU provides up to 4096 directly addressable input bits and 4096 directly addressable output bits. Both input and output bits can be addressed individually or in fields of 1 to 16 bits. The microprocessor employs three dedicated I/O pins (CRUIN, CRUOUT, and CRUCLK) and 12 bits (A3 through A14) of the address bus at the interface to the CRU system. The microprocessor instructions that drive the CRU interface can set, reset, or test any bit in the CRU array or move data between memory and CRU data fields.

Because of its flexible data format, the CRU interface is used for a wide range of control and data transaction operations. These applications may be divided into two broad categories: those involving a single control bit transfer, and those requiring input or output of several data or status bits.




The microprocessor instruction set includes three single-bit CRU instructions: test bit (TB), set bit to one (SBO), and set bit to zero (SBZ). To identify the bit to be operated upon, the microprocessor develops a CRU-bit address and places it on the address bus, A3 to A14.

For the two output operations (SBO and SBZ), the microprocessor generates a CRUCLK pulse and places bit 7 of the instruction word on the CRUOUT line to accomplish the specified operation (bit 7 is a ONE for SBO and a ZERO for SBZ). The test bit instruction is an input operation that transfers the addressed CRU bit from CRUIN input line to bit 2 (equal bit) of the status register.

The microprocessor develops the CRU-bit address for the single-bit operations using the CRU base address in workspace register 12 (W12) and the signed displacement field (bits 8 through 15) of the instruction. The displacement allows two's complement addressing from base minus 128 bits through base plus 127 bits. The base address from W12 is added to the signed displacement specified in the instruction and the result is loaded onto the address bus. Figure 1-7 illustrates the development of a single-bit CRU address.

The microprocessor also performs two multiple-bit CRU operations: store communications register (STCR) and load communications register (LDCR). Both operations perform a data transfer from the CRU-to-memory or from memory-to-CRU as illustrated in figure 1-8. Although the figure shows a full 16-bit transfer operation, any number of bits from 1 to 16 may be involved. The LDCR instruction fetches a word from memory and executes a series of right-shifts to serially transfer the word to the CRU device via the CRUBITOUT data line. If the LDCR involves 8 or fewer bits, those bits come from the right-justified field within the addressed byte of the memory word. If the LDCR involves 9 or more bits, those bits come from the



(A)133120

Figure 1-7. TMS 9900 Single-Bit CRU Address Development




Figure 1-8. TMS 9900 LDCR/STCR Data Transfer

right-justified field within the whole memory word. As the bits are transferred to the CRU interface, the CRU address is incremented for each successive bit. This addressing mechanism results in an order reversal of the bits; that is, bit 15 of the memory word (or bit 7) becomes the lowest addressed bit in the CRU and bit 0 becomes the highest addressed bit in the CRU field.

An STCR instruction transfers data from the CRU to memory. If the operation involves the transfer of 8-bits or less, the transferred data will be stored right-justified in the memory byte with leading bits set to zero. If the operation involves 9 to 16 bits, the transferred data is stored right-justified in the memory word with leading bits set to zero. When the input from the CRU device is complete, the first bit from the CRU is in the least significant bit position in the memory word or byte.

The TMS 9900 also contains a 16-bit parallel memory bus interface which is to access the ROM and RAM memories in the 990/4 system. The address bus portion of the memory interface (AB 0-14) is shared by the CRU interface. To distinguish between CRU addresses and memory addresses, the TMS 9900 generates a memory enable signal for each memory cycle.

Memory Bus Gating for External Controller. The 990/4 microcomputer board contains a number of tri-state drivers (and associated control logic) which permit external direct memory access (DMA) controllers to share the full 32K memory address space with the TMS 9900 microprocessor.



During normal operation, all memory transfers are controlled by the TMS 9900. However, an external controller may gain access to any of the 32K address space by generating an active HOLD signal. In response to this signal, the TMS 9900 sends back a HOLDA (hold acknowledge) signal which is used on the 990/4 board to gate the memory bus tri-state drivers to/from the microprocessor to the high impedance state. The hold acknowledge also informs the controller that it has access to memory. After completion of the direct memory access, the controller relinquishes memory to the microprocessor by deactivating the HOLD line to the TMS 9900. As a result, hold acknowledge goes away and the microprocessor's memory bus lines are activated once more.

4K Dynamic RAM. The "dash 2" configuration of the 990/4 microcomputer board is equipped with a 4K onboard dynamic RAM memory which is used for data and program storage. This memory is implemented with 16 TMS 4051 4096 \times 1-bit RAM memory chips. In a standard system, this memory is assigned a starting address of 0000_{16} by a jumper between terminals E16 and E17 (see figure 1-9). Optionally, the starting address can also be set to 2000_{16} (4K boundary) by placing the jumper between E16 and E18. The onboard RAM memory occupies a contiguous block of 4K addresses beginning with the selected starting address.


The operation of the 4K RAM memory is as follows. Each time a Memory Enable signal is generated by either the TMS 9900 (or by an external controller), the addressing logic associated with the 4K RAM examines the memory address on the address lines. If the address is below or above the address assigned to the 4K RAM, the 4K RAM ignores the memory cycle. However, if the address falls within the RAM's address space, a 4K address OK is generated which permits a fetch or store cycle at the specified address.

A factory-installed parity option is also available with the 4K RAM which includes a 17th TMS 4051 RAM chip in the U74 slot (see figure 1-5) and two SN74180 parity generator/checker ICs which are installed in slots U43 and U81. This option results in a parity bit being generated and stored with each write data word. During subsequent read cycles at the same address, new parity bits are generated for the read data word and compared with the parity bit previously stored during the write cycle. If an error is detected, a memory error interrupt is generated which normally is wired to interrupt level 2 on the 990/4 board (jumper between terminals E13 and E14).

1K ROM/Static RAM. The 1K ROM/RAM memory section is normally used for loader ROMs, self-test ROMs and the programmer panel software ROMs plus any special-purpose programs whose high-usage merits placing the programs on custom ROMs. The ROMs used in this section are SN74S287 256 \times 1-bit programmable ROMs. This section may also be converted to RAM storage (in 256 word blocks) using TMS 4043 256 by 4-bit RAM chips.


Functionally, the 1K ROM/RAM section consists of 4, 256-word banks (bank 0 through bank 3). Each bank consists of 4 ROM or 4 RAM chips (a given bank must contain all ROM or all RAM chips) placed in a vertical column as shown in figure 1-9. Bank 0 is the left-most column (U37, U53, U59 and U76) and bank 3 is the right-most column. Jumper wires must be installed across the two terminals which correspond to a memory bank equipped with ROM memory. No jumpers are required for banks containing RAM memory.

In the standard "dash 1" configuration of the 990/4 microcomputer board, bank 3 comes factory equipped with TMS 4043 static RAM chips (figure 1-10) and the jumper between terminals E1 and E2 is clipped. The remaining three banks may contain any combination of ROM or RAM memory as long as all four chips in a given bank are the same type. Similarly, jumper wires must be installed for each bank containing ROM memory as shown in figure 1-9.




(B)133597

Figure 1-9. 990/4 Microcomputer Board Options



(A) MACHINE CONTROLLER CONFIGURATION (944910-1)



(B) GENERAL PURPOSE COMPUTER CONFIGURATION (944910-2)

(B)133342

Figure 1-10. 990/4 Microcomputer Board Standard Configurations



In the standard “dash 2” configuration, a set of 8 special purpose ROMs are installed in banks 2 and 3 as shown in figure 1-10. These ROMs contain the 733 ROM loader, programmer panel software and the self-test routine. Other optional ROM sets are also identified in figure 1-11. In addition to these special-purpose ROMs, the user may also install custom ROMs which may be identified by the absence of part numbers or part numbers different from those listed in figure 1-11.


CAUTION

When replacing a 990/4 microcomputer board in a system, these custom ROMs must always be transferred to the replacement board in the exact same locations.

Load Control Logic. The load control logic on the 990/4 microcomputer board generates a LOAD signal which causes the TMS 9900 to trap to memory location FFFC under the following conditions:

- When power is initially applied to the chassis (if the jumper is installed between terminals E21 and E22). If the jumper is installed between terminals E22 to E27, the LOAD signal is inhibited and the microprocessor traps to memory location 0000 when the power reset (TLPRES–) occurs.
- When the programmer panel is in the RUN mode (RUN LED lit), the key switch is in the UNLOCK position and the HALT/SIE switch is pressed on the panel. This results in a RESTART signal being generated by the panel which causes the load control logic on the 990/4 board to generate a load signal. The same signal is generated by the operator panel when the key switch is set to the LOAD position.
- When the panel is in the HALT mode and the HALT/SIE switch is pressed on the programmer panel, the panel software utility executes an SBO instruction which is decoded on the 990/4 board to generate an SIECLK– (single instruction clock). After one user instruction is executed, the load control logic generates a LOAD signal resulting in another trap to memory location FFFC.
- When an LREX external instruction is decoded. This instruction permits software to initiate a load when location FFFC contains the loader program vector.

In the standard configuration, memory location FFFC contains the workspace pointer (WP) value for the panel software and the next memory location (FFFE) contains the associated program counter (PC) value for the panel software. For systems not equipped with a programmer panel, locations FFFC and FFFE contain the WP and PC values for the loader ROM.



| ROM KIT PART NO. | DESCRIPTION | ROM PART NO.'S | | | | | | | |
|------------------|---|----------------|-----------|-----------|-----------|----------|-----------|-----------|-----------|
| | | U40 | U56 | U62 | U79 | U39 | U55 | U61 | U78 |
| 945121-1 | 733 ASR/CARD READER ROM LOADER | 945191-7 | 945191-8 | 945191-9 | 945191-10 | - | - | - | - |
| 945121-2 | 733 ASR/CARD READER LOADER WITH SELF TEST | 945191-1 | 945191-2 | 945191-3 | 945191-4 | 945192-1 | 945192-2 | 945192-3 | 945192-4 |
| 945121-3 | FLOPPY DISC LOADER | 945190-7 | 945190-8 | 945190-9 | 945190-10 | - | - | - | - |
| 945121-4 | FLOPPY DISC LOADER WITH SELF TEST | 945190-1 | 945190-2 | 945190-3 | 945190-4 | 945192-1 | 945192-2 | 945192-3 | 945192-4 |
| 945121-5 | 733 ASR ROM LOADER WITH SELF TEST (PROTOTYPING) | 945191-13 | 945191-14 | 945191-15 | 945191-16 | 945192-9 | 945192-10 | 945192-11 | 945192-12 |

(B)133598

Figure 1-11. 990/4 Microcomputer Board ROM Loader Options



External Instruction Decode. The TMS 9900 contains provisions for five external instructions which result in “NO OPS” internal to the chip. These instructions include:

- IDLE – Causes the programmer interface logic on the 990/4 board to send a signal to the programmer panel which lights the IDLE LED on the panel indicating microprocessor inactivity.
- RSET – Results in a system reset signal (IORES–) being sent out to all boards in the system and causes the FAULT LED on the programmer panel to be reset.
- CKON/CKOF – These two instructions are used to enable and reset the real time clock interrupt circuit.
- LREX – This instruction is decoded on the 990/4 board and sent to the load control logic to generate a LOAD signal.

Real Time Clock Logic. The real time clock logic receives a 120 Hz pulse train continuously from the main power supply board. Software makes use of these pulses to generate interrupts by executing a sequence of CKON and CKOF external instructions. A CKON instruction enables the real time clock logic and an interrupt is generated when the next clock pulse is received from the power supply. The interrupt is reset by a CKOF instruction. To enable another interrupt, the software must issue another CKON instruction and then reset that interrupt with a CKOF instruction.

As shown in figure 1-9, the real time clock interrupts may be connected to either interrupt level 5 or interrupt level 7 using terminals E9, E10, and E23. Interrupt level 5 is selected when the jumper is installed between E9 and E10 (standard jumper configuration) and interrupt level 7 is selected when the jumper is installed between E10 and E23. If no jumper is installed, the real time clock interrupts are disabled.

Programmer Panel Interface Logic. The programmer panel interface logic provides an interface between the TMS 9900 microprocessor and the programmer panel. This section generates a module select for the programmer panel whenever a CRU transfer is addressed to the panel and permits 990 software to light the FAULT, RUN and IDLE LEDs on the programmer panel. This logic also skews the memory address bits 11 to 14 to develop CRU address bits 12-15. These address bits are used in the programmer panel to select one of 16 possible input data sources during a serial transfer from the panel to the CPU or to specify a command type to the panel during a CPU to panel transfer (e.g., start debounce timer or enable switch scanner logic).

The programmer panel interface also fans out a store clock and the serial output data line (CRUBITOUT) to the panel and buffers the power on reset signal from the power supply to light the POWER LED when the reset signal goes away.

CRU Interface Logic. The CRU interface logic monitors addresses on the memory address lines during nonmemory transfers (memory enable not present) and decodes CRU addresses between 000_{16} and $17F_{16}$ to generate a low-active signal on one of 24 module select lines (each P1 slot receives one module select line and each P2 slot receives 2 module select lines as listed in table 1-2). For a 6-slot chassis, software ensures that the highest CRU base address for the main chassis is limited to $09F_{16}$ which results in 1 of 12 module select lines going low. In order for a given interface board to respond to a CRU address, its module select line must be active. All other boards ignore the CRU address. The CRU interface logic also fans out memory address lines 03-14 as CRU address lines 04-15.



Table 1-2. CRU Interface Signals

| Signature | CRU Addr | 990/4 Circuit Board Pin Number | Main or Expansion Chassis Backpanel Pin Number | Function |
|--|----------------|--------------------------------|--|---|
| MODSEL0- | 000 | P1-23 | Slot 13, P2-48 | Module select signals generated by the microprocessor from address bits 7-11 (CRUBITS 8-11) for use within the main or an expansion chassis. Note that P1 in each slot of the backpanel receives one module select signal whereas P2 receives two module select signals. This configuration permits P2 to use 32 bits of the CRU. Note that pin 48 of successive P2 connectors in the chassis slots are connected to even-numbered module select signals and at the CRU circuit board level carries a MODSELA- signature. Pin 46 of successive P2 connectors in the chassis slots are connected to pin 48 of P1 of that slot and then to an odd-numbered module select signal and carries a signature of MODSELB-. Pin P1-48 is not used when a full-sized CRU circuit board is implemented in a chassis slot. MODSEL signal lines will drive 10 TTL loads. |
| MODSEL1- | 020 | P1-35 | Slot 13, P1-48 and P2-46 | |
| MODSEL2- | 040 | P1-37 | Slot 12, P2-48 | |
| MODSEL3- | 060 | P1-43 | Slot 12, P1-48 and P2-46 | |
| MODSEL4- | 080 | P1-44 | Slot 11, P2-48 | |
| MODSEL5- | 0A0 | P1-45 | Slot 11, P1-48 and P2-46 | |
| MODSEL6- | 0C0 | P1-46 | Slot 10, P2-48 | |
| MODSEL7- | 0E0 | P1-47 | Slot 10, P1-48 and P2-46 | |
| MODSEL8- | 100 | P1-48 | Slot 9, P2-48 | |
| MODSEL9- | 120 | P1-49 | Slot 9, P1-48 and P2-46 | |
| MODSEL10- | 140 | P1-51 | Slot 8, P2-48 | |
| MODSEL11- | 160 | P1-53 | Slot 8, P1-48 and P2-46 | |
| MODSEL12- | 180 | P1-61 | Slot 7, P2-48 | |
| MODSEL13- | 1A0 | P1-67 | Slot 7, P1-48 and P2-46 | |
| MODSEL14- | 1C0 | P1-69 | Slot 6, P2-48 | |
| MODSEL15- | 1E0 | P1-76 | Slot 6, P1-48 and P2-46 | |
| MODSEL16- | 200 | P2-38 | Slot 5, P2-48 | |
| MODSEL17- | 220 | P2-36 | Slot 5, P1-48 and P2-46 | |
| MODSEL18- | 240 | P2-34 | Slot 4, P2-48 | |
| MODSEL19- | 260 | P2-32 | Slot 4, P1-48 and P2-46 | |
| MODSEL20- | 280 | P2-22 | Slot 3, P2-48 | |
| MODSEL21- | 2A0 | P2-18 | Slot 3, P1-48 and P2-46 | |
| MODSEL22- | 2C0 | P2-16 | Slot 2, P2-48 | |
| MODSEL23- | 2E0 | P2-13 | Slot 2, P1-48 and P2-46 | |
| CRUBIT4 } CRUBIT5 } CRUBIT6 } CRUBIT7 } CRUBIT8 } CRUBIT9 } CRUBIT10 } CRUBIT11 } | Chassis Select | P1-56 | P1-56 | Address bit generated by the microprocessor to select a particular chassis (bits 4-6), a 16-bit module within that chassis (bits 7-11), and a particular bit from that module (bits 12-15). CRUBITS 4-11 are capable of driving at least 12 normalized TTL loads, CRUBITS 12-15 are capable of driving 30 normalized TTL loads. |
| CRUBIT12 } CRUBIT13 } | | P/O Bit Select | P1-54 | |
| | | | P1-52 | |
| | | P1-50 | P1-50 | |
| | | P1-62 | P1-62 | |
| | | P1-64 | P1-64 | |
| | | P1-68 | P1-68 | |
| | | P1-70 | P1-70 | |
| | | P1-36 | P1-36, P2-36 | |
| | | P1-32 | P1-32, P2-32 | |



Table 1-2. CRU Interface Signals (Continued)

| Signature | 990/4 Circuit Board Pin Number | Main or Expansion Chassis Backpanel Pin Number | Function |
|-------------------|--------------------------------|--|---|
| CRUBIT14) P/O Bit | P1-38 | P1-38, P2-38 | Serial data line for transfer of data from the microprocessor to the addressed CRU bit(s). This line is active only when STORECLK- goes low. (This line will drive 30 normalized TTL loads.) |
| CRUBIT15) Select | P1-34 | P1-34, P2-34 | |
| CRUBITOUT | P1-18 | P1-18, P2-18 | |
| CRUBITIN | P1-60 | P1-60, P2-60 | Serial data line for transfer of data from the addressed CRU bit(s) to the microprocessor. This line must be driven by an open collector gate and only when the module is selected. A 470-ohm pull-up resistor is mounted on the 990/4 circuit board for this line. |
| STORECLK- | P1-22 | P1-22, P2-22 | An active-when-low pulse that indicates to the selected CRU module that the operation is a write (Set Bit or LDCR) operation. This pulse transfers the data on the CRUBITOUT line into a holding flip-flop that is the CRU bit. (Will drive 30 TTL loads.) |
| TLIORES- | P1-14 | P1-14, P2-14 | I/O Reset: A normally high signal that, when low, resets all connected devices. This signal is a minimum 250 nanoseconds pulse that is generated by a RSET instruction in the microprocessor. This signal is also low until dc power is up and stable. (Will drive 30 TTL loads.) |
| TLPFWP- | P1-16 | P1-16, P2-16 | Power Failure Warning Pulse: A low signal of at least 7.0 milliseconds duration that indicates that a power failure is imminent. (Will drive 30 TTL loads.) |
| TLPRES- | P1-13 | P1-13, P2-13 | Power Reset: A normally high signal that goes low to reset connected devices at least 10 microseconds before dc voltages begin to fail during power down. |



In addition, the CRU interface logic provides buffering for the CRU Store Clock, CRUBITOUT and CRUBITIN lines used to transfer serial data between an interface board (or write protect circuit on the 990/4 memory expansion board) and the microprocessor.

Interrupt Encoder Logic. The 990/4 microcomputer board contains a 7-bit interrupt register and an interrupt encoder circuit used for processing of onboard and external interrupts. These circuits provide for temporary storage of interrupts received from the half-board slots in the chassis (via the jumper plugs on the backpanel board) and from certain onboard interrupt conditions and generate a 4-bit interrupt code corresponding to the highest priority interrupt present. Interrupt level 1 is the highest priority interrupt external to the TMS 9900 (interrupt level 0 is assigned to the power on RESET signal). Level 7 is assigned the lowest priority level.

All on-board interrupt signals are connected to selected interrupt levels through jumper wires on the 990/4 board as shown in figure 1-9.

The onboard interrupt options include:

- Power failure warning – May be connected to interrupt level 1 via a jumper between E11 and E12.
- Memory error interrupt – May be connected to interrupt level 2 by means of jumper between E13 and E14.
- Real time clock interrupt – May connect to interrupt level 5 (jumper between E9 and E10) or interrupt level 7 (jumper between E10 and E23).

4-Phase Clock Generator. The 4-phase clocks, used to synchronize all TMS 9900 internal operations and all memory operations, are developed by a crystal-controlled oscillator on the 990/4 microcomputer board. Each of the 4-phase clocks (which are designated I1 through I4) are approximately 60 nanoseconds wide and have a cycle time of 333 nanoseconds.

Clock and Reset Fanout. The 990/4 board contains provisions for fanning out the “bar” phase 1 and “bar” phase 3 clocks (CLK1– and CLK3–) which are used to synchronize operations on all memory boards and DMA-type controllers. The power on reset (TLPRES–) from the power supply board is ORed with the reset generated by the execution of an RSET external instruction and fanned out to all boards in the system as IORES–. This signal initializes all control circuits and resets all interrupt flip-flops.

1.2.1.2 990/4 Memory Expansion Board. The 990/4 memory expansion board provides additional dynamic RAM memory space in 4K increments ranging from 4K to 20K (factory installed only). Other factory options include the parity option and the write protect option.

Parity Option. The parity option is a factory installed option that consists of a parity error LED on the top edge of the board, a 17th memory chip in each implemented memory bank (A16U1 through A16U4), parity generator/checker ICs (SN74180s), and a parity error flip-flop. When implemented, this section develops and stores a parity bit with each 16-bit data word. During a subsequent read cycle at the same memory location, the parity generator/checker circuits develop a new parity bit and compare this bit against the parity bit read from memory. In the event of a data error, the logic generates a memory error signal which is ORed with the memory error signal from the 990/4 microcomputer board’s 4K RAM memory to develop the memory error interrupt. A parity error also lights the LED on the memory board. This LED may be manually cleared using switch bit 1 on U37 or by a system reset signal IORES– from the 990/4 microcomputer board.



Write Protect Option. The 990/4 memory expansion board may also be equipped with an optional (factory installed) write protect circuit which may be used to prevent write cycles into software specified memory areas. The protected area is defined by a 16-bit vector (protect mode bit and upper and lower bounds of the protected area) sent from the TMS 9900 to the write protect's bounds register via a load CRU instruction. The 16-bit vector is transferred to the memory board via a standard CRU interface. In the event that a write cycle is attempted in a protected memory location, the write cycle is inhibited, the protect violate (PV) flip-flop is set, and an interrupt is generated. Software may then read the contents of the PV flip-flop through a store CRU instruction or reset the flip-flop via an SBO CRU instruction.

If the write protect option is *not* installed on the 990/4 memory expansion board, a jumper wire must be installed between terminals E7 and E8.

If a system is equipped with two memory expansion boards, only one of the boards may be equipped with write protect. However, the board with the write protect feature can detect attempted writes into protected areas on the second board and generate an interrupt although the write cycle will be permitted.

Memory Bank Organization. The memory section, implemented on the 990/4 memory expansion board, is organized into 4K banks as shown in figure 1-12. Bank 0 is the uppermost bank and bank 4 is the lowermost bank. Each 4K bank is implemented with 16 TMS 4050 4096 \times 1-bit random access memory chips (plus an optional parity storage chip). All bit 0s are stored in the leftmost memory chip in each bank and all subsequent bit positions are arranged in numerical order from left to right. In addition, all similar bit positions (e.g., all bit 0s) in all banks are wire-ORed together. Therefore, a bit failure which shows up in one of the memory banks could actually be caused by a chip in the same bit position in one of the other banks.

Starting Address Option. The starting address of the memory expansion board may be set to any 4K boundary from 0 to 28K in the 990/4's 32K address space using the miniature switches S2 through S4 in the DIP switch package in U37 (see figure 1-12). These switches are set up in binary fashion with S2 being the MSB and S4 being the LSB. The starting address settings include:

| Address Boundary (Decimal and Hex Byte Addresses) | S2 | S3 | S4 |
|--|-----|-----|-----|
| 0 (0000 ₁₆) | off | off | off |
| 4K (2000 ₁₆) | off | off | on |
| 8K (4000 ₁₆) | off | on | off |
| 12K (6000 ₁₆) | off | on | on |
| 16K (8000 ₁₆) | on | off | off |
| 20K (A000 ₁₆) | on | off | on |
| 24K (C000 ₁₆) | on | on | off |
| 28K (E000 ₁₆) | on | on | on |



945401-9701




Figure 1-12. 990/4 Memory Expansion Board Options



Memory Size Jumper Options. The amount of memory implemented on the memory expansion board must be encoded using jumpers in terminals E1 through E6 as follows:

| Memory Size | Required Jumpers |
|-------------|--------------------|
| 4K | none |
| 8K | E1 to E2 |
| 12K | E3 to E4 |
| 16K | E1 to E2, E3 to E4 |
| 20K | E5 to E6 |

1.2.1.3 EPROM Memory Module. The EPROM memory module is an optional memory board with IC sockets and associated control circuitry to accommodate from 1K to 8K (field expandable) of erasable programmable read-only-memory (EPROM). This memory is implemented with INTEL 2708 1024 × 4-bit EPROM ICs. Two memory chips are required for each 1K memory bank. As shown in figure 1-13, a maximum of 8 memory banks may be installed on the board with the leftmost column identified as bank 0 and the rightmost vertical column of two chips being bank 7.

The board jumper options are briefly described in the following subparagraphs.

Computer Type ID Jumper. The 990 EPROM memory module may be used in either a 990/4 or 990/10 computer. For use in a 990/4 chassis, a jumper wire must be installed between terminals E11 and E12 (E10 to E11 designates 990/10 chassis).

Starting Memory Address Bias. The starting address of the EPROM memory module may be placed at any 1K boundary in the 990/4's 32K address space between 0 and 31K as controlled by the five switch positions on DIP switch S2. Switch bit 1 is the MSB and switch bit 5 is the LSB. To select a starting address, the switches are set up in straight binary fashion with a switch in the "on" position designating a logic 1 and a switch in the "off" position designating a logic 0. For example, a starting address at 0 would be set up with all five switches in the off position; a starting address at 1K would have only switch 5 set to the on position and all others set to the off position; and a starting address of 31K would have all five switch bits set to the on position.

Memory Size Jumpers. A group of 9 terminals (E1 through E9) are used to encode the amount of memory implemented on the board (1K to 8K). These jumpers are set up as follows:

| Memory Size | Jumper Connections |
|-------------|---------------------|
| 1K | E1-E2, E4-E5, E7-E8 |
| 2K | E1-E2, E4-E5, E8-E9 |
| 3K | E1-E2, E5-E6, E7-E8 |
| 4K | E1-E2, E5-E6, E8-E9 |
| 5K | E2-E3, E4-E5, E7-E8 |
| 6K | E2-E3, E4-E5, E8-E9 |
| 7K | E2-E3, E5-E6, E7-E8 |
| 8K | E2-E3, E5-E6, E8-E9 |



945401-9701





Figure 1-13. EPROM Memory Module Options



1.2.1.4 990/4 Chassis. The 990/4 microcomputer may be housed in one of three chassis types including:

- 3-Slot OEM chassis (requires external power supply and cooling)
- 6-Slot chassis – Contains built-in 20 amp power supply and optional standby supply for semiconductor memory protection during power failure conditions; also contains either programmer or operator panel for system control.
- 13-Slot chassis – Contains built-in 40 amp or 20 amp main power supply, optional standby power supply and either a programmer or operator panel. This chassis is basically the same as the 6-slot chassis except that it contains provisions for additional full-size logic boards.

6- and 13-Slot Chassis Interconnections. All internal connections (with exception of the ac distribution circuits) are accomplished through the connectors and the etch wiring on the backpanel board. Interconnections between each peripheral or data terminal and the computer is accomplished by an interface cable which connects to the top edge of its dedicated interface board (see figure 1-14) in the main computer chassis. In general, the 990/4 microcomputer board must be installed in slot 1 and various other peripheral interface boards in the standard configuration must be installed in accordance with the chassis map shown in figure 1-15. This standard configuration is required to assure software compatibility. However, some boards such as memory expansion, EPROM memory module and CRU expander may be installed in any slot (other than slot 1) since these devices respond to dedicated CRU addresses (see figure 1-26). Those logic board slots which are marked “spare” may be used to house any CRU interface



(A)133600

Figure 1-14. System Interconnections, Simplified Diagram



SLOT NUMBER

P1 (CHASSIS FRONT)

P2 (CHASSIS REAR)

| SLOT NUMBER | FIXED CRU BASE ADDRESS | CIRCUIT BOARD | INTER-RUPT LEVEL | FIXED CRU BASE ADDRESS | CIRCUIT BOARD | INTER-RUPT LEVEL |
|-------------|------------------------|---------------------------|------------------|------------------------|---------------------------|------------------|
| 1 | N/A | 990/4 AU | N/A | N/A | 990/4 AU | N/A |
| 2 | 02E0 | MEMORY EXPANSION OR SPARE | | 02C0 | MEMORY EXPANSION OR SPARE | |
| 3 | 02A0 | MEMORY EXPANSION OR SPARE | | 0280 | MEMORY EXPANSION OR SPARE | |
| 4 | 0260 | SPARE | | 0240 | SPARE | |
| 5 | 0220 | SPARE | | 0200 | SPARE | |
| 6 | 01E0 | SPARE | | 01C0 | SPARE | |
| 7 | 01A0 | SPARE | (13)* | 0180 | SPARE | (13)* |
| 8 | 0160 | CRT 3 | (9)* | 0140 | CRT 3 | (9)* |
| 9 | 0120 | CRT 2 OR CRU EXPANDER | (10)* | 0100 | CRT 2 OR CRU EXPANDER | (10)* |
| 10 | 00E0 | CRT 1 | (11)* | 00C0 | CRT 1 | (11)* |
| 11 | 00A0 | FLOPPY DISC CONTROLLER | 7 | 0080 | FLOPPY DISC CONTROLLER | 7 |
| 12 | 0060 | LINE PRINTER | (14)* | 0040 | CARD READER | 4 |
| 13 | 0020 | PROM PROGRAMMER | (15)* NOT USED | 0000 | 733 ASR/KSR | 6 |

*INTERRUPTS PREWIRED BUT NOT RECOGNIZED BY 990/4. MUST BE RECONFIGURED FOR USE WITH 990/4.

(A)133090

(B) 13-SLOT PREWIRED CHASSIS

SLOT NO.

| SLOT NO. | FIXED CRU BASE ADDRESS | CIRCUIT BOARD | INTER-RUPT LEVEL | FIXED CRU BASE ADDRESS | CIRCUIT BOARD | INTER-RUPT LEVEL |
|----------|------------------------|---------------------------|------------------|------------------------|---------------------------|------------------|
| 1 | N/A | 990/4 AU | N/A | N/A | 990/4 AU | N/A |
| 2 | 0120 | MEMORY EXPANSION OR SPARE | N/A | 0100 | MEMORY EXPANSION OR SPARE | N/A |
| 3 | 00E0 | 913A VDT NO. 1 | 3 | 00C0 | 913A VDT NO. 1 | 3 |
| 4 | 00A0 | FLOPPY DISC CONTROLLER | 7 | 0080 | FLOPPY DISC CONTROLLER | 7 |
| 5 | 0060 | SPARE | N/A | 0040 | CARD READER | 4 |
| 6 | 0020 | PROM PROGRAMMER | NOT USED | 0000 | 733 ASR/KSR | 6 |

(A)133082

(A) 6-SLOT PREWIRED CHASSIS

Figure 1-15. Factory Prewired Chassis Configurations



board not otherwise identified on the chassis map. However, the software system must reflect the board locations.

NOTE


The map on top of the chassis should always indicate the latest hardware configuration to prevent inadvertently placing a replacement board in the wrong slot.

Interrupt Wiring. Interrupt wiring for the three chassis configurations is accomplished using jumper plugs in jacks 1A1J3 and 1A1J2 on the backpanel board. These jacks may be accessed by removing the logic boards from the first 5 slots.

NOTE

The standard 990 chassis is prewired to reflect the interrupt levels shown in figure 1-15. For use of the 13-slot chassis as a 990/4 main chassis, interrupt levels above 7 must be rewired since the 990/4 does not implement interrupt levels 8 through 15. Also, if chassis is used as expansion chassis, the interrupts must be reconfigured depending on expansion software and types of peripherals used.

The interrupt jumper plugs are molded plastic connectors with two rows square holes for inserting jumper wires. The jumper plug associated with each chassis contains several holes to accommodate jumper wires. Each hole has a plastic detent that holds the jumper wires in place when it is completely inserted into the hole. Figure 1-16 illustrates the mating of the jumper



(A)133097

Figure 1-16. Interrupt Jumper Wire Installation




wire with the plastic jumper plug. Notice that the brass connector on the jumper wire must be oriented properly when inserted into the jumper plug so that the plastic detent can engage the slot in the top of the jumper wire brass connector. The jumper wire can be removed from the jumper plug by lifting up on the plastic detent to free the jumper wire brass connector to slide out the rear of the jumper plug. The spring force of the detent is slight enough that only a fingernail is required to lift it up to release the jumper wire.

Figure 1-17 illustrates the position assignments on the interrupt plugs for both the 6- and the 13-slot chassis. Notice that each interrupt generated by a module has two positions on the plug assigned to it. This configuration allows interrupts that will be recognized on the same level to be daisy-chain linked to each other. A typical daisy-chaining example is provided in figure 1-18.

OEM Chassis Connectors. The OEM chassis is a minimum configuration chassis that accommodates a 990/4 microcomputer board in slot 1 and two full-size logic boards (or a combination of full- and half-size boards) in slots 2 and 3. All electrical interconnections between the logic boards and the remainder of the system are accomplished through etch circuits on the chassis' backpanel board and interface cables on the top edge of the CRU interface boards in the chassis as shown in figure 1-14.


The OEM chassis also requires an external power supply, real time clock source, several control signal inputs and an external source of cooling air (approximately 300 cubic feet/minute). The control signal and dc power connections to the chassis are accomplished through the terminal strip on the rear of the chassis as shown in figure 1-19. The electrical connections include:

- Processor Restart – An external input used to cause the microprocessor to trap to memory location 0000_{16} or $FFFC_{16}$ depending on a jumper option on the 990/4 microcomputer board.
- Restart – An output from a circuit on the backpanel board in the chassis which causes the microprocessor on the 990/4 microcomputer board to initiate a level 0 interrupt and trap to location 0000_{16} when power is initially applied to the computer. This output is also available at the terminal strip for external use in the system.
- Power Fail Warning – A user-supplied power condition signal which is true a few milliseconds before a power failure occurs. This signal may be wired to interrupt level 1 through a jumper option on the 990/4 microcomputer board.
- 120 Hz Real Time Clock – A user-supplied real time clock source for the programmable real time clock interrupt logic on the 990/4 microcomputer board. This interrupt source may be wired into interrupt level 5 or 7 depending on a jumper option on the 990/4 microcomputer board.
- +5 Main and ± 12 Main – User-supplied regulated dc voltages used in all logic circuits except some of the MOS memory circuits (990/4 microcomputer board and the 990/4 memory expansion board). If an optional standby power supply (with storage batteries) is not used, the +5 Main and the +12 Main voltages are jumpered to the +5 Mem and the +12 Mem inputs, respectively.
- ± 5 Mem and +12 Mem – Regulated dc inputs from the user's standby power supply which are routed to the memory refresh circuits on boards containing MOS memory.



(A) 133099

Figure 1-17. Chassis Interrupt Jumper Plugs



(A)133100

Figure 1-18. Jumper Plug Daisy Chain Sample Connection

1.2.1.5 Programmer Panel. The programmer panel provides for manual control of a system and permits data to be entered into selected registers in the TMS 9900 (PC, WP, and status registers) or any memory location in the 32K address space and displayed from selected TMS 9900 registers and memory locations. A key-controlled switch on the programmer panel controls the application of ac power to the chassis and prevents unauthorized program intervention (panel cannot be activated with the switch set to LOCK position and key removed).

When power is first applied to the chassis, the system comes up in the RUN mode and all programmer panel switches (except the HALT/SIE switch if the key switch is in the UNLOCK position) are locked out. The DATA LEDs are all forced to a logic 1 (all lit). If the microprocessor goes to the idle state, information may be displayed on the panel under software control.




Figure 1-19. OEM Chassis External Connections

To activate the panel, the key switch must be set to the UNLOCK position and the HALT/SIE switch must be pressed. When these two events occur, a LOAD signal is sent to the TMS 9900 which causes the microprocessor to execute a trap to location $FFFC_{16}$ which contains the workspace register pointer value of 80_{16} for the front panel software. The last word in memory (FFFE) contains the program counter value which defines the starting memory address for the panel software. The processor then begins processing the panel utility and constantly monitors the switch outputs via CRU STORE instructions. If any DATA or control switch is pressed, the software activates a debounce timer and then determines when timeout has occurred (approximately 10 milliseconds) by a CRU STORE instruction. The software then reads the switch output and takes the appropriate action. In the case of a DATA switch being pressed, the panel software changes the state of the associated DATA LED (if previously unlit, the LED lights). In case of a control switch entry, the software executes the command.

NOTE

See Section II for a detailed description of the programmer panel controls and indicators.

1.2.1.6 990 Power Supply. Both the 6-slot and 13-slot 990 chassis are equipped with built-in power supplies and cooling fans. The 6-slot chassis contains a 20 amp main power supply and an optional standby power supply which protects the semiconductor memories against accidental loss of data due to temporary power failures.

The 13-slot chassis contains either a 20 amp main power supply or a 40 amp power supply and optional standby power supply.



Main Power Supply. The main power supply (both 20 and 40 amp versions) consists of the following:

- Ac distribution circuits
- Ac power converter board
- Main power supply board

A schematic diagram of the 990 power supply system is shown in figure 1-20 and the associated parts location diagram is shown in figure 1-21.

The ac distribution circuits route ac power through a 10-amp fuse 1F1 located at the rear of the chassis, through the key switch on the front panel, and back through a line filter 1FL1 and an optional line transformer (used only in 100, 200 and 230 Vac systems) to a distribution terminal strip 1TB1 all located in the rear of the chassis. Ac power on the terminal strip is tied directly to the blower fans and to the input side of the ac power converter board. Protection against a high surge voltage (230V) on the ac line is provided by 1C2 which temporarily shorts out and blows the fuse if lightning strikes the power lines. When the surge is gone, 1C2 ceases conduction but the fuse 1F1 must be replaced before normal operation can be restored.

The ac power converter board performs two functions in the main supply:

- Develops an unregulated +160 Vdc used to drive the regulators on the main power supply board (both 20 and 40 amp configurations) and the regulators and battery charger circuits on optional standby power supply board.
- Develops a 120 Hz pulse train which is further shaped on the main power supply board and routed to the 990/4 microcomputer board to drive the real time clock interrupt circuit.

The main power supply board (1A3) converts the unregulated +160 Vdc from the ac power converter board into the following regulated dc output voltages: +5 Vdc, +12 Vdc and -12 Vdc. If a standby supply is used, the regulated ± 5 and ± 12 Vdc outputs from the standby power supply board are routed through P3 on the main power supply board to P1 which connects to the backpanel board. If the standby supply option is not used, a jumper plug is installed on 1A3J3 which routes the main dc voltages developed on the main power supply board onto the memory dc lines at 1A3P1.

The main power supply board also generates a power on reset signal (TLPRES-) when ac power is initially applied to the chassis and generates a power failure warning (TLPFWP-) approximately 8 milliseconds before a power failure occurs. The power failure warning is normally tied into interrupt level 1 on the 990/4 microcomputer board.

The main power supply also provides a pulse shaping and driver function for the 120 Hz real time clock pulse train which originates on the ac power converter board. This pulse train is used to drive the real time clock interrupt logic on the 990/4 microcomputer board.




Standby Power Supply. The standby power supply is an optional power system used to provide the regulated dc voltages used by the semiconductor memories in the 990/4 system. The supply consists of a pair of storage batteries, a battery switch, and protective fuse in the rear of the chassis and a standby power supply board which mounts piggy-back on a set of standoffs on top of the main power supply board.

During normal operation, the standby power supply board converts the +160 Vdc (unregulated) output from the ac power converter board into a regulated +5 Vdc and ± 12 Vdc. (The -5 MEM regulated voltage is developed on the main power supply board using the -12 Vdc output from the standby power supply.) This continuously supplies the memory voltages for the first seven slots. The standby power supply board also supplies charging current to the two 6-volt standby batteries which are wired in series to provide a 12-volt output.

In the event of a power failure, the standby power supply board generates an under voltage signal (UV-) which is used by the main power supply to generate a reset (TLPRES-) and then switches over to battery operation. When the batteries discharge to a minimum functional voltage level, the standby power supply shuts down to protect the batteries. When normal ac power is restored, the standby power supply board develops an equalizing voltage used to provide initial charging current for the batteries until the charge current drops to a trickle charge level. The supply then switches to a float voltage to maintain the batteries at full charge. The standby power supply also contains provisions for preventing a switchover to battery operation (even if the battery switch is in the on position) unless ac power has first been applied to the system. This safety feature prevents inadvertent discharging of the batteries. The standby supply is also equipped with over-voltage sensing circuits which disable the standby supply and blows the battery fuse if any of the memory voltages exceed safe levels.


1.2.1.7 CRU Interface Boards. Each terminal or peripheral in the 990/4 system requires a separate CRU interface board which plugs into one of the board slots in the main chassis or expansion chassis. These boards may be implemented as either half- or full-size boards. Basically, each interface board provides the address decoding, data buffering and data packing and unpacking functions required to match up the serial CRU interface presented by the 990/4 microcomputer board with the bit-, byte- or word-oriented interface presented by the peripherals and terminals.

Each CRU interface board decodes the address on the CRU address lines when it receives a low-active Module Select signal from the board installed in slot 1 of the chassis (990/4 microcomputer board in main chassis or CRU buffer board in expansion chassis). If a store clock is present when a valid CRU address is on the CRU address lines (and the module select is present), the interface board accepts serial data from the CRUBITOUT line from the microprocessor. If the clock is not present, a CRU read operation is being performed and serial data from the CRU interface board is sent to the microprocessor via the CRUBITIN line. All bit selection for CRU board-to-microprocessor transfers is controlled by 990 software which addresses 1 of 16 bits via the 4 LSBs of the CRU address (bits 12-15). The TTY/EIA terminal interface module, which is used with the 733 ASR data terminal, is described in the following paragraphs. For a detailed description of the various other interface boards available for 990/4 system use, refer to the depot manual for the associated device (e.g., 16 I/O Data Module, Floppy Disc, Synchronous Modem, etc.).




(B)133322

Figure 1-20. 990 Power System Schematic Diagram (6- and 13-slot chassis)



133323 (990-576-14-1)

AC DISTRIBUTION CIRCUITS (REAR OF COMPUTER)



133601 (990-576-74-2)

POWER SUPPLY BOARDS

Figure 1-21. Power Supply Assemblies and Subassemblies



TTY/EIA Terminal Interface Module. The TTY/EIA terminal interface module (Part Number 945075-1) provides an interface between the 990/4 and any terminal device using an EIA standard RS232 interface or 20 milliampere TTY current loop. Some of the 990 peripherals and data terminals which use the TTY/EIA terminal interface module include:

- 733 ASR data terminal
- 745 KSR data terminal
- 733 KSR data terminal
- Model 306 line printer
- Model 588 line printer


The jumper options used to modify the board operation for use with each device type are summarized in figure 1-22.

1.2.1.8 CRU Expansion Board. The CRU expansion board primarily expands the CRU interface in the main chassis to drive up to seven additional 990 expansion chassis. The board monitors for interrupts from the seven chassis using two independent interrupt recognition sections (A and B). If an interrupt occurs in chassis 1 through 4, the expansion board generates an INTA— (interrupt A). If the interrupt occurs in chassis 5 through 7, the expander board generates an interrupt B. The expander board then enables the interrupt ID lines from the highest priority chassis (chassis 1 highest priority, chassis 4 lowest priority in interrupt section A). The 990 software may then determine the source of the interrupt by executing an STCR instruction at address $F80_{16}$ (interrupt vector for section A) or $F90_{16}$ (interrupt vector for section B). As a result of the instruction, the CRU expander board serially transfers a 16-bit vector in the format shown in figure 1-23. As indicated in this figure, the interrupt vector identifies the chassis and the unit within the chassis which issued the interrupt. The vector also indicates the on-line status of each expansion chassis which reports to this interrupt monitoring section (chassis 1-4 for section A; chassis 5-7 for section B).

The CRU expansion board also contains provisions for fanning-in a direct interrupt (IREQ—) from each of the seven chassis and issuing an INTC— to the 990/4 if a direct interrupt is received from any chassis. The direct interrupt scheme is used with peripherals requiring faster interrupt service than is available with the interrupt scanner method.

The interrupt on the originating board is cleared by the interrupt servicing software via a CRU instruction addressed to the board in the respective expansion chassis.

Interrupt Servicing Jumpers. The two interrupt servicing sections on the CRU expansion board are normally enabled by jumper wires between terminals E5 and E6 (section A) and between terminals E7 and E8 (section B). This option permits disabling the interrupt servicing logic on a CRU expander board when two CRU expander boards are installed in the main chassis (see figure 1-24).




SUMMARY OF JUMPER OPTIONS

| <u>TERMINAL DEVICE</u> | <u>BAUD RATE</u> | <u>JUMPER CONNECTIONS</u> |
|-------------------------|------------------|--|
| 733 KSR DATA TERMINAL | 300 | E1 TO E3, E8 TO E9, E11 TO E12, E14 TO E15, E17 TO E18, E20 TO E21, E25 TO E26 |
| 733 ASR DATA TERMINAL | 1200 | E1 TO E4 (ALL OTHERS SAME AS ABOVE) |
| 588 OR 306 LINE PRINTER | 4800 | E1 TO E6, E26 TO E27 (ALL OTHERS SAME AS ABOVE) |

(A)133602

Figure 1-22. TTY/EIA Module Options



(A)133442

Figure 1-23. Expansion Interrupt Vector Format

Power On Reset Option. The CRU expander board also contains an option to accept either the power on reset from the power supply board (TLPRES-) via a jumper between terminals E1 and E2 or the reset signal from the 990/4 microcomputer board (TLIORES-) via a jumper between E3 and E4 (normal configuration). The IO reset signal from the 990/4 board permits a clear to be generated by either the power supply or by 990 software.


1.2.2 990 I/O EXPANSION CHASSIS. The 990 I/O expansion chassis is added to a system when the main chassis does not contain enough board slots to house all of the CRU interface boards required by the system. The chassis used for the I/O expansion chassis is identical to the main computer chassis except that it contains an operator panel instead of a programmer panel and slot 1 of the expansion chassis houses a CRU buffer board instead of a 990/4 microcomputer board. Also, the interrupt wiring for the expansion chassis is accomplished through jumper plugs on the backpanel board similar to the main chassis except that all 15 levels are implemented in the expansion chassis. The dc power supplies in the expansion chassis are identical to the power supply used in the main chassis except that a standby supply is not used with an expansion chassis.



945401-9701

1-43

Digital Systems Division



(B)133356 (945005)

Figure 1-24. CRU Expansion Board Options




The operator panel on the expansion chassis contains a key switch which controls ac power to the chassis and a POWER LED which indicates when the power supplies are functioning properly. The interconnection between the operator panel and the CRU buffer board is accomplished through a 26-pin ribbon cable and connector which attaches to connector plug P5 on the top edge of the buffer board. The interface between the main chassis and the expansion chassis is accomplished through a 12-foot ribbon cable (Part Number 945001-1) which attaches to one of the 7 ports on the CRU expansion board in the main chassis (P3 through P9 depending on chassis number) and attaches to plug P3 on the top edge of the CRU buffer board in the expansion chassis.

1.2.2.1 Expansion Chassis Interrupt Scheme. A simplified block diagram of the interrupt system associated with a fully expanded 990/4 microcomputer system is shown in figure 1-25. As indicated in this figure, interrupts from each half-board slot in a given expansion chassis are wired to the interrupt jacks J2 and J3 on the backpanel board. These interrupt lines are then jumpered to selected interrupt levels 1 through 15 using wire jumpers on the backpanel board. The 15 interrupt levels are routed to an interrupt scanner on the CRU buffer board which is located in slot 1 of the expansion chassis. If an interrupt is received on any of the 15 interrupt levels, the CRU buffer board issues an "interrupt present" to the CRU expander board in the main chassis (see figure 1-26). The CRU expander board then responds to the interrupting chassis (having highest priority) with an ID enable signal. This enable is used to gate the four ID bits (which represent the binary value of the interrupt level) back to the CRU expander board. In response to an interrupt request from any of the seven chassis, the CRU expander board issues either an interrupt A (interrupt present in chassis 1-4), an interrupt B (interrupt present from chassis 5 through 7) or an interrupt C (direct interrupt present from interrupt chassis 1 through 7).

Interrupts A and B are used to activate the expander interrupt servicing routine which, in turn, addresses the appropriate interrupt servicing section (A or B) with a store CRU instruction addressed to either F80₁₆ (interrupt A) or F90₁₆ (interrupt B). As a result of the store CRU instruction, a 16-bit interrupt vector is sent back to the microprocessor. As shown in figure 1-23, the interrupt vector contains the ID of the originating unit (developed by the CRU buffer board in the interrupting chassis), the ID of the expansion chassis (developed in the CRU expander board) and the status of the expansion chassis associated with the reporting interrupt section (chassis 1-4 associated with interrupt section A and chassis 5-7 associated with section B). The interrupt vector is then used to select the proper device interrupt servicing routine associated with the interrupting board.


If a direct interrupt (INT C-) is generated, the interrupt is processed more speedily since the expansion interrupt servicing routine is bypassed and the microprocessor traps directly to the board-level interrupt servicing routine. This interrupt scheme is used when peripherals requiring rapid response to interrupts are located in the expansion system.

1.2.2.2 CRU Expansion Address Scheme. A CRU address map for the standard fully expanded 990/4 system is shown in figure 1-27. As indicated in this figure, each chassis is assigned a band of location-dependent CRU addresses which are used to address the CRU interface boards implemented within a given chassis. The chassis number (1 to 7) which is assigned to each chassis is determined by an ID plug on the CRU buffer board.




(D)133603

Figure 1-25. 990 Interrupt Paths, Simplified Diagram



(C)133305

Figure 1-26. CRU Expansion, Simplified Block Diagram



(A) 133616

Figure 1-27. CRU Address Map for Standard Expansion Implementation Using 13-slot Chassis



In addition to the location dependent address blocks, several bands of addresses are assigned as dedicated or location-independent addresses. In order to implement the dedicated CRU addresses, the boards associated with these address functions contain decoding logic that permits the board to respond to its dedicated address regardless of location. For example, the two interrupt servicing sections on the CRU expansion board are assigned dedicated addresses F80 and F90, respectively. The interrupt servicing logic on the expander board will respond to these CRU addresses regardless of physical placement of the CRU expansion board. Similarly, the write protect logic on the 990/4 memory expansion board responds to a CRU address ranging between FD0 and FDF regardless of physical placement within the main chassis.

1.2.2.3 CRU Buffer Board. The CRU buffer board contains fanout and fanin circuits for the CRU interface signals including CRUBITIN, CRUBITOUT, CRUCLK and CRU address lines. The board also contains an interrupt scanner circuit which monitors the interrupt lines from the various CRU interface boards within the chassis and issues an interrupt to the CRU expander board in the main chassis anytime an interrupt is detected. When the interrupt is acknowledged by means of an ID enable signal, the CRU buffer board sends back the ID code corresponding to the originating interrupt level (1 through 15). The interrupt scanner then halts until software clears the interrupt on the originating board.

The various jumper options on the CRU buffer board are shown in figure 1-28 and are described briefly in the following paragraphs.

Chassis Number Select Plug. The jumper plug P4 may be installed into any of seven slots on J2 to assign a chassis number to a given expansion chassis. This plug determines which of the seven possible chassis decode lines is routed to the module select decode circuitry on the board.

Direct Interrupt Jumper Option. Interrupt level 1 from the interrupt jumper plug on the backpanel board may be routed through the interrupt scanner and processed by the expansion interrupt routine or wired directly to the interrupt plug on the backpanel board in the main chassis to permit faster interrupt processing. The latter method is used when a peripheral requiring fast interrupt processing response time is implemented in one of the expansion chassis.

For conventional scanner processing of interrupt level 1, a jumper wire is installed between DI1, DI3 and DI4. For direct interrupt processing of interrupt level 1, the jumper between DI3 and DI4 is removed and a jumper is installed between DI1 and DI2.

Interrupt Expansion Jumpers. Jumper options are also provided for interrupt levels 0 and 16 through 31 but are not implemented in the current 990/4 system.

Interrupt Scanner Maintenance Options. For normal interrupt scanner option, the jumper wire between E1 and E2 is installed to enable the internal scanner clock. For maintenance operations, the jumper between E1 and E2 may be removed and the interrupt scanner may be driven with an external clock source using terminal E3 as an input point. The scanner may also be cleared by temporarily connecting a ground potential at terminal E4.



945401-9701

P3 CONNECTS TO ONE OF CRU PORTS (P3 TO P9) ON CRU EXPANSION BOARD

P5 CONNECTS TO FRONT PANEL OF EXPANSION CHASSIS

MADE IN U.S.A.
ASSY# 944905-0001
SCH# 944907

E4-COUNTER CLEAR INPUT


EXTERNAL CLOCK INPUT

CHASSIS SELECT JUMPER PLUG-INSTALLED IN SLOT CORRESPONDING TO CHASSIS NUMBER (1 TO 7)

VECTORED/DIRECT INTERRUPT OPTION JUMPERS (NORMALLY, 1, 3, AND 4 CONNECTED)

MODULE SELECT JUMPERS (24-31) NOT USED IN STANDARD CONFIGURATION

CLOCK ENABLE (JUMPER MUST BE INSTALLED BETWEEN E1 AND E2 FOR INTERNAL CLOCK TO FUNCTION)



1-51/1-52

Digital Systems Division

(B)133358 (944905)

Figure 1-28. CRU Buffer Board Options



SECTION II

FIELD SERVICE TEST EQUIPMENT

2.1 GENERAL

This section describes the 990 Maintenance Unit and other tools, test equipment, diagnostic cassettes and spares required for field-level maintenance of 990/4 Microcomputer Systems.

2.2 TOOLS, TEST EQUIPMENT AND SPARES REQUIRED FOR FIELD MAINTENANCE

A listing of tools, test equipment and replaceable parts required to perform field-level maintenance is provided in tables 2-1 through 2-3, respectively.

2.3 990 MAINTENANCE UNIT

The 990 Maintenance Unit consists of a conventional 990 programmer panel, a 733 ASR cassette transport and a maintenance controller board (containing the cassette read electronics and CRU interfacing logic) all housed in a portable aluminum carrying case as shown in figure 2-1. The maintenance unit permits diagnostics to be loaded into a system not equipped with an operational 733 ASR data terminal and provides for manual control of a computer equipped with an operator panel or inoperative programmer panel. The maintenance unit's carrying case also provides storage space for manuals, CPU ROMs, diagnostic cassettes and interface cables.

Table 2-1. Recommended Tools and Test Equipment for Field-Level Maintenance

| Nomenclature | Function | TI Part Number |
|---|---|----------------|
| 990 Maintenance Unit (115 Vac Operation) | Used to load diagnostics and display test results in 990/4 systems not equipped with 733 ASR data terminal. | 946710-1 |
| 990 Maintenance Unit (230 Vac Operation) | Same as above but equipped to operate from 230 Vac input power. | 946710-2 |
| 14/16 Pin IC inserter/ extractor tool | Used to remove and replace memory ICs. | — |
| 64-pin inserter/ extractor tool | Used to remove and replace TMS 9900 chip. | — |
| Standard Technician tool kit | Used to assemble/remove assemblies and components and to install new components and assemblies. | — |



Table 2-2. 990/4 Diagnostic Tests

| Diagnostic Name | Description | TI Part Number |
|-----------------|--|----------------|
| HDT04 | Hardware demonstration test; used to verify proper connection of all peripherals. | 945460 |
| AU04 | 990/4 arithmetic unit test. | 945434 |
| ROMVER | 990 ROM verifier test. | 945443 |
| RAM04 | 990/4 Random access memory test; used to test RAM memory on 990/4 microcomputer board and 990/4 memory expansion board(s). | 945440 |
| MEMPRO04 | 990/4 memory protect test; used to test write protect function on 990/4 memory expansion board. | 945442 |
| EROMBT | 990 EROM memory module test. | 945459 |
| CRUST04 | 990/4 CRU interface logic test; checks the CRU interface logic on the 990/4 microcomputer board. | 945446 |
| TST733 | 733 ASR/KSR data terminal test. | 945447 |
| CRUEXP | 990 CRU expansion chassis interface test. | 945457 |
| LPTEST | 990 line printer diagnostic test. | 945448 |
| CARDRD | 990 Model 804 card reader test. | 945449 |
| CRT913 | 990 Model 913 CRT diagnostic test. | 945450 |
| IO16 | 990 Model 16 I/O TTL module test. | 945452 |
| TTYEIA | 990 Full duplex TTY/EIA interface module test. | 945453 |
| PROMPG | PROM programmer test. | 945454 |
| TILCOM | 990 TILINE coupler logic test, synchronous and asynchronous communication interface test. | 945458 |
| DAADC | 990 Digital to analog and analog to digital converter test. | 945438 |
| TINET | 990 TINET test. | 945448 |

2.3.1 TEST CONFIGURATIONS. The maintenance unit accommodates two different test configurations depending on the system under test. In the first configuration (figure 2-2), the maintenance unit ties into the system under test through P3 on the 990/4 microcomputer board (after removal of the existing interface cable from the chassis-mounted operator or programmer panel). In this configuration, diagnostic programs are loaded into program memory from the cassette tape transport on the maintenance unit and the test results are displayed on the DATA LEDs on the programmer panel in the maintenance unit. This configuration is used when the system is not equipped with an operational 733 ASR data terminal.



Table 2-3. Field Replaceable Components for 990/4 System

| Assembly/Subassembly | TI Part Number |
|---|----------------|
| LOGIC BOARDS | |
| 990/4 microcomputer board with 4K RAM | 944910-2 |
| 990/4 microcomputer board with 256 words static RAM | 944910-1 |
| 990/4 memory expansion board | |
| • with 4K RAM | 944935-1 |
| • with 8K RAM | 944935-2 |
| • with 12K RAM | 944935-3 |
| • with 16K RAM | 944935-4 |
| • with 20K RAM | 944935-5 |
| • with 4K and write protect | 944935-6 |
| • with 8K and write protect | 944935-7 |
| • with 12K and write protect | 944935-8 |
| • with 16K and write protect | 944935-9 |
| • with 20K and write protect | 944935-10 |
| • with 20K, and write protect and parity | 944935-10 |
| • with 4K memory parity option | 945120-0001 |
| • with 8K memory parity option | 945120-0002 |
| • with 12K memory parity option | 945120-0003 |
| • with 16K memory parity option | 945120-0004 |
| • with 20K memory parity option | 945120-0005 |
| 990 EPROM memory module | 945170-1 |
| CRU expander board | 945005-1 |
| CRU buffer board | 944905-1 |
| TTY/EIA terminal interface module | 945075-1 |
| 990 communications interface module | 946104-1 |
| 913A video display terminal controller | 946695-1 |
| Card reader interface module | 945185-1 |
| 16 I/O EIA data module | 945140-1 |
| 16 I/O TTL data module | 945145-1 |
| Floppy disc controller | 945940-1 |
| CHASSIS AND POWER SUPPLY ASSEMBLIES | |
| 3-slot OEM chassis | 945040-1 |
| 6-slot chassis with programmer panel | 944960-1 |
| 6-slot chassis with operator panel and 20 ampere power supply | 944960-2 |
| 13-slot chassis with programmer panel and 40-ampere power supply | 945050-1 |
| 13-slot chassis with operator panel and 40 ampere power supply | 945050-8 |
| AC power converter board | 946650-1 |
| 20 Ampere main power supply board | 944970-1 |
| Standby power supply board | 944990-1 |
| Standby power supply kit (with board, batteries and all hardware) | 945128-1 |
| International voltage kit, 100 volt service | 945125-1 |
| International voltage kit, 230 volt service | 945125-2 |



Table 2-3. Field Replaceable Components for 990/4 System (Continued)

| Assembly/Subassembly | TI Part Number |
|--|----------------|
| CHASSIS AND POWER SUPPLY ASSEMBLIES (Continued) | |
| Operator panel assembly | 945030-1 |
| Programmer panel assembly | 945020-1 |
| Interrupt jumper | 975321-4 |
| Chassis center card guide kit | 945129-1 |
| CABLE ASSEMBLIES | |
| CRU expansion cable (12 feet) | 945001-1 |
| Model 913A VDT extension cable (50 feet) | 974998-50 |
| Model 588/306 line printer extension cable (50 feet) | 975056-50 |
| LOADER ROMS, MEMORY CHIPS AND REPLACEABLE ICs | |
| 733 ASR/card reader loader ROM | 945121-1 |
| 733 ASR/card reader loader ROM with self-test | 945121-2 |
| 990/4 floppy disc loader ROM | 945121-3 |
| 990/4 floppy disc loader ROM with self-test | 945121-4 |
| 733 ASR loader ROM (prototyping) | 945121-5 |
| TMS 4050 | 972659-1 |
| TMS 4043 static RAM (256 × 4-bit) | 972658-1 |
| TMS 4051 dynamic RAM (4096 × 1-bit) | 972660-1 |
| TMS 4060 dynamic RAM (4096 × 1-bit) | 974679-1 |
| 1024 by 8-bit EPROM IC | 996019-1 |
| SN74180N parity generator/checker | 222222-7180 |
| NE 555V | 972188-1 |
| TMS 9900 microprocessor chip | 972671-1 |
| CHASSIS REPLACEABLE COMPONENTS | |
| Fuse 1F1, 10 amp slo-blo (BUS MDA10.0) | 772995-4 |
| Fuseholder | 972690-1 |
| Standby replacement plug | 946739-1 |
| 13-slot chassis air filter | 945152-2 |
| 6-slot chassis air filter | 945152-1 |
| Terminal block 1TB1 | 975270-5 |
| Surge voltage protector | 974805-7 |
| 5-inch fan | 947512-1 |
| Ac line filter (1FL1) | 972838-5 |
| Capacitor (1C1) | 972930-69 |



945401-9701

CASSETTE
TRANSPORT

LOAD

REWIND

RESET


POWER
ON/OFF

AC FUSE

ROM
STORAGE

DIAGNOSTIC
CASSETTE
STORAGE

CONVENTIONAL
990 PROGRAMMER
PANEL




133604 (990-776-10-1)

Figure 2-1. Model 990 Maintenance Unit




POWER AND FAULT LEDS
DISABLED ON CHASSIS-MOUNTED
PANEL

CABLE FROM CHASSIS-MOUNTED
OPERATOR OR PROGRAMMER PANEL
WHICH IS REMOVED FROM P3 TO
ACCOMMODATE THE MAINTENANCE
UNIT CABLE




CONNECTOR P3 ON
990/4 MICROCOMPUTER
BOARD (CHASSIS SLOT 1)

KEY SWITCH ON CHASSIS-MOUNTED
PANEL CONTROLS AC POWER TO
COMPUTER UNDER TEST



733 ASR-TYPE CASSETTE
TRANSPORT-USED TO LOAD
DIAGNOSTICS INTO UNIT UNDER
TEST IF OPERABLE 733 ASR
DATA TERMINAL NOT AVAILABLE



MAINTENANCE UNIT'S PROGRAMMER
PANEL

(A)133605

Figure 2-2. Test Setup for System Not Containing Operational
733 ASR Data Terminal



2.3.1.1 Standalone Programmer Panel. The programmer panel may also be detached from the maintenance unit and used as a standalone unit. In this case, the existing interface cable from the chassis-mounted operator or programmer panel is removed from P3 on the 990/4 microcomputer board and the maintenance unit's programmer panel interface cable is connected to P3 (see figure 2-3). In this configuration, the key switch on the chassis-mounted panel controls the application of ac power to the computer but all other functions are controlled by the standalone programmer panel.

This configuration is used when the system under test is equipped with an operator panel or inoperative programmer panel but contains an operative 733 ASR data terminal. In this case, the diagnostic cassettes are loaded into the system from the 733 ASR and the programmer panel is used to display test data from selected registers in the TMS 9900 on the 990/4 microcomputer board or from selected memory locations on any of the boards containing memory storage.


2.3.2 OPERATING CONTROLS AND INDICATORS. The maintenance unit's operating controls and indicators are shown in figure 2-4 and listed and described in table 2-4. Basically, the maintenance unit contains a POWER ON/OFF switch which controls power to the maintenance unit, a RESET switch which initializes the controller board in the maintenance unit, a REWIND switch which is used to rewind cassette tapes, a LOAD switch which is used to initiate diagnostic load operations plus the conventional controls and indicators found on the 990 programmer panel. However, the function of three of the programmer panel controls and indicators are slightly different when the programmer panel is used as a part of the maintenance unit. These differences include:

- Key switch – Does not affect ac power to the computer or maintenance unit, but otherwise exercises the same key control over program intervention in the computer.
- POWER LED – Indicates the status of the power supply in the maintenance unit rather than the power supply in the computer chassis.
- FAULT LED – May be lit by either the computer (self-test failure) or by the maintenance controller board in the maintenance unit in the event of a faulty tape read operation.

The functions of all other programmer panel controls and indicators are exactly the same as those of a conventional chassis-mounted programmer panel (see figure 2-4 and table 2-4).


2.3.2.1 Maintenance Unit Operating Procedures. Some of the more common operating procedures are briefly described in the following paragraphs. These procedures include:

- Changing panel mode of operation
- Mounting cassette tapes in maintenance unit
- Diagnostic load from cassette transport in maintenance unit
- Entering data into CPU registers or memory locations
- Displaying data from CPU registers or memory locations
- Single instruction execution



(A)133606

Figure 2-3. Alternate Test Setup Using Programmer Panel Only



(A)133607

Figure 2-4. Maintenance Unit Controls and Indicators



Table 2-4. Maintenance Unit Controls and Indicators

| Ref. No. | Control or Indicator | Function |
|----------|----------------------|---|
| 1 | DATA LEDs | <p>The DATA LEDs are used to display data being entered into a CPU register or memory location or data presently stored in a register or memory location. During execution of the diagnostics, error numbers (in hex) are displayed on the right byte and the left byte is forced to all 1's (see error message number descriptions in 990 Computer Diagnostics Handbook).</p> <p>A lit LED denotes a logic 1, an extinguished indicator denotes logic 0. The LSB is displayed on the far right of the LEDs. In the HALT mode, the LEDs display a computer register contents, memory contents or value entered into computer memory via the data entry switches depending on which switches are pressed (see ref. 5, 7, 9, 11, 13, 15).</p> |
| 2 | DATA entry switches | Used in conjunction with the ENTRY switches on the panel to enter data and addresses into selected computer registers and memory locations (active only when the panel is in the HALT mode of operation). In the HALT mode, the data LED located immediately above each data entry switch lights as each switch is pressed. The value indicated by the DATA LEDs is then stored in the register or memory address selected by the entry switches. |
| 3 | CLR switch | When pressed, this switch clears the DATA LED displays. |
| 4 | MDE switch | This switch is pressed to transfer a value displayed on the DATA LEDs to the memory location defined by the contents of the memory address (MA) register in the computer. |
| 5 | MAI switch | The memory address increment (MAI) switch is pressed to increment the value stored in the memory address register by a value of 2. |
| 6 | MDD switch | When pressed, this switch causes the contents of the memory location defined by the contents of the memory address register to be displayed on the DATA DISPLAY LEDs. |
| 7 | ENTER MA switch | When pressed, this switch causes the value displayed by the DATA LEDs to be entered into the computer's memory address register |
| 8 | ENTER ST switch | When pressed, the value displayed on the DATA LEDs is entered into the computer's status register. |
| 9 | ENTER PC | When pressed, the value displayed on the DATA LEDs is loaded into the computer's program counter. |
| 10 | ENTER WP | When pressed, the value displayed on the DATA LEDs is loaded into the computer's workspace pointer register. |
| 11 | DISPLAY MA | When pressed, the value stored in the computer's memory address register is displayed on the DATA LEDs. |
| 12 | DISPLAY ST | When pressed, the contents of the computer's status register is displayed on the DATA LEDs. |
| 13 | DISPLAY PC | When pressed, the contents of the computer's program counter is displayed on the DATA LEDs. |



Table 2-4. Maintenance Unit Controls and Indicators (Continued)

| Ref. No. | Control or Indicator | Function |
|----------|----------------------|--|
| 14 | DISPLAY WP | When pressed, the contents of the computer's workspace pointer register is displayed on the DATA LEDs. |
| 15 | LOAD switch | For a programmer panel on the chassis (or PANEL mode of operation for the maintenance unit), pressing the switch causes the computer to trap to the ROM loader. |
| 16 | RESET switch | Pressing the RST switch results in an IORESET— pulse being generated which resets all units in the system. |
| 17 | RUN switch | When the computer is halted (programmer panel is active), pressing the RUN switch returns the computer to the RUN mode of operation and deactivates the panel. |
| 18 | HALT/SIE switch | When the computer is in the RUN mode (RUN LED is lit), pressing the HALT/SIE switch causes the computer to halt and begin processing the front panel software <i>if</i> the key switch is set to the UNLOCK position. Pressing the switch when the computer is not in the RUN mode causes the computer to execute a single instruction at the present PC (program counter) address. The contents of the program counter are incremented by two and displayed on the DATA LEDs. |
| 19 | Key switch | The key switch (OFF/LOCK/UNLOCK) switch prevents unauthorized computer program intervention. The key must be inserted into the switch and the switch set to the UNLOCK position in order to enable the output of the HALT/SIE switch to the computer. The ac power control function for the 990/4 computer is controlled by the key switch on the chassis-mounted operator or programmer panel. |
| 20 | RUN LED | The RUN LED lights when a low-active RUN— signal is generated by the computer indicating the computer is in the RUN mode. When this LED is lit, all switches on the panel except the HALT/SIE switch are disabled and the DATA LEDs are driven under program control. When the RUN LED is extinguished, the panel controls are active. |
| 21 | IDLE LED | Lights when the computer is executing an idle instruction (indication of computer inactivity for most interrupt driven software). |
| 22 | FAULT LED | The FAULT LED lights when the computer has detected a self-test diagnostic failure or if the maintenance unit has detected a tape data fault. |
| 23 | POWER LED | Lights when the POWER ON/OFF switch on the maintenance unit is set to the ON position and the maintenance unit's internal power supply is functioning properly. |
| 24 | POWER ON/OFF switch | Controls ac power to the maintenance unit. |
| 25 | RESET switch | Initializes the logic on the maintenance unit's maintenance controller board. Has no affect on the system under test. |
| 26 | REWIND switch | Causes the cassette tape in the cassette transport to rewind back to the beginning of the tape (tape motion stops when clear leader is sensed). |
| 27 | LOAD switch | When the programmer panel is in the HALT mode (RUN LED extinguished), this switch causes the program on cassette tape to be loaded into memory. When the load is complete, program execution begins. |



Changing Panel Mode of Operation. The programmer panel in the 990 maintenance unit may be operated in one of two modes including RUN and HALT. The computer initially comes up in the RUN mode when ac power is applied to the computer through the key switch on the chassis-mounted front panel. During this time, the RUN LED and all DATA LEDs on the programmer panel in the maintenance unit light and remain lit until the mode of operation changes. If the key switch on the programmer panel in the maintenance unit is set to the LOCK position, all controls on the panel are disabled. To change from the RUN mode of operation to the HALT mode, the key must be inserted in the switch and the key switch must be rotated to the UNLOCK position. At this point, only the HALT/SIE switch on the panel is enabled. When the HALT/SIE switch is pressed, the computer ceases normal program execution and traps to the panel software utility which is located in a ROM in the upper 256 words of address space on the 990/4 microcomputer board. At this time, the RUN LED on the programmer panel extinguishes and the outputs of the switches on the programmer panel are constantly monitored by software through the programmer panel CRU type interface. At this point, the panel is operating in the HALT mode.

In the HALT mode, a diagnostic tape may be loaded from the maintenance unit or information may be entered into or displayed from selected CPU registers or program memory locations.


In order to switch from the HALT mode of operation to the RUN mode, the RUN switch must be pressed on the programmer panel. This causes the TMS 9900 on the 990/4 microcomputer board to begin program execution at the memory address indicated by its program counter.

Mounting and Removing Tape Cassettes. In order to load a diagnostic tape cassette into the maintenance unit, the cassette transport door must be opened and the cassette inserted with the tape end up. The desired diagnostic title should be facing the operator as shown in figure 2-5. The cassette should then be firmly pressed into the transport such that the capstan and reel motors properly engage the cassette tape and reels. The transport door must then be closed to complete installation of the cassette.


To remove a cassette from the transport, the door should be opened to the first stop and then opened the rest of the way using a quick downward motion. This causes the cassette to eject from the tape transport. When not in use, the transport door should be closed to prevent accumulation of dust or dirt in the tape drive mechanism and read head.

Loading a Diagnostic Into Program Memory. Before initiating a load from a cassette tape, the POWER ON/OFF switch should be set to the ON position and the tape fully rewound by pressing the REWIND switch on the maintenance unit (reference no. 26 in figure 2-4). The tape motion will automatically stop when the clear leader at the beginning of the tape is sensed by the maintenance controller board.

The Key switch on the 990/4 microcomputer's chassis-mounted operator or programmer panel must be set to one of the ON positions (ON, LOCK, or UNLOCK) to apply ac power to the computer. At this point, the RUN and POWER LEDs should light on the programmer panel in the maintenance unit. The panel's mode of operation must then be changed to the HALT mode by setting the Key switch on the maintenance unit's programmer panel to the UNLOCK position and pressing the HALT/SIE switch. The RUN LED on the panel should extinguish indicating the TMS 9900 is now processing the panel software utility. At this point, the panel software begins examining the switch outputs from the programmer panel. The cassette diagnostic load operation may now be initiated by pressing the LOAD switch (reference no. 27 in figure 2-4) on the



STEP 1. CASSETTE IS PROPERLY ORIENTED AND ALIGNED IN TRANSPORT




STEP 2. CASSETTE PRESSED INTO POSITION AND DOOR IS CLOSED.

(A)133608

Figure 2-5. Cassette Tape Installation, Simplified Diagram

maintenance unit. The panel software recognizes the combination of the Load signal with the Maintenance Unit Present signal as a "Load from maintenance unit cassette" command (refer to the flowchart in figure 2-6). As a result, the panel software branches to the self-test program (if the loader ROM is equipped with self-test). If the self-test fails to execute correctly, the TMS 9900 lights the FAULT LED on the programmer panel in the maintenance unit and inhibits the diagnostic load operation.

However, if the self-test executes satisfactorily (or if self-test is not present), the CPU branches to the ASR loader program which is also stored in ROM on the 990/4 microcomputer board. Since the load signal occurred with maintenance unit present, the software retains the CRU base address of the front panel.



(A)133609

Figure 2-6. Diagnostic Load From Maintenance Unit, Flowchart



At this point, the maintenance unit waits for RUN to turn on and then begins transmitting tape read data over the programmer panel CRU interface under control of the 733 loader program. Each time the maintenance controller board in the maintenance unit has a byte of data ready for the computer, it sets CRU bit 12 which is interpreted by software as a Read Request. When the 733 loader recognizes the Read Request, it serially transfers the next byte of data from the maintenance unit and resets CRU bit 12, freeing the maintenance unit to ready the next data byte. If the maintenance unit has another byte of data available before the loader has accepted the previous data byte (CRU bit 12 still set to the computer), the load operation is aborted and the FAULT LED lights on the maintenance unit's programmer panel. When the 733 loader decodes an End of File tag, it sets Clear Write Request via CRU output bit 13 which causes the maintenance unit to stop the cassette transport and return to an idle state.



SECTION III

MAINTENANCE

3.1 GENERAL

This section contains preventive and corrective field-level maintenance procedures for 990/4 microcomputer systems. This section includes assembly and disassembly procedures plus instructions for evaluating each system configuration and incorporating the necessary jumper options on replacement boards before installing the boards in a given system.

3.2 PREVENTIVE MAINTENANCE

Preventive maintenance for the 990/4 microcomputer system is limited to cleaning the washable intake air filter on each computer or expansion chassis in the system on a monthly basis (or more often if required) and periodically executing the diagnostics listed in table 2-2 to ensure that the system is functioning properly. All other preventive maintenance procedures are associated with the system peripherals and are described in the *Model 990 Peripheral Equipment Field Maintenance Manual*.

3.2.1 FILTER REMOVAL/REPLACEMENT. The washable filter used in the 990 chassis snaps into place and is removed by applying finger pressure along the top and bottom edges.

3.3 CORRECTIVE MAINTENANCE

Corrective maintenance at the field-level for the 990/4 is limited to the following:

- Removal and replacement of logic boards in the main chassis or one of the expansion chassis
- Removal and replacement of power supply boards
- Removal and replacement of interconnecting cables
- Removal and replacement of plug-in memory chips, ROM loaders and other 16-pin ICs
- Removal and replacement of the TMS 9900 microprocessor chip on the 990/4 microcomputer board
- Removal and replacement of the front panel assembly (programmer panel or operator panel) and/or key switch assembly
- Removal and replacement of cooling fans and ac power distribution components

3.3.1 LOGIC BOARD REMOVAL AND REPLACEMENT PROCEDURES. Logic boards are removed from a computer or I/O expansion chassis using the following procedure.



CAUTION

Always turn off power to the chassis before attempting logic board removal. Failure to observe this precaution may result in damage to the board since connector pins are temporarily misaligned during board removal and installation.

1. Set the KEY switch on the front panel of the chassis to the OFF position and remove the key to prevent accidental turn on before the new board has been installed.
2. Remove any top-edge cable connectors which may be mounted on the board.
3. Free the board from the backpanel connectors using the ejector tabs on the top of the board.
4. Remove board from chassis and immediately tag the board with such information as symptom, chassis and slot which the board was removed from and the system location and number (when several systems are installed at the same site).
5. Carefully record the jumper options and any other options (such as parity option, amount of memory, types of ROM loaders and custom ROMs, etc.) which may be installed on the board. These same options must be installed on the replacement board prior to installing the board in the system.

NOTE

Refer to table 3-1 for a summary of board and system options. Additional board and system option descriptions are provided in Section I of this manual.

6. Install the same options on the replacement board (unless an obvious problem is detected with the original setup of the board).
7. Note the serial number and board options incorporated on the replacement board and transfer this data to the system's configuration chart.

3.3.2 OPERATOR/PROGRAMMER PANEL REMOVAL AND REPLACEMENT. The front panel (either operator or programmer panel) may be removed and replaced using the following procedure.

WARNING

Prior to attempting the following removal procedure, disconnect the chassis power cord from ac power. The 115 Vac hot lead is exposed when the panel is removed.

1. Remove the left-side access panel (directly opposite the open side of the chassis) by removing the six holding screws around the perimeter of the panel.
2. Remove two screws from the rear of the panel on each side of the chassis (4 screws total).



3. Remove the two terminal leads from the ac microswitch on the rear of the key switch (the ac microswitch is the leftmost switch as viewed from the rear as shown in figure 3-1).
4. Remove connector plug 1A4P3 from top edge of 990/4 microcomputer board and push plug through slot in chassis.
5. Install replacement panel by reversing the above procedure. See figure 3-2 for correct orientation of connector plug.

3.3.3 POWER SUPPLY REMOVAL AND REPLACEMENT. The 990 power supply consists of a 20 or 40 amp main power supply board, an ac power converter board and an optional standby power supply board and batteries. Removal and replacement procedures for these assemblies are provided in the following paragraphs.

WARNING

The chassis ac power cord must be removed from ac power before attempting the following power supply board removal procedures. Dangerous ac and dc voltages are exposed if this precaution is not observed.




Figure 3-1. 1A4S1 Switch Connections




Figure 3-2. Programmer/Operator Panel Cabling Diagram



Table 3-1. Summary of 990/4 Jumper Options

990/4 MICROCOMPUTER BOARD

| PROM/RAM Starting Address | Jumper Option |
|---|---------------------------|
| 0000 ₁₆ (0) | E19 to E20; E24 to E25 |
| 0800 ₁₆ (1K) | E19 to E20; E24 to E26 |
| F000 ₁₆ (30K) | E19, E20 Open; E24 to E25 |
| F800 ₁₆ (31K) | E19, E20 Open; E24 to E26 |
| PROM/Static RAM Option | |
| Bank 0 = PROM | E7 to E8 |
| Bank 0 = RAM | E7, E8 Open |
| Bank 1 = PROM | E5 to E6 |
| Bank 1 = RAM | E5, E6 Open |
| Bank 2 = PROM | E3 to E4 |
| Bank 2 = RAM | E3, E4 Open |
| Bank 3 = PROM | E1→E2 |
| Bank 3 = RAM | E1, E2 Open |
| Dynamic RAM Starting Address | |
| Start address = 0000 ₁₆ (0) | E16 to E17 |
| Start address = 2000 ₁₆ (4K) | E17 to E18 |
| Power-Up Trap Vector | |
| Vector at address = 0000 ₁₆ | E22 to E27 |
| Vector at address = FFFC ₁₆ | E21 to E22 |
| Clock Interrupt Level | |
| Level = Interrupt 5 | E9 to E10 |
| Level = Interrupt 7 | E10 to E23 |
| Clock Interrupt not Connected | E9, E10, E23 Open |
| Memory Error Interrupt | |
| Connected to Interrupt 2 | E13 to E14 |
| Not Connected | E13, E14 Open |
| Power-Fail Interrupt | |
| Connected to Interrupt 1 | E11 to E12 |
| Not Connected | E11, E12 Open |



Table 3-1. Summary of 990/4 Jumper Options (Continued)

990/4 MEMORY EXPANSION BOARD

| Starting Address | Switch Settings |
|--------------------------|-----------------------|
| 0000 ₁₆ (0) | S2, S3 and S4 off |
| 2000 ₁₆ (4K) | S2, S3 off; S4 on |
| 4000 ₁₆ (8K) | S2 off; S3 on; S4 off |
| 6000 ₁₆ (12K) | S2 off; S3, S4 on |
| 8000 ₁₆ (16K) | S2 on, S3, S4 off |
| A000 ₁₆ (20K) | S2 on, S3 off; S4 on |
| C000 ₁₆ (24K) | S2, S3 on; S4 off |
| E000 ₁₆ (28K) | S2, S3, S4 on |

| Memory Size | Jumpers Required |
|-------------|--|
| 4K | None |
| 8K | Jumper E1 to E2 (E3 thru E6 OPEN) |
| 12K | Jumper E3 to E4 (E1, E2, E5 and E6 OPEN) |
| 16K | Jumper E1 to E2, E3 to E4 (E5 and E6 OPEN) |
| 20K | Jumper E5 to E6 (E1 thru E4 OPEN) |

| Write Protect Option | Jumpers Required |
|----------------------|--------------------------|
| Option installed | E7 and E8 OPEN |
| Option not installed | Jumper between E7 and E8 |

EPROM MEMORY MODULE

| Starting Address (Hex Byte Addresses) | Bias Switch Setting | | | | | Starting Address (Hex Byte Addresses) | Bias Switch Setting | | | | |
|--|---------------------|-----|-----|-----|-----|--|---------------------|-----|-----|-----|-----|
| | S1 | S2 | S3 | S4 | S5 | | S1 | S2 | S3 | S4 | S5 |
| 0000 (0) | off | off | off | off | off | 9000 (18K) | on | off | off | on | off |
| 0800 (1K) | off | off | off | off | on | 9800 (19K) | on | off | off | on | on |
| 1000 (2K) | off | off | off | on | off | A000 (20K) | on | off | on | off | off |
| 1800 (3K) | off | off | off | on | on | A800 (21K) | on | off | on | off | on |
| 2000 (4K) | off | off | on | off | off | B000 (22K) | on | off | on | on | off |
| 2800 (5K) | off | off | on | off | on | B800 (23K) | on | off | on | on | on |
| 3000 (6K) | off | off | on | on | off | C000 (24K) | on | on | off | off | off |
| 3800 (7K) | off | off | on | on | on | C800 (25K) | on | on | off | off | on |
| 4000 (8K) | off | on | off | off | off | D000 (26K) | on | on | off | on | off |
| 4800 (9K) | off | on | off | off | on | D800 (27K) | on | on | off | on | on |
| 5000 (10K) | off | on | off | on | off | E000 (28K) | on | on | on | off | off |
| 5800 (11K) | off | on | off | on | on | E800 (29K) | on | on | on | off | on |
| 6000 (12K) | off | on | on | off | off | F000 (30K) | on | on | on | on | off |
| 6800 (12K) | off | on | on | off | on | F800 (31K) | on | on | on | on | on |



Table 3-1. Summary of 990/4 Jumper Options (Continued)

EPROM MEMORY MODULE

| Starting Address (Hex Byte Addresses) | Bias Switch Setting | | | | | Starting Address (Hex Byte Addresses) | Bias Switch Setting | | | | |
|--|---------------------|-----|-----|-----|-----|--|---------------------|----|----|----|----|
| | S1 | S2 | S3 | S4 | S5 | | S1 | S2 | S3 | S4 | S5 |
| 7000 (14K) | off | on | on | on | off | | | | | | |
| 7800 (15K) | off | on | on | on | on | | | | | | |
| 8000 (16K) | on | off | off | off | off | | | | | | |
| 8800 (17K) | on | off | off | off | on | | | | | | |

Memory Size

Jumpers Required

| | |
|----|------------------------------|
| 1K | E1 to E2; E4 to E5; E7 to E8 |
| 2K | E1 to E2; E4 to E5; E8 to E9 |
| 3K | E1 to E2; E5 to E6; E7 to E8 |
| 4K | E1 to E2; E5 to E6; E8 to E9 |
| 5K | E2 to E3; E4 to E5; E7 to E8 |
| 6K | E2 to E3; E4 to E5; E8 to E9 |
| 7K | E2 to E3; E5 to E6; E7 to E8 |
| 8K | E2 to E3; E5 to E6; E8 to E9 |

Computer Type

Jumper Required

| | |
|-------|----------------------|
| 990/4 | E11 to E12; E10 OPEN |
|-------|----------------------|

CRU EXPANSION BOARD

Reset Source

Jumper Required

| | |
|--------|---------------------------------|
| TLPRES | Jumper E1 to E2, E3 and E4 OPEN |
| IORES | Jumper E3 to E4; E1 and E2 OPEN |

Interrupt Section Enable Option

Jumper Required

| | |
|-----------------------------|-----------------|
| Interrupt Section A enabled | Jumper E5 to E6 |
| Interrupt Section B enabled | Jumper E7 to E8 |

CRU BUFFER BOARD

Chassis No. Select Option

Jumper Required

| | |
|---|------------------|
| 1 | P4 in position 1 |
| 2 | P4 in position 2 |
| . | . |
| . | . |
| . | . |
| 7 | P4 in position 7 |



Table 3-1. Summary of 990/4 Jumper Options (Continued)

| Interrupt 1 Options | Jumpers Required |
|---|-------------------------------------|
| Direct Interrupt | Jumper D11 to D12, D13 and D14 OPEN |
| Interrupt 1 to Scanner | Jumper D13 to D14, D11 and D12 OPEN |
| Internal Clock Option | Jumper Required |
| Internal Clock Enabled | Jumper E1 to E2 |
| Internal Clock Disabled (External clock input at E3; Clear input at E4) | E1 and E2 OPEN |

3.3.3.1 Main Power Supply Board Removal and Replacement. The main power supply board is removed and replaced using the following procedure:

1. If standby power supply is installed, this board must be removed first using the procedures provided in paragraph 3.3.3.3.
2. Remove 4 holding screws (2 from each end of board) and three standoffs from center of board.
3. Remove connectors 1A3P1A and 1A3P2 from board. Also, remove 1A3P1B if 40 amp main power supply board is being removed.
4. Carefully pull board straight back to unplug connector 1A3P3 from backpanel board.
5. Install replacement board by aligning board with two board guide pins which protrude from the backpanel board.
6. Carefully exert gentle pressure near the middle of the bottom edge of the replacement board to mate the backpanel and board connectors.
7. Install holding screws and standoffs removed from faulty board.
8. Install connectors 1A3P1A and 1A3P2 (also 1A3P1B if 40 amp supply).
9. Install 1A3P3 on 1A3J3 if standby power supply option is used. If standby option is not used, install standby replacement plug (Part Number 946739-1) on 1A3J3.

3.3.3.2 Ac Power Converter Board Removal and Replacement. The ac power converter board is removed and replaced using the following procedures.

WARNING

Remove chassis power plug from ac outlet before attempting the following removal/replacement procedures.

1. Remove the chassis filter by applying finger pressure along the top and bottom edges of the filter.



2. Remove the rear access cover (directly behind the filter unit) by removing the six screws around the perimeter of the cover.
3. Remove three cable connectors (1A2P1, 1A2P2, and 1A2P3) from board.
4. Remove single screw from center of board and remove board from chassis.
5. The replacement procedures are essentially the reverse of the removal procedures described in steps 1 through 4.

3.3.3.3 Standby Power Supply Board Removal and Replacement. The standby power supply is removed and replaced using the following procedures.

WARNING

Do not attempt removal of the standby power supply board without first unplugging the chassis power plug from the ac outlet.

1. Remove connector plugs 1A6P1 and 1A6P2 from standby board and remove 1A6P3 from 1A3J3 on main power supply board.
2. Remove five holding screws from board.
3. Installation of a replacement board is the reverse of steps 1 and 2.

3.3.3.4 Cooling Fan Removal and Replacement. The cooling fans in the 990 chassis may be removed and replaced using the following procedure.

WARNING

Before removing the rear access cover, remove chassis power plug from ac outlet.

1. Remove chassis filter by applying finger pressure at top and bottom of filter.
2. Remove rear access cover plate by removing six screws around perimeter of cover plate.
3. Remove two plug-on terminal wires from faulty motor.
4. Remove holding screws and lift motor out of chassis.
5. Install new motor by reversing steps 1 through 4.



3.3.4 IC REMOVAL AND REPLACEMENT. All memory ICs used on 990/4 logic boards are plug-in types which are installed in soldered-in IC sockets. These ICs may be removed and replaced using an IC extractor/installer tool. Since the IC leads are slightly flared, a special tool must be used to compress these leads during removal and installation.

NOTE

Failure to use the proper tool can result in bent pins and improperly seated ICs.

Also, correct IC orientation must be observed when installing a new IC. As shown in figure 3-3, the IC index should face the left side of the board for horizontally mounted ICs and face the bottom of the board for vertically oriented sockets.




Figure 3-3. IC Installation Diagram



SECTION IV

TROUBLESHOOTING

4.1 GENERAL

This section provides troubleshooting procedures to permit rapid isolation of system failures down to a replaceable logic board or cable assembly. Once a suspect subassembly has been identified, the subassembly is removed and replaced in accordance with the corrective maintenance procedures provided in Section III. In the case of a peripheral failure, additional maintenance information is provided in the *Model 990 Computer Peripheral Equipment Field Maintenance Manual*.

4.2 MAINTENANCE PHILOSOPHY

The maintenance philosophy for the 990/4 Microcomputer System at the field-maintenance level is based on a careful evaluation of the customer-failure report. Then the system checkout chart in table 4-1 helps locate system malfunctions, and the procedures provided in table 4-2, combined with the field service test equipment described in Section II and the system-level troubleshooting diagrams in Section V, isolate the malfunction down to the replaceable subassembly (logic card, power supply board, programmer panel/operator panel, cable or plug-in type IC in some cases).

Once a suspect board is identified, the board is removed in accordance with the procedures provided in Section III and the suspect board is *immediately* tagged. The replacement board (or other subassembly) is then modified to incorporate the jumper-wire options and any other options originally installed on the faulty board (see instructions in Section III). The replacement board is then installed in the system and the system is retested in accordance with the procedures provided in table 4-1.

4.2.1 DISPOSITION OF FAULTY SUBASSEMBLY. The removed subassembly (less any special-purpose ROMS) should then be packaged for shipment back to the factory using the packing materials removed from the replacement subassembly. In order to avoid damage in shipment, the subassembly should be carefully packed according to the instructions provided in Section VI.

4.3 TROUBLESHOOTING PROCEDURES

A logical approach to troubleshooting a 990/4 microcomputer system is presented in table 4-1. Once a malfunction is discovered, the fault-isolation procedures in table 4-2 should be used to identify the faulty subassembly.



Table 4-1. 990/4 Microcomputer System Checkout Procedures

| Step | Procedure | Normal Indication | If Abnormal |
|------|---|--|------------------------------|
| 1 | Evaluate system problem report and hardware configuration to determine if 990 Maintenance Unit or the unit's programmer panel will be required to troubleshoot the system. If the system is equipped with both an operable 733 ASR data terminal and operable programmer panel, the Maintenance Unit is not required. However, if the system under test does not contain a 733 ASR, the 990 Maintenance Unit is connected to P3 on the 990/4 microcomputer board and all programmer panel functions (except ac power control) is transferred to the programmer panel in the maintenance unit (see figure 2-2). If the system contains a 733 ASR but does not contain an operable programmer panel, install the programmer panel from the maintenance unit on P3 of the 990/4 microcomputer board as shown in figure 2-3. | — | — |
| 2 | If system is off, set key switch on chassis front panel to the LOCK or ON position and observe the POWER LED on the active programmer panel. | POWER LED lights | See step 1 in table 4-2 |
| 3 | Observe RUN LED on active programmer panel. | RUN LED should light | See step 5 in table 4-2 |
| 4 | Set key switch on active programmer panel (either chassis-mounted or panel in the 990 Maintenance Unit) to UNLOCK position. | — | — |
| 5 | Press HALT/SIE switch on active programmer panel. | RUN LED extinguishes | See step 4 in table 4-2 |
| 6 | If 733 data terminal will be used to load diagnostics into system, proceed to step 7. If the maintenance unit is hooked to the system, skip to step 8 and continue the procedural steps. | — | — |
| 7 | DIAGNOSTIC LOAD PROCEDURE FOR 733 ASR TERMINAL | | |
| | a. Install AU04 diagnostic (part no. 945434) into cassette transport (either 1 or 2) and set the PLAYBACK/RECORD switch so that transport containing diagnostic is in PLAYBACK mode. Set POWER switch to ON. | — | — |
| | b. Rewind the cassette by momentarily pressing REWIND. | END LED lights and tape motion ceases. | See 733 ASR Operating Manual |
| | c. Press LOAD/FF to position tape at the beginning. | READY LED lights | — |
| | d. Setup the terminal's control switches for online operation as follows: <ul style="list-style-type: none"> • Set ONLINE switch to ONLINE position • Set KEYBOARD, PLAYBACK and PRINTER switches to LINE positions | | |
| | e. Press LOAD switch on active programmer panel. | PLAYBACK ON LED on the 733 lights; cassette tape moves forward in short jerky steps. When load is complete, diagnostic ID is printed out on terminal and program execution begins. | See step 6 in table 4-2 |
| | f. Proceed to step 9 of this table. | | |
| 8 | DIAGNOSTIC LOAD FROM MAINTENANCE UNIT | | |
| | a. Install AU04 diagnostic cassette (part no. 945434) into cassette transport on maintenance unit. | — | — |
| | b. Set POWER ON/OFF switch to ON position. | — | — |



Table 4-1. 990/4 Microcomputer System Checkout Procedures (Continued)

| Step | Procedure | Normal Indication | If Abnormal |
|---|---|---|--|
| 8 (Cont) | c. Press REWIND switch. d. Press LOAD on the maintenance unit. | Cassette rewinds and halts at clear leader. Tape load begins; tape moves forward in short jerky steps. When load is complete, ID is displayed on programmer panel. | See step 6 in table 4-2 |
| 9 | The AU04 diagnostic checks each instruction in the TMS 9900 microprocessor's instruction set and verifies the real time clock interrupt logic on the 990/4 microcomputer board. | No error message printout (733) or error number display on programmer panel. (Error message numbers are displayed in the right byte of the DATA LEDs and the left byte is forced to FF ₁₆ when using programmer panel for error message displays) | Reference error message descriptions in diagnostics handbook; see steps 7 thru 10 in table 4-2. |
| NOTE | | | |
| This test is applicable only for the dash 2 configuration of the 990/4 board with 4K RAM memory. For a description of the test options available with the AU04 test, refer to the 990 Computer Diagnostic Handbook. | | | |
| 10 | Rewind cassette tape by pressing REWIND on 733 ASR or 990 Maintenance Unit and repeat diagnostic load procedures for the RAM04 diagnostic test (part no. 945440) which checks each memory location as defined at the beginning of the test. (See diagnostics handbook.) | No errors | Refer to diagnostics handbook for error message interpretation and see steps 8, 9, 11, 12, and 13. |
| 11 | Rewind cassette and install one of the other standalone tests identified in table 2-2 as dictated by the problem report. | No errors | See table 4-2. For peripheral failures, see 990 Computer Peripheral Field Maintenance Manual. |
| NOTE | | | |
| A collection of loop programs which may be entered from the programmer panel to continuously read or write to/from selected memory locations is provided in Appendix E. | | | |



Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures

| Step | Abnormal Indication | Probable Cause | Corrective Action |
|------|---|--|---|
| 1 | POWER LED does not light and cooling fans inoperative when key switch on front panel is set to LOCK or ON position. | <p>Loss of ac power at the power outlet.</p> <p>Blown fuse due to temporary overvoltage condition on ac power line.</p> <p>Open circuit condition in ac distribution system.</p> <p>Faulty power cord.</p> <p>Faulty ac microswitch on rear of operator panel; faulty cam on key switch; loose terminal or broken wire between fuse holder and microswitch or between line filter and ac microswitch.</p> <p>Open circuit in line filter.</p> <p>Loose terminal or break in wiring between line filter and terminal strip.</p> | <p>Using multimeter, measure ac voltage at outlet. If voltage is normal (115 Vac, 230 Vac, or 100 Vac as marked on the rear of the chassis next to the power cable outlet), proceed to next substep.</p> <p>Disconnect ac power cord from ac outlet. Remove fuse 1F1 (located at rear of chassis) and perform continuity check using ohmmeter. Replace fuse (if infinite resistance is indicated) and apply power to the system again. If fuse continues to blow, proceed to step 2. If fuse was not blown when first checked, proceed to next substep.</p> <p>UNPLUG AC POWER CORD FROM AC OUTLET. Set key switch on front panel of chassis to LOCK or ON position. Remove rear access cover and perform following resistance checks:</p> <ol style="list-style-type: none">1. Measure resistance between hot prong of power cord and the black lead of the power cord which connects to pin 2 of the fuse holder 1XF1 (should be 0 ohms). If open, replace power cable. If normal, check resistance between neutral prong of power plug and white lead of power cord which connects to pin 5 of the ac line filter 1FL1. If open circuit is indicated, replace power cord.2. Measure dc resistance between fuse holder (pin 1 or 2) and pin 3 of line filter. If 0 ohms, proceed to next measurement. If infinite or high resistance, remove side access cover (across from logic board side of chassis) and check continuity between the common and normally-open terminals on the ac switch 1A4S4 located directly behind the key switch on the front panel. (The two terminals are the leftmost two terminals on the leftmost switch as viewed from the rear of the panel.) If the switch is open, check the switch cam operation to ensure that the microswitch is being actuated. If not, replace front panel assembly. If the cam is functioning properly, replace 1A4S1. If the switch resistance is normal (0 ohms), use ohmmeter to locate break in wiring between the fuse holder 1XF1 and the N.O. terminal of the switch 1A4S1 or between the common terminal of 1A4S1 and pin 3 of the line filter. If resistance between fuse holder terminal and pin 3 of line filter is normal, perform next check.3. Measure dc resistance between line filter pins 1 and 3 (0 ohms) and between 2 and 5 (0 ohms). Replace filter if either path is open.4. Measure dc resistance between pin 1 of line filter and terminal 1 on terminal strip and between pin 2 of line filter and terminal 2 of terminal strip. If either reading indicates open circuit, repair break in wiring or loose terminal. |



945401-9701

Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures (Continued)

| Step | Abnormal Indication | Probable Cause | Corrective Action |
|------|---------------------------------------|--|---|
| 2 | Fuse continues to blow when replaced. | <p>Shorted winding on one of the blower motors or shorted surge voltage protector.</p> <p>Short circuit condition on ac power converter board (1A2).</p> <p>Short circuit condition on main power supply board (1A3).</p> <p>Short circuit condition on input side of standby power supply board 1A6 (if used).</p> <p>Leaking filter capacitor 1C1.</p> | <p>TURN OFF AC POWER TO CHASSIS. Disconnect 1A2P1 (purple plug on the end of the ac power converter board). Install new fuse and retest system. If fuse does not blow, proceed to next substep. If fuse blows, remove the hot lead of each blower motor from terminal 1 on the terminal strip (end terminal on the right), one motor at a time, and measure the dc resistance of the motor (normally between 20 and 30 ohms). Replace any motor with obvious shorted windings. If all motors test good, measure dc resistance between terminals 1 and 2 of terminal block. If less than 5 ohms, replace surge voltage protector 1C2. If all resistance checks are normal, disconnect hot leads of all blower motors and replace one at a time. After each lead is reconnected, turn on ac power to system. Then check fuse. Repeat for each motor until fuse blows. Replace last motor connected when fuse blows.</p> <p>TURN OFF AC POWER TO THE CHASSIS. Remove all connector plugs from ac power converter board and measure dc resistance between pins 1 and 2 of J1 (purple jack) using R \times 1K scale on ohmmeter. Should be approximately 5K ohms in one direction and a minimum of 100K when the leads are reversed. If abnormal, replace ac power converter board. Then proceed to next substep to ensure that a faulty main power supply or standby power supply board did not result in failure of the converter board.</p> <p>Using R \times 1K scale on ohmmeter, measure input resistance to main power supply by measuring resistance between pins 1 and 2 of 1A2P3 (white plug removed from ac converter board). Normal resistance is approximately 4.5K in one direction and 11K ohms in the reverse direction. If lower resistance is measured, replace main power supply board. If normal, measure resistance between pins 3 and 4 of the same plug (1A2P3) using the R \times 1K scale. Normal values are approximately 2K in one direction and 20K in the reverse direction. If resistance is much lower than normal values, replace main power supply board. If readings are normal, proceed to the next substep.</p> <p>Measure dc resistance between pins 2 and 4 of 1A2P2 (red plug removed from ac power converter board) using R \times 1K scale on ohmmeter. Normal reading is approximately 4K and 10K (reverse direction). If short circuit is indicated, replace standby power supply board. If standby option is not used, locate and correct short-circuit condition in wiring harness. If resistance is normal (above values if standby supply is used or infinity if supply is not used), proceed to next substep.</p> <p>Measure dc resistance of capacitor 1C1 using RX100 scale by measuring between pins 1 and 3 or connector plug 1A2P2 (red plug removed from ac power converter board). Normal indication is a near-zero initial reading with a gradual movement of the meter pointer toward the infinity side of the scale. If resistance value is low or if capacitor shows signs of leakage, replace capacitor.</p> <p>Reconnect the plugs originally removed from ac power converter board. The plugs are keyed such that the plugs will mate in only one way.</p> |



Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures (Continued)

| Step | Abnormal Indication | Probable Cause | Corrective Action |
|--|--|---|---|
| 2 | (Continued) | Faulty main power supply board or ac power converter board under full load conditions. | If all static dc resistance tests are normal, swap out main power supply board first. If problem is still present, swap out ac power converter board and ICs if problem continues. |
| 3 | POWER LED on front panel fails to light when key switch is set to LOCK or ON position; cooling fans function normally; system inoperative. | Faulty main power supply board 1A3 or low output voltage from ac converter board 1A2. Short circuit on one of the boards in the chassis. | Remove and replace main power supply board. If problem persists, remove 1A3P1 from main power supply and measure dc voltage between pins 1 and 2 (pin 1 is POSITIVE lead). Set key switch on chassis front panel to OFF position. If less than 130 Vdc, replace ac power converter and/or capacitor 1C1. If problem still persists, proceed to next substep. Remove all logic boards from the chassis (as each board is removed, ensure that the board location chart on the top of the computer chassis accurately reflects the boards installed in each slot). Then, install known good 990/4 microcomputer board (or CRU buffer board if problem exists in expansion chassis) in slot 1. If problem is solved, install original boards in remaining slots (one at a time) and retest the system as each board is installed. |
| CAUTION | | | |
| Always turn off power to the chassis when removing and replacing logic boards to avoid damage to the boards due to temporary misalignment of pins. | | | |
| If all original boards are reinstalled (except board in slot 1) and system functions normally, the original board in slot 1 is faulty. If the problem returns as one of the other original boards is installed, the last board installed before reappearance of the power failure is the faulty board and should be replaced. Reinstall all other original boards and retest system. | | | |
| 4 | Unable to get programmer panel into halt mode; same symptom appears when programmer panel from 990 Maintenance Unit is substituted for chassis panel. NOTE If symptom appears only with chassis-mounted panel, remove and replace panel. | Custom ROMS installed in bank 3 of 1K ROM memory on 990/4 microcomputer board. Faulty 1K ROM memory section or faulty load generation logic on 990/4 microcomputer board. 1K ROM memory starting address set up for lower 1K of memory address space (jumper between E19 and E20) on 990/4 microcomputer board. | Replace custom ROMs in bank 3 (or banks 2 and 3) with one of the standard ROM loader configurations as shown in figure 1-11. Move custom ROMs to another location in the ROM memory and ensure that address change is reflected by customer's software. Remove and replace 990/4 microcomputer board. Ensure that all jumper options, ROM loaders and custom ROMs are properly installed on replacement board. Carefully evaluate memory system. If the panel software is to be used, the jumper between E19 and E20 must be removed since the last two addresses in memory (FFF ₁₆ C ₁₆ and FFF ₁₆ E ₁₆) must contain ROM WP and PC values for the panel software program which is also located in bank 3 of the ROM memory. |



945401-9701

Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures

| Step | Abnormal Indication | Probable Cause | Corrective Action |
|------|--|---|---|
| 5 | System fails to come up in RUN mode when power is applied to the chassis. | Loss of power up clear signal from main power supply board or faulty driver stage on 990/4 microcomputer board. | Remove and replace 990/4 microcomputer board after transferring all custom ROMs onto replacement board and setting up the jumper options correctly (see Section I). If problem persists, replace main power supply board. Reinstall original 990/4 board if problem was narrowed down to main power supply board. |
| | | | NOTE Problem may also be TMS 9900 on 990/4 microcomputer board. If replacement 990/4 board is not available and problem is not on main power supply board, replace TMS 9900 on 990/4 board. |
| 6 | Unable to load diagnostics from Maintenance Unit; FAULT LED lights when LOAD is initiated. | Self-test failure due to faulty self-test ROMs, memory or microprocessor error. Loss of memory voltage(s). | Remove and inspect all jumper options on 990/4 microcomputer board and all memory boards in the chassis. Ensure that no two memory sections occupy the same address space. If all jumper options are correctly installed, replace the loader ROMs in the 1K memory section on the 990/4 microcomputer board (see figure 1-11). If problem persists, replace 990/4 microcomputer board (ensure that replacement board is properly configured and that all custom ROMs from faulty board have been transferred to replacement board). If problem persists, proceed to next substep. If standby power supply option is not installed, ensure that standby jumper plug is installed on 1A3J3. Using multimeter, observe the following memory voltages at any connector slot in backplane (use extender board if available): <ul style="list-style-type: none">• P2-71: -5 MEM• P2-73: +5 MEM• P2-75: +12 MEM If standby supply option is not used, replace main power supply board if any of these voltages are abnormal. If standby supply is used, replace standby supply if the voltages are abnormal. (-5 MEM may also be due to failure on main power supply board.) |
| 7 | Failure of one or more instructions when executing AU04 diagnostic. | Faulty TMS 9900 or support functions on the 990/4 microcomputer board. | Replace 990/4 microcomputer board. Ensure that all jumper options, loader ROMs and custom ROMs are correctly installed on new board. |
| | | | NOTE If spare board is not available, replace TMS 9900 and retest suspect board. |



Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures (Continued)

| Step | Abnormal Indication | Probable Cause | Corrective Action | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------|--|--|--|---------|---------------|---|-----|---|-----|---|-----|---|-----|---|-----|---|-----|---|-----|---|-----|---|-----|---|-----|----|-----|----|-----|----|-----|----|-----|----|-----|----|-----|--------|-----|
| 8 | ROM04 diagnostic printout indicates single bit error at one or more memory location(s) in 4K RAM address space on 990/4 microcomputer board. NOTE See Appendix E for loop program which may be entered from the programmer panel to loop on a selected address or band of addresses. | Faulty TMS 4051 memory chip. | Remove and replace TMS 4051 memory chip corresponding to bit position as follows: <table border="1" data-bbox="1323 308 1680 795"> <thead> <tr> <th>BIT NO.</th> <th>CHIP LOCATION</th> </tr> </thead> <tbody> <tr><td>0</td><td>U44</td></tr> <tr><td>1</td><td>U45</td></tr> <tr><td>2</td><td>U46</td></tr> <tr><td>3</td><td>U47</td></tr> <tr><td>4</td><td>U48</td></tr> <tr><td>5</td><td>U49</td></tr> <tr><td>6</td><td>U50</td></tr> <tr><td>7</td><td>U51</td></tr> <tr><td>8</td><td>U66</td></tr> <tr><td>9</td><td>U67</td></tr> <tr><td>10</td><td>U68</td></tr> <tr><td>11</td><td>U69</td></tr> <tr><td>12</td><td>U70</td></tr> <tr><td>13</td><td>U71</td></tr> <tr><td>14</td><td>U72</td></tr> <tr><td>15</td><td>U73</td></tr> <tr><td>Parity</td><td>U74</td></tr> </tbody> </table> <p>If problem persists after replacement of memory chip, remove and replace 990/4 microcomputer board after carefully implementing all jumper options and loader options on the replacement board (see Section I for option descriptions).</p> | BIT NO. | CHIP LOCATION | 0 | U44 | 1 | U45 | 2 | U46 | 3 | U47 | 4 | U48 | 5 | U49 | 6 | U50 | 7 | U51 | 8 | U66 | 9 | U67 | 10 | U68 | 11 | U69 | 12 | U70 | 13 | U71 | 14 | U72 | 15 | U73 | Parity | U74 |
| BIT NO. | CHIP LOCATION | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | U44 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | U45 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | U46 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | U47 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | U48 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | U49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | U50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | U51 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | U66 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | U67 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | U68 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | U69 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | U70 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | U71 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | U72 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | U73 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Parity | U74 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Memory failure on 4K RAM address space on 990/4 microcomputer board. Board replaced and problem persists. | One of the expansion memory boards is operating with the same starting address due to an improperly selected starting address or faulty address decode on the board. Starting address of 4K RAM memory improperly jumpered. | Check the starting address associated with each memory expansion board or EPROM memory module in the chassis in accordance with the information provided in figures 1-12 and 1-13. If starting address for each board is properly setup, replace each memory board and repeat diagnostic. Last board replaced when diagnostic board executes properly is the faulty board. Reinstall the other board(s) and repeat the test to ensure that only one problem exists in the system. Recheck jumper options on 990/4 microcomputer board (see figures 1-9 and 1-10). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Real time clock interrupt error. | Interrupt jumper between E9 and E10 or faulty circuit on 990/4 microcomputer board. Loss of 120 Hz pulses from power supply. | Check for jumper between E9 and E10 on 990/4 microcomputer board. If present, replace board (after installing all options and ROMs to replacement board. If problem persists, proceed to next substep. Remove and replace main power supply board and repeat test. If problem persists, replace ac power converter board. If problem persists, proceed to next substep. NOTE Faulty subassembly is the last unit replaced before normal test results are obtained. Reinstall other subassemblies and repeat test to ensure that only one faulty subassembly exists on the system. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



945401-9701

Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures (Continued)

| Step | Abnormal Indication | Probable Cause | Corrective Action |
|------|--|--|--|
| 10 | (Continued) | Software problem. | See 990 Assembly Language Programmer's Guide concerning use of CKOF instructions. |
| 11 | Low order memory banks on 990/4 memory expansion board inoperative, high order banks normal. | Improperly set starting address switches on DIP switch U37. | Refer to figure 1-12 and set up switch positions S2 thru S4 to correspond to expansion memory starting address. In conventional system, the starting address is set at 4K (2000 ₁₆) with S2 and S3 of U37 OFF and S4 ON. If properly set, replace board. |
| 12 | High order memory address space on 990/4 memory expansion board inoperative, low order banks functioning normally. | Memory size jumpers improperly installed. | Set up maximum memory size jumpers (terminals E1 to E6) in accordance with figure 1-12 to reflect the amount of memory implemented on the board. If properly set, replace memory expansion board. |
| 13 | Single bit failure in one or more addresses in the 990/4 memory expansion board's address space. | Faulty TMS 4050 memory chip. | Remove and replace TMS 4050 memory chip in memory bank corresponding to faulty address at bit position corresponding to faulty data bit (see figure 1-2). If problem persists, replace TMS 4050 ICs in same column in the remaining memory banks. If problem still persists, remove and replace memory expansion board. |
| 14 | Unexpected write protect error on memory expansion board. | Faulty write protect circuit on expansion board. | Replace 990/4 memory expansion board and set up starting address and size jumpers as shown in figure 1-12. |
| 15 | Memory failure on address space reserved for EPROM memory module. | Jumpers not properly installed on board or starting address for EPROM board not properly set, faulty EPROM board. | Refer to figure 1-13 and ensure that all board options are properly installed. If so, replace the board. |
| | | | CAUTION |
| | | | All EPROM chips from the faulty board must be transferred to the exact same socket locations on the replacement board. These chips contain custom software programs which will not function if any of the chips are installed out of their original pattern. |
| 16 | One peripheral device within main chassis is inoperative; all other peripherals function normally. | Peripheral's interface board installed in wrong slot (see figure 1-15 for standard configuration recognized by software). Interrupt not wired properly on backpanel board. Improperly seated interface board or loose cable connector. Faulty interface board or jumper options improperly installed. | Move interface board to correct location. If properly located, proceed to next substep. Remove first five logic boards in chassis and ensure that jumper is installed correctly (see figure 1-17). If so, replace boards and proceed to next substep. Check interface board and associated interface cable connectors for snug fit. If device is 733 ASR, 733 KSR or line printer, see figure 1-22 to verify proper jumper connections. At this point, refer to the 990 Computer Peripherals Field Maintenance Manual for additional fault isolation procedures. |



Table 4-2. 990/4 Microcomputer System Fault Isolation Procedures

| Step | Abnormal Indication | Probable Cause | Corrective Action | | | | | | | | | | | | | | | | |
|-------------------|---|--|--|-------------------|-------------|----|---|----|---|----|---|----|---|----|---|----|---|----|---|
| 17 | All peripherals implemented within one expansion chassis are inoperative; peripherals implemented in other expansion chassis function properly. | <p>If POWER LED on chassis is lit and fans are functioning properly, the CRU buffer board is most likely at fault.</p> <p>NOTE</p> <p>If POWER LED and blower motors in expansion chassis are inoperative, see steps 1 and 2 at the beginning of this procedure.</p> | <p>Remove CRU buffer board from chassis and check to see that the jumper plug (P4) on the board is inserted in the slot corresponding to the correct chassis number as follows:</p> <table border="1"> <thead> <tr> <th>CRU EXPANDER PORT</th> <th>CHASSIS NO.</th> </tr> </thead> <tbody> <tr> <td>P3</td> <td>1</td> </tr> <tr> <td>P4</td> <td>2</td> </tr> <tr> <td>P5</td> <td>3</td> </tr> <tr> <td>P6</td> <td>4</td> </tr> <tr> <td>P7</td> <td>5</td> </tr> <tr> <td>P8</td> <td>6</td> </tr> <tr> <td>P9</td> <td>7</td> </tr> </tbody> </table> | CRU EXPANDER PORT | CHASSIS NO. | P3 | 1 | P4 | 2 | P5 | 3 | P6 | 4 | P7 | 5 | P8 | 6 | P9 | 7 |
| CRU EXPANDER PORT | CHASSIS NO. | | | | | | | | | | | | | | | | | | |
| P3 | 1 | | | | | | | | | | | | | | | | | | |
| P4 | 2 | | | | | | | | | | | | | | | | | | |
| P5 | 3 | | | | | | | | | | | | | | | | | | |
| P6 | 4 | | | | | | | | | | | | | | | | | | |
| P7 | 5 | | | | | | | | | | | | | | | | | | |
| P8 | 6 | | | | | | | | | | | | | | | | | | |
| P9 | 7 | | | | | | | | | | | | | | | | | | |
| | | Faulty CRU expander board in main chassis or faulty interface cable between CRU expander board in main chassis and CRU buffer board in expansion chassis. | If the jumper plug is properly installed, replace the CRU buffer board and set up the jumper plug (as described above) on the replacement board. If the problem persists, replace the interface cable between the CRU expander board in the main chassis and the CRU board in the expansion chassis and/or CRU expansion board in the main chassis. If problem persists, proceed to next substep. | | | | | | | | | | | | | | | | |
| | | Interrupt jumpers not properly installed on expansion chassis backpanel. | Refer to figures 1-16 and 1-17. Check interrupt jumpers in chassis backpanel board to ensure that the interrupt assignments listed on the chassis map (top of chassis) are correctly implemented. | | | | | | | | | | | | | | | | |
| 18 | One or more function keys on chassis-mounted programmer panel inoperative; programmer panel on Maintenance Unit functions properly. | Defective switch block on programmer panel. | Remove and replace chassis-mounted panel in accordance with the instructions in Section III. | | | | | | | | | | | | | | | | |
| 19 | One or more function keys inoperative on chassis-mounted programmer panel; same problem exists with programmer panel on maintenance unit. | Faulty panel software ROM on 990/4 microcomputer board. | Install new ROM loader ICs in the 1K ROM memory in accordance with the information provided in figure 1-11. If problem persists, replace 990/4 microcomputer board. | | | | | | | | | | | | | | | | |
| | | | <p>NOTE</p> <p>Ensure that all jumper options on the replacement board match the options installed on the faulty board and that all custom ROMs in the 1K ROM memory have been transferred to the replacement board.</p> | | | | | | | | | | | | | | | | |

**SECTION V****TROUBLESHOOTING DIAGRAMS****5.1 GENERAL**


This section contains a collection of chassis wiring diagrams, backpanel schematics and logic board block diagrams (complete with interface pin assignments) useful in performing field-level maintenance. An index to the drawings in this section is provided in table 5-1.

NOTE

Logic diagrams, IC schematics and power supply schematic diagrams are available in the *990 Computer Family Maintenance Drawings Manual*.

Table 5-1. Diagram Index

| Figure No. | Diagram Title | Page No. |
|-------------------|--|-----------------|
| 5-1 | OEM chassis backpanel schematic | 5-3 |
| 5-2 | 6-slot chassis backpanel schematic | 5-5 |
| 5-3 | 6-slot chassis wiring diagram (2 sheets) | 5-7 |
| 5-4 | 13-slot chassis backpanel schematic | 5-9 |
| 5-5 | 13-slot chassis wiring diagram (2 sheets) | 5-11 |
| 5-6 | 990/4 Microcomputer board block diagram | 5-13 |
| 5-7 | 990/4 Memory expansion board block diagram | 5-15 |
| 5-8 | CRU expander board block diagram | 5-16 |
| 5-9 | CRU buffer board block diagram | 5-17 |
| 5-10 | EPROM memory module block diagram | 5-18 |
| 5-11 | Main power supply board, block diagram | 5-19 |
| 5-12 | Ac power converter board block diagram | 5-21 |
| 5-13 | Standby power supply board block diagram | 5-22 |
| 5-14 | Programmer panel block diagram | 5-23 |



(B) 133385
944918

Figure 5-1. OEM Chassis Backpanel Schematic





Figure 5-2. 6-slot Chassis Backpanel Schematic




945401-9701



NOTES:
 [1] TIED OFF WITH TIE DOWNS
 [2] IA3J3 ON POWER SUPPLY MATES WITH IA3P3 ON STANDBY POWER SUPPLY OR THE STANDBY REPLACEMENT PLUG

(B)133368 (1/2)
 946709

Figure 5-3. 6-slot Chassis Wiring Diagram (Sheet 1 of 2)



(B)133368 (2/2)
946709

Figure 5-3. 6-slot Chassis Wiring Diagram (Sheet 2 of 2)




Figure 5-4. 13-slot Chassis Backpanel Schematic



945401-9701








Figure 5-5. 13-slot Chassis Wiring Diagram (Sheet 1 of 2)

5-11

Digital Systems Division



(B) 133195 (2/2)
946736

Figure 5-5. 13-slot Chassis Wiring Diagram (Sheet 2 of 2)




Figure 5-6. 990/4 Microcomputer Board Block Diagram



P1 CRUBIT(4-11)

| BIT | PIN |
|-----|-----------------|
| 4 | STORCLK- |
| 5 | CRUBITOUT |
| 6 | CRU BIT (4-11) |
| 7 | PVINT- |
| 8 | CRUBITIN |
| 9 | PROTECT VIOLATE |
| 10 | |
| 11 | |

P2 ADR/C-14

| BIT | PIN |
|-----|----------|
| 0 | ADR/C-14 |
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | |
| 7 | |
| 8 | |
| 9 | |
| 10 | |
| 11 | |
| 12 | |
| 13 | |
| 14 | |


P2 DAT/C-11

| BIT | PIN |
|-----|----------|
| 0 | DAT/C-11 |
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | |
| 7 | |
| 8 | |
| 9 | |
| 10 | |
| 11 | |

P1 DAT(12-15)


| BIT | PIN |
|-----|-----|
| 12 | 27 |
| 13 | 28 |
| 14 | 30 |
| 15 | 31 |

DB113343




* WITH OPTIONAL 4K X 1-BIT PARITY STORAGE

Figure 5-7. 990/4 Memory Expansion Board Block Diagram



(B)133355

Figure 5-8. CRU Expander Board Block Diagram



P3

| | | | | |
|------------|----|---|----|----------|
| CHPRES- | 26 | • | 25 | IREQA |
| ID6 | 24 | • | 23 | ID5 |
| ID4 | 22 | • | 21 | ID3 |
| ID2 | 20 | • | 19 | IDENA- |
| INTPRESA- | 18 | • | 17 | EDATOUT- |
| DATAINA- | 16 | • | 15 | EBIT15- |
| EBIT14- | 14 | • | 13 | EBIT13- |
| EBIT12- | 12 | • | 11 | EBIT11- |
| EBIT10- | 10 | • | 9 | EBIT9- |
| EBIT8- | 8 | • | 7 | EBIT7- |
| EBIT6- | 6 | • | 5 | EBIT5- |
| EBIT4- | 4 | • | 3 | RESET- |
| ESTORECLKA | 2 | • | 1 | GND |

TO/FROM CRU EXPANSION BOARD IN MAIN CHASSIS

TO/FROM CRU INTERFACE BOARDS

P2 INT(0-15)-

| BIT | PIN | BIT | PIN | BIT | PIN |
|-----|-----|-----|-----|-----|-----|
| 3 | 24 | 8 | 54 | 13 | 65 |
| 4 | 46 | 9 | 56 | 14 | 66 |
| 5 | 48 | 10 | 58 | 15 | 68 |
| 6 | 50 | 11 | 62 | | |
| 7 | 52 | 12 | 64 | | |

P2 INT(16-31)-

| BIT | PIN | BIT | PIN | BIT | PIN |
|-----|-----|-----|-----|-----|-----|
| 16 | 55 | 22 | 47 | 28 | 11 |
| 17 | 44 | 23 | 49 | 29 | 15 |
| 18 | 51 | 24 | 17 | 30 | 8 |
| 19 | 53 | 25 | 19 | 31 | 9 |
| 20 | 57 | 26 | 10 | | |
| 21 | 59 | 27 | 12 | | |

P1 MODESEL(0-15)-

| BIT | PIN | BIT | PIN |
|-----|-----|-----|-----|
| 0 | 23 | 8 | 48 |
| 1 | 35 | 9 | 49 |
| 2 | 37 | 10 | 51 |
| 3 | 43 | 11 | 53 |
| 4 | 44 | 12 | 61 |
| 5 | 45 | 13 | 67 |
| 6 | 46 | 14 | 69 |
| 7 | 47 | 15 | 76 |

P2 MODESEL(16-31)-

| BIT | PIN | BIT | PIN |
|-----|-----|-----|-----|
| 16 | 38 | 24 | 61 |
| 17 | 36 | 25 | 63 |
| 18 | 34 | 26 | 43 |
| 19 | 32 | 27 | 45 |
| 20 | 22 | 28 | 21 |
| 21 | 18 | 29 | 33 |
| 22 | 16 | 30 | 23 |
| 23 | 13 | 31 | 20 |

P1 CRUBIT(4-15)


| BIT | PIN |
|-----|-----|
| 4 | 56 |
| 5 | 54 |
| 6 | 52 |
| 7 | 50 |
| 8 | 62 |
| 9 | 64 |
| 10 | 68 |
| 11 | 70 |
| 12 | 36 |
| 13 | 32 |
| 14 | 38 |
| 15 | 34 |

Figure 5-9. CRU Buffer Board Block Diagram

(C)133357




945401-9701



(B)1 33350

Figure 5-10. EPROM Memory Module Block Diagram



(B)133361

Figure 5-11. Main Power Supply Board Block Diagram



945401-9701





Figure 5-13. Standby Power Supply Board Block Diagram



P3 CRUBIT(12-15)

| BIT | PIN |
|-----|-----|
| 12 | 19 |
| 13 | 20 |
| 14 | 18 |
| 15 | 16 |

(B)133.153

Figure 5-14. Programmer Panel Block Diagram



SECTION VI

PACKING AND SHIPPING

6.1 GENERAL

This section provides instructions for unpacking new units and packing faulty assemblies for reshipment to the factory for repair. In most cases, the subassembly will consist of a printed circuit card or cable and will be packed using the packing materials from the replacement subassembly. The procedures for repacking the subassemblies are provided in the following paragraphs.

6.2 UNPACKING/PACKING (6- AND 13-SLOT CHASSIS)

The computer is shipped in a corrugated cardboard container together with the circuit boards and interconnecting cables required to install the system. Upon receipt of the container, inspect to ensure that no signs of physical damage are present. Following preliminary inspection, perform the following steps to remove the computer from its container and ready it for operation. Figure 6-1 illustrates the required steps.

NOTE

Save shipping carton and all packing materials for use in reshipment of the unit.

1. Position container so that the address label is right-side up.
2. Open top of container and remove cushioning material from corners.

NOTE

If the computer has the table top enclosure (6-slot chassis only) no foam block is required to secure circuit boards in chassis.

3. Remove cardboard inner sleeve and foam block (rackmount configurations) from shipping container.

WARNING


Use proper lifting techniques to avoid backstrain when lifting computer chassis.

4. Remove computer and attached shipping pallet from container. When lifting assembly, lift from under the assembly to avoid undue strain on the chassis assembly.

CAUTION

To prevent the mounting screws on the underside of the shipping pallet from scratching table surface, place a shielding material (the packing sleeve removed in step 3 makes an excellent shield) on the table before setting the assembly on the table.

5. Place the removed assembly on a convenient, protected work surface.



(A)133078

Figure 6-1. Computer Shipping Packaging

**NOTE**

For rackmount configurations, the slides are packed in the bottom of the shipping container.

6. Remove the rackmount slides (if present) and the interface cables from the bottom of the shipping container.

CAUTION

In the following steps, do not allow the unit to overhang the work surface so far that it will fall off the surface.

7. Position the computer and shipping pallet assembly so that the front edge of the assembly overhangs the edge of the work surface to reveal two (2) #10 mounting screws that secure computer to shipping pallet. See figure 6-2 for location of all mounting screws.
8. Use a straight blade screwdriver to remove the two screws and their associated washers and lock washers. Save the screws and washers for reshipment.
9. Reposition the computer and shipping pallet assembly so that the rear edge of the assembly overhangs the edge of the work surface to reveal three (3) #10 mounting screws that secure computer to shipping pallet.
10. Remove the three screws, washers and lockwashers and save for reshipment.

NOTE


If the computer was ordered for overseas operation, two (2) additional mounting screws are visible on the underside of the shipping pallet. If these screws are not included on the unit being installed, skip step 11.

11. Remove two (2) #6 transformer mounting screws and their associated washers and lockwashers and save for reshipment.
12. Lift computer chassis from shipping pallet and place it on the work surface such that the rear of the unit overhangs the work surface to reveal the holes for the removed mounting screws.


NOTE

If the unit being installed did not have the two #6 mounting screws (see step 11), skip the following step.

13. Remove two (2) #6 screws taped to the top of the computer chassis and insert them in the holes vacated by the two #6 mounting screws moved in step 11. Tighten the two new screws to secure the transformer to the chassis.



(A) 6-SLOT AND TABLE TOP CHASSIS BOTTOM VIEW



(B) 13-SLOT CHASSIS BOTTOM VIEW

(A)133079

Figure 6-2. Location of Chassis Shipping Pallet Mounting Screws



14. Remove the strip of self-adhesive hole covers that are taped to the top of the computer chassis. Use three of the hole covers to cover the three mounting screw holes along the rear of the chassis.
15. Reposition the computer chassis such that the front edge overhangs the work surface to reveal the mounting holes for the front mounting screws.
16. Use the remaining two (2) self-adhesive hole covers to cover the front mounting screw holes.
17. Set the computer chassis in a safe position on the work surface to continue with the remaining portions of the installation procedure.
18. Pack all shipping materials into the original shipping container and store the container for use in reshipment of the unit.
19. Inspect the computer chassis and included components for signs of damage that may have occurred during shipment. If damage has occurred, notify the carrier immediately.

To repack the unit, reverse the above procedure using the original packing material.

6.3 UNPACKING/PACKING (OEM CHASSIS)

The OEM chassis is shipped in a corrugated cardboard container together with the circuit boards and mounting hardware for the system. Upon receipt of the container, inspect to ensure that no signs of physical damage are present. Following preliminary inspection, perform the following steps to remove the chassis from its container. Figure 6-3 illustrates the material included in the packing container.

NOTE


Save shipping carton and all packing materials for use in reshipment of the unit.

1. Position container so that the address label is right-side up.
2. Open top of container and remove chassis assembly enclosed in cushion wrap.
3. Remove cushion wrap from chassis assembly.
4. Remove bag containing mounting hardware from chassis assembly.

NOTE

If circuit boards are included in shipment, they are secured in place by pieces of tape. If no circuit boards are included, skip step 5.

5. Remove pieces of tape that secure circuit boards in chassis.
6. Inspect the chassis and all included components for signs of damage that may have occurred during shipment. If damage has occurred, notify the carrier immediately.



(A)133080

Figure 6-3. OEM Chassis Shipping Packaging

6.4 BOARD PACKING/UNPACKING

The logic board assemblies and power supply boards are shipped in bubble-wrap and corrugated cardboard containers. When removing the shipping materials from a spare subassembly, save the bubble wrap and corrugated cardboard for packing faulty boards for reshipment back to the factory.



APPENDIX A
PROGRAMMING REFERENCE DATA

**990/4 INSTRUCTION SET
(ALPHABETICAL ORDER)**

| Mnemonic Operation Code | Hexadecimal Operation Code | Name | Format |
|--|---|--------------------------------------|---------------|
| A | A000 | Add Words | I |
| AB | B000 | Add Bytes | I |
| ABS | 0740 | Absolute Value | VI |
| AI | 0220 | Add Immediate | VIII |
| ANDI | 0240 | AND Immediate | VIII |
| B | 0440 | Branch | VI |
| BL | 0680 | Branch and Link | VI |
| BLWP | 0400 | Branch and Load Workspace Pointer | VI |
| C | 8000 | Compare Words | I |
| CB | 9000 | Compare Bytes | I |
| CI | 0280 | Compare Immediate | VIII |
| CKOF | 03C0 | Clock Off | VII |
| CKON | 03A0 | Clock On | VII |
| CLR | 04C0 | Clear Operand | VI |
| COC | 2000 | Compare Ones Corresponding | III |
| CZC | 2400 | Compare Zeros Corresponding | III |
| DEC | 0600 | Decrement By One | VI |
| DECT | 0640 | Decrement By Two | VI |
| DIV | 3C00 | Divide | IX |
| IDLE | 0340 | Computer Idle | VII |
| INC | 0580 | Increment By One | VI |
| INCT | 05C0 | Increment By Two | VI |
| INV | 0540 | Invert | VI |
| JEQ | 1300 | Jump Equal | II |
| JGT | 1500 | Jump Greater Than | II |
| JH | 1B00 | Jump High | II |
| JHE | 1400 | Jump High Or Equal | II |
| JL | 1A00 | Jump Low | II |
| JLE | 1200 | Jump Low Or Equal | II |
| JLT | 1100 | Jump Less Than | II |
| JMP | 1000 | Jump Unconditional | II |



990/4 INSTRUCTION SET
(ALPHABETICAL ORDER) (Continued)

| Mnemonic Operation Code | Hexadecimal Operation Code | Name | Format |
|-------------------------------|----------------------------------|-------------------------------------|--------|
| JNC | 1700 | Jump No Carry | II |
| JNE | 1600 | Jump Not Equal | II |
| JNO | 1900 | Jump No Overflow | II |
| JOC | 1800 | Jump On Carry | II |
| JOP | 1C00 | Jump Odd Parity | II |
| LDCR | 3000 | Load Communication Register | IV |
| LI | 0200 | Load Immediate | VIII |
| LIMI | 0300 | Load Interrupt Mask Immediate | VIII |
| LREX | 03E0 | Load or Restart Execution | VII |
| LWPI | 02E0 | Load Workspace Pointer Immediate | VIII |
| MOV | C000 | Move Word | I |
| MOVB | D000 | Move Byte | I |
| MPY | 3800 | Multiply | IX |
| NEG | 0500 | Negate | VI |
| ORI | 0260 | OR Immediate | VIII |
| RSET | 0360 | Computer Reset | VII |
| RTWP | 0380 | Return From Interrupt Subroutine | VII |
| S | 6000 | Subtract Word | I |
| SB | 7000 | Subtract Byte | I |
| SBO | 1D00 | Set Bit To One | II |
| SBZ | 1E00 | Set Bit To Zero | II |
| SETO | 0700 | Set Ones | VI |
| SLA | 0A00 | Shift Left Arithmetic | V |
| SOC | E000 | Set Ones Corresponding, Word | I |
| SOCB | F000 | Set Ones Corresponding, Byte | I |



990/4 INSTRUCTION SET
(ALPHABETICAL ORDER) (Continued)

| Mnemonic Operation Code | Hexadecimal Operation Code | Name | Format |
|-------------------------------|----------------------------------|-------------------------------|--------|
| SRA | 0800 | Shift Right Arithmetic | V |
| SRC | 0B00 | Shift Right Circular | V |
| SRL | 0900 | Shift Right Logical | V |
| STCR | 3400 | Store Communication Register | IV |
| STST | 02C0 | Store Status | VIII |
| STWP | 02A0 | Store Workspace Pointer | VIII |
| SWPB | 06C0 | Swap Bytes | VI |
| SZC | 4000 | Set Zeros Corresponding, Word | I |
| SZCB | 5000 | Set Zeros Corresponding, Byte | I |
| TB | 1F00 | Test Bit | II |
| X | 0480 | Execute | VI |
| XOP | 2C00 | Extended Operation | IX |
| XOR | 2800 | Exclusive OR | III |



**990/4 INSTRUCTION SET
(HEXADECIMAL OP CODE ORDER)**

| Hexadecimal Operation Code | Mnemonic Operation Code | Name | Format |
|----------------------------------|-------------------------------|--------------------------------------|--------|
| 0200 | LI | Load Immediate | VIII |
| 0220 | AI | Add Immediate | VIII |
| 0240 | ANDI | AND Immediate | VIII |
| 0260 | ORI | OR Immediate | VIII |
| 0280 | CI | Compare Immediate | VIII |
| 02A0 | STWP | Store Workspace Pointer | VIII |
| 02C0 | STST | Store Status | VIII |
| 02E0 | LWPI | Load Workspace Pointer Immediate | VIII |
| 0300 | LIMI | Load Interrupt Mask Immediate | VIII |
| 0340 | IDLE | Computer Idle | VII |
| 0360 | RSET | Computer Reset | VII |
| 0380 | RTWP | Return From Interrupt Subroutine | VII |
| 03A0 | CKON | Clock On | VII |
| 03C0 | CKOF | Clock Off | VII |
| 03E0 | LREX | Load ROM and Execute | VII |
| 0400 | BLWP | Branch And Load Workspace Pointer | VI |
| 0440 | B | Branch | VI |
| 0480 | X | Execute | VI |
| 04C0 | CLR | Clear Operand | VI |
| 0500 | NEG | Negate | VI |
| 0540 | INV | Invert | VI |
| 0580 | INC | Increment By One | VI |
| 05C0 | INCT | Increment By Two | VI |
| 0600 | DEC | Decrement By One | VI |
| 0640 | DECT | Decrement By Two | VI |
| 0680 | BL | Branch and Link | VI |
| 06C0 | SWPB | Swap Bytes | VI |
| 0700 | SETO | Set Ones | VI |



990/4 INSTRUCTION SET
(HEXADECIMAL OP CODE ORDER) (Continued)

| Hexadecimal Operation Code | Mnemonic Operation Code | Name | Format |
|----------------------------------|-------------------------------|---------------------------------|--------|
| 0740 | ABS | Absolute Value | VI |
| 0800 | SRA | Shift Right Arithmetic | V |
| 0900 | SRL | Shift Right Logical | V |
| 0A00 | SLA | Shift Left Arithmetic | V |
| 0B00 | SRC | Shift Right Circular | V |
| 1000 | JMP | Jump Unconditional | II |
| 1100 | JLT | Jump Less Than | II |
| 1200 | JLE | Jump Low Or Equal | II |
| 1300 | JEQ | Jump Equal | II |
| 1400 | JHE | Jump High Or Equal | II |
| 1500 | JGT | Jump Greater Than | II |
| 1600 | JNE | Jump Not Equal | II |
| 1700 | JNC | Jump No Carry | II |
| 1800 | JOC | Jump On Carry | II |
| 1900 | JNO | Jump No Overflow | II |
| 1A00 | JL | Jump Low | II |
| 1B00 | JH | Jump High | II |
| 1C00 | JOP | Jump Odd Parity | II |
| 1D00 | SBO | Set Bit To One | II |
| 1E00 | SBZ | Set Bit To Zero | II |
| 1F00 | TB | Test Bit | II |
| 2000 | COC | Compare Ones Corresponding | III |
| 2400 | CZC | Compare Zeros Corresponding | III |
| 2800 | XOR | Exclusive OR | III |
| 2C00 | XOP | Extended Operation | IX |
| 3000 | LDCR | Load Communication Register | IV |
| 3400 | STCR | Store Communication Register | IV |
| 3800 | MPY | Multiply | IX |
| 3C00 | DIV | Divide | IX |



990/4 INSTRUCTION SET
(HEXADECIMAL OP CODE ORDER) (Continued)

| Hexadecimal Operation Code | Mnemonic Operation Code | Name | Format |
|----------------------------------|-------------------------------|----------------------------------|--------|
| 4000 | SZC | Set Zeros Corresponding, Word | I |
| 5000 | SZCB | Set Zeros Corresponding, Byte | I |
| 6000 | S | Subtract Word | I |
| 7000 | SB | Subtract Byte | I |
| 8000 | C | Compare Words | I |
| 9000 | CB | Compare Bytes | I |
| A000 | A | Add Words | I |
| B000 | AB | Add Bytes | I |
| C000 | MOV | Move Word | I |
| D000 | MOVB | Move Byte | I |
| E000 | SOC | Set Ones Corresponding, Word | I |
| F000 | SOCB | Set Ones Corresponding, Byte | I |



APPENDIX B
INTERRUPT VECTOR TABLE



945401-9701

990/4 Interrupt

| Interrupt Priority | Interrupt Name | Reason for Interrupt | Transfer Vector Memory Location | Interrupt Cleared by | Remarks |
|--------------------|----------------------------------|---|---------------------------------|---|--|
| 0 | Power Restored | Ac power restored and power supply voltages are stabilized (RESET - LOW) | 0000 | | All other interrupts are masked, level 0 cannot be masked. |
| 1 | Power Fail (Jumper E11 to E12) | The power supply senses loss of ac. Approximately 7 milliseconds of program time is available before the system will reset. | 0004 | Power Restored Reset (TLPRES-) | Optional jumper at E11 and E12 |
| 2 | Memory Error (Jumper E13 to E14) | ¹ A memory parity error has occurred either on the 990/4 board or the memory expansion board (if available). | 0008 | CRU Bit 12 of console base address-1FE8 or Manual reset on expansion board or power reset (TLPRES-) | Memory parity on the 990/4 board or memory expansion board is optional - on the memory expansion board, switch S1 will disable memory parity error detection. On memory expansion board the Parity Error LED will indicate. |
| 2 | Memory Error (Jumper E13 to E14) | ² An attempt to write into an area assigned as protected memory. Protected memory is an optional feature. | 0008 | Same as ¹ | On optional memory protect the protected areas are defined by an LDCR to a dedicated CRU address of 1FA0. |
| 3 | External Device | | 000C | | |
| 4 | External Device | | 0010 | | |



945401-9701

990/4 Interrupt (Continued)

| Interrupt Priority | Interrupt Name | Reason for Interrupt | Transfer Vector Memory Location | Interrupt Cleared by | Remarks |
|--------------------|-----------------|--|---------------------------------|---|--|
| 5 | Real Time Clock | When enabled with CKON, an interrupt will occur on the next cycle of the 120hz clock | 0014 | An output command sequence of CKOF and CKON or RESET. | This interrupt can be jumpered to either level 5 or level 7 or disconnected. |
| 6 | External Device | | 0018 | | |
| 7 | External Device | | 001C | | The real-time clock may be jumpered to level 7 instead of level 5. |



945401-9701

APPENDIX C
DEVICE CRU FORMATS




Figure C-1. 733 Data Terminal CRU Formats




Figure C-2. Model 306/588 Line Printer CRU Formats





Figure C-3. 804 Card Reader CRU Formats




Figure C-4. 913A CRT Display Terminal CRU Formats



APPENDIX D
HEXADECIMAL TO DECIMAL CONVERSION CHARTS



Table D-1. Hexadecimal Arithmetic

ADDITION TABLE

| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 02 | 03 | 04 | 05 | 06 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 |
| 2 | 03 | 04 | 05 | 06 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 |
| 3 | 04 | 05 | 06 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 |
| 4 | 05 | 06 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 |
| 5 | 06 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 |
| 6 | 07 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 |
| 7 | 08 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 8 | 09 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| 9 | 0A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| A | 0B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |
| B | 0C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 1A |
| C | 0D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 1A | 1B |
| D | 0E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 1A | 1B | 1C |
| E | 0F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 1A | 1B | 1C | 1D |
| F | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 1A | 1B | 1C | 1D | 1E |

MULTIPLICATION TABLE

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2 | 04 | 06 | 08 | 0A | 0C | 0E | 10 | 12 | 14 | 16 | 18 | 1A | 1C | 1E |
| 3 | 06 | 09 | 0C | 0F | 12 | 15 | 18 | 1B | 1E | 21 | 24 | 27 | 2A | 2D |
| 4 | 08 | 0C | 10 | 14 | 18 | 1C | 20 | 24 | 28 | 2C | 30 | 34 | 38 | 3C |
| 5 | 0A | 0F | 14 | 19 | 1E | 23 | 28 | 2D | 32 | 37 | 3C | 41 | 46 | 4B |
| 6 | 0C | 12 | 18 | 1E | 24 | 2A | 30 | 36 | 3C | 42 | 48 | 4E | 54 | 5A |
| 7 | 0E | 15 | 1C | 23 | 2A | 31 | 38 | 3F | 46 | 4D | 54 | 5B | 62 | 69 |
| 8 | 10 | 18 | 20 | 28 | 30 | 38 | 40 | 48 | 50 | 58 | 60 | 68 | 70 | 78 |
| 9 | 12 | 1B | 24 | 2D | 36 | 3F | 48 | 51 | 5A | 63 | 6C | 75 | 7E | 87 |
| A | 14 | 1E | 28 | 32 | 3C | 46 | 50 | 5A | 64 | 6E | 78 | 82 | 8C | 96 |
| B | 16 | 21 | 2C | 37 | 42 | 4D | 58 | 63 | 6E | 79 | 84 | 8F | 9A | A5 |
| C | 18 | 24 | 30 | 3C | 48 | 54 | 60 | 6C | 78 | 84 | 90 | 9C | A8 | B4 |
| D | 1A | 27 | 34 | 41 | 4E | 5B | 68 | 75 | 82 | 8F | 9C | A9 | B6 | C3 |
| E | 1C | 2A | 38 | 46 | 54 | 62 | 70 | 7E | 8C | 9A | A8 | B6 | C4 | D2 |
| F | 1E | 2D | 3C | 4B | 5A | 69 | 78 | 87 | 96 | A5 | B4 | C3 | D2 | E1 |



Table D-2. Table of Powers of 16₁₀

| 16 ⁿ | | | | n | 16 ⁻ⁿ | | | | | | | |
|-----------------|-----|-----|-----|-----|------------------|---------|---------|---------|--------------------|---------------------|---------------------|---------------------|
| | | | 1 | 0 | 0.10000 | 00000 | 00000 | 00000 | x 10 | | | |
| | | | 16 | 1 | 0.62500 | 00000 | 00000 | 00000 | x 10 ⁻¹ | | | |
| | | | 256 | 2 | 0.39062 | 50000 | 00000 | 00000 | x 10 ⁻² | | | |
| | | 4 | 096 | 3 | 0.24414 | 06250 | 00000 | 00000 | x 10 ⁻³ | | | |
| | | 65 | 536 | 4 | 0.15258 | 78906 | 25000 | 00000 | x 10 ⁻⁴ | | | |
| | 1 | 048 | 576 | 5 | 0.95367 | 43164 | 06250 | 00000 | x 10 ⁻⁶ | | | |
| | 16 | 777 | 216 | 6 | 0.59604 | 64477 | 53906 | 25000 | x 10 ⁻⁷ | | | |
| | 268 | 435 | 456 | 7 | 0.37252 | 90298 | 46191 | 40625 | x 10 ⁻⁸ | | | |
| | 4 | 294 | 967 | 296 | 8 | 0.23283 | 06436 | 53869 | 62891 | x 10 ⁻⁹ | | |
| | 68 | 719 | 476 | 736 | 9 | 0.14551 | 91522 | 83668 | 51807 | x 10 ⁻¹⁰ | | |
| | 1 | 099 | 511 | 627 | 776 | 10 | 0.90949 | 47017 | 72928 | 23792 | x 10 ⁻¹² | |
| | 17 | 592 | 186 | 044 | 416 | 11 | 0.56843 | 41886 | 08080 | 14870 | x 10 ⁻¹³ | |
| | 281 | 474 | 976 | 510 | 656 | 12 | 0.35527 | 13678 | 80050 | 09294 | x 10 ⁻¹⁴ | |
| | 4 | 503 | 599 | 627 | 370 | 496 | 13 | 0.22204 | 46049 | 25031 | 30808 | x 10 ⁻¹⁵ |
| | 72 | 057 | 594 | 037 | 927 | 936 | 14 | 0.13877 | 78780 | 78144 | 56755 | x 10 ⁻¹⁶ |
| 1 | 152 | 921 | 504 | 606 | 846 | 976 | 15 | 0.86736 | 17379 | 88403 | 54721 | x 10 ⁻¹⁸ |

Table D-3. Table of Powers of 10₁₆

| 10 ⁿ | | | | n | 10 ⁻ⁿ | | | | | | |
|-----------------|------|--|------|------|------------------|--------|--------|------|--------------------|---------------------|---------------------|
| | | | 1 | 0 | 1.0000 | 0000 | 0000 | 0000 | | | |
| | | | A | 1 | 0.1999 | 9999 | 9999 | 999A | | | |
| | | | 64 | 2 | 0.28F5 | C28F | 5C28 | F5C3 | x 16 ⁻¹ | | |
| | | | 3E8 | 3 | 0.4189 | 374B | C6A7 | EF9E | x 16 ⁻² | | |
| | | | 2710 | 4 | 0.68DB | 8BAC | 710C | B296 | x 16 ⁻³ | | |
| | 1 | | 86A0 | 5 | 0.A7C5 | AC47 | 1B47 | 8423 | x 16 ⁻⁴ | | |
| | F | | 4240 | 6 | 0.10C6 | F7A0 | B5ED | 8D37 | x 16 ⁻⁴ | | |
| | 98 | | 9680 | 7 | 0.1AD7 | F29A | BCAF | 4858 | x 16 ⁻⁵ | | |
| | 5F5 | | E100 | 8 | 0.2AF3 | 1DC4 | 6118 | 73BF | x 16 ⁻⁶ | | |
| | 3B9A | | CA00 | 9 | 0.44B8 | 2FA0 | 9B5A | 52CC | x 16 ⁻⁷ | | |
| | 2 | | 540B | E400 | 10 | 0.6DF3 | 7F67 | 5EF6 | EADF | x 16 ⁻⁸ | |
| | 17 | | 4876 | E800 | 11 | 0.AFEB | FF0B | CB24 | AAFF | x 16 ⁻⁹ | |
| | E8 | | D4A5 | 1000 | 12 | 0.1197 | 9981 | 2DEA | 1119 | x 16 ⁻⁹ | |
| | 918 | | 4E72 | A000 | 13 | 0.1C25 | C268 | 4976 | 81C2 | x 16 ⁻¹⁰ | |
| | 5AF3 | | 107A | 4000 | 14 | 0.2D09 | 370D | 4257 | 3604 | x 16 ⁻¹¹ | |
| | 3 | | 8D7E | A4C6 | 8000 | 15 | 0.480E | BE7B | 9D58 | 566D | x 16 ⁻¹² |
| | 23 | | 86F2 | 6FC1 | 0000 | 16 | 0.734A | CA5F | 6226 | F0AE | x 16 ⁻¹³ |
| | 163 | | 4578 | 5D8A | 0000 | 17 | 0.B877 | AA32 | 36A4 | B449 | x 16 ⁻¹⁴ |
| | DE0 | | B6B3 | A764 | 0000 | 18 | 0.1272 | 5DD1 | D243 | ABA1 | x 16 ⁻¹⁴ |
| | 8AC7 | | 2304 | 89E8 | 0000 | 19 | 0.1D83 | C94F | B6D2 | AC35 | x 16 ⁻¹⁵ |



Table D-4. Table of Powers of Two

| 2^n | n | 2^{-n} | | | | | | | | | | | | | | | | | | |
|------------|----|-----------------------------------|------------------------|-----|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| 1 | 0 | 1.0 | | | | | | | | | | | | | | | | | | |
| 2 | 1 | 0.5 | | | | | | | | | | | | | | | | | | |
| 4 | 2 | 0.25 | | | | | | | | | | | | | | | | | | |
| 8 | 3 | 0.125 | | | | | | | | | | | | | | | | | | |
| 16 | 4 | 0.0625 | 5 | | | | | | | | | | | | | | | | | |
| 32 | 5 | 0.03125 | 25 | | | | | | | | | | | | | | | | | |
| 64 | 6 | 0.015625 | 625 | | | | | | | | | | | | | | | | | |
| 128 | 7 | 0.0078125 | 8125 | 5 | | | | | | | | | | | | | | | | |
| 256 | 8 | 0.00390625 | 90625 | 25 | | | | | | | | | | | | | | | | |
| 512 | 9 | 0.001953125 | 953125 | 125 | | | | | | | | | | | | | | | | |
| 1024 | 10 | 0.0009765625 | 9765625 | 5 | | | | | | | | | | | | | | | | |
| 2048 | 11 | 0.00048828125 | 48828125 | 25 | | | | | | | | | | | | | | | | |
| 4096 | 12 | 0.000244140625 | 244140625 | 625 | | | | | | | | | | | | | | | | |
| 8192 | 13 | 0.0001220703125 | 1220703125 | 5 | | | | | | | | | | | | | | | | |
| 16384 | 14 | 0.00006103515625 | 6103515625 | 25 | | | | | | | | | | | | | | | | |
| 32768 | 15 | 0.000030517578125 | 30517578125 | 125 | | | | | | | | | | | | | | | | |
| 65536 | 16 | 0.0000152587890625 | 152587890625 | 5 | | | | | | | | | | | | | | | | |
| 131072 | 17 | 0.00000762939453125 | 762939453125 | 25 | | | | | | | | | | | | | | | | |
| 262144 | 18 | 0.000003814697265625 | 3814697265625 | 625 | | | | | | | | | | | | | | | | |
| 524288 | 19 | 0.0000019073486328125 | 19073486328125 | 5 | | | | | | | | | | | | | | | | |
| 1048576 | 20 | 0.00000095367431640625 | 95367431640625 | 25 | | | | | | | | | | | | | | | | |
| 2097152 | 21 | 0.000000476837158203125 | 476837158203125 | 125 | | | | | | | | | | | | | | | | |
| 4194304 | 22 | 0.0000002384185791015625 | 2384185791015625 | 5 | | | | | | | | | | | | | | | | |
| 8388608 | 23 | 0.00000011920928955078125 | 11920928955078125 | 25 | | | | | | | | | | | | | | | | |
| 16777216 | 24 | 0.000000059604644775390625 | 59604644775390625 | 625 | | | | | | | | | | | | | | | | |
| 33554432 | 25 | 0.0000000298023223876953125 | 298023223876953125 | 5 | | | | | | | | | | | | | | | | |
| 67108864 | 26 | 0.00000001490116119384765625 | 1490116119384765625 | 25 | | | | | | | | | | | | | | | | |
| 134217728 | 27 | 0.000000007450580596923828125 | 7450580596923828125 | 125 | | | | | | | | | | | | | | | | |
| 268435456 | 28 | 0.0000000037252902984619140625 | 37252902984619140625 | 5 | | | | | | | | | | | | | | | | |
| 536870912 | 29 | 0.00000000186264514923095703125 | 186264514923095703125 | 25 | | | | | | | | | | | | | | | | |
| 1073741824 | 30 | 0.000000000931322574615478515625 | 931322574615478515625 | 625 | | | | | | | | | | | | | | | | |
| 2147483648 | 31 | 0.0000000004656612873077392578125 | 4656612873077392578125 | 5 | | | | | | | | | | | | | | | | |



Table D-5. Hexadecimal–Decimal Integer
Conversion Table

The table appearing on the following pages provides a means for direct conversion of decimal integers in the range of 0 to 4095 and for hexadecimal integers in the range of 0 to FFF.

To convert numbers above those ranges, add table values to the figures below:

| Hexadecimal | Decimal | Hexadecimal | Decimal |
|-------------|---------|-------------|------------|
| 01 000 | 4 096 | 20 000 | 131 072 |
| 02 000 | 8 192 | 30 000 | 196 608 |
| 03 000 | 12 288 | 40 000 | 262 144 |
| 04 000 | 16 384 | 50 000 | 327 680 |
| 05 000 | 20 480 | 60 000 | 393 216 |
| 06 000 | 24 576 | 70 000 | 458 752 |
| 07 000 | 28 672 | 80 000 | 524 288 |
| 08 000 | 32 768 | 90 000 | 589 824 |
| 09 000 | 36 864 | A0 000 | 655 360 |
| 0A 000 | 40 960 | B0 000 | 720 896 |
| 0B 000 | 45 056 | C0 000 | 786 432 |
| 0C 000 | 49 152 | D0 000 | 851 968 |
| 0D 000 | 53 248 | E0 000 | 917 504 |
| 0E 000 | 57 344 | F0 000 | 983 040 |
| 0F 000 | 61 440 | 100 000 | 1 048 576 |
| 10 000 | 65 536 | 200 000 | 2 097 152 |
| 11 000 | 69 632 | 300 000 | 3 145 728 |
| 12 000 | 73 728 | 400 000 | 4 194 304 |
| 13 000 | 77 824 | 500 000 | 5 242 880 |
| 14 000 | 81 920 | 600 000 | 6 291 456 |
| 15 000 | 86 016 | 700 000 | 7 340 032 |
| 16 000 | 90 112 | 800 000 | 8 388 608 |
| 17 000 | 94 208 | 900 000 | 9 437 184 |
| 18 000 | 98 304 | A00 000 | 10 485 760 |
| 19 000 | 102 400 | B00 000 | 11 534 336 |
| 1A 000 | 106 496 | C00 000 | 12 582 912 |
| 1B 000 | 110 592 | D00 000 | 13 631 488 |
| 1C 000 | 114 688 | E00 000 | 14 680 064 |
| 1D 000 | 118 784 | F00 000 | 15 728 640 |
| 1E 000 | 122 880 | 1 000 000 | 16 777 216 |
| 1F 000 | 126 976 | 2 000 000 | 33 554 432 |



Table D-5. Hexadecimal–Decimal Integer Conversion Table (Cont.)

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| 000 | 0000 | 0001 | 0002 | 0003 | 0004 | 0005 | 0006 | 0007 | 0008 | 0009 | 0010 | 0011 | 0012 | 0013 | 0014 | 0015 |
| 010 | 0016 | 0017 | 0018 | 0019 | 0020 | 0021 | 0022 | 0023 | 0024 | 0025 | 0026 | 0027 | 0028 | 0029 | 0030 | 0031 |
| 020 | 0032 | 0033 | 0034 | 0035 | 0036 | 0037 | 0038 | 0039 | 0040 | 0041 | 0042 | 0043 | 0044 | 0045 | 0046 | 0047 |
| 030 | 0048 | 0049 | 0050 | 0051 | 0052 | 0053 | 0054 | 0055 | 0056 | 0057 | 0058 | 0059 | 0060 | 0061 | 0062 | 0063 |
| 040 | 0064 | 0065 | 0066 | 0067 | 0068 | 0069 | 0070 | 0071 | 0072 | 0073 | 0074 | 0075 | 0076 | 0077 | 0078 | 0079 |
| 050 | 0080 | 0081 | 0082 | 0083 | 0084 | 0085 | 0086 | 0087 | 0088 | 0089 | 0090 | 0091 | 0092 | 0093 | 0094 | 0095 |
| 060 | 0096 | 0097 | 0098 | 0099 | 0100 | 0101 | 0102 | 0103 | 0104 | 0105 | 0106 | 0107 | 0108 | 0109 | 0110 | 0111 |
| 070 | 0112 | 0113 | 0114 | 0115 | 0116 | 0117 | 0118 | 0119 | 0120 | 0121 | 0122 | 0123 | 0124 | 0125 | 0126 | 0127 |
| 080 | 0128 | 0129 | 0130 | 0131 | 0132 | 0133 | 0134 | 0135 | 0136 | 0137 | 0138 | 0139 | 0140 | 0141 | 0142 | 0143 |
| 090 | 0144 | 0145 | 0146 | 0147 | 0148 | 0149 | 0150 | 0151 | 0152 | 0153 | 0154 | 0155 | 0156 | 0157 | 0158 | 0159 |
| 0A0 | 0160 | 0161 | 0162 | 0163 | 0164 | 0165 | 0166 | 0167 | 0168 | 0169 | 0170 | 0171 | 0172 | 0173 | 0174 | 0175 |
| 0B0 | 0176 | 0177 | 0178 | 0179 | 0180 | 0181 | 0182 | 0183 | 0184 | 0185 | 0186 | 0187 | 0188 | 0189 | 0190 | 0191 |
| 0C0 | 0192 | 0193 | 0194 | 0195 | 0196 | 0197 | 0198 | 0199 | 0200 | 0201 | 0202 | 0203 | 0204 | 0205 | 0206 | 0207 |
| 0D0 | 0208 | 0209 | 0210 | 0211 | 0212 | 0213 | 0214 | 0215 | 0216 | 0217 | 0218 | 0219 | 0220 | 0221 | 0222 | 0223 |
| 0E0 | 0224 | 0225 | 0226 | 0227 | 0228 | 0229 | 0230 | 0231 | 0232 | 0233 | 0234 | 0235 | 0236 | 0237 | 0238 | 0239 |
| 0F0 | 0240 | 0241 | 0242 | 0243 | 0244 | 0245 | 0246 | 0247 | 0248 | 0249 | 0250 | 0251 | 0252 | 0253 | 0254 | 0255 |
| 100 | 0256 | 0257 | 0258 | 0259 | 0260 | 0261 | 0262 | 0263 | 0264 | 0265 | 0266 | 0267 | 0268 | 0269 | 0270 | 0271 |
| 110 | 0272 | 0273 | 0274 | 0275 | 0276 | 0277 | 0278 | 0279 | 0280 | 0281 | 0282 | 0283 | 0284 | 0285 | 0286 | 0287 |
| 120 | 0288 | 0289 | 0290 | 0291 | 0292 | 0293 | 0294 | 0295 | 0296 | 0297 | 0298 | 0299 | 0300 | 0301 | 0302 | 0303 |
| 130 | 0304 | 0305 | 0306 | 0307 | 0308 | 0309 | 0310 | 0311 | 0312 | 0313 | 0314 | 0315 | 0316 | 0317 | 0318 | 0319 |
| 140 | 0320 | 0321 | 0322 | 0323 | 0324 | 0325 | 0326 | 0327 | 0328 | 0329 | 0330 | 0331 | 0332 | 0333 | 0334 | 0335 |
| 150 | 0336 | 0337 | 0338 | 0339 | 0340 | 0341 | 0342 | 0343 | 0344 | 0345 | 0346 | 0347 | 0348 | 0349 | 0350 | 0351 |
| 160 | 0352 | 0353 | 0354 | 0355 | 0356 | 0357 | 0358 | 0359 | 0360 | 0361 | 0362 | 0363 | 0364 | 0365 | 0366 | 0367 |
| 170 | 0368 | 0369 | 0370 | 0371 | 0372 | 0373 | 0374 | 0375 | 0376 | 0377 | 0378 | 0379 | 0380 | 0381 | 0382 | 0383 |
| 180 | 0384 | 0385 | 0386 | 0387 | 0388 | 0389 | 0390 | 0391 | 0392 | 0393 | 0394 | 0395 | 0396 | 0397 | 0398 | 0399 |
| 190 | 0400 | 0401 | 0402 | 0403 | 0404 | 0405 | 0406 | 0407 | 0408 | 0409 | 0410 | 0411 | 0412 | 0413 | 0414 | 0415 |
| 1A0 | 0416 | 0417 | 0418 | 0419 | 0420 | 0421 | 0422 | 0423 | 0424 | 0425 | 0426 | 0427 | 0428 | 0429 | 0430 | 0431 |
| 1B0 | 0432 | 0433 | 0434 | 0435 | 0436 | 0437 | 0438 | 0439 | 0440 | 0441 | 0442 | 0443 | 0444 | 0445 | 0446 | 0447 |
| 1C0 | 0448 | 0449 | 0450 | 0451 | 0452 | 0453 | 0454 | 0455 | 0456 | 0457 | 0458 | 0459 | 0460 | 0461 | 0462 | 0463 |
| 1D0 | 0464 | 0465 | 0466 | 0467 | 0468 | 0469 | 0470 | 0471 | 0472 | 0473 | 0474 | 0475 | 0476 | 0477 | 0478 | 0479 |
| 1E0 | 0480 | 0481 | 0482 | 0483 | 0484 | 0485 | 0486 | 0487 | 0488 | 0489 | 0490 | 0491 | 0492 | 0493 | 0494 | 0495 |
| 1F0 | 0496 | 0497 | 0498 | 0499 | 0500 | 0501 | 0502 | 0503 | 0504 | 0505 | 0506 | 0507 | 0508 | 0509 | 0510 | 0511 |
| 200 | 0512 | 0513 | 0514 | 0515 | 0516 | 0517 | 0518 | 0519 | 0520 | 0521 | 0522 | 0523 | 0524 | 0525 | 0526 | 0527 |
| 210 | 0528 | 0529 | 0530 | 0531 | 0532 | 0533 | 0534 | 0535 | 0536 | 0537 | 0538 | 0539 | 0540 | 0541 | 0542 | 0543 |
| 220 | 0544 | 0545 | 0546 | 0547 | 0548 | 0549 | 0550 | 0551 | 0552 | 0553 | 0554 | 0555 | 0556 | 0557 | 0558 | 0559 |
| 230 | 0560 | 0561 | 0562 | 0563 | 0564 | 0565 | 0566 | 0567 | 0568 | 0569 | 0570 | 0571 | 0572 | 0573 | 0574 | 0575 |
| 240 | 0576 | 0577 | 0578 | 0579 | 0580 | 0581 | 0582 | 0583 | 0584 | 0585 | 0586 | 0587 | 0588 | 0589 | 0590 | 0591 |
| 250 | 0592 | 0593 | 0594 | 0595 | 0596 | 0597 | 0598 | 0599 | 0600 | 0601 | 0602 | 0603 | 0604 | 0605 | 0606 | 0607 |
| 260 | 0608 | 0609 | 0610 | 0611 | 0612 | 0613 | 0614 | 0615 | 0616 | 0617 | 0618 | 0619 | 0620 | 0621 | 0622 | 0623 |
| 270 | 0624 | 0625 | 0626 | 0627 | 0628 | 0629 | 0630 | 0631 | 0632 | 0633 | 0634 | 0635 | 0636 | 0637 | 0638 | 0639 |
| 280 | 0640 | 0641 | 0642 | 0643 | 0644 | 0645 | 0646 | 0647 | 0648 | 0649 | 0650 | 0651 | 0652 | 0653 | 0654 | 0655 |
| 290 | 0656 | 0657 | 0658 | 0659 | 0660 | 0661 | 0662 | 0663 | 0664 | 0665 | 0666 | 0667 | 0668 | 0669 | 0670 | 0671 |
| 2A0 | 0672 | 0673 | 0674 | 0675 | 0676 | 0677 | 0678 | 0679 | 0680 | 0681 | 0682 | 0683 | 0684 | 0685 | 0686 | 0687 |
| 2B0 | 0688 | 0689 | 0690 | 0691 | 0692 | 0693 | 0694 | 0695 | 0696 | 0697 | 0698 | 0699 | 0700 | 0701 | 0702 | 0703 |
| 2C0 | 0704 | 0705 | 0706 | 0707 | 0708 | 0709 | 0710 | 0711 | 0712 | 0713 | 0714 | 0715 | 0716 | 0717 | 0718 | 0719 |
| 2D0 | 0720 | 0721 | 0722 | 0723 | 0724 | 0725 | 0726 | 0727 | 0728 | 0729 | 0730 | 0731 | 0732 | 0733 | 0734 | 0735 |
| 2E0 | 0736 | 0737 | 0738 | 0739 | 0740 | 0741 | 0742 | 0743 | 0744 | 0745 | 0746 | 0747 | 0748 | 0749 | 0750 | 0751 |
| 2F0 | 0752 | 0753 | 0754 | 0755 | 0756 | 0757 | 0758 | 0759 | 0760 | 0761 | 0762 | 0763 | 0764 | 0765 | 0766 | 0767 |



Table D-5. Hexadecimal - Decimal Integer Conversion Table (Cont.)

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| 300 | 0768 | 0769 | 0770 | 0771 | 0772 | 0773 | 0774 | 0775 | 0776 | 0777 | 0778 | 0779 | 0780 | 0781 | 0782 | 0783 |
| 310 | 0784 | 0785 | 0786 | 0787 | 0788 | 0789 | 0790 | 0791 | 0792 | 0793 | 0794 | 0795 | 0796 | 0797 | 0798 | 0799 |
| 320 | 0800 | 0801 | 0802 | 0803 | 0804 | 0805 | 0806 | 0807 | 0808 | 0809 | 0810 | 0811 | 0812 | 0813 | 0814 | 0815 |
| 330 | 0816 | 0817 | 0818 | 0819 | 0820 | 0821 | 0822 | 0823 | 0824 | 0825 | 0826 | 0827 | 0828 | 0829 | 0830 | 0831 |
| 340 | 0832 | 0833 | 0834 | 0835 | 0836 | 0837 | 0838 | 0839 | 0840 | 0841 | 0842 | 0843 | 0844 | 0845 | 0846 | 0847 |
| 350 | 0848 | 0849 | 0850 | 0851 | 0852 | 0853 | 0854 | 0855 | 0856 | 0857 | 0858 | 0859 | 0860 | 0861 | 0862 | 0863 |
| 360 | 0864 | 0865 | 0866 | 0867 | 0868 | 0869 | 0870 | 0871 | 0872 | 0873 | 0874 | 0875 | 0876 | 0877 | 0878 | 0879 |
| 370 | 0880 | 0881 | 0882 | 0883 | 0884 | 0885 | 0886 | 0887 | 0888 | 0889 | 0890 | 0891 | 0892 | 0893 | 0894 | 0895 |
| 380 | 0896 | 0897 | 0898 | 0899 | 0900 | 0901 | 0902 | 0903 | 0904 | 0905 | 0906 | 0907 | 0908 | 0909 | 0910 | 0911 |
| 390 | 0912 | 0913 | 0914 | 0915 | 0916 | 0917 | 0918 | 0919 | 0920 | 0921 | 0922 | 0923 | 0924 | 0925 | 0926 | 0927 |
| 3A0 | 0928 | 0929 | 0930 | 0931 | 0932 | 0933 | 0934 | 0935 | 0936 | 0937 | 0938 | 0939 | 0940 | 0941 | 0942 | 0943 |
| 3B0 | 0944 | 0945 | 0946 | 0947 | 0948 | 0949 | 0950 | 0951 | 0952 | 0953 | 0954 | 0955 | 0956 | 0957 | 0958 | 0959 |
| 3C0 | 0960 | 0961 | 0962 | 0963 | 0964 | 0965 | 0966 | 0967 | 0968 | 0969 | 0970 | 0971 | 0972 | 0973 | 0974 | 0975 |
| 3D0 | 0976 | 0977 | 0978 | 0979 | 0980 | 0981 | 0982 | 0983 | 0984 | 0985 | 0986 | 0987 | 0988 | 0989 | 0990 | 0991 |
| 3E0 | 0992 | 0993 | 0994 | 0995 | 0996 | 0997 | 0998 | 0999 | 1000 | 1001 | 1002 | 1003 | 1004 | 1005 | 1006 | 1007 |
| 3F0 | 1008 | 1009 | 1010 | 1011 | 1012 | 1013 | 1014 | 1015 | 1016 | 1017 | 1018 | 1019 | 1020 | 1021 | 1022 | 1023 |
| 400 | 1024 | 1025 | 1026 | 1027 | 1028 | 1029 | 1030 | 1031 | 1032 | 1033 | 1034 | 1035 | 1036 | 1037 | 1038 | 1039 |
| 410 | 1040 | 1041 | 1042 | 1043 | 1044 | 1045 | 1046 | 1047 | 1048 | 1049 | 1050 | 1051 | 1052 | 1053 | 1054 | 1055 |
| 420 | 1056 | 1057 | 1058 | 1059 | 1060 | 1061 | 1062 | 1063 | 1064 | 1065 | 1066 | 1067 | 1068 | 1069 | 1070 | 1071 |
| 430 | 1072 | 1073 | 1074 | 1075 | 1076 | 1077 | 1078 | 1079 | 1080 | 1081 | 1082 | 1083 | 1084 | 1085 | 1086 | 1087 |
| 440 | 1088 | 1089 | 1090 | 1091 | 1092 | 1093 | 1094 | 1095 | 1096 | 1097 | 1098 | 1099 | 1100 | 1101 | 1102 | 1103 |
| 450 | 1104 | 1105 | 1106 | 1107 | 1108 | 1109 | 1110 | 1111 | 1112 | 1113 | 1114 | 1115 | 1116 | 1117 | 1118 | 1119 |
| 460 | 1120 | 1121 | 1122 | 1123 | 1124 | 1125 | 1126 | 1127 | 1128 | 1129 | 1130 | 1131 | 1132 | 1133 | 1134 | 1135 |
| 470 | 1136 | 1137 | 1138 | 1139 | 1140 | 1141 | 1142 | 1143 | 1144 | 1145 | 1146 | 1147 | 1148 | 1149 | 1150 | 1151 |
| 480 | 1152 | 1153 | 1154 | 1155 | 1156 | 1157 | 1158 | 1159 | 1160 | 1161 | 1162 | 1163 | 1164 | 1165 | 1166 | 1167 |
| 490 | 1168 | 1169 | 1170 | 1171 | 1172 | 1173 | 1174 | 1175 | 1176 | 1177 | 1178 | 1179 | 1180 | 1181 | 1182 | 1183 |
| 4A0 | 1184 | 1185 | 1186 | 1187 | 1188 | 1189 | 1190 | 1191 | 1192 | 1193 | 1194 | 1195 | 1196 | 1197 | 1198 | 1199 |
| 4B0 | 1200 | 1201 | 1202 | 1203 | 1204 | 1205 | 1206 | 1207 | 1208 | 1209 | 1210 | 1211 | 1212 | 1213 | 1214 | 1215 |
| 4C0 | 1216 | 1217 | 1218 | 1219 | 1220 | 1221 | 1222 | 1223 | 1224 | 1225 | 1226 | 1227 | 1228 | 1229 | 1230 | 1231 |
| 4D0 | 1232 | 1233 | 1234 | 1235 | 1236 | 1237 | 1238 | 1239 | 1240 | 1241 | 1242 | 1243 | 1244 | 1245 | 1246 | 1247 |
| 4E0 | 1248 | 1249 | 1250 | 1251 | 1252 | 1253 | 1254 | 1255 | 1256 | 1257 | 1258 | 1259 | 1260 | 1261 | 1262 | 1263 |
| 4F0 | 1264 | 1265 | 1266 | 1267 | 1268 | 1269 | 1270 | 1271 | 1272 | 1273 | 1274 | 1275 | 1276 | 1277 | 1278 | 1279 |
| 500 | 1280 | 1281 | 1282 | 1283 | 1284 | 1285 | 1286 | 1287 | 1288 | 1289 | 1290 | 1291 | 1291 | 1293 | 1294 | 1295 |
| 510 | 1296 | 1297 | 1298 | 1299 | 1399 | 1301 | 1302 | 1303 | 1304 | 1305 | 1306 | 1307 | 1308 | 1309 | 1310 | 1311 |
| 520 | 1312 | 1313 | 1314 | 1315 | 1316 | 1317 | 1318 | 1319 | 1329 | 1321 | 1322 | 1323 | 1324 | 1325 | 1326 | 1327 |
| 530 | 1328 | 1329 | 1330 | 1331 | 1332 | 1333 | 1334 | 1335 | 1336 | 1337 | 1338 | 1339 | 1340 | 1341 | 1342 | 1343 |
| 540 | 1344 | 1345 | 1346 | 1347 | 1348 | 1349 | 1350 | 1351 | 1352 | 1353 | 1354 | 1355 | 1356 | 1367 | 1358 | 1359 |
| 550 | 1360 | 1361 | 1362 | 1363 | 1364 | 1365 | 1366 | 1367 | 1368 | 1369 | 1370 | 1371 | 1372 | 1373 | 1374 | 1375 |
| 560 | 1376 | 1377 | 1378 | 1379 | 1380 | 1381 | 1382 | 1383 | 1384 | 1385 | 1386 | 1387 | 1388 | 1389 | 1390 | 1391 |
| 570 | 1392 | 1393 | 1394 | 1395 | 1396 | 1397 | 1398 | 1399 | 1400 | 1401 | 1402 | 1403 | 1404 | 1405 | 1406 | 1407 |
| 580 | 1408 | 1409 | 1410 | 1411 | 1412 | 1413 | 1414 | 1415 | 1416 | 1417 | 1418 | 1419 | 1429 | 1421 | 1422 | 1423 |
| 590 | 1324 | 1425 | 1426 | 1427 | 1428 | 1429 | 1430 | 1431 | 1432 | 1433 | 1434 | 1435 | 1436 | 1437 | 1438 | 1439 |
| 5A0 | 1440 | 1441 | 1442 | 1443 | 1444 | 1445 | 1446 | 1447 | 1448 | 1449 | 1450 | 1451 | 1452 | 1453 | 1454 | 1455 |
| 5B0 | 1456 | 1457 | 1458 | 1459 | 1460 | 1461 | 1462 | 1463 | 1464 | 1465 | 1466 | 1467 | 1468 | 1469 | 1470 | 1471 |
| 5C0 | 1472 | 1473 | 1474 | 1475 | 1476 | 1477 | 1478 | 1479 | 1480 | 1481 | 1482 | 1483 | 1484 | 1485 | 1486 | 1487 |
| 5D0 | 1488 | 1489 | 1490 | 1491 | 1492 | 1493 | 1494 | 1495 | 1496 | 1497 | 1498 | 1499 | 1500 | 1501 | 1502 | 1503 |
| 5E0 | 1504 | 1505 | 1506 | 1507 | 1508 | 1509 | 1510 | 1511 | 1512 | 1513 | 1514 | 1515 | 1516 | 1517 | 1518 | 1519 |
| 5F0 | 1520 | 1521 | 1522 | 1523 | 1524 | 1525 | 1526 | 1527 | 1528 | 1529 | 1530 | 1531 | 1532 | 1533 | 1534 | 1535 |



Table D-5. Hexadecimal–Decimal Integer Conversion Table (Cont.)

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|-----|------|------|------|------|------|------|------|------|------|------|------|-------|------|------|------|------|
| 600 | 1536 | 1537 | 1538 | 1539 | 1540 | 1541 | 1542 | 1543 | 1544 | 1545 | 1546 | 1547 | 1548 | 1549 | 1550 | 1551 |
| 610 | 1552 | 1553 | 1554 | 1555 | 1556 | 1557 | 1558 | 1559 | 1560 | 1561 | 1562 | 1563 | 1564 | 1565 | 1566 | 1567 |
| 620 | 1568 | 1569 | 1570 | 1571 | 1572 | 1573 | 1574 | 1575 | 1576 | 1577 | 1578 | 1579 | 1580 | 1581 | 1582 | 1583 |
| 630 | 1584 | 1585 | 1586 | 1587 | 1588 | 1589 | 1590 | 1591 | 1592 | 1592 | 1594 | 1595 | 1596 | 1597 | 1598 | 1599 |
| 640 | 1600 | 1601 | 1602 | 1603 | 1604 | 1605 | 1606 | 1607 | 1608 | 1609 | 1610 | 1611 | 1612 | 1613 | 1614 | 1615 |
| 650 | 1616 | 1617 | 1618 | 1619 | 1620 | 1621 | 1622 | 1623 | 1624 | 1625 | 1626 | 1627 | 1628 | 1629 | 1630 | 1631 |
| 660 | 1632 | 1633 | 1634 | 1635 | 1636 | 1637 | 1638 | 1639 | 1640 | 1641 | 1642 | 1643 | 1644 | 1645 | 1646 | 1647 |
| 670 | 1648 | 1649 | 1650 | 1651 | 1652 | 1653 | 1654 | 1655 | 1656 | 1657 | 1658 | 1659 | 1660 | 1661 | 1662 | 1663 |
| 680 | 1664 | 1665 | 1666 | 1667 | 1668 | 1669 | 1670 | 1671 | 1672 | 1673 | 1674 | 1675 | 1676 | 1677 | 1678 | 1679 |
| 690 | 1680 | 1681 | 1682 | 1683 | 1684 | 1685 | 1686 | 1687 | 1688 | 1689 | 1690 | 1691 | 1692 | 1693 | 1694 | 1695 |
| 6A0 | 1696 | 1697 | 1698 | 1699 | 1700 | 1701 | 1702 | 1703 | 1704 | 1705 | 1706 | 1707 | 1708 | 1709 | 1710 | 1711 |
| 6B0 | 1712 | 1713 | 1714 | 1715 | 1716 | 1717 | 1718 | 1719 | 1720 | 1721 | 1722 | 17231 | 1724 | 1725 | 1726 | 1727 |
| 6C0 | 1728 | 1729 | 1730 | 1731 | 1732 | 1733 | 1734 | 1735 | 1736 | 1737 | 1738 | 1739 | 1740 | 1741 | 1742 | 1743 |
| 6D0 | 1744 | 1745 | 1746 | 1747 | 1748 | 1749 | 1750 | 1751 | 1752 | 1753 | 1754 | 1755 | 1756 | 1757 | 1758 | 1759 |
| 6E0 | 1760 | 1761 | 1762 | 1763 | 1764 | 1765 | 1766 | 1767 | 1768 | 1769 | 1770 | 1771 | 1772 | 1773 | 1774 | 1775 |
| 6F0 | 1776 | 1777 | 1778 | 1779 | 1780 | 1781 | 1782 | 1783 | 1784 | 1785 | 1786 | 1787 | 1788 | 1789 | 1790 | 1791 |
| 700 | 1792 | 1793 | 1794 | 1795 | 1796 | 1797 | 1798 | 1799 | 1800 | 1801 | 8102 | 1803 | 1804 | 1805 | 1806 | 1807 |
| 710 | 1808 | 1809 | 1810 | 1811 | 1812 | 1813 | 1814 | 1815 | 1816 | 1817 | 1818 | 1819 | 1820 | 1821 | 1822 | 1823 |
| 720 | 1824 | 1825 | 1826 | 1827 | 1818 | 1829 | 1830 | 1831 | 1832 | 1833 | 1834 | 1835 | 1836 | 1837 | 1838 | 1839 |
| 730 | 1840 | 1841 | 1842 | 1843 | 1844 | 1845 | 1846 | 1847 | 1848 | 1849 | 1850 | 1851 | 1852 | 1853 | 1854 | 1855 |
| 740 | 1856 | 1857 | 1858 | 1859 | 1860 | 1861 | 1862 | 1863 | 1864 | 1865 | 1866 | 1867 | 1868 | 1869 | 1870 | 1871 |
| 750 | 1872 | 1873 | 1874 | 1875 | 1876 | 1877 | 1878 | 1879 | 1880 | 1881 | 1882 | 1883 | 1884 | 1885 | 1886 | 1887 |
| 760 | 1888 | 1889 | 1890 | 1891 | 1892 | 1893 | 1894 | 1895 | 1896 | 1897 | 1898 | 1899 | 1900 | 1909 | 1902 | 1903 |
| 770 | 1904 | 1905 | 1906 | 1907 | 1908 | 1909 | 1910 | 1911 | 1912 | 1913 | 1914 | 1915 | 1916 | 1917 | 1918 | 1919 |
| 780 | 1920 | 1921 | 1922 | 1923 | 1924 | 1925 | 1926 | 1927 | 1928 | 1929 | 1930 | 1931 | 1932 | 1933 | 1934 | 1935 |
| 790 | 1936 | 1937 | 1938 | 1939 | 1940 | 1941 | 1942 | 1943 | 1944 | 1945 | 1946 | 1947 | 1948 | 1949 | 1950 | 1951 |
| 7A0 | 1952 | 1953 | 1954 | 1955 | 1956 | 1957 | 1958 | 1959 | 1960 | 1961 | 1962 | 1963 | 1964 | 1965 | 1966 | 1967 |
| 7B0 | 1968 | 1969 | 1970 | 1971 | 1972 | 1973 | 1974 | 1975 | 1976 | 1977 | 1978 | 1979 | 1980 | 1981 | 1982 | 1983 |
| 7C0 | 1984 | 1985 | 1986 | 1987 | 1988 | 1989 | 1990 | 1991 | 1992 | 1993 | 1994 | 1995 | 1996 | 1997 | 1998 | 1999 |
| 7D0 | 2000 | 2001 | 2002 | 2003 | 2004 | 2005 | 2006 | 2007 | 2008 | 2009 | 2010 | 2011 | 2012 | 2013 | 2014 | 2015 |
| 7E0 | 2016 | 2017 | 2018 | 2019 | 2020 | 2021 | 2022 | 2023 | 2024 | 2025 | 2026 | 2027 | 2028 | 2029 | 2030 | 2031 |
| 7F0 | 2032 | 2033 | 2034 | 2035 | 2036 | 2037 | 2038 | 2039 | 2040 | 2041 | 2042 | 2043 | 2044 | 2045 | 2046 | 2047 |
| 800 | 2048 | 2049 | 2050 | 2051 | 2052 | 2053 | 2054 | 2055 | 2056 | 2057 | 2058 | 2059 | 2060 | 2061 | 2062 | 2063 |
| 810 | 2064 | 2065 | 2066 | 2067 | 2068 | 2069 | 2070 | 2071 | 2072 | 2073 | 2074 | 2075 | 2076 | 2077 | 2078 | 2079 |
| 820 | 2080 | 2081 | 2082 | 2083 | 2084 | 2085 | 2086 | 2087 | 2088 | 2089 | 2090 | 2091 | 2092 | 2093 | 2094 | 2095 |
| 830 | 2096 | 2097 | 2098 | 2099 | 2100 | 2101 | 2102 | 2103 | 2104 | 2105 | 2106 | 2107 | 2108 | 2109 | 2110 | 2111 |
| 840 | 2112 | 2113 | 2114 | 2115 | 2116 | 2117 | 2118 | 2119 | 2120 | 2121 | 2122 | 2123 | 2124 | 2125 | 2126 | 2127 |
| 850 | 2128 | 2129 | 2130 | 2131 | 2132 | 2133 | 2134 | 2135 | 2136 | 2137 | 2138 | 2139 | 2140 | 2141 | 2142 | 2143 |
| 860 | 2144 | 2145 | 2146 | 2147 | 2148 | 2149 | 2150 | 2151 | 2152 | 2153 | 2154 | 2155 | 2156 | 2157 | 2158 | 2159 |
| 870 | 2160 | 2161 | 2162 | 2163 | 2164 | 2165 | 2166 | 2167 | 2168 | 2169 | 2170 | 2171 | 2172 | 2173 | 2174 | 2175 |
| 880 | 2176 | 2177 | 2178 | 2179 | 2180 | 2181 | 2182 | 2183 | 2184 | 2185 | 2186 | 2187 | 2188 | 2189 | 2190 | 2191 |
| 890 | 2192 | 2193 | 2194 | 2195 | 2196 | 2197 | 2198 | 2199 | 2200 | 2201 | 2202 | 2203 | 2204 | 2205 | 2206 | 2207 |
| 8A0 | 2208 | 2209 | 2210 | 2211 | 2212 | 2213 | 2214 | 2215 | 2216 | 2217 | 2218 | 2219 | 2220 | 2221 | 2222 | 2223 |
| 8B0 | 2224 | 2225 | 2226 | 2227 | 2228 | 2229 | 2230 | 2231 | 2232 | 2233 | 2234 | 2235 | 2236 | 2237 | 2238 | 2239 |
| 8C0 | 2240 | 2241 | 2242 | 2243 | 2244 | 2245 | 2246 | 2247 | 2248 | 2249 | 2250 | 2251 | 2252 | 2253 | 2254 | 2255 |
| 8D0 | 2256 | 2257 | 2258 | 2259 | 2260 | 2261 | 2262 | 2263 | 2264 | 2265 | 2266 | 2267 | 2268 | 2269 | 2270 | 2271 |
| 8E0 | 2272 | 2273 | 2274 | 2275 | 2276 | 2277 | 2278 | 2279 | 2280 | 2281 | 2282 | 2283 | 2284 | 2285 | 2286 | 2287 |
| 8F0 | 2288 | 2289 | 2290 | 2291 | 2292 | 2293 | 2294 | 2295 | 2296 | 2297 | 2298 | 2299 | 2300 | 2301 | 2302 | 2303 |



Table D-5. Hexadecimal–Decimal Integer Conversion Table (Cont.)

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| 900 | 2304 | 2305 | 2306 | 2307 | 2308 | 2309 | 2310 | 2311 | 2312 | 2313 | 2314 | 2315 | 2316 | 2317 | 2318 | 2319 |
| 910 | 2320 | 2321 | 2322 | 2323 | 2324 | 2325 | 2326 | 2327 | 2328 | 2329 | 2330 | 2331 | 2332 | 2333 | 2334 | 2335 |
| 920 | 2336 | 2337 | 2338 | 2339 | 2340 | 2341 | 2342 | 2343 | 2344 | 2345 | 2346 | 2347 | 2348 | 2349 | 2350 | 2351 |
| 930 | 2352 | 2353 | 2354 | 2355 | 2356 | 2357 | 2358 | 2359 | 2360 | 2361 | 2362 | 2363 | 2364 | 2365 | 2366 | 2367 |
| 940 | 2368 | 2369 | 2370 | 2371 | 2372 | 2373 | 2374 | 2375 | 2376 | 2377 | 2378 | 2379 | 2380 | 2381 | 2382 | 2383 |
| 950 | 2384 | 2385 | 2386 | 2387 | 2388 | 2389 | 2390 | 2391 | 2392 | 2393 | 2394 | 2395 | 2396 | 2397 | 2398 | 2399 |
| 960 | 2400 | 2401 | 2402 | 2403 | 2404 | 2405 | 2406 | 2407 | 2408 | 2409 | 2410 | 2411 | 2412 | 2413 | 2414 | 2415 |
| 970 | 2416 | 2417 | 2418 | 2419 | 2420 | 2421 | 2422 | 2423 | 2424 | 2425 | 2426 | 2427 | 2428 | 2429 | 2430 | 2431 |
| 980 | 2432 | 2433 | 2434 | 2435 | 2436 | 2437 | 2438 | 2439 | 2440 | 2441 | 2442 | 2443 | 2444 | 2445 | 2446 | 2447 |
| 990 | 2448 | 2449 | 2450 | 2451 | 2452 | 2453 | 2454 | 2455 | 2456 | 2457 | 2458 | 2459 | 2460 | 2461 | 2462 | 2463 |
| 9A0 | 2464 | 2465 | 2466 | 2467 | 2468 | 2469 | 2470 | 2471 | 2472 | 2473 | 2474 | 2475 | 2476 | 2477 | 2478 | 2479 |
| 9B0 | 2480 | 2481 | 2482 | 2483 | 2484 | 2485 | 2486 | 2487 | 2488 | 2489 | 2490 | 2491 | 2492 | 2493 | 2494 | 2495 |
| 9C0 | 2496 | 2497 | 2498 | 2499 | 2500 | 2501 | 2502 | 2503 | 2504 | 2505 | 2506 | 2507 | 2508 | 2509 | 2510 | 2511 |
| 9D0 | 2512 | 2513 | 2514 | 2515 | 2516 | 2517 | 2518 | 2519 | 2520 | 2521 | 2522 | 2523 | 2524 | 2525 | 2526 | 2527 |
| 9E0 | 2528 | 2529 | 2530 | 2531 | 2532 | 2533 | 2534 | 2535 | 2536 | 2537 | 2538 | 2539 | 2540 | 2541 | 2542 | 2543 |
| 9F0 | 2544 | 2545 | 2546 | 2547 | 2548 | 2549 | 2550 | 2551 | 2552 | 2553 | 2554 | 2555 | 2556 | 2557 | 2558 | 2559 |
| A00 | 2560 | 2561 | 2562 | 2563 | 2564 | 2565 | 2566 | 2567 | 2568 | 2569 | 2570 | 2571 | 2572 | 2573 | 2574 | 2575 |
| A10 | 2576 | 2577 | 2578 | 2579 | 2580 | 2581 | 2582 | 2583 | 2584 | 2585 | 2586 | 2587 | 2588 | 2589 | 2590 | 2591 |
| A20 | 2592 | 2593 | 2594 | 2595 | 2596 | 2597 | 2598 | 2599 | 2600 | 2601 | 2602 | 2603 | 2604 | 2605 | 2606 | 2607 |
| A30 | 2608 | 2609 | 2610 | 2611 | 2612 | 2613 | 2614 | 2615 | 2616 | 2617 | 2618 | 2619 | 2620 | 2621 | 2622 | 2623 |
| A40 | 2624 | 2625 | 2626 | 2627 | 2628 | 2629 | 2630 | 2631 | 2632 | 2633 | 2634 | 2635 | 2636 | 2637 | 2638 | 2639 |
| A50 | 2640 | 2641 | 2642 | 2643 | 2644 | 2645 | 2646 | 2647 | 2648 | 2649 | 2650 | 2651 | 2652 | 2653 | 2654 | 2655 |
| A60 | 2656 | 2657 | 2658 | 2659 | 2660 | 2661 | 2662 | 2663 | 2664 | 2665 | 2666 | 2667 | 2668 | 2669 | 2670 | 2671 |
| A70 | 2672 | 2673 | 2674 | 2675 | 2676 | 2677 | 2678 | 2679 | 2680 | 2681 | 2682 | 2683 | 2684 | 2685 | 2686 | 2687 |
| A80 | 2688 | 2689 | 2690 | 2691 | 2692 | 2693 | 2694 | 2695 | 2696 | 2697 | 2698 | 2699 | 2700 | 2701 | 2702 | 2703 |
| A90 | 2704 | 2705 | 2706 | 2707 | 2708 | 2709 | 2710 | 2711 | 2712 | 2713 | 2714 | 2715 | 2716 | 2717 | 2718 | 2719 |
| AA0 | 2720 | 2721 | 2722 | 2723 | 2724 | 2725 | 2726 | 2727 | 2728 | 2729 | 2730 | 2731 | 2732 | 2733 | 2734 | 2735 |
| AB0 | 2736 | 2737 | 2738 | 2739 | 2740 | 2741 | 2742 | 2743 | 2744 | 2745 | 2746 | 2747 | 2748 | 2749 | 2750 | 2751 |
| AC0 | 2752 | 2753 | 2754 | 2755 | 2756 | 2757 | 2758 | 2759 | 2760 | 2761 | 2762 | 2763 | 2764 | 2765 | 2766 | 2767 |
| AD0 | 2768 | 2769 | 2770 | 2771 | 2772 | 2773 | 2774 | 2775 | 2776 | 2777 | 2778 | 2779 | 2780 | 2781 | 2782 | 2783 |
| AE0 | 2784 | 2785 | 2786 | 2787 | 2788 | 2789 | 2790 | 2791 | 2792 | 2793 | 2794 | 2795 | 2796 | 2797 | 2798 | 2799 |
| AF0 | 2800 | 2801 | 2802 | 2803 | 2804 | 2805 | 2806 | 2807 | 2808 | 2809 | 2810 | 2811 | 2812 | 2813 | 2814 | 2815 |
| B00 | 2816 | 2817 | 2818 | 2819 | 2820 | 2821 | 2822 | 2823 | 2824 | 2825 | 2826 | 2827 | 2828 | 2829 | 2830 | 2831 |
| B10 | 2832 | 2833 | 2834 | 2835 | 2836 | 2837 | 2838 | 2839 | 2840 | 2841 | 2842 | 2843 | 2844 | 2845 | 2846 | 2847 |
| B20 | 2848 | 2849 | 2850 | 2851 | 2852 | 2853 | 2854 | 2855 | 2856 | 2857 | 2858 | 2859 | 2860 | 2861 | 2862 | 2863 |
| B30 | 2864 | 2865 | 2866 | 2867 | 2868 | 2869 | 2870 | 2871 | 2872 | 2873 | 2874 | 2875 | 2876 | 2877 | 2878 | 2879 |
| B40 | 2880 | 2881 | 2882 | 2883 | 2884 | 2885 | 2886 | 2887 | 2888 | 2889 | 2890 | 2891 | 2892 | 2893 | 2894 | 2895 |
| B50 | 2896 | 2897 | 2898 | 2899 | 2900 | 2901 | 2902 | 2903 | 2904 | 2905 | 2906 | 2907 | 2908 | 2909 | 2910 | 2911 |
| B60 | 2912 | 2913 | 2914 | 2915 | 2916 | 2917 | 2918 | 2919 | 2920 | 2921 | 2922 | 2923 | 2924 | 2925 | 2926 | 2927 |
| B70 | 2928 | 2929 | 2930 | 2931 | 2932 | 2933 | 2934 | 2935 | 2936 | 2937 | 2938 | 2939 | 2940 | 2941 | 2942 | 2943 |
| B80 | 2944 | 2945 | 2946 | 2947 | 2948 | 2949 | 2950 | 2951 | 2952 | 2953 | 2954 | 2955 | 2956 | 2957 | 2958 | 2959 |
| B90 | 2960 | 2961 | 2962 | 2963 | 2964 | 2965 | 2966 | 2967 | 2968 | 2969 | 2970 | 2971 | 2972 | 2973 | 2974 | 2975 |
| BA0 | 2976 | 2977 | 2978 | 2979 | 2980 | 2981 | 2982 | 2983 | 2984 | 2985 | 2986 | 2987 | 2988 | 2989 | 2990 | 2991 |
| BB0 | 2992 | 2993 | 2994 | 2995 | 2996 | 2997 | 2998 | 2999 | 3000 | 3001 | 3002 | 3003 | 3004 | 3005 | 3006 | 3007 |
| BC0 | 3008 | 3009 | 3010 | 3011 | 3012 | 3013 | 3014 | 3015 | 3016 | 3017 | 3018 | 3019 | 3020 | 3021 | 3022 | 3023 |
| BD0 | 3024 | 3025 | 3026 | 3027 | 3028 | 3029 | 3030 | 3031 | 3032 | 3033 | 3034 | 3035 | 3036 | 3037 | 3038 | 3039 |
| BE0 | 3040 | 3041 | 3042 | 3043 | 3044 | 3045 | 3046 | 3047 | 3048 | 3049 | 3050 | 3051 | 3052 | 3053 | 3054 | 3055 |
| BF0 | 3056 | 3057 | 3058 | 3059 | 3060 | 3061 | 3062 | 3063 | 3064 | 3065 | 3066 | 3067 | 3068 | 3069 | 3070 | 3071 |



Table D-5. Hexadecimal–Decimal Integer Conversion Table (Cont.)

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| C00 | 3072 | 3073 | 3074 | 3075 | 3076 | 3077 | 3078 | 3079 | 3080 | 3081 | 3082 | 3083 | 3084 | 3085 | 3086 | 3087 |
| C10 | 3088 | 3089 | 3090 | 3091 | 3092 | 3093 | 3094 | 3095 | 3096 | 3097 | 3098 | 3099 | 3100 | 3101 | 3102 | 3103 |
| C20 | 3104 | 3105 | 3106 | 3107 | 3108 | 3109 | 3110 | 3111 | 3112 | 3113 | 3114 | 3115 | 3116 | 3117 | 3118 | 3119 |
| C30 | 3120 | 3121 | 3122 | 3123 | 3124 | 3125 | 3126 | 3127 | 3128 | 3129 | 3130 | 3131 | 3132 | 3133 | 3134 | 3135 |
| C40 | 3136 | 3137 | 3138 | 3139 | 3140 | 3141 | 3142 | 3143 | 3144 | 3145 | 3146 | 3147 | 3148 | 3149 | 3150 | 3151 |
| C50 | 3152 | 3153 | 3154 | 3155 | 3156 | 3157 | 3158 | 3159 | 3160 | 3161 | 3162 | 3163 | 3164 | 3165 | 3166 | 3167 |
| C60 | 3168 | 3169 | 3170 | 3171 | 3172 | 3173 | 3174 | 3175 | 3176 | 3177 | 3178 | 3179 | 3180 | 3181 | 3182 | 3183 |
| C70 | 3184 | 3185 | 3186 | 3187 | 3188 | 3189 | 3190 | 3191 | 3192 | 3193 | 3194 | 3195 | 3196 | 3197 | 3198 | 3199 |
| C80 | 3200 | 3201 | 3202 | 3203 | 3204 | 3205 | 3206 | 3207 | 3208 | 3209 | 3210 | 3211 | 3212 | 3213 | 3214 | 3215 |
| C90 | 3216 | 3217 | 3218 | 3219 | 3220 | 3221 | 3222 | 3223 | 3224 | 3225 | 3226 | 3227 | 3228 | 3229 | 3230 | 3231 |
| CA0 | 3232 | 3233 | 3234 | 3235 | 3236 | 3237 | 3238 | 3239 | 3240 | 3241 | 3242 | 3243 | 3244 | 3245 | 3246 | 3247 |
| CB0 | 3248 | 3249 | 3250 | 3251 | 3252 | 3253 | 3254 | 3255 | 3256 | 3257 | 3258 | 3259 | 3260 | 3261 | 3262 | 3263 |
| CC0 | 3264 | 3265 | 3266 | 3267 | 3268 | 3269 | 3270 | 3271 | 3272 | 3273 | 3274 | 3275 | 3276 | 3277 | 3278 | 3279 |
| CD0 | 3280 | 3281 | 3282 | 3283 | 3284 | 3285 | 3286 | 3287 | 3288 | 3289 | 3290 | 3291 | 3292 | 3293 | 3294 | 3295 |
| CE0 | 3296 | 3297 | 3298 | 3299 | 3300 | 3301 | 3302 | 3303 | 3304 | 3305 | 3306 | 3307 | 3308 | 3309 | 3310 | 3311 |
| CF0 | 3312 | 3313 | 3314 | 3315 | 3316 | 3317 | 3318 | 3319 | 3320 | 3321 | 3322 | 3323 | 3324 | 3325 | 3326 | 3327 |
| D00 | 3328 | 3329 | 3330 | 3331 | 3332 | 3333 | 3334 | 3335 | 3336 | 3337 | 3338 | 3339 | 3340 | 3341 | 3342 | 3343 |
| D10 | 3344 | 3345 | 3346 | 3347 | 3348 | 3349 | 3350 | 3351 | 3352 | 3353 | 3354 | 3355 | 3356 | 3357 | 3358 | 3359 |
| D20 | 3360 | 3361 | 3362 | 3363 | 3364 | 3365 | 3366 | 3367 | 3368 | 3369 | 3370 | 3371 | 3372 | 3373 | 3374 | 3375 |
| D30 | 3376 | 3377 | 3378 | 3379 | 3380 | 3381 | 3382 | 3383 | 3384 | 3385 | 3386 | 3387 | 3388 | 3389 | 3390 | 3391 |
| D40 | 3392 | 3393 | 3394 | 3395 | 3396 | 3397 | 3398 | 3399 | 3400 | 3401 | 3402 | 3403 | 3404 | 3405 | 3406 | 3407 |
| D50 | 3408 | 3409 | 3410 | 3411 | 3412 | 3413 | 3414 | 3415 | 3416 | 3417 | 3418 | 3419 | 3420 | 3421 | 3422 | 3423 |
| D60 | 3424 | 3425 | 3426 | 3427 | 3428 | 3429 | 3430 | 3431 | 3432 | 3433 | 3434 | 3435 | 3436 | 3437 | 3438 | 3439 |
| D70 | 3440 | 3441 | 3442 | 3443 | 3444 | 3445 | 3446 | 3447 | 3448 | 3449 | 3450 | 3451 | 3452 | 3453 | 3454 | 3455 |
| D80 | 3456 | 3457 | 3458 | 3459 | 3460 | 3461 | 3462 | 3463 | 3464 | 3465 | 3466 | 3467 | 3468 | 3469 | 3470 | 3471 |
| D90 | 3472 | 3473 | 3474 | 3475 | 3476 | 3477 | 3478 | 3479 | 3480 | 3481 | 3482 | 3483 | 3484 | 3485 | 3486 | 3487 |
| DA0 | 3488 | 3489 | 3490 | 3491 | 3492 | 3493 | 3494 | 3495 | 3496 | 3497 | 3498 | 3499 | 3500 | 3501 | 3502 | 3503 |
| DB0 | 3504 | 3505 | 3506 | 3507 | 3508 | 3509 | 3510 | 3511 | 3512 | 3513 | 3514 | 3515 | 3516 | 3517 | 3518 | 3519 |
| DC0 | 3520 | 3521 | 3522 | 3523 | 3524 | 3525 | 3526 | 3527 | 3528 | 3529 | 3530 | 3531 | 3532 | 3533 | 3534 | 3535 |
| DD0 | 3536 | 3537 | 3538 | 3539 | 3540 | 3541 | 3542 | 3543 | 3544 | 3545 | 3546 | 3547 | 3548 | 3549 | 3550 | 3551 |
| DE0 | 3552 | 3553 | 3554 | 3555 | 3556 | 3557 | 3558 | 3559 | 3560 | 3561 | 3562 | 3563 | 3564 | 3565 | 3566 | 3567 |
| DF0 | 3568 | 3569 | 3570 | 3571 | 3572 | 3573 | 3574 | 3575 | 3576 | 3577 | 3578 | 3579 | 3580 | 3581 | 3582 | 3583 |
| E00 | 3584 | 3585 | 3586 | 3587 | 3588 | 3589 | 3590 | 3591 | 3592 | 3593 | 3594 | 3595 | 3596 | 3597 | 3598 | 3599 |
| E10 | 3600 | 3601 | 3602 | 3603 | 3604 | 3605 | 3606 | 3607 | 3608 | 3609 | 3610 | 3611 | 3612 | 3613 | 3614 | 3615 |
| E20 | 3616 | 3617 | 3618 | 3619 | 3620 | 3621 | 3622 | 3623 | 3624 | 3625 | 3626 | 3627 | 3628 | 3629 | 3630 | 3631 |
| E30 | 3632 | 3633 | 3634 | 3635 | 3636 | 3637 | 3638 | 3639 | 3640 | 3641 | 3642 | 3643 | 3644 | 3645 | 3646 | 3647 |
| E40 | 3648 | 3649 | 3650 | 3651 | 3652 | 3653 | 3654 | 3655 | 3656 | 3657 | 3658 | 3659 | 3660 | 3661 | 3662 | 3663 |
| E50 | 3664 | 3665 | 3666 | 3667 | 3668 | 3669 | 3670 | 3671 | 3672 | 3673 | 3674 | 3675 | 3676 | 3677 | 3678 | 3679 |
| E60 | 3680 | 3681 | 3682 | 3683 | 3684 | 3685 | 3686 | 3687 | 3688 | 3689 | 3690 | 3691 | 3692 | 3693 | 3694 | 3695 |
| E70 | 3696 | 3697 | 3698 | 3699 | 3700 | 3701 | 3702 | 3703 | 3704 | 3705 | 3706 | 3707 | 3708 | 3709 | 3710 | 3711 |
| E80 | 3712 | 3713 | 3714 | 3715 | 3716 | 3717 | 3718 | 3719 | 3720 | 3721 | 3722 | 3723 | 3724 | 3725 | 3726 | 3727 |
| E90 | 3728 | 3729 | 3730 | 3731 | 3732 | 3733 | 3734 | 3735 | 3736 | 3737 | 3738 | 3739 | 3740 | 3741 | 3742 | 3743 |
| EA0 | 3744 | 3745 | 3746 | 3747 | 3748 | 3749 | 3750 | 3751 | 3752 | 3753 | 3754 | 3755 | 3756 | 3757 | 3758 | 3759 |
| EB0 | 3760 | 3761 | 3762 | 3763 | 3764 | 3765 | 3766 | 3767 | 3768 | 3769 | 3770 | 3771 | 3772 | 3773 | 3774 | 3775 |



945401-9701

APPENDIX E
SCOPING LOOP PROGRAMS



APPENDIX E

SCOPING LOOP PROGRAMS

E.1 GENERAL

This section contains a collection of loop programs which may be entered into the computer through the programmer panel. The procedure for entering all of these programs is essentially the same as outlined in paragraph E.2.

E.2 READ FOLLOWED BY WRITE AT SAME MEMORY LOCATION

The following program may be used to loop on a single specified address within the 32K address space of the 990/4:

| MEM Location | Machine Code | Comments |
|--------------|--------------|---------------------------------------|
| 0900 | 02E0 | LWPI, >100 |
| 0902 | 0100 | |
| 0904 | 0208 | LI R8, (location) |
| 0906 | 2000 | Desired memory address (byte address) |
| 0908 | 0209 | LI R9, (data) |
| 090A | 0F0F | (or any desired data pattern) |
| 090C | → C609 | Mov R9, *R8 |
| 090E | └ 10FE | JMP \$-1 |

The scoping loop is entered into the computer from the programmer panel using the following procedure:

1. Set the key switch on the programmer panel to the UNLOCK position.
2. If the RUN LED is lit, press the HALT/SIE switch to halt the processor and begin execution of the programmer panel code. When the panel is active, the RUN LED is extinguished.
3. Press the CLR switch to clear the panel's display register.
4. Press the ENTER ST (enter status) switch to clear the status register in the TMS 9900.
5. Set up 0900_{16} on the data display LEDs using the data entry switches. This is the address in memory where the first instruction of the scoping loop is to be stored.

NOTE

When a data display LED is lit, it indicates a "1".

6. Press ENTER MA switch to load the memory address value 0900 into the memory address register of the TMS 9900.
7. Press CLR to clear the displays for the next entry.



8. Set up the instruction code (02E0₁₆) on the data LED displays using the data entry switches.
9. Press MDE switch which causes 02E0 to be loaded into memory location 0900.
10. Press MAI which increments the memory address value stored in the memory address register and repeat steps 8-11 to enter the following program values into successive memory locations:
 - 0100
 - 0208
 - Address on which the test will loop (0000 to 1FFFE inclusive)
 - 0209
 - Data to be written into the looped memory location (e.g., 1F1F₁₆)
 - C609
 - 10FE
11. Press CLR to clear the displays.
12. Enter 0900 into the displays (address of first instruction in the scoping loop).
13. Press ENTER PC to load the value into the program counter.
14. Press RUN to begin execution of the program. The RUN LED should light to indicate proper operation.

NOTE

If the RUN LED fails to light, return to step 1 and repeat the program setup procedure.

E.3 CONTINUOUS READ FROM SELECTED MEMORY LOCATION

The basic scoping loop program described in E.2 may be modified to perform a continuous read at a selected memory address by changing the instruction at memory location 090C in the previous program from C609 to C258 which is a MOV *R8,R9 instruction. This change to the basic program causes data to be read from a selected address and stored in memory location 0112 (workspace register 9). For maintenance purposes, the scoping loop may be interrupted at any time and the value stored in the workspace register may be examined using the following procedure:

1. Halt the processor by pressing HALT/SIE. The RUN LED should extinguish.
2. Press CLR to clear the displays.
3. Enter 0112 into the displays using the data entry switches.



4. Press ENTER MA to load 0112 into the memory address register.
5. Press MDD. The resulting value displayed on the panel LEDs should be the same value stored in memory location 90A of the scoping loop program.

E.4 SCOPING LOOP FOR A BAND OF MEMORY ADDRESSES

The basic scoping loop program may also be modified as follows to permit looping over a band of memory addresses in which the beginning and ending addresses are specified in the program:

Scoping Loop for Reading Band of Memory Addresses

| MEM Location | Machine Code | Comments |
|--------------|--------------|-------------------|
| 0900 | 02E0 | LWPI >80 |
| 0902 | 0100 | |
| 0904 | 020A | LI R10, ENDLOC |
| 0906 | ENDLOC | Ending address +2 |
| 0908 | 0209 | LI R9, DATA |
| 090A | DATA | |
| 090C | 0208 | LI R8, LOC |
| 090E | LOC | |
| 0910 | CE09 | MOV R9, *R8+ |
| 0912 | 820A | C R10, R8 |
| 0914 | 14FB | JHE |
| 0916 | 10FC | JMP |

The procedures for entering this program into computer memory are essentially the same as described in paragraph E.2.


E.5 SCOPING LOOP FOR WRITE PROTECT

The following scoping loop will permit the write protect register on the memory expansion board to be loaded with a protect value and will then attempt to write into the protected memory space resulting in a protect violate condition. The program then loops back and repeats these functions to permit a dynamic test of the write protect section.

| MEM Location | Machine Code | Comments |
|--------------|--------------|--|
| 0200 | 0300 | LIMI >0 |
| 0202 | 0000 | |
| 0204 | 02E0 | LWPI >100 |
| 0206 | 0100 | |
| 0208 | 020C | LI R12, >1FA0 |
| 020A | 1FA0 | |
| 020C | 0209 | LI R9, >1011 (Adr. 2000 to 21FE) |
| 020E | 1011 | |
| 0210 | 3009 | LDCR R9, 0 |
| 0212 | C809 | MOV R9, >2000 (Attempt write into LOC 2000) |
| 0214 | 2000 | |
| 0216 | 1F00 | TB 0 |
| 0218 | 1D00 | SBO 0 |
| 021A | 10FA | JMP S-6 |



E.5.1 SETTING A WRITE PROTECT REGION. To set a write protect region, the lower and upper bounds must be output to CRU base address $1FA0_{16}$. The most significant bit (bit 0) is the Protect/Permit bit. Bit 0, when set to 1, indicates write permit, and, when set to 0, indicates write protect. To specify the protect region, memory is divided into 256-word blocks. The lower and upper bounds are each seven bits long and serve as an index into the memory addresses to specify which contiguous 256-word block of memory is to be protected. For example, the lower bound of the protect region equal to 2000_{16} would be represented in the Protect register as 10_{16} . The memory block beginning at location 2000_{16} is the sixteenth 256-word (512-byte) memory block. A bound is calculated by dividing the starting address of the memory block by 200_{16} (512_{10}). In this example, 2000_{16} divided by 200_{16} is equal to 10_{16} . The upper bound is not included in the protect region. When outputting to the CRU Protect register to specify the protect bounds, a Load CRU (LDCR) instruction with a count of 16 must be used to sell all 16 bits because the Protect register works like a shift register. To protect the memory range 2000_{16} to 4000_{16} , the lower bound is set equal to 10_{16} , the upper bound is set equal to 20_{16} , and the Protect bit is set to 0. Therefore, the Protect register is set to 1020_{16} by outputting these fields to the CRU in the format specified in figure E-1.



NOT
USED

BIT FIELDS

P PROTECT/PERMIT BIT
0-PROTECT
1-PERMIT

LB LOWER BOUND

UB UPPER BOUND

NOTES

THE CRU OUTPUT DATA FORMAT IS THE SAME AS THE FORMAT OF DATA IN MEMORY BEFORE LDCR INSTRUCTION IS EXECUTED.

BITS 1 AND 9 ARE THE MOST SIGNIFICANT BITS, AND BITS 7 AND 15 ARE THE LEAST SIGNIFICANT BITS OF THE LB AND UB FIELDS.

(A)133373

Figure E-1. Write Protect Vector Format



945401-9701

ALPHABETICAL INDEX



ALPHABETICAL INDEX

INTRODUCTION

The following index lists key words and concepts from the subject material of the manual together with the area(s) in the manual that supply major coverage of the listed concept. The numbers along the right side of the listing reference the following manual areas:

- Sections - References to Sections of the manual appear as “Section x” with the symbol x representing any numeric quantity.
- Appendixes - References to Appendixes of the manual appear as “Appendix y” with the symbol y representing any capital letter.
- Paragraphs - References to paragraphs of the manual appear as a series of alphanumeric or numeric characters punctuated with decimal points. Only the first character of the string may be a letter; all subsequent characters are numbers. The first character refers to the section or appendix of the manual in which the paragraph is found.
- Tables - References to tables in the manual are represented by the capital letter T followed immediately by another alphanumeric character (representing the section or appendix of the manual containing the table). The second character is followed by a dash (-) and a number:

Tx-yy

- Figures - References to figures in the manual are represented by the capital letter F followed immediately by another alphanumeric character (representing the section or appendix of the manual containing the figure). The second character is followed by a dash (-) and a number:

Fx-yy

- Other entries in the Index - References to other entries in the index are preceded by the word “See” followed by the referenced entry.



| | | | |
|--|--|--|---------------------------|
| AC Power Converter Board | 1.2.1.6, F5-12 | Microcomputer Board | 1.2.1.1, F1-4, F5-6 |
| Air Filter | 3.2.1 | Microcomputer System | .1.2, F1-1 |
| Assemblies and Subassemblies, 990/4 | F1-2, F1-3 | Microcomputer, 990/4 | 1.2.1 |
| ASR, 733 Data Terminal | 1.2 | Assemblies and Subassemblies | F1-2 |
| Backpanel Wiring | | Microprocessor | 1.2.1.1 |
| OEM Chassis | F5-1 | Module Selects | 1.2.1.1, T1-2 |
| 6-Slot Chassis | F5-2 | OEM Chassis | F1-19 |
| 13-Slot Chassis | F5-4 | Operator Panel | 1.2.2 |
| Cassette Tape Installation | 2.3.2.1, F2-5 | Options | |
| Chassis | 1.2.1.4, F1-15 | CRU Buffer Board | F1-3, F5-9 |
| Context Switch | 1.2.1.1 | CRU Expander Board | F1-24, F5-8, F1-3 |
| CRU Address Development | 1.2.1.1, F1-7 | EPROM Memory Module | 1.2.1.3, F1-13 |
| CRU Address Map | F1-27 | 990/4 Microcomputer Board | F1-9, F1-10, F1-11 |
| CRU Buffer Board Options | 1.2.2.3, F1-28 | Parity (Memory Expansion Board) | 1.2.1.2 |
| CRU Expansion Chassis | 1.2.2 | Starting Memory Address | 1.2.1.1, 1.2.1.2, 1.2.1.3 |
| CRU Expansion Board | 1.2.1.8 | Peripherals, 990/4 | 1.2, F1-1 |
| CRU Formats | Appendix D | Power Supply | 1.2.1.6 |
| CRU Interface Boards | 1.2.1.7 | AC Distribution Circuits | F1-20, F5-3, F5-5 |
| CRU Interface Signals | T1-2 | Main Power Supply Board | F5-11 |
| Diagnostic Tests | T2-2 | Standby Power Supply Board | F5-13 |
| Disposition of Faulty Subassemblies | 4.2.1 | AC Power Converter Board | F5-12 |
| Dynamic RAM | 1.2.1.1 | Programmer Panel | F2-4, T2-4, F5-14 |
| External Instruction Decode (990/4 Board) | 1.2.1.1 | Programmer Panel Interface Logic | 1.2.1.1, F5-6 |
| Expansion Chassis | 1.2.2 | RAM Memory | 1.2.1.1, F5-6, F5-7 |
| Expansion Interrupt Vector Format | F1-23 | Recommended Tools and Test Equipment | 2.2, T2-1 |
| Instruction Set, 990/4 | Appendix A | Real Time Clock Logic | 1.2.1.1 |
| Interrupts | 1.2.1.8, 1.2.2.1, 1.2.1.4, F1-16, F1-17, F1-18 | Removal/Replacement Procedures | |
| LDCR/STCR Data Transfer | F1-8 | AC Power Converter Board | 3.3.3.2 |
| Load Control Logic | 1.2.1.1 | Cooling Fans | 3.3.3.4 |
| Loader ROM Options | F1-11 | Main Power Supply Board | 3.3.3.1 |
| Maintenance Unit, 990 | 2.3, F2-1 | ICs | 3.3.4 |
| Operating Procedures | 2.3.2.1 | Logic Boards | 3.3.1 |
| Controls and Indicators | F2-4, T2-4 | Operator/Programmer Panel | 3.3.2 |
| Maintenance Philosophy | 4.2 | Replaceable Components/Assemblies | T2-3 |
| Masking Interrupts | 1.2.1.1 | Standby Power Supply | 1.2.1.6, F5-13 |
| Memory | | System Interconnections | 1.2.1.4, F1-14 |
| Bank Organization (Memory Expansion Board) | 1.2.1.2 | Test Configurations | 2.3.1, F2-2, F2-3 |
| EPROM Memory Module | 1.2.1.3, F1-13, F5-10 | TMS 9900 | 1.2.1.1 |
| Memory Expansion Board | 1.2.1.2, F1-12, F5-7 | Troubleshooting Procedures | 4.3, T4-1, T4-2 |
| 4K RAM (990/4 Board) | 1.2.1.1, F1-2, F5-6 | TTY/EIA Module Options | F1-22 |
| 1K ROM/RAM (990/4 Board) | 1.2.1.1, F1-2, F5-6 | Unpacking/Packing | |
| Map (General Purpose Computer Configuration) | F1-5 | Workspace Registers | 1.2.1.1, F1-6, T1-1 |
| Bus Gating for DMA Controller | 1.2.1.1, F5-6 | 990/4 Board Level Organization | F1-3 |
| | | 990/4 Chassis | 1.2.1.4 |
| | | 990/4 Microcomputer Board | 1.2.1.1, F5-6 |

USER'S RESPONSE SHEET

Manual Title: Model 990/4 Computer System Field Maintenance Manual (945401-9701)

Manual Date: 1 April 1979 **Date of This Letter:** _____

User's Name: _____ **Telephone:** _____

Company: _____ **Office/Department:** _____

Street Address: _____

City/State/Zip Code: _____

Please list any discrepancy found in this manual by page, paragraph, figure, or table number in the following space. If there are any other suggestions that you wish to make, feel free to include them. Thank you.

CUT ALONG LINE

Location in Manual

Comment/Suggestion

| Location in Manual | Comment/Suggestion |
|--------------------|--------------------|
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |
| _____ | _____ |

NO POSTAGE NECESSARY IF MAILED IN U.S.A.
FOLD ON TWO LINES (LOCATED ON REVERSE SIDE), TAPE AND MAIL

FOLD



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES


BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 7284 DALLAS, TX

POSTAGE WILL BE PAID BY ADDRESSEE

TEXAS INSTRUMENTS INCORPORATED
DIGITAL SYSTEMS GROUP
ATTN: TECHNICAL PUBLICATIONS
P.O. Box 2909 M/S 2146
Austin, Texas 78769



FOLD



TEXAS INSTRUMENTS

INCORPORATED
DIGITAL SYSTEMS DIVISION

POST OFFICE BOX 2909 AUSTIN, TEXAS 78769