

*Apollo Documentation
Quick Reference*

apollo

Apollo Documentation Quick Reference

Order No. 002685-A01

Restricted Rights Notice

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 52.227-7013.

Apollo Computer Inc.
330 Billerica Road
Chelmsford, MA 01824
(508) 256-6600

Notice: Notwithstanding any other lease or license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the Government regarding its use, reproduction and disclosure are as set forth in Section 52.227-19 of the FARS Computer Software - Restricted Rights clause.

© 1988, 1989 Apollo Computer Inc., Chelmsford, Massachusetts. Unpublished -- all rights reserved under the Copyright Laws of the United States.

This notice shall be marked on any reproduction of these data, in whole or in part.

Copyright © 1988, 1989 Apollo Computer Inc.
All rights reserved. Printed in U.S.A.

First Printing: July 1988
Latest Printing: July 1989

This document was produced using the Interleaf Technical Publishing Software (TPS) and the InterCAP Illustrator I Technical Illustrating System, a product of InterCAP Graphics Systems Corporation. Interleaf and TPS are trademarks of Interleaf, Inc.

Apollo and Domain are registered trademarks of Apollo Computer Inc.

DEC is a registered trademark of Digital Equipment Corporation. IBM, Personal Computer AT, and AT are registered trademarks of International Business Machines Corporation. XT is a trademark of International Business Machines Corporation. APPLE and LaserWriter are registered trademarks of Apple Computer, Inc. PostScript is a registered trademark and TransScript is a trademark of Adobe Systems, Inc. IMAGEN is a registered trademark of IMAGEN Corp. Tektronix is a registered trademark of Tektronix, Inc.

UNIX is a registered trademark of AT&T in the USA and other countries.

3DGMR, Aegis, Apollo/Bridge, Apollo/TECHnet, D3M, DGR, Domain/Access, Domain/Ada, Domain/Bridge, Domain/C, Domain/C++, Domain/ComController, Domain/CommonLISP, Domain/CORE, Domain/Debug, Domain/DFL, Domain/Dialogue, Domain/DQC, Domain/IX, Domain/Laser-26, Domain/LISP, Domain/PAK, Domain/PCC, Domain/PCI, Domain/SNA, Domain/X.25, DPSS, DPSS/Mail, DSEE, FPX, GMR, GPR, GSR, Knowledge Broker, NLS, Network Computing Kernel, Network Computing System, Network Interface Definition Language, Network License Server, NIDL, OmniBack, Open Dialogue, Open Network Toolkit, Open System Toolkit, Passwd Etc, Personal Supercomputer, Personal Super Workstation, *PRISM*, Series 3000, Series 3500, Series 4000, Series 4500, and Series 10000 are trademarks of Apollo Computer Inc.

Apollo Computer Inc. reserves the right to make changes in specifications and other information contained in this publication without prior notice, and the reader should in all cases consult Apollo Computer Inc. to determine whether any such changes have been made.

THE TERMS AND CONDITIONS GOVERNING THE SALE OF APOLLO COMPUTER INC. HARDWARE PRODUCTS AND THE LICENSING OF APOLLO COMPUTER INC. SOFTWARE PROGRAMS CONSIST SOLELY OF THOSE SET FORTH IN THE WRITTEN CONTRACTS BETWEEN APOLLO COMPUTER INC. AND ITS CUSTOMERS. NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS PUBLICATION, INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY APOLLO COMPUTER INC. FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY BY APOLLO COMPUTER INC. WHATSOEVER.

IN NO EVENT SHALL APOLLO COMPUTER INC. BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATING TO THIS PUBLICATION OR THE INFORMATION CONTAINED IN IT, EVEN IF APOLLO COMPUTER INC. HAS BEEN ADVISED, KNEW OR SHOULD HAVE KNOWN OF THE POSSIBILITY OF SUCH DAMAGES.

THE SOFTWARE PROGRAMS DESCRIBED IN THIS DOCUMENT ARE CONFIDENTIAL INFORMATION AND PROPRIETARY PRODUCTS OF APOLLO COMPUTER INC. OR ITS LICENSORS.

10 9 8 7 6 5 4 3 2 1

Preface

The *Apollo Documentation Quick Reference* provides information to help you choose user's manuals, order them, and organize them on your bookshelf. We've organized the manuals by category. An icon represents each category; the icon also appears on the spines of manuals in that category. The icon can help you organize your Apollo manual library, and identify types of manuals on your shelf.

Within each category, we've listed manuals by product or topic, such as *Reference Manuals*, *Peripherals*, or *Domain 3D Graphics Metafile Resources*.

The *Apollo Documentation Quick Reference* lists titles and order numbers for the most recent versions (at this printing) of all our manuals, for each product. The first section of this document, lists manuals for most software products that support Apollo's Domain/OS 10 (SR10.X). The last section of this document, lists manuals for software products that support the previous version of Apollo's operating system SR9.7.X. The help file, manuals, lists both the most recent versions, and the earlier versions. To see this file, type the following if you are running in an Aegis shell:

```
$ help manuals
```

If you are running a UNIX® shell, access the online manuals information by reading the file:

```
/install/doc/apollo/os.v.10.1__manuals
```

Ordering Information

To order manuals, call Apollo Direct at 1-800-225-5290. Outside the US, call (508) 256-6600 and ask for Apollo Direct. Apollo Direct representatives can take your order Monday through Friday, 8:30 a.m. to 5:00 p.m. Eastern time. Please be ready to provide the following information when you call: your name, your company's name, a purchase order number, the *bill-to* address, the *ship-to* address, the model number, and the quantity of each manual that you wish to order. Apollo Direct representatives can also send you a copy of the *Apollo Documentation and Software Replacement Media Catalog* for pricing information. Apollo Direct will ship the latest version available for all manuals, unless otherwise specified. You may also order manuals through your local sales office.

Contents

SR10 Documentation

<i>Operating System</i>	3
<i>Software Development Tools</i>	4
<i>Languages</i>	6
<i>Graphics</i>	7
<i>Communications Networks</i>	8
<i>Distributed Computing</i>	11
<i>Text Processing and Editing</i>	11
<i>Systems</i>	12
<i>Apollo Documentation</i>	15

SR9.7 Documentation

<i>Operating System</i>	19
<i>Software Development Tools</i>	20
<i>Languages</i>	21
<i>Graphics</i>	22
<i>Communications Networks</i>	23
<i>Distributed Computing</i>	25
<i>Systems</i>	26
<i>Apollo Documentation</i>	28

SR10 Documentation



Operating System

Software Installation Manuals

- | | |
|------------|--|
| 011435-A00 | Making the Transition to SR10 Operating System Releases |
| 008860-A00 | Installing Software with Apollo's Release and Installation Tools |

Introductory Manuals

- | | |
|------------|--------------------------------|
| 002348-A00 | Getting Started with Domain/OS |
| 014962-A00 | Domain/OS Design Principles |
| 011021-A00 | Using Your Aegis Environment |
| 011020-A00 | Using Your BSD Environment |
| 011022-A00 | Using Your SysV Environment |
| 010852-A00 | Managing Aegis System Software |
| 010853-A00 | Managing BSD System Software |
| 010851-A00 | Managing SysV System Software |

Programming and Reference Manuals

- | | |
|------------|---|
| 011418-A00 | Domain Display Manager Command Reference |
| 002547-A00 | Aegis Command Reference |
| 005800-A00 | BSD Command Reference |
| 005798-A00 | SysV Command Reference |
| 007196-A00 | Domain/OS Call Reference, Volume 1 |
| 012888-A00 | Domain/OS Call Reference, Volume 2 |
| 005801-A00 | BSD Programmer's Reference |
| 005799-A00 | SysV Programmer's Reference |
| 005506-A00 | Programming with Domain/OS Calls |
| 000959-A00 | Writing Device Drivers with GPIO Calls |
| 012276-A00 | Getting Started with SysV STREAMS |
| 012275-A00 | Programming with SysV STREAMS |
| 012205-A00 | Programming with the SysV STREAMS Transport Interface |
| 011774-A00 | Printing in the Aegis Environment |

X Window System

- 015213-A01 Using the X Window System on Apollo Workstations
- 011241-A00 Domain/X11 Xlib Reference
- 013418-A00 Domain/X11 Xlib Programming Manual
- 015534-A00 Domain/X11 User's Guide



Software Development Tools

- 011010-A00 Domain/OS Programming Environment Reference
- 008863 Using the Open Systems Toolkit to Extend the Streams Facility
(order as DOC-OST)
- 015853-A00 Domain/OS Floating-Point Guide

Domain/PAK

- 008906-A00 Analyzing Program Performance with Domain/PAK

Domain/DDE

- 011024-A00 Domain Distributed Debugging Environment Reference

Domain Software Engineering Environment (DSEE)

- 008788-A00 Getting Started with Domain Software Engineering Environment (DSEE)
- 008790-A00 Engineering in the DSEE Environment
- 003016 Domain Software Engineering Environment (DSEE) Command Reference
- 010264 Domain Software Engineering Environment (DSEE) Call Reference

D3M

001950	Introduction to D3M
004302-A00	How to Design, Define, and Operate a D3M Database
004303-A00	How to Write DML Programs
004304-A00	How to Use the D3M/Dataview and Formatter

Knowledge Broker

011270-A01	Retrieving Information with the Knowledge Broker
014951-A00	Publishing with the Knowledge Broker
014952-A00	Administering the Knowledge Broker

Domain/Dialogue

010218	Getting Started with Domain/Dialogue
004299	Domain/Dialogue User's Guide

Open Dialogue

012807-A01	Open Dialogue Reference
011166-A01	Customizing Open Dialogue
011167-A01	Creating User Interfaces with Open Dialogue

TMLib

011280-A00	The Text Management Library Call Reference
011281-A00	Programming with the Text Management Library



Languages

- | | |
|------------|-----------------------------------|
| 000792-A00 | Domain Pascal Language Reference |
| 000530-A00 | Domain FORTRAN Language Reference |
| 002093-A00 | Domain C Language Reference |
| 012777-A00 | The C++ Programming Language |

Domain/Ada


- | | |
|------------|---|
| 008684 | Ada Language Reference Manual |
| 008917-A01 | Domain/Ada Development System Reference |
| 010978-A01 | Domain/Ada Quick Reference |
| 014948-A00 | Domain/Ada Technical Summary |

Domain/CommonLISP Version 2.2

- | | |
|--------|--------------------------------|
| 008791 | Domain/CommonLISP User's Guide |
| 010849 | Domain/CommonLISP Reference |

Domain/CommonLISP Version 3.0

- | | |
|------------|---|
| 008791-A00 | Domain/CommonLISP User's Guide |
| 015739-A00 | Domain/CommonLISP Tool Reference |
| 015738-A00 | Domain/CommonLISP Advanced User's Guide |
| 015458-A00 | CommonLISP: The Language |



Graphics

General Graphics

009791-A01	Domain Graphics Instruction Set Reference
009797-A01	Programming with Domain Graphics Service Routines
001955	Programming with Domain Core Graphics
012077-A00	Domain/GKS User and Reference Manual
005224	Domain 4014 User's Guide

Graphics Primitives Resource (GPR)

005808	Programming with Domain Graphics Primitives
007194	Domain Graphics Primitives Resource Call Reference
010430	Domain Graphics Primitives Quick Reference

Domain 2D Graphics Metafile Resources

005097-A00	Programming with Domain 2D Graphics Metafile Resource
009793-A00	Domain 2D Graphics Metafile Resource Call Reference

Domain 3D Graphics Metafile Resources

005807-A00	Programming with Domain 3D Graphics Metafile Resource
005812-A00	Domain 3D Graphics Metafile Resource Call Reference

Domain/PHIGS

009701-A00	Programming with Domain/PHIGS
009702-A00	Domain/PHIGS Call Reference

Domain 5080 Emulator

010045	Installing the Domain 5080 Emulator
010046	Using the Domain 5080 Emulator
010047	Managing the Domain 5080 Emulator
010265	Planning for the Domain 5080 Emulator



Communications Networks

Site Planning

009916-A00	Planning Domain Networks and Internets
------------	--

Network Backup System

014819-A00	Managing Network Backups with OmniBack
------------	--

Network File Systems

010414-A00	Using NFS on the Domain Network
------------	---------------------------------

Electronic Mail

003660-A00	DPSS/Mail User's Guide
------------	------------------------

Apollo Token Ring Network

010005	Apollo Token Ring Media Access Control Layer and Physical Layer Protocols
009860-A00	Installing Coaxial Cable and Accessories for an Apollo Token Ring Network
008626	Installing and Operating the Domain/DFL100 Fiber Interface Unit
014447-A00	Isolating Faults in the Apollo Token Ring Network

013419-A00	Using Network Topology Control (NTC) Software
014961-A00	ATR-RNS Installation Summary
012798-A00	Planning for ATR-RNS

Internets

005694-A00	Managing Domain/OS and Domain Routing in an Internet
011717-A00	Making the Transition to SR10 TCP/IP
008667-A00	Using TCP/IP Network Applications
008543-A00	Configuring and Managing TCP/IP

DEC® Interconnect Products

008012	Using the Domain/Access Application
010173	Managing the Domain/Access Application
014625-A01	Planning for Apollo/TECHnet
014626-A01	Using Apollo/TECHnet
014627-A01	Managing Apollo/TECHnet

IBM® Interconnect Products

005146	Using the Domain System RJE Emulator Package
007760-A00	Planning for the Domain/SNA-3270 Gateway
012882-A00	Planning for the Domain/SNA-3770 Gateway
007762-A00	Using the Domain/SNA-3270 Gateway
012881-A00	Using the Domain/SNA-3770 Gateway
007763-A00	Managing the Domain/SNA-3270 Gateway
011901-A00	Managing the Domain/SNA-3770 Gateway
008918-A00	Planning for the Domain/LU 6.2 Gateway
008919-A00	Managing the Domain/LU 6.2 Gateway
010017-A00	Domain/LU 6.2 Transaction Verb Reference

Domain/X.25 Version 2.3

003223	Domain/X.25 Reference
008264	Installing the COM-X.25 Product

PC Interconnect Products

007457	Planning for and Installing the Domain/PCI Connection
007460-A00	Using the Domain/PCI Connection
009498	Using Domain/PCC Compatibility Products
009501	Installing Domain/PCC in Your Series DN3000/DN4000

Communications Controllers

007761-A00	Installing the Domain/ComController Product
008265	Unpacking and Installing the EtherController-MB
005697	Unpacking and Installing the Domain/Bridge Controllers
010614-A00	802.3 Network Controller-AT Installation Information
010616-A00	Apollo Token Ring Network Controller-AT Installation Information
010616-A01	Apollo Token Ring Network Controller-AT Installation Information (APN 015892)
011904-A00	Installing the Serial Controller-AT
014448-A01	802.5 Network Controller-AT Installation Information
014818-A00	Planning Information for Domain IEEE 802.5 Networks and Internets
016336-A00	IEEE 802.5 Network Controller-AT Installation Procedure
016696-A00	Apollo Token Ring Network Controller-VME Installation Information
016697-A00	802.3 Network Controller-VME Plus Installation Information



Distributed Computing

011273-A00
011272-A00
010201-A00

Licensing Application Software with NLS
Managing Application Software with NLS
Network Computing Architecture (NCA)
Protocol Specifications

*Order the following three manuals
together as DOC-NCS:*

010200-A00

Network Computing System (NCS)
Reference

010233

Concurrent Programming Support (CPS)
Reference

011895-A01


Managing the NCS Location Broker



Text Processing and Editing

011018-A00
007765
012887-A00

UNIX® Text Processing
PostScript® Language Reference
Using TranScript™ with Domain/OS



Systems

Domain Series 3000, Series 3500, Series 4000, Series 4500

- | | |
|------------|---|
| 007857-A01 | Unpacking and Installing Your Domain Personal Workstations and Servers |
| 007858-A00 | Operating the Domain Personal Workstations and Servers |
| 007859-A01 | Servicing the Domain Personal Workstations and Servers |
| 008778-A01 | Domain Personal Workstations and Servers Technical Reference |
| 007861-A00 | Domain Personal Workstations and Servers Hardware Architecture Handbook |
| 015110-A01 | Domain Personal Workstations Power Ratings Worksheet |
| 015111-A01 | Domain Personal Workstations Address and Request Lines Worksheet |
| 010332-A00 | Adding Third-Party AT® Compatible Options to Domain Workstations and Writing Device Drivers |
| 010409-A01 | Installing Graphics Controllers in the PC AT Compatible Bus |
| 010615-A00 | Installing Memory in the Domain Personal Workstations and Servers |
| 011398-A01 | Unpacking and Installing Your DN3040/DN3540 Workstation and the DSP3040/DSP3540 Server |
| 011400-A01 | Servicing the DN3040/DN3540 Workstation and the DSP3040/DSP3540 Server |
| 013077-A00 | Domain Personal Workstations Floating-Point Accelerator Handbook |
| 012947-A02 | Operating the Disk/Multiple Disk Expansion Module on the Personal Workstation or Series 10000 |

Series 10000

011903-A00	Unpacking and Installing the Series 10000 Workstation and Server
012880-A00	Operating the Series 10000 Workstation and Server
011404-A01	Series 10000 Programmer's Handbook
011719-A01	Servicing the Series 10000 Workstation and Server
011720-A00	Series 10000 Technical Reference Library, Volume 1 — Processors and Instruction Set
011721-A00	Series 10000 Technical Reference Library, Volume 2 — I/O Devices
011723-A00	Series 10000 Technical Reference Library, Volume 4 — Network Controllers
011724-A00	Series 10000 Technical Reference Library, Volume 5 — Hardware Specifications
013918-A01	Series 10000 Configuration Worksheet
016654-A00	Unpacking and Installing the Multiple Disk Expansion Module for the Series 10000
016655-A00	Product Servicing Summary for the Multiple Disk Expansion Module for the Series 10000
015337-A00	Product Servicing Summary for the Series 10000 Workstation and Server
012947-A02	Operating the Disk/Multiple Disk Expansion Module on the Personal Workstations or Series 10000

DN5xx-T, DSP500-T

009493-A00	Unpacking and Installing the DN5xx-T Workstations and DSP500-T Server
009494	Operating the DN5xx-T Workstations and DSP500-T Server
009489	Servicing the DN5xx-T Workstations and DSP500-T Server
009491	DN5xx-T Workstations and DSP500-T Server Technical Reference
009490	DN5xx-T Workstations and DSP500-T Server Hardware Architecture Handbook

DN550, DN560, DN570, DN580, DN590

004108	Unpacking and Installing the DN550/DN560/DN570 (A) Workstation
004107	Operating the DN550/DN560/DN570
004827	Servicing the DN550/DN560/DN570
007450	Unpacking and Installing the DN580
007451	Operating the DN580
007452	Servicing the DN580/DN590

DSP80A, DSP90, DSP160, DSP9000

004958	Unpacking and Installing the DSP80A/DSP90
004957	Operating the DSP80A/DSP90
005806	Servicing the DSP80A/DSP90
005489	Operating the DSP160

DN3xx, DN4xx, DN6xx

005447	Unpacking and Installing the DN3xx
005448	Operating the DN3xx
003135	Servicing the DN3xx
005509	Operating the DN4xx/6xx
003239	Troubleshooting Guide (DN4xx/DN6xx)

Peripherals

008268-A00	Installing Input/Output (I/O) Devices for Domain Nodes
009798-A00	Installing and Programming the Domain SPE Option
008257	Installing the Tablet
008258	Installing the Multi-Mode Printer
008261	Installing the Printer/Plotter
008262	Installing the Disk Storage Module (MSD-300M)
008263	Installing the MSD-1600
008266	Installing the IMAGEN® Laser Printers
008267	Installing the FSD-500
007456-A00	Unpacking and Installing the Model 6250 Magnetic Tape Drive
009906	Installing and Operating the Tektronix® 4692 Printer Interface
007851	Installing the Domain/Laser-26 Printer in a Domain System
007852	Operating the Domain/Laser-26 Printer
007864	Installing the APPLE® LaserWriter® Printer in a Domain System

- 012945-A02 Product Servicing Summary for the Disk/Multiple Disk Expansion Module on the Personal Workstations
- 016411-A00 Unpacking and Installing the Disk/Multiple Disk Expansion Module for the Personal Workstations
- 016698-A00 Cartridge Tape Controller Installation Information
- 016699-A00 IKON 92 Parallel Interface Installation Information

General Systems Documentation

- 009859-A01 Domain Hardware Site Planning Specifications
- 014881-A00 Domain Hardware Utilities Reference
- 009329-A00 Using Domain Diagnostics, Volume 1
- 011775-A00 Using Domain Diagnostics, Volume 2
- 011776-A00 Using Domain Diagnostics, Volume 3
- 009349-A00 Servicing Domain Monitors
- 008665 Installation Summary for the DQC-100 Network Controller
- 015722-A00 Apollo Product Servicing Guide



Apollo Documentation

- 011242-A00 Domain Documentation Master Index
- 002685-A01 Apollo Documentation Quick Reference

SR9.7 Documentation



Operating System

Aegis

002348	Getting Started with Your Domain System
005488	Domain System User's Guide
002547	Domain System Command Reference
007196	Domain System Call Reference
007194	Domain GPR Call Reference
008860	Installing Domain Software
001746	Administering Your Domain System
005506	Programming with General System Calls
005696	Programming with System Calls for Interprocess Communication
000959	Writing Device Drivers with GPI/O
009492	Making the Transition to SR9.5

Domain/IX

008017	Getting Started with Domain/IX
005798	Domain/IX Command Reference, System V
005800	Domain/IX BSD4.2 Command Reference
005801	Domain/IX BSD4.2 Programmer's Reference
005799	Domain/IX Programmer's Reference, System V
005804	Domain/IX Text Editor Quick Reference
005803	Domain/IX User's Guide
005802	Domain/IX Text Processor's Guide
009355	BSD4.2 System Administrator's Guide
009356	System V System Administrator's Guide
009413	Domain/IX Support Tools Guide

X Window System

015213-A00	Using the X Window System on Apollo Workstations
011241-A00	Domain/X11 Xlib Reference
013418-A00	Domain/X11 Xlib Programming Manual
015534-A00	Domain/X11 User's Guide



Software Development Tools

- 008906 Analyzing Program Performance with DPAK
- 008863 Using the Open Systems Toolkit to Extend Your Domain Streams
- 001525 Domain Language Level Debugger
- 004977 Domain Binder and Librarian Reference

Domain Software Engineering Environment (DSEE)

- 008788-A00 Getting Started with Domain Software Engineering Environment (DSEE)
- 008790-A00 Engineering in the DSEE Environment
- 003016 Domain Software Engineering Environment (DSEE) Command Reference
- 010264 Domain Software Engineering Environment (DSEE) Call Reference

D3M

- 001950 Introduction to D3M
- 004302-A00 How to Design, Define, and Operate a D3M Database
- 004303-A00 How to Write DML Programs
- 004304-A00 How to Use the D3M/Dataview and Formatter

Domain/Dialogue and Open Dialogue

- 010218 Getting Started with Domain/Dialogue
- 004299 Domain/Dialogue User's Guide
- 011166-A01 Customizing Open Dialogue
- 011167-A01 Creating User Interfaces with Open Dialogue
- 012807-A01 Open Dialogue Reference



Languages

- | | |
|------------|-----------------------------------|
| 000792 | Domain Pascal Language Reference |
| 000530 | Domain FORTRAN Language Reference |
| 002093 | Domain C Language Reference |
| 005805 | Domain C Library (CLIB) Reference |
| 012777-A00 | The C++ Programming Language |

Domain/Ada


- | | |
|------------|---|
| 008684 | Ada Language Reference Manual |
| 008917-A01 | Domain/Ada Development System Reference |
| 010978-A01 | Domain/Ada Quick Reference |

Domain/CommonLISP Version 2.2

- | | |
|--------|--------------------------------|
| 008791 | Domain/CommonLISP User's Guide |
| 010849 | Domain/CommonLISP Reference |

Domain/CommonLISP Version 3.0

- | | |
|------------|---|
| 008791-A00 | Domain/CommonLISP User's Guide |
| 015739-A00 | Domain/CommonLISP Tool Reference |
| 015738-A00 | Domain/CommonLISP Advanced User's Guide |
| 015458-A00 | CommonLISP: The Language |



Graphics

General Graphics

009791-A01	Domain Graphics Instruction Set Reference
009797-A01	Programming with Domain Graphics Service Routines
001955	Programming with Domain Core Graphics
012077-A00	Domain/GKS User and Reference Manual
005224	Domain 4014 User's Guide

Graphics Primitives Resource (GPR)

005808	Programming with Domain Graphics Primitives
007194	Domain Graphics Primitives Resource Call Reference
010430	Domain Graphics Primitives Quick Reference

Domain 2D Graphics Metafile Resources

005097-A00	Programming with Domain 2D Graphics Metafile Resource
009793-A00	Domain 2D Graphics Metafile Resource Call Reference

Domain 3D Graphics Metafile Resources

005807-A00	Programming with Domain 3D Graphics Metafile Resource
005812-A00	Domain 3D Graphics Metafile Resource Call Reference

Domain/PHIGS

009701-A00	Programming with Domain/PHIGS
009702-A00	Domain/PHIGS Call Reference

Domain 5080 Emulator

010045	Installing the Domain 5080 Emulator
010046	Using the Domain 5080 Emulator
010047	Managing the Domain 5080 Emulator
010265	Planning for the Domain 5080 Emulator



Communications Networks

Site Planning

009916	Planning Domain Networks and Internets
--------	--

Network File Systems

010414	Using NFS on the Domain Network
--------	---------------------------------

Electronic Mail

003660	DPSS/Mail User's Guide
--------	------------------------

Apollo Token Ring Network

010005	Apollo Token Ring Media Access Control Layer and Physical Layer Protocols
009860-A00	Installing Coaxial Cable and Accessories for an Apollo Token Ring Network
008626	Installing and Operating the Domain/DFL100 Fiber Interface Unit
014447-A00	Isolating Faults in the Apollo Token Ring Network
013419-A00	Using Network Topology Control (NTC) Software
014961-A00	ATR-RNS Installation Summary
012798-A00	Planning for ATR-RNS

SR9.7 Documentation

Internets

005694	Managing the Domain Environment in an Internet
008667	Using Telenet and FTP
008543	Configuring and Managing TCP/IP
010483	Planning for TCP/IP

DEC® Interconnect Products

008012	Using the Domain/Access Application
010173	Managing the Domain/Access Application

IBM® Interconnect Products

005146	Using the Domain System RJE Emulator Package
007760	Planning for the Domain/SNA Gateway Products
007762	Using the Domain/SNA Gateway Products
007763	Managing the Domain/SNA Gateway Products
008918-A00	Planning for the Domain/LU 6.2 Gateway
008919-A00	Managing the Domain/LU 6.2 Gateway
010017-A00	Domain/LU 6.2 Transaction Verb Reference

Domain/X.25 Version 3.0

013586-A00	Planning for Domain/X.25
013587-A00	Using Domain/X.25
013588-A00	Managing Domain/X.25

Domain/X.25 Version 2.3


003223	Domain/X.25 Reference
008264	Installing the COM-X.25 Product

PC Interconnect Products


007457	Planning for and Installing the Domain/PCI Connection
007460-A00	Using the Domain/PCI Connection
009498	Using Domain/PCC Compatibility Products
009501	Installing Domain/PCC in Your Series DN3000/DN4000

Communications Controllers

007761-A00	Installing the Domain/ComController Product
008265	Unpacking and Installing the EtherController-MB
005697	Unpacking and Installing the Domain/Bridge Controllers
010614-A00	802.3 Network Controller-AT Installation Information
010616-A00	Apollo Token Ring Network Controller-AT Installation Information
011904-A00	Installing the Serial Controller-AT
014448-A01	802.5 Network Controller-AT Installation Information
014818-A00	Planning Information for Domain IEEE 802.5 Networks and Internets

**Distributed Computing**

011273-A00	Licensing Application Software with NLS
011272-A00	Managing Application Software with NLS
010201-A00	Network Computing Architecture(NCA) Protocol Specifications
	<i>Order the following three manuals together as DOC-NCS:</i>
010200	Network Computing System (NCS) Reference
010233	Concurrent Programming Support (CPS) Reference
011895-A00	Managing the NCS Location Broker



Systems

Domain Series 3000, Series 3500, Series 4000, Series 4500

007857-A01	Unpacking and Installing Your Domain Personal Workstations and Servers
007858-A00	Operating the Domain Personal Workstations and Servers
007859-A01	Servicing the Domain Personal Workstations and Servers
008778-A01	Domain Personal Workstations and Servers Technical Reference
007861-A00	Domain Personal Workstations and Servers Hardware Architecture Handbook
015110-A01	Domain Personal Workstations Power Ratings Worksheet
015111-A01	Domain Personal Workstations Address and Request Lines Worksheet
010332-A00	Adding Third-Party AT® Compatible Options to Domain Workstations and Writing Device Drivers
010409-A01	Installing Graphics Controllers in the PC AT Compatible Bus
010615-A00	Installing Memory in the Domain Personal Workstations and Servers
011398-A01	Unpacking and Installing Your DN3040/DN3540 Workstation and the DSP3040/DSP3540 Server
011400-A01	Servicing the DN3040/DN3540 Workstation and the DSP3040/DSP3540 Server
013077-A00	Domain Personal Workstations Floating-Point Accelerator Handbook

DN5xx-T, DSP500-T

009493-A00	Unpacking and Installing the DN5xx-T Workstations and DSP500-T Server
009494	Operating the DN5xx-T Workstations and DSP500-T Server

009489	Servicing the DN5xx-T Workstations and DSP500-T Server
009491	DN5xx-T Workstations and DSP500-T Server Technical Reference
009490	DN5xx-T Workstations and DSP500-T Server Hardware Architecture Handbook

DN550, DN560, DN570, DN580, DN590

004108	Unpacking and Installing the DN550/DN560/DN570(A) Workstation
004107	Operating the DN550/DN560/DN570
004827	Servicing the DN550/DN560/DN570
007450	Unpacking and Installing the DN580
007451	Operating the DN580
007452	Servicing the DN580/DN590

DSP80A, DSP90, DSP160, DSP9000

004958	Unpacking and Installing the DSP80A/DSP90
004957	Operating the DSP80A/DSP90
005806	Servicing the DSP80A/DSP90
005489	Operating the DSP160

DN3xx, DN4xx, DN6xx

005447	Unpacking and Installing the DN3xx
005448	Operating the DN3xx
003135	Servicing the DN3xx
005509	Operating the DN4xx/6xx
003239	Troubleshooting Guide (DN4xx/DN6xx)

Peripherals

008268-A00	Installing Input/Output (I/O) Devices for Domain Nodes
009798-A00	Installing and Programming the Domain SPE Option
008257	Installing the Tablet
008258	Installing the Multi-Mode Printer
008261	Installing the Printer/Plotter
008262	Installing the Disk Storage Module (MSD-300M)
008263	Installing the MSD-1600
008266	Installing the IMAGEN® Laser Printers
008267	Installing the FSD-500

SR9.7 Documentation

007456-A00	Unpacking and Installing the Model 6250 Magnetic Tape Drive
009906	Installing and Operating the Tektronix® 4692 Printer Interface
007851	Installing the Domain/Laser-26 Printer in a Domain System
007852	Operating the Domain/Laser-26 Printer
007864	Installing the APPLE® LaserWriter® Printer in a Domain System
007765	PostScript® Language Reference
012947-A02	Operating the Disk/Multiple Disk Expansion Module on the Personal Workstations or Series 10000
012945-A02	Product Servicing Summary for the Disk/Multiple Disk Expansion Module on the Personal Workstations

General Systems Documentation

009859-A01	Domain Hardware Site Planning Specifications
009329-A00	Using Domain Diagnostics, Volume 1
011775-A00	Using Domain Diagnostics, Volume 2
011776-A00	Using Domain Diagnostics, Volume 3
009349-A00	Servicing Domain Monitors
008665	Installation Summary for the DQC-100 Network Controller
015722-A00	Apollo Product Servicing Guide



Apollo Documentation

011242-A00	Domain Documentation Master Index
002685-A01	Apollo Documentation Quick Reference
011270-A00	Retrieving Information with Domain/Delphi

Notes



002685-A01