

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

.REM *

IDENTIFICATION

PRODUCT CODE: AC F756C-MC
PRODUCT NAME: CVDRCCO DRV11J DIAG 1ST PRT1
DATE CREATED: AUGUST 1983
AUTHOR: BILL HEAVY
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979 DIGITAL EQUIPMENT CORPORATION

52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
3.0	LOADING PROCEDURE
4.0	STARTING PROCEDURE
4.1	PROGRAM START
5.0	SOFTWARE SWITCH REGISTER
5.1	OPTIONS
5.2	CONTROL
6.0	ERROR REPORTING
6.1	ERROR COMMENT
6.2	ERROR DATA
7.0	MISCELLANEOUS
7.1	DRV11J BUS ADDRESS MODIFICATION
7.2	XXDP/APT NOTES
7.3	POWER FAIL
7.4	MULTIPLE DRV11J INTERFACE TESTING
7.5	RESTRICTIONS
8.0	EXECUTION TIME
9.0	PROGRAM TEST DESCRIPTIONS
10.0	LISTING

94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150

1.0 ABSTRACT

THE DRV11-J IS A GENERAL PURPOSE PARALLEL INTERFACE FOR THE LSI-11 BUS. IT HAS A BASIC CONFIGURATION OF 64 TRI STATE IN/OUT LINES DIVIDED INTO FOUR GROUPS OR PORTS OF 16 BIT WORDS.

THERE ARE TWO 4K DIAGNOSTICS FOR THE DRV11-J OPTION. THE DRV11-J DIAGNOSTIC TEST PART 1 OF 2 CONTAINS A SERIES OF TESTS WITHOUT DRV11J INTERRUPTS DESIGNED TO TEST ALL LOGIC FUNCTIONS AND DATA PATHS MADE ACCESSIBLE WITH THE LOOPBACK CABLE INSERTED INTO THE DRV11-J I/O CONNECTORS.

THE DRV11-J DIAGNOSTIC PART 2 OF 2 IS A SERIES OF TESTS WITH DRV11J INTERRUPTS DESIGNED TO TEST ALL LOGIC AND DATA PATHS MADE ACCESSIBLE WITH THE LOOPBACK CABLE INSERTED INTO THE I/O CONNECTORS.

THE DRV11 J IS CONTAINED ON A DOUBLE HEIGHT MODULE. THE MODULE CONTAINS TWO 50 PIN CONNECTORS FOR INTERFACING TO EXTERNAL USER DEVICES.

FOR DIAGNOSTIC TESTING, THE DRV11-J CABLE (BC05W-02) MUST BE INSTALLED WITH 1/2 TWIST BETWEEN THE 50 PIN CONNECTORS.

```

*****
*                                     ;;GPA *
* NOTE: THIS DIAGNOSTIC HAS BEEN MODIFIED TO RUN IN KXT11 (SBC 11/21) *
* BASED SYSTEMS. THE PROGRAM WILL AUTOMATICALLY ADJUST ITSELF TO RUN *
* IN THE APPROPRIATE ENVIRONMENT AS FOLLOWS: *
*                                     *
*          LSI-11, 11/2, AND 11/23          SBC 11/21 *
*          ----- *
* CSR RANGE:          160010 TO 177760          174000 TO 177760 *
* PROGRAMMABLE... *
* ...VECTOR RANGE:    0000 TO 1774          000 TO 374 *
*                                     ;;GPA *
*****
    
```

2.0 REQUIREMENTS

2.1 EQUIPMENT

1. PDP11/03, 11/23 COMPUTER OR LSI-11 PROCESSOR WITH A MINIMUM OF 4K MEMORY.
2. SERIAL LINE INTERFACE AND CONSOLE TERMINAL
3. DRV11-J OPTION WITH A BC05W-02 CABLE

2.2 STORAGE

THE PROGRAM USES THE LOWER 4K OF MEMORY.

3.0 LOADING PROCEDURE

151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207

USE STANDARD PROCEDURE FOR POP 11 ABSOLUTE
BINARY FORMATTED PAPER TAPE'S OR XXDP MEDIA
(FILES WITH .BIC OR .BIN EXTENSIONS ONLY).

4.0 STARTING PROCEDURE

1. MAKE SURE THE DRV11 J CABLE IS INSERTED WITH 1/2 A TWIST ON THE I/O CONNECTORS OF THE DRV11-J OPTION. THIS WILL CONNECT PORT A TO PORT C AND PORT B TO PORT D.
 2. MAKE SURE THE DEVICE BUS ADDRESSES AGREE WITH THE DEFAULT VALUES DEFINED IN SECTION 7.1. IF NOT, CHANGE LOCATION(S) AS DESIRED VIA THE 'ADDRESS/' ODT COMMAND.
 3. THE PROGRAM SHOULD ALWAYS BE STARTED AT 200. STARTING AT 200(200G OR .R CVDRCC UNDER XXDP*), THE PROGRAM INITIALIZES ITSELF, PRINTS ITS ID(FIRST TIME ONLY) AND THEN PRINTS THAT THE DRV11-J CABLE IS REQUIRED(FIRST TIME ONLY) AND THEN PRINTS: SWR=XXXXXX NEW=
- WHERE XXXXXX REPRESENTS THE CURRENT VALUE OF THE SOFTWARE SWITCH REGISTER. IF NO CHANGES ARE REQUIRED IN THE SWITCH REGISTER THEN JUST HIT CARRIAGE RETURN. IF CHANGES ARE REQUIRED, THEN A NEW VALUE MAY BE TYPED FOLLOWED BY A CARRIAGE RETURN. REFER TO SECTION 5.0 FOR SWITCH REGISTER OPTIONS.
4. IF THE FOLLOWING ERROR OCCURS RIGHT AFTER STARTUP IT IS POSSIBLE THAT THE DRV11J LOOPBACK CABLE MAY NOT BE INSTALLED OR WAS NOT INSTALLED PROPERLY:

```
REG READ/WRITE ER
ERRPC  TSTNUM  BUSADR  EXPCT  RCVD
002224  000002  *16416C  100700  000700
*BUSADR MAY BE DIFFERENT DEPENDING ON THE CSR OF THE DRV11J.
```

5.0 SOFTWARE SWITCH REGISTER

5.1 OPTIONS

THE PROGRAM SWITCH DEFAULT MODE IS SWR = 000000
IF USING A VIDEO TERMINAL, BIT 15 = 1 (HALT ON ERROR)
MAY BE HELPFUL IN KEEPING THE ERROR ON THE SCREEN.

SWITCH	OCTAL	FUNCTION
SW15=1	100000	HALT ON ERROR
SW14=1	040000	LOOP ON TEST
SW13=1	020000	INHIBIT ERROR TYPEOUTS
SW11=1	004000	INHIBIT ITERATIONS
SW09=1	001000	LOOP ON ERROR
SW08=1	0004XX	LOOP ON TEST IN SWR <7-0>

208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224

5.2 CONTROL

1. THE SOFTWARE SWITCH REGISTER 'SWREG' (LOC. 176) CAN BE CHANGED BY USING THE ODT FACILITIES.
2. THE SOFTWARE SWITCH REGISTER CAN BE CHANGED UNDER PROGRAM CONTROL BY TYPING THE 'CONTROL & G' KEYS. THIS KEYBOARD OPERATION WILL PRINT OUT THE CURRENT CONTENTS AND ACCEPT NEW OCTAL SWITCH REGISTER DATA TERMINATED WITH A CARRIAGE RETURN.
3. ONCE THE ODT MODE HAS BEEN ENTERED BECAUSE OF AN ERROR CONDITION WITH BIT15 SET (HALT ON ERROR), STEP #2 ABOVE IS OF NO VALUE, SO RESORT TO STEP #1 TO ALTER THE SOFTWARE SWITCH REGISTER IF DESIRED BEFORE TYPING 'P' (CONTINUE).

226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270

6.0 ERROR REPORTING

6.1 ERROR COMMENT

ALL ERRORS ARE ACCOMPANIED WITH AN ENGLISH LANGUAGE DESCRIPTIVE COMMENT AS TO THE TYPE OF FAILURE. FURTHER QUALIFICATION OF THE ERROR CAN BE OBTAINED IF NEEDED FROM THE COMMENT AT THE ERROR PC OR FROM THE TEST ITSELF.

TO CONSERVE MEMORY SPACE FOR THE 4K PROGRAM MEMORY REQUIREMENT, REGISTER 5 (R5) IS RESERVED FOR THE \$BDDAT LOCATION (1126).

EXAMPLE: CMP \$GDDAT,(R5) IS THE SAME AS CMP \$GDDAT,\$BDDAT.

6.2.1 ERROR DATA

ERROR TITLE HEADING

ERRPC	ISTNUM	BUSADR	EXPCT	RCVD
YXXXXX	XXXXXX	YXXXXX	XXXXXX	XXXXXX

ERRPC	LISTING ADDRESS WHERE THE ERROR WAS DETECTED
ISTNUM	TEST NUMBER WHERE THE ERROR OCCURRED
BUSADR	DRV11J BUS REG ADDRESS OF CONCERNED OPERATION
EXPCT	DATA THAT WAS EXPECTED
RCVD	DATA THAT WAS RECEIVED

6.2.2 ERROR TITLES

REG TIMEOUT ER	;REGISTER TIMEOUT ERROR
REG READ/WRITE ER	;REGISTER READ/WRITE ERROR
IRR REG ER	;INTERRUPT REQUEST REGISTER ERROR
ACR REG ER	;AUTOCLEAR REGISTER ERROR
IMR REG ER	;INTERRUPT MASK REGISTER ERROR
ISR REG ER	;INTERRUPT SERVICE REGTSTER ERROR
CHIP STAT ER	;CHIP STATUS ERROR

```

272          7.0  MISCELLANEOUS
273
274
275          7.1  DRV11 J BUS ADDRESS MODIFICATION
276
277              MODIFY LOCATION '$BASE' (ADDR: 1244) IF BASE BUS ADDRESS
278              IS NOT 164160.
279
280
281          7.2  XXDP APT NOTES
282
283              THIS DIAGNOSTIC DOES SUPPORT ACT AND APT ENVIRONMENTS.
284
285          7.3  POWER FAIL
286
287              A POWER FAILURE WILL CAUSE A RESTART MESSAGE ON POWER UP AT
288              WHICH TIME THE PROGRAM IS RESTARTED (ONLY ON SYSTEMS WITH
289              NON-VOLATILE MEMORY AND WITH APPROPRIATE HARDWARE).
290
291          7.4  MULTIPLE DRV11J INTERFACE TESTING
292
293              THIS PROGRAM DOES NOT "AUTO-SIZE" THE NUMBER OF DRV11J'S CONNECTED.
294              THIS DIAGNOSTIC WILL TEST SEQUENTIALLY UP TO 4 DRV11J INTERFACES
295              WITH CONTIGUCUS BUS ADDRESSES. THIS IS ACCOMPLISHED
296              BY THE USER SETTING UP LOCATION 'DEVM' (ADDR: 1246)
297              WITH A BIT MAP INDICATING WHAT INTERFACES ARE TO BE TESTED.
298              I.E. BIT0 = 1 SAYS TEST 1ST DRV11J,
299                   BIT1 = 1 SAYS TEST 2ND DRV11J
300                   BIT2 = 1 SAYS TEST 3RD DRV11J
301                   BIT3 = 1 SAYS TEST 4TH DRV11J
302
303              1ST UNIT = STARTING CSRA          164160  $DEVM = 1
304              2ND UNIT = STARTING CSRA          164140  $DEVM = 3
305              3RD UNIT = STARTING CSRA          164120  $DEVM = 7
306              4TH UNIT = STARTING CSRA          164100  $DEVM = 17
307
308          7.5  RESTRICTIONS
309
310
311          8.0  EXECUTION TIME
312
313
314              EXECUTION TIME RANGES FROM ABOUT <5 SECONDS ON FIRST
315              PASS WITH NO ITERATIONS TO <20 SECONDS WITH ITERATIONS
316              ENABLED AFTER FIRST PASS,PER DRV11J UNIT CONNECTED.
317              AN "END PASS" MESSAGE INDICATES ALL TESTS HAVE COMPLETED
318              ON ALL SELECTED UNITS.

```

320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376

9.0 PROGRAM TEST DESCRIPTIONS

GENERAL

THIS DIAGNOSTIC CONTAINS A SERIES OF INDEPENDENT TESTS DESIGNED TO TEST LOGIC FUNCTIONS AND DATA PATHS OF THE DRV11J OPTION. TESTING IS ACCOMPLISHED WITH THE AID OF THE DRV11J LOOP BACK CABLE PROVIDED FOR DIAGNOSTIC TESTING. A COMPLETE LIST OF TESTS IS AVAILABLE IN THE TABLE OF CONTENTS AT THE BEGINNING OF THE LISTING. THE COMMENT FIELD WITHIN EACH TEST CAN BE BENEFICIAL IN TEST UNDERSTANDING.

TESTING WITH THE DRV11J CABLE ALLOWS FOR TESTING OF PORT A WITH PORT C AND THE TESTING OF PORT B WITH PORT D.

9.1 TESTS T1 T22 REGISTER CHECKING

THESE TESTS WILL WRITE/READ PORTS A TO C AND WRITE/READ PORTS B TO D WITH FLOATING ONES AND FLOATING ZEROS, GROWING ONES AND GROWING ZEROS AND DATA PATTERNS. TESTS ARE PERFORMED TO INSURE INTERACTION WITH CONNECTED PORTS AND NO INTERACTION BETWEEN UNCONNECTED PORTS.

9.2 T22-T42 INTERRUPT CONTROL REGISTER CHECKING

TESTS ARE MADE TO THE INTERRUPT CONTROL CHIP REGISTERS IRR, ACR, IMR AND LIMITED TESTING OF ISR REGISTER UNTIL INTERRUPTS ARE PERFORMED. TESTS ARE PERFORMED ON THE REGISTERS WITH FLOATING ONES, FLOATING ZEROS, GROWING ONES AND GROWING ZEROS. CHIP RESET CAPABILITIES ARE TESTED AS WELL AS UNIQUENESS OF REGISTERS WITHIN A CHIP GROUP AND THE UNIQUENESS OF ONE GROUP'S REGISTERS TO ANOTHER GROUP'S REGISTERS.

9.3 TEST 43 - TEST STATUS BITS GINT, S2, S1, S0, GP1, GP2

EXERCISE THE STATUS BITS S2, S1, S0 AND GINT FOR EACH GROUP CHIP BY SETTING SINGLE IRR BITS TO CAUSE THE STATUS BITS TO GO FROM 120 TO 127. EACH IRR BIT IS THEN MASKED TO RETURN STATUS BACK TO ORIGINAL STATUS WITH NO IRR BITS SET.

9.4 T44-T47 POLLED MODE TESTING

THIS TEST WILL WRITE PATTERNS INTO DBRA WITH EITHER LOW TO HIGH OR HIGH TO LOW POLARITIES. AFTER PLACING ALL ONES IN DBRA AND THEN SELECTING ACTIVE LOW, CLEARING DBRA WILL NOW SET IRR BITS 0-7, GROUP 1 AND IRR BITS 0-3, GROUP 2.

377 THE RPLY SIGNALS WILL SET IRR BITS 4-7
378 WHEN WRITING DBRA IN OUTPUT MODE, THIS WILL
379 SET THE RPLY FOR DBRC.(IRR6, GROUP 2)
380 WHEN READING DBRC IN INPUT MODE WILL SET
381 THE RPLY FOR DBRA.(IRR BIT 4, GROUP 2)
382 WHEN WRITING DBRB IN OUTPUT MODE, THIS WILL
383 SET THE RPLY FOR DBRD(IRR BIT 7, GROUP 2)
384 WHEN READING DBRD IN INPUT MODE, THIS WILL
385 SET THE RPLY FOR DBRB(IRR BITS, GROUP 2).
386 TEST ALL DATA PATTERNS TO SET IRR BITS
387 GROUP 1 AND GROUP 2 AND FOR THE SETTING OF RPLY
388 BITS IN THE GROUP 2 IRR REGISTER BY WRITING IN
389 OUTPUT MODE AND READING IN INPUT MODE.
390 TEST THAT NO RPLY BITS SET WHEN READING IN OUTPUT
391 MODE AND WHEN WRITING IN INPUT MODE.
392
393 9.5 T50 T51 CSR'S WITH RESET
394 SET UP CSR'S IN OUTPUT MODE AND CLEAR
395 DIRECTION BIT OUT OF EACH CSR EXCEPT FOR
396 CSRA WHICH WILL CLEAR DIR BIT AND I/E BIT.
397
398 10.0 LISTING
399 -----
400 *

```

412      ;;GPA .HEADER +/CVDRCA DRV11J DIAG TST PRT1/,1979,+/BILL HEAVEY/
413      ;;JRS .HEADER +/CVDRCB DRV11J DIAG TST PRT1/,1979,+/BILL HEAVEY/
414      .TITLE CVDRCC DRV11J DIAG TST PRT1
      ;*COPYRIGHT (C) 1979
      ;*DIGITAL EQUIPMENT CORP.
      ;*MAYNARD, MASS. 01754
      ;*
      ;*PROGRAM BY BILL HEAVEY
      ;*
      ;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
      ;*PACKAGE (MAINDEC-11-DZQAC-C7), JUL, 1982.
      ;*
000001  $IN=1
160000  $SWR=160000      ;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
415      ;* EDITED TO PERMIT DRV'S TO RUN ON FALCON (KXT11).      ;;GPA
416      ;*              G. PASQUANTONIO, JULY '81                ;;GPA
417      ;*
418      ;* REVISED TO COMPENSATE FOR LONG CABLES & FILTERS      ;;JRS
419      ;*              J. SUTTON, JULY '83                      ;;JRS
420      $SWR=165400
421      $IN=1
422      .SBTTL OPERATIONAL SWITCH SETTINGS
      ;*
      ;*      SWITCH          USE
      ;*      -----
      ;*      15             HALT ON ERROR
      ;*      14             LOOP ON TEST
      ;*      13             INHIBIT ERROR TYPEOUTS
      ;*      11             INHIBIT ITERATIONS
      ;*      9              LOOP ON ERROR
      ;*      8              LOOP ON TEST IN SWR<7;0>
423      .SBTTL BASIC DEFINITIONS
      ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100  STACK= 1100
104000  ERROR= EMT      ;;BASIC DEFINITION OF ERROR CALL
000004  SCOPE= IOT      ;;BASIC DEFINITION OF SCOPE CALL
      ;*MISCELLANEOUS DEFINITIONS
000011  HT= 11          ;;CODE FOR HORIZONTAL TAB
000012  LF= 12          ;;CODE FOR LINE FEED
000015  CR= 15          ;;CODE FOR CARRIAGE RETURN
000200  CRLF= 200       ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776  PS= 177776     ;;PROCESSOR STATUS WORD
177776  PSW= PS
177774  STKLMT= 177774  ;;STACK LIMIT REGISTER
177772  PIRQ= 177772   ;;PROGRAM INTERRUPT REQUEST REGISTER
177570  DSWR= 177570   ;;HARDWARE SWITCH REGISTER
177570  DDISP= 177570  ;;HARDWARE DISPLAY REGISTER
      ;*GENERAL PURPOSE REGISTER DEFINITIONS
000000  R0= #0          ;;GENERAL REGISTER
000001  R1= #1          ;;GENERAL REGISTER
000002  R2= #2          ;;GENERAL REGISTER
000003  R3= #3          ;;GENERAL REGISTER
000004  R4= #4          ;;GENERAL REGISTER
000005  R5= #5          ;;GENERAL REGISTER
000006  R6= #6          ;;GENERAL REGISTER
000007  R7= #7          ;;GENERAL REGISTER
000006  SP= #6         ;;STACK POINTER

```

BASIC DEFINITIONS

```
000007 PC = #7 ;;PROGRAM COUNTER
; *PRIORITY LEVEL DEFINITIONS
000000 PR0 = 0 ;;PRIORITY LEVEL 0
000040 PR1 = 40 ;;PRIORITY LEVEL 1
000100 PR2 = 100 ;;PRIORITY LEVEL 2
000140 PR3 = 140 ;;PRIORITY LEVEL 3
000200 PR4 = 200 ;;PRIORITY LEVEL 4
000240 PR5 = 240 ;;PRIORITY LEVEL 5
000300 PR6 = 300 ;;PRIORITY LEVEL 6
000340 PR7 = 340 ;;PRIORITY LEVEL 7
; * "SWITCH REGISTER" SWITCH DEFINITIONS
100000 SW15 = 100000
040000 SW14 = 40000
020000 SW13 = 20000
010000 SW12 = 10000
004000 SW11 = 4000
002000 SW10 = 2000
001000 SW09 = 1000
000400 SW08 = 400
000200 SW07 = 200
000100 SW06 = 100
000040 SW05 = 40
000020 SW04 = 20
000010 SW03 = 10
000004 SW02 = 4
000002 SW01 = 2
000001 SW00 = 1
001000 SW9 = SW09
000400 SW8 = SW08
000200 SW7 = SW07
000100 SW6 = SW06
000040 SW5 = SW05
000020 SW4 = SW04
000010 SW3 = SW03
000004 SW2 = SW02
000002 SW1 = SW01
000001 SW0 = SW00
; * DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15 = 100000
040000 BIT14 = 40000
020000 BIT13 = 20000
010000 BIT12 = 10000
004000 BIT11 = 4000
002000 BIT10 = 2000
001000 BIT09 = 1000
000400 BIT08 = 400
000200 BIT07 = 200
000100 BIT06 = 100
000040 BIT05 = 40
000020 BIT04 = 20
000010 BIT03 = 10
000004 BIT02 = 4
000002 BIT01 = 2
000001 BIT00 = 1
001000 BIT9 = BIT09
000400 BIT8 = BIT08
000200 BIT7 = BIT07
```

BASIC DEFINITIONS

```

000100 BIT6* BIT06
000040 BIT5* BIT05
000020 BIT4* BIT04
000010 BIT3* BIT03
000004 BIT2* BIT02
000002 BIT1* BIT01
000001 BIT0* BIT00
; *BASIC "CPU" TRAP VECTOR ADDRESSES
000004 ERRVEC= 4 ; TIME OUT AND OTHER ERRORS
000010 RESVEC= 10 ; RESERVED AND ILLEGAL INSTRUCTIONS
000014 TBITVEC= 14 ; "T" BIT
000014 TRTVEC= 14 ; TRACE TRAP
000014 BPTVEC= 14 ; BREAKPOINT TRAP (BPT)
000020 IOTVEC= 20 ; INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC= 24 ; POWER FAIL
000030 EMTVEC= 30 ; EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC= 34 ; "TRAP" TRAP
000060 TKVEC= 60 ; TTY KEYBOARD VECTOR
000064 TPVEC= 64 ; TTY PRINTER VECTOR
000240 PIRQVEC= 240 ; PROGRAM INTERRUPT REQUEST VECTOR
424 164160 ABASE* 164160 ; BASE ADDRESS
425 000001 ADEVM* 1 ; DEFAULT TO ONE DRV11J
426 100000 RDY* BIT15
427 000400 DIR* BIT8
428 001000 IE* BIT9
429
430 ; CHIP COMMAND SUMMARY
431 000020 CIRMR* 20 ; CLEAR IRR AND IMR
432 000030 CSIRMR* 30 ; CLEAR SINGLE IRR AND IMP BIT
433
434 000040 CIMR* 40 ; CLEAR IMR
435 000050 CSIMR* 50 ; CLEAR SINGLE IMR BIT
436 000060 SIMR* 60 ; SET ALL IMR BITS
437 000070 SSIMR* 70 ; SET SINGLE IMR BITS
438
439 000100 CIRR* 100 ; CLEAR IRR
440 000110 CSIRR* 110 ; CLEAR SINGLE IRR BITS
441 000120 SIRR* 120 ; SET ALL IRR BITS
442 000130 SSIRR* 130 ; SET SINGLE IRR BITS
443
444 000140 CHPISR* 140 ; CLEAR HIGHEST PRIORITY ISR BIT
445 000160 CISR* 160 ; CLEAR ISR
446 000170 CSISR* 170 ; CLEAR SINGLE ISR BIT
447
448 000200 LMD04* 200 ; LOAD MODE BITS M0-M4
449 000240 LMD57* 240 ; LOAD MODE BITS M5-M7
450
451 ; CHIP MODE BIT PRESELECTION
452 000240 MISR* 240
453 000244 MIMR* 244
454 000250 MIRR* 250
455 000254 MACR* 254
456
457 ; CHIP WRITE PRESELECTION
458 000300 PACH* 300 ; PRESELECT AUTO CLEAR REG. FOR WRITING
459 000260 PIMR* 260 ; PRESELECT IMR REG. FOR WRITING
460 000340 PVMA* 340 ; PRESELECT VECTOR MEMORY ADDRESS

```

BASIC DEFINITIONS

```

461
462          000000          .SBTTL TRAP CATCHER
                                .=0
                                ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
                                ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
                                ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
                                .=174
                                DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
                                SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER
                                .SBTTL STARTING ADDRESS(ES)
                                JMP      @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
463          000200 000137 001402          .-100
464          000100 000104 000200 000002  .WORD 104,200,2          ;IF 'B EVENT' ON Q BUS IS CONNECTED
465                                     ;IGNORE IT'S INTERRUPT - JUST DO A RTI

```

ACT11 HOOKS

467

```

.SBTTL ACT11 HOOKS
;*****
;HOOKS REQUIRED BY ACT11
      $SVPC*      ;SAVE PC
      .-46       ;
000046 000106    $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN , $EOP
      .-52       ;
000052 000000    .WORD 0     ;;2)SET LOC.52 TO ZERO
      .-$SVPC    ;; RESTORE PC
      .-1000     ;

```

468
469
470
471
472

```

;LONGEST TEST TIME
;1ST PASS RUN TIME
;ADDITIONAL RUN TIME

.SBTTL APT PARAMETER BLOCK
;*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
;*****
      . $X*      ;;SAVE CURRENT LOCATION
      .-24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
000024 000200    200        ;;FOR APT START UP
      .-44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
000044 001000    $APTHDR    ;;POINT TO APT HEADER BLOCK
      .-$X      ;;RESET LOCATION COUNTER
;*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.
$APTHD:
$HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
$MBADR: .WORD $MAIL  ;;ADDRESS OF APT MAILBOX (BITS 0-15)
$TSTM:  .WORD 6      ;;RUN TIM OF LONGEST TEST
$PASTM: .WORD 20.    ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
$UNITM: .WORD 20.    ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

```

001000
001000 000000
001002 001170
001004 000006
001006 000024
001010 000024
001012 000031

COMMON TAGS

473

```

.SBTTL COMMON TAGS
;*****
;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;USED IN THE PROGRAM.
      .-1100
001100 001100 $CMTAG:          ;;START OF COMMON TAGS
001100 000000   .WORD      0
001102 000   $TSTNM: .BYTE      0 ;;CONTAINS THE TEST NUMBER
001103 000   $ERFLG: .BYTE      0 ;;CONTAINS ERROR FLAG
001104 000000 $ICNT:  .WORD      0 ;;CONTAINS SUBTEST ITERATION COUNT
001106 000000 $LPADR: .WORD      0 ;;CONTAINS SCOPE LOOP ADDRESS
001110 000000 $LPERR: .WORD      0 ;;CONTAINS SCOPE RETURN FOR ERRORS
001112 000000 $ERTTL: .WORD      0 ;;CONTAINS TOTAL ERRORS DETECTED
001114 000   $ITEMB: .BYTE      0 ;;CONTAINS ITEM CONTROL BYTE
001115 001   $ERMAX: .BYTE      1 ;;CONTAINS MAX. ERRORS PER TEST
001116 000000 $ERRPC: .WORD      0 ;;CONTAINS PC OF LAST ERROR INSTRUCTION
001120 000000 $GDADR: .WORD      0 ;;CONTAINS ADDRESS OF 'GOOD' DATA
001122 000000 $BDADR: .WORD      0 ;;CONTAINS ADDRESS OF 'BAD' DATA
001124 000000 $GDDAT: .WORD      0 ;;CONTAINS 'GOOD' DATA
001126 000000 $BDDAT: .WORD      0 ;;CONTAINS 'BAD' DATA
001130 000000   .WORD      0 ;;RESERVED--NOT TO BE USED
001132 000000   .WORD      0
001134 000   $AUTOB: .BYTE      0 ;;AUTOMATIC MODE INDICATOR
001135 000   $INTAG: .BYTE      0 ;;INTERRUPT MODE INDICATOR
001136 000000   .WORD      0
001140 177570 $SWR:  .WORD      DSWR ;;ADDRESS OF SWITCH REGISTER
001142 177570 $DISPLAY: .WORD      DDISP ;;ADDRESS OF DISPLAY REGISTER
001144 177560 $TKS:  177560 ;;TTY KBD STATUS
001146 177562 $TKB:  177562 ;;TTY KBD BUFFER
001150 177564 $TPS:  177564 ;;TTY PRINTER STATUS REG. ADDRESS
001152 177566 $TPB:  177566 ;;TTY PRINTER BUFFER REG. ADDRESS
001154 000   $NULL:  .BYTE      0 ;;CONTAINS NULL CHARACTER FOR FILLS
001155 002   $FILLS: .BYTE      2 ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
001156 012   $FILLC: .BYTE     12 ;;INSERT FILL CHARS. AFTER A "LINE FEED"
001157 000   $TPFLG: .BYTE      0 ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
001160 000000 $TIMES: 0 ;;MAX. NUMBER OF ITERATIONS
001162 000000 $ESCAPE: 0 ;;ESCAPE ON ERROR ADDRESS
001164 077   $QUES:  .ASCII  '??' ;;QUESTION MARK
001165 015   $CRLF:  .ASCII  '<15>' ;;CARRIAGE RETURN
001166 012   $LF:    .ASCII  '<12>' ;;LINE FEED
;*****
.SBTTL APT MAILBOX-ETABLE
;*****
.EVEN
001170 $MAIL:          ;;APT MAILBOX
001170 000000 $MSGTY: .WORD      MSGTY ;;MESSAGE TYPE CODE
001172 000000 $FATAL: .WORD      AFATAL ;;FATAL ERROR NUMBER
001174 000000 $TESTN: .WORD      ATESTN ;;TEST NUMBER
001176 000000 $PASS:  .WORD      APASS ;;PASS COUNT
001200 000000 $DEVCT: .WORD      ADEVCT ;;DEVICE COUNT
001202 000000 $UNIT:  .WORD      AUNIT ;;I/O UNIT NUMBER
001204 000000 $MSGAD: .WORD      AMSGAD ;;MESSAGE ADDRESS
001206 000000 $MSGLG: .WORD      AMSGLG ;;MESSAGE LENGTH
001210 $ETABLE:       ;;APT ENVIRONMENT TABLE
001210 000   $ENV:  .BYTE      AENV ;;ENVIRONMENT BYTE
001211 000   $ENVM: .BYTE      AENVM ;;ENVIRONMENT MODE BITS
001212 000000 $SWREG: .WORD      ASWREG ;;APT SWITCH REGISTER

```

D.1

APT MAILBOX-E-TABLE

001214	000000	\$USWR: .WORD	AUSWR	::USER SWITCHES
001216	000000	\$CPUOP: .WORD	ACPUOP	::CPU TYPE,OPTIONS
		:*		BITS 15-11=CPU TYPE
		:*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		:*		11/70=06,PDQ=07,Q=10
		:*		BIT 10=REAL TIME CLOCK
		:*		BIT 9=FLOATING POINT PROCESSOR
		:*		BIT 8=MEMORY MANAGEMENT
001220	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
001221	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE,BLK#1
		:*		MEM. TYPE BYTE -- (HIGH BYTE)
		:*		900 NSEC CORE=001
		:*		300 NSEC BIPOLAR=002
		:*		500 NSEC MOS=003
001222	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS,BLK#1
		:*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
001224	000	\$MAMS2: .BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
001225	000	\$MTYP2: .BYTE	AMTYP2	::MEM TYPE,BLK#2
001226	000000	\$MADR2: .WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
001230	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
001231	000	\$MTYP3: .BYTE	AMTYP3	::MEM.TYPE,BLK#3
001232	000000	\$MADR3: .WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
001234	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
001235	000	\$MTYP4: .BYTE	AMTYP4	::MEM.TYPE,BLK#4
001236	000000	\$MADR4: .WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
001240	000000	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001242	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
001244	164160	\$BASE: .WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001246	000001	\$DEVM: .WORD	ADEVN	::DEVICE MAP
001250	000000	\$CDW1: .WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001252		\$ETEND:		
		.MEXIT		

ERROR POINTER TABLE

```

.SBTTL ERROR POINTER TABLE
;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
;*      FM          ;;POINTS TO THE ERROR MESSAGE
;*      DH          ;;POINTS TO THE DATA HEADER
;*      DT          ;;POINTS TO THE DATA
;*      DF          ;;POINTS TO THE DATA FORMAT
$ERRTB:
;ERROR 1
474
475 001252 017022      EM1          ;REG TIMEOUT ER
476 001254 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
477 001256 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
478 001260 000000      0
479
480
;ERROR 2
481 001262 017041      EM2          ;REG READ/WRITE ER
482 001264 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
483 001266 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
484 001270 000000      0
485
486
;ERROR 3
487 001272 017063      EM3          ;IRR REG ER
488 001274 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
489 001276 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
490 001300 000000      0
491
492
;ERROR 4
493 001302 017076      EM4          ;ACR REG ER
494 001304 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
495 001306 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
496 001310 000000      0
497
498
;ERROR 5
499 001312 017111      EM5          ;IMR REG ERROR
500 001314 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
501 001316 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
502 001320 000000      0
503
504
;ERROR 6
505 001322 017124      EM6          ;ISR REG ERROR
506 001324 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
507 001326 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
508 001330 000000      0
509
510
511
;ERROR 7
512 001332 017137      EM7          ;CHIP STAT ER
513 001334 017154      DH1          ;ERRPC TSTNUM BUSADR EXPCT RCVD
514 001336 017276      DT1          ;$ERRPC TSTNUM $BDADR $GDDAT $BDDAT(R5)
515 001340 000000      0
516
517
; BUS REGISTER ADDRESS POINTERS
518
519

```

ERROR POINTER TABLE

520				
521	001342	164160	DRCSA:	ABASE
522	001344	164162	DRDBA:	ABASE+2
523	001346	164164	DRCSB:	ABASE+4
524	001350	164166	DRDBB:	ABASE+6
525	001352	164170	DRDSC:	ABASE+10
526	001354	164172	DRDBC:	ABASE+12
527	001356	164174	DRDSD:	ABASE+14
528	001360	164176	DRDBD:	ABASE+16
529				
530				
531			;COMMON PROGRAM LOCATION(S)	
532				
533	001362	000000	TSTNUM:	0 ;CONTAINS TEST NUMBER ON ERROR
534	001364	000001	DMAP:	1
535	001366	000000	INTFLG:	.WORD 0
536	001370	000000	XXDP:	.WORD 0
537	001372	000000	IMRLOC:	.WORD 0
538	001374	000000	ISRLOC:	.WORD 0
539	001376	000000	IRRLOC:	.WORD 0
540	001400	000000	ACRLOC:	.WORD 0

PROGRAM START

543

544 001402

```

001402 012706 001100
001406 005026
001410 022706 001140
001414 001374
001416 012706 001100

001422 012737 015376 000020
001430 012737 000340 000022
001436 012737 015050 000030
001444 012737 000340 000032
001452 012737 016646 000034
001460 012737 000340 000036
001466 012737 016442 000024
001474 012737 000340 000026
001502 005037 001160
001506 005037 001162
001512 112737 000001 001115
001520 012737 001520 001106
001526 012737 001526 001110

001534 013746 000004
001540 012737 001574 000004
001546 012737 177570 001140
001554 012737 177570 001142
001562 022777 177777 177350
001570 001012

001572 000403
001574 012716 001602
001600 000002
001602 012737 000176 001140
001610 012737 000174 001142
001616 012637 000004
001622 005037 001176
001626 132737 000200 001211
001634 001403
001636 012737 001212 001140
001644

545 001644 005037 001172
546 001650 005037 001170
547 001654 005037 001174
548 001660 004737 017370
549 001664 001420
550 001666 042737 000040 000022
551 001674 042737 000040 000032
552 001702 042737 000040 000036
553 001710 023727 001244 164160
554 001716 001003
555 001720 012737 174160 001244
556 001726
557
558 001726 005737 000042
    
```

```

.SBTTL PROGRAM START
START:
.SBTTL INITIALIZE THE COMMON TAGS
;;CLEAR THE COMMON TAGS (%CMTAG) AREA
MOV %CMTAG,R6 ;;FIRST LOCATION TO BE CLEARED
CLR (R6)+ ;;CLEAR MEMORY LOCATION
CMP %SWR,R6 ;;DONE?
BNE -6 ;;LOOP BACK IF NO
MOV %1100,SP ;;SETUP THE STACK POINTER
;;INITIALIZE A FEW VECTORS
MOV %$SCOPE,%$IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
MOV %340,%$IOTVEC+2 ;;LEVEL 7
MOV %$ERROR,%$EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
MOV %340,%$EMTVEC+2 ;;LEVEL 7
MOV %$TRAP,%$TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
MOV %340,%$TRAPVEC+2;LEVEL 7
MOV %$PWRDN,%$PWRVEC ;;POWER FAILURE VECTOR
MOV %340,%$PWRVEC+2 ;;LEVEL 7
CLR $TIMES ;;INITIALIZE NUMBER OF ITERATIONS
CLR $ESCAPE ;;CLEAR THE ESCAPE ON ERROR ADDRESS
MOVB %1,$ERMAX ;;ALLOW ONE ERROR PER TEST
MOV %,$LPADR ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
MOV %,$LPERR ;;SETUP THE ERROR LOOP ADDRESS
;;SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
MOV %$ERRVEC,-(SP) ;;SAVE ERROR VECTOR
MOV %C4,%$ERRVEC ;;SET UP ERROR VECTOR
MOV %DSWR,SWR ;;SETUP FOR A HARDWARE SWITCH REGISTER
MOV %DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
CMP %-1,%SWR ;;TRY TO REFERENCE HARDWARE SWR
BNE 66$ ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
;;AND THE HARDWARE SWR IS NOT * -1
BR 65$ ;;BRANCH IF NO TIMEOUT
MOV %65$,(SP) ;;SET UP FOR TRAP RETURN
RTI
65$: MOV %SWREG,SWR ;;POINT TO SOFTWARE SWR
MOV %DISPREG,DISPLAY
66$: MOV (SP)+,%$ERRVEC ;;RESTORE ERROR VECTOR
CLR $PASS ;;CLEAR PASS COUNT
BITB %APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
BEQ 67$ ;;YES,USE NON-APT SWITCH
MOV %$SWREG,SWR ;;NO,USE APT SWITCH REGISTER
67$: CLR $FATAL ;;CLEAR ERROR NUMBER
CLR $MSGTYP ;;CLEAR MESSAGE TYPE
CLR $TESTN ;;CLEAR TEST NUMBER
CALL FALCON ;;CHECK FOR FALCON (KXT11) ;;GPA
BEQ 1000$ ;;BR IF NOT KXT11 SYSTEM ;;GPA
BIC %40,%$22 ;;YES, STRAP IOT... ;;GPA
BIC %40,%$32 ;;...EMT... ;;GPA
BIC %40,%$36 ;;...AND TRAP TO LEVEL 6. ;;GPA
CMP $BASE,%ABASE ;;IS $BASE VIRGIN ?? ;;GPA
BNE 1000$ ;;BR IF NOT. ;;GPA
MOV %174160,$BASE ;;YES, USE ENGINEERING DEFAULT ;;GPA
1000$:
;;CHECK OPERATING ENVIRONMENT
TST %42 ;;ARE WE IN ACT/XXDP AUTO MODE?
    
```

INITIALIZE THE COMMON TAGS

```

559 001732 001410          BEQ      1$          ;BRANCH IF NO
560 001734 023737 000042 000046    CMP      @#42,@#46    ;IS IT ACT AUTO MODE?
561 001742 001410          BEQ      2$          ;BRANCH IF YES
562 001744 012737 177777 001370    MOV      @-1,XXDP    ;SET XXDP CHAIN MODE INDICATOR
563 001752 000404          BR       2$
564 001754 123727 001210 000001 1$:  CMPB    $ENV,@1      ;ARE WE IN APT AUTO MODE?
565 001762 001003          BNE     3$          ;BRANCH IF NO
566 001764 112737 000001 001134 2$:  MOVB   @1,$AUTOB    ;SET AUTO MODE INDICATOR
567
568          ;PRINT TITLE IF NOT IN ACT OR APT AUTO MODE
569 001772 005227 177777 3$:  INC     @-1          ;FIRST TIME?
570 001776 001012          BNE     5$          ;SKIP TITLE IF NO
571 002000 005737 001134          TST     $AUTOB      ;ARE WE IN AUTO MODE?
572 002004 001403          BEQ     4$          ;BRANCH TO TITLE TYPEOUT IF NOT
573 002006 005737 001370          TST     XXDP        ;IS THE AUTO MODE UNDER XXDP?
574 002012 001404          BEQ     5$          ;SKIP TITLE IF NOT
575 002014 104401 016726 4$:  TYPE   ,TITLED      ;PRINT OUT THE TITLE
576 002020 104401 016773          TYPE   ,TLCABL     ;PRINT "DRV11J CABLE REQ'D"
577
578          ;GET THE VALUE IN THE SOFTWARE SWITCH REGISTER
579 002024 005737 001134 5$:  TST     $AUTOB      ;ARE WE IN AUTOMATIC MODE?
580 002030 001001          BNE     START1     ;BRANCH IF YES
581 002032 104406          GTSWR
582 002034 005037 001202          START1: CLR    $UNIT       ;ASK FOR SWR INPUT FROM CONSOLE
583 002040 013737 001246 001364    MOV     $DEVM,DMAP  ;CLEAR UNIT NUMBER
584 002046 042737 177760 001364    BIC    @177760,DMAP ;POSITION OF DRV11-J'S
585 002054 013701 001244          MOV     $BASE,R1    ;UP TO 4 DRV11-J'S ONLY
586 002060 010137 001342          MOV     R1,DRCSA    ;GET BASE ADDRESS
587 002064 032737 000001 001364    BIT    @1,DMAP      ;MAKE BUS REG. POINTER = $BASE
588 002072 001002          BNE     NEXPAS     ;IS FIRST DRV11-J SELECTED?
589 002074 000137 013006          JMP     NXPAS       ;YES
590 002100 012700 001342          NEXPAS: MOV   @DRCSA,R0 ;ADVANCE BASE DRV11-J ADDRESS
591 002104 010120          NEXPA1: MOV   R1,(R0)+ ;SET UP REGISTER ADDRESS POINTERS
592 002106 062701 000002          ADD    @2,R1        ;LOAD EM,R1 = DRV11 J CSRA ADDRESS
593 002112 022700 001367          CMP    @DRDBD+2,R0 ;DO POINTERS FOR ALL REGS, A THRU D
594 002116 001372          BNE     NEXPA1     ;ALL DONE?
595 002120 012706 001100          MOV     @STACK,SP  ;BR IF NOT
596 002124 012705 001126          MOV     @BDDAT,R5  ;ALWAYS RESET STACK
597 002130 013737 001202 001200    MOV     $UNIT,$DEVCT ;INIT R5 WITH $BDDAT
598 002136 106427 000340          MIPS   @PR7        ;LOAD APT COUNTER WITH UNIT NO.
599
600          ;SET PRIORITY TO 7
601
602          ;*****
603          ;*TEST 1 TEST THAT ALL REGISTERS ARE ADDRESSABLE
604          ;*****
605          TST1: SCOPE
606          CLR    $GDDAT ;NO DATA COMPARE
607          CLR    (R5)   ;NO DATA COMPARE
608          MOV    @2,$@ERRVEC ;SET UP TIMEOUT RETURN ADDR
609          MOV    DRCSA,R0 ;SET UP 1ST DRV11 BUS ADRS
610          MOV    @8,R1   ;SET UP REG COUNT
611          MOV    R0,$BDDADR ;SET UP CURRENT DRV BUS ADRS
612          CLR    (R0)    ;SEE IF THERE
613          TST    (R0)+   ;BUMP TO NEXT
614          DEC    R1      ;COUNT 8 OF THEM
615          BEQ    3$      ;BR IF ALL DONE

```

T1 TEST THAT ALL REGISTERS ARE ADDRESSABLE

```

613 002204 000771          BR      1$          ;TRY NEXT
614 002206 022626          2$:    CMP      (SP)+,(SP)+ ;FIX STACK SINCE NO RTI
615 002210 104001          ERROR+ 1          ;BUS ADRS INDICATED DID NOT RESPOND
616 002212 012737 000006 000004 3$:    MOV      @ERRVEC+2,@ERRVEC ;RESTORE LOC 4
617
618
;*****
;*TEST 2      TEST CSRA W/R DIR BIT,INT. CHIP RESET STATUS
;*****
TST2:  SCOPE
619 002220 000004          MOV      DRCSA,R0          ;GET CSR ADDRESS
620 002222 013700 001342          MOV      DRCSA,R1          ;STORE CSRC ADDRESS
621 002226 013701 001352          CLR      (R0)              ;INIT CSRA
622 002232 005010          CLR      (R1)              ;INIT CSRC
623 002234 005011          MOV      RO,$BDADR         ;STORE CSR ADDRESS
624 002236 010037 001122          ;SET UP EXPECTED DATA
625 002242 012737 100700 001124          MOV      @RDY!DIR!BIT7!BIT6,$GDDAT
626 002244 112760 000001 000001          MOVVB   @BIT0,1(R0)        ;SET DIRECTION BIT
627 002250 011015          MOV      (R0),(R5)         ;GET CSR DATA
628 002256 042715 000007          BIC     @7,(R5)            ;CLEAR UNDEFINED BITS
629 002260 023715 001124          CMP     $GDDAT,(R5)
630 002270 001401          BEQ     100$
631 002272 104002          ERROR+ 2                  ;CSRA ERROR
632 002274 010137 001122          MOV     R1,$BDADR          ;STORE CSRC ADDRESS
633 002300 012737 000200 001124          MOV     @BIT7,$GDDAT       ;STORE EXPECTED
634 002306 011115          MOV     (R1),(R5)          ;STORE CSRC
635 002310 042715 000007          BIC     @7,(R5)            ;CLEAR UNDEFINED BITS
636 002314 023715 001124          CMP     $GDDAT,(R5)
637 002320 001401          BEQ     1$
638 002322 104002          ERROR+ 2                  ;CSRC ERROR
639 002324 010037 001122          MOV     RO,$BDADR          ;CSRA ADDRESS
640 002330 012737 100300 001124          MOV     @RDY!BIT7!BIT6,$GDDAT
641 002336 105060 000001          CLR     1(R0)              ;CLEAR CSRA DIR BIT
642 002342 011015          MOV     (R0),(R5)          ;READ CSRA
643 002344 042715 000007          BIC     @7,(R5)            ;CLEAR UNDEFINED BITS
644 002350 023715 001124          CMP     $GDDAT,(R5)
645 002354 001401          BEQ     2$
646 002356 104002          ERROR+ 2                  ;BR IF EQUAL
647 002360 012737 000300 001124          MOV     @BIT7!BIT6,$GDDAT
648 002366 112761 000001 000001          MOVVB   @BIT0,1(R1)        ;CSRC TO OUTPUT MODE
649 002374 011015          MOV     (R0),(R5)          ;READ CSRA
650 002376 042715 000007          BIC     @7,(R5)            ;CLEAR UNDEFINED BITS
651 002402 023715 001124          CMP     $GDDAT,(R5)        ;CHECK IF RDY BIT CLEARED
652 002406 001401          BEQ     TST3              ;BR IF EQUAL
653 002410 104002          ERROR+ 2                  ;CSRA REG ERROR
654
655
;*****
;*TEST 3      TEST CSRA INT. ENABLE BIT
;*****
TST3:  SCOPE
656 002412 000004          JSR     PC,CLRCR           ;CLEAR CSR REGISTER
657 002414 004737 013164          MOV     DRCSA,R0          ;GET CSRA ADDRESS
658 002420 013700 001342          MOV     DRCSA,R1          ;GET CSRC ADDRESS
659 002424 013701 001352          MOVVB   @BIT0,1(R1)        ;SET DIRECTION BIT CSRC
660 002430 112761 000001 000001          MOV     RO,$BDADR         ;STORE CSRA ADDRESS
661 002436 010037 001122          MOV     @BIT9!BIT7!BIT6,$GDDAT
662 002442 012737 001300 001124          MOV     @IE,(R0)          ;SET INTERRUPT ENABLE BIT
663 002450 012710 001000          MOV     (R0),(R5)

```

T3 TEST CSRA INT. ENABLE BIT

```

664 002456 042715 000007      BIC    #7,(R5)          ;CLEAR UNDEFINED BITS
665 002462 023715 001124      CMP    $GDDAT,(R5)
666 002466 001401              BEQ    1$
667 002470 104002              ERROR+ 2                ;INT. ENABLE ERROR,CSRA
668 002472 012737 000300 001124 1$:  MOV    #BIT7!BIT6,$GDDAT
669 002500 105060 000001      CLR    1(R0)           ;CLEAR I/F BIT
670 002504 011015              MOV    (R0),(R5)
671 002506 042715 000007      BIC    #7,(R5)          ;CLEAR UNDEFINED BITS
672 002512 023715 001124      CMP    $GDDAT,(R5)
673 002516 001401              BEQ    TST4            ;;BR IF EQUAL
674 002520 104002              ERROR+ 2                ;CSRA ERROR
675
676

```

```

;*****
;*TEST 4      TEST CSRA I/E,DIR BIT
;*****

```

```

TST4:  SCOPE
677 002522 000004              JSR    PC,CLRCSR       ;CLEAR CSR REGISTERS
678 002524 004737 013164      MOV    DRCSA,R0        ;GET CSRA ADDRESS
679 002530 013700 001342      MOV    RO,#BDADR       ;SAVE CSRA ADDRESS
680 002534 010037 001122      MOV    #101700,$GDDAT ;EXPECTED I/E,DIR
681 002540 012737 101700 001124  MOV    #BIT1!BIT0,1(R0)
682 002546 112760 000003 000001      MOV    (R0),(R5)      ;SET I/E AND DIR BIT
683 002554 011015              BIC    #7,(R5)          ;CLEAR UNDEFINED BITS
684 002556 042715 000007      CMP    $GDDAT,(R5)
685 002562 023715 001124      BEQ    1$
686 002566 001401              ERROR+ 2                ;CSRA ERROR
687 002570 104002              MOV    #RDY!BIT7!BIT6,$GDDAT
688 002572 012737 100300 001124 1$:  CLR    (R0)
689 002600 005010              MOV    (R0),(R5)
690 002602 011015              BIC    #7,(R5)          ;CLEAR UNDEFINED BITS
691 002604 042715 000007      CMP    $GDDAT,(R5)
692 002610 023715 001124      BEQ    TST5            ;;BR IF EQUAL
693 002614 001401              ERROR+ 2                ;CSRA ERROR
694 002616 104002
695
696
697

```

```

;*****
;*TEST 5      TEST CSRB W/R DIR BIT,INT CHIP RESET STATUS
;*****

```

```

TST5:  SCOPE
698 002620 000004              JSR    PC,CLRCSR       ;CLEAR CSR REGISTERS
699 002622 004737 013164      MOV    DRCSB,R0        ;GET CSR ADDRESS
700 002626 013700 001346      MOV    DRCSB,R1        ;GET CSRD ADDRESS
701 002632 013701 001356      MOV    RO,#BDADR       ;STORE CSR ADDRESS
702 002636 010037 001122      MOV    #RDY!DIR,$GDDAT ;SET UP EXPECTED DATA
703 002642 012737 100400 001124  MOVE    #BIT0,1(R0)    ;SET DIRECTION BIT
704 002650 112760 000001 000001      MOV    (R0),(R5)      ;GET CSRB DATA
705 002656 011015              CMP    $GDDAT,(R5)
706 002660 023715 001124      BEQ    100$
707 002664 001401              ERROR+ 2                ;CSRB ERROR
708 002666 104002              MOV    R1,#BDADR       ;STORE CSRD ADDRESS
709 002670 010137 001122 100$:  CLR    $GDDAT          ;STORE EXPECTED
710 002674 005037 001124      MOV    (R1),(R5)      ;READ CSRD
711 002700 011115              CMP    $GDDAT,(R5)
712 002702 023715 001124      BEQ    1$
713 002706 001401              ERROR+ 2                ;CSRD ERROR
714 002710 104002              MOV    RO,#BDADR       ;STORE CSRB ADDRESS
715 002712 010037 001122 1$:

```

T5 TEST CSRB W/R DIR BIT,INT CHIP RESET STATUS

```

715 002716 C12737 100000 001124      MOV    #RDY,$GDDAT      ;STORE EXPECTED
716 002724 105060 000001              CLR    1(R0)           ;CLEAR CSR DIR BIT
717 002730 011015              MOV    (R0),(R5)       ;READ CSR
718 002732 023715 001124      CMP    $GDDAT,(R5)
719 002736 001401              BEQ    2$              ;BR IF EQUAL
720 002740 104002              ERROR+ 2
721 002742 005037 001124      CLR    $GDDAT          ;STORE EXPECTED
722 002746 112761 000001 000001 2$:  MOV    #BIT0,1(R1)     ;CSRD TO OUTPUT MODE
723 002754 011015              MOV    (R0),(R5)       ;READ CSRB
724 002756 023715 001124      CMP    $GDDAT,(R5)     ;RDY BIT CLEARED
725 002762 001401              BEQ    TST6            ;BR IF EQUAL
726 002764 104002              ERROR+ 2              ;CSRB REG ERROR
727
728

```

```

;*****
;*TEST 6      TEST CSRC W/R DIR BIT,INT CHIP RESET STATUS
;*****

```

```

002766 000004
729 002770 004737 013164      JSR    PC,CLRCSR       ;CLEAR CSR REGISTERS
730 002774 013700 001352      MOV    DRCSO,R0        ;GET CSR ADDRESS
731 003000 013701 001342      MOV    DRCSA,R1        ;GET CSRA ADDRESS
732 003004 010037 001122      MOV    R0,$BDADR       ;STORE CSR ADDRESS
733 003010 012737 100600 001124      MOV    #RDY!DIR!BIT7,$GDDAT
734 003016 112760 000001 000001      MOVE   #BIT0,1(R0)     ;SET DIRECTION BIT
735 003024 011015              MOV    (R0),(R5)       ;GET CSR DATA
736 003026 023715 000007      BIC    #7,(R5)         ;CLEAR UNDEFINED BITS
737 003032 023715 001124      CMP    $GDDAT,(R5)
738 003036 001401              BEQ    100$            ;CHECK CSRA
739 003040 104002              ERROR+ 2              ;CSRA ERROR
740 003042 010137 001122      MOV    R1,$BDADR       ;STORE CSR ADDRESS
741 003046 012737 000300 001124 100$:  MOV    #BIT7!BIT6,$GDDAT
742 003054 011115              MOV    (R1),(R5)       ;READ CSRA
743 003056 042715 000007      BIC    #7,(R5)         ;CLEAR UNDEFINED BITS
744 003062 023715 001124      CMP    $GDDAT,(R5)
745 003066 001401              BEQ    1$              ;CHECK CSRA
746 003070 104002              ERROR+ 2              ;CSRA ERROR
747 003072 010037 001122      MOV    R0,$BDADR       ;STORE CSR ADDRESS
748 003076 012737 100200 001124 1$:  MOV    #RDY!BIT7,$GDDAT ;STORE EXPECTED DATA
749 003104 105060 000001              CLR    1(R0)           ;CLEAR CSR DIR BIT
750 003110 011015              MOV    (R0),(R5)       ;READ CSR
751 003112 042715 000007      BIC    #7,(R5)         ;CLEAR UNDEFINED BITS
752 003116 023715 001124      CMP    $GDDAT,(R5)
753 003122 001401              BEQ    2$              ;BR IF EQUAL
754 003124 104002              ERROR+ 2
755 003126 012737 000200 001124 2$:  MOV    #BIT7,$GDDAT    ;EXPECTED DATA
756 003134 112761 000001 000001      MOV    #BIT0,1(R1)     ;CSRA TO OUTPUT MODE
757 003142 011015              MOV    (R0),(R5)       ;READ CSRC
758 003144 042715 000007      BIC    #7,(R5)         ;CLEAR UNDEFINED BITS
759 003150 023715 001124      CMP    $GDDAT,(R5)     ;RDY BIT CLEARED
760 003154 001401              BEQ    TST7            ;BR IF EQUAL
761 003156 104002              ERROR+ 2              ;CSRC REG ERROR
762
763

```

```

;*****
;*TEST 7      TEST CSRD W/R DIR BIT,INT CHIP RESET STATUS
;*****

```

```

003160 000004
764 003162 004737 013164      JSR    PC,CLRCSR       ;CLEAR CSR REGISTERS
765 003166 013700 001356      MOV    DRCSO,R0        ;GET CSR ADDRESS

```

T7 TEST CSRD W/R DIR BIT,INT CHIP RESET STATUS

```

766 003172 013701 001346      MOV      DRCSB,R1      ;CSRB ADDRESS
767 003176 010037 001122      MOV      R0,$BDADR    ;STORE CSRB ADDRESS
768 003202 012737 100400 001124  MOV      #RDY!DIR,$GDDAT ;SET UP EXPECTED DATA
769 003210 112760 000001 000001  MOVVB   #BIT0,1(R0)   ;SET DIRECTION BIT
770 003216 011015                MOV      (R0),(R5)    ;GET CSR DATA
771 003220 023715 001124      CMP      $GDDAT,(R5)
772 003224 011401                BEQ      100$
773 003226 104002                ERROR+  2
774 003230 010137 001122      100$:  MOV      R1,$BDADR    ;STORE CSRB ADDRESS
775 003234 005037 001124      CLR      $GDDAT      ;STORE EXPECTED
776 003240 011115                MOV      (R1),(R5)
777 003242 023715 001124      CMP      $GDDAT,(R5)
778 003246 001401                BEQ      1$
779 003250 104002                ERROR+  2      ;CSRB ERROR
780 003252 010037 001122      1$:   MOV      R0,$BDADR    ;STORE CSRD ADDRESS
781 003256 012737 100000 001124  MOV      #RDY,$GDDAT  ;STORE EXPECTED
782 003264 105060 000001      CLR      1(R0)       ;CLEAR CSR DIR BIT
783 003270 011015                MOV      (R0),(R5)   ;READ CSR
784 003272 023715 001124      CMP      $GDDAT,(R5)
785 003276 001401                BEQ      2$
786 003300 104002                ERROR+  2      ;;BR IF EQUAL
787 003302 005037 001124      2$:   CLR      $GDDAT      ;EXPECTED
788 003306 112761 000001 000001  MOVVB   #BIT0,1(R1)   ;CSRD TO OUTPUT MODE
789 003314 011015                MOV      (R0),(R5)   ;READ CSR
790 003316 023715 001124      CMP      $GDDAT,(R5) ;RDY BIT CLEARED
791 003322 001401                BEQ      TST10       ;;BR IF EQUAL
792 003324 104002                ERROR+  2      ;CSRD REG ERROR
793
794
;*****
;*TEST 10      TEST DBRA W/R IN OUTPUT MODE
;*****
TST10:  SCOPE
795 003330 004737 013164      JSR      PC,CLRCSR    ;CLEAR ALL CSRS
796 003334 012703 013272      MOV      #BEGPAT,R3  ;GET DATA PATTERN TABLE
797 003340 012737 003370 001110  MOV      #1$,$LPERR   ;SET UP SCOPE ADDRESS
798 003346 013700 001342      MOV      DRCSA,R0    ;GET CSRA
799 003352 013701 001344      MOV      DRDBA,R1    ;GET DBRA ADDRESS
800 003356 010137 001122      MOV      R1,$BDADR   ;STORE DBRA ADDRESS
801 003362 112750 000001 000001  MOVVB   #BIT0,1(R0)   ;SET CSRA IN OUTPUT MODE
802 003370 011337 001124      1$:   MOV      (R3),$GDDAT ;SAVE EXPECTED DATA
803 003374 005011                CLR      (R3)        ;CLEAR DBRA
804 003376 051311                BIS      (R3),(R1)   ;WRITE INTO DBRA
805 003400 011115                MOV      (R1),(R5)   ;READ DBRA
806 003402 023715 001124      CMP      $GDDAT,(R5) ;CHECK W/R DBRA
807 003406 001401                BEQ      2$
808 003410 104002                ERROR+  2      ;NEXT PAT. IF EQUAL
809 003412 005723                TST     (R3)+        ;DBRA W/R ERROR
810 003414 020327 013572      2$:   CMP      R3,#ENDDAT ;INC FOR NEXT PATTERN
811 003420 001363                BNE     1$          ;CHECK FOR END
812
813
;*****
;*TEST 11      TEST DBRB W/R IN OUTPUT MODE
;*****
TST11:  SCOPE
814 003424 004737 013164      JSR      PC,CLRCSR    ;CLEAR ALL CSRS
815 003430 012703 013272      MOV      #BEGPAT,R3  ;GET DATA PATTERN TABLE
816 003434 012737 003464 001110  MOV      #1$,$LPERR   ;SET UP SCOPE ADDRESS

```


T11 TEST DBRB W/R IN OUTPUT MODE

```

817 003442 013700 001346      MOV      DRC5B,R0      ;GET CSRB
818 003446 013701 001350      MOV      DRDBB,R1     ;GET DBRB ADDRESS
819 003452 010137 001122      MOV      R1,$BDADP   ;STORE DBRB ADDRESS
820 003456 112760 0000C1 000001  MOVVB   #BIT0,1(R0)   ;SET CSRB IN OUTPUT MODE
821 003464 011337 001124      MOV      (R3),$GDDAT  ;SAVE EXPECTED DATA
822 003470 005011      CLR      (R1)        ;CLEAR DBRB
823 003472 051711      BIS      (R3),(R1)   ;WRITE INTO DBRB
824 003474 011115      MOV      (R1),(R5)   ;READ DBRB
825 003476 023715 001124      CMP     $GDDAT,(R5)  ;CHECK W/R DBRB
826 003502 001401      BEQ     2$          ;NEXT PAT. IF EQUAL
827 003504 104002      ERROR+  2          ;DBRB W/R ERROR
828 003506 005723      TST     (R3)+       ;INC FOR NEXT PATTERN
829 003510 020327 013572      CMP     R3,#ENDDAT  ;CHECK FOR END
830 003514 001363      BNE     1$          ;DO NEXT PATTERN
831
832
833

```

```

;*****
;+TEST 12 TEST DBRC W/R IN OUTPUT MODE
;*****

```

```

003516 000000
834 003520 004737 013164      TST12: SCOPE
835 003524 012703 013272      JSR     PC,CLRC5R   ;CLEAR ALL CSRS
836 003530 012737 005560 001110  MOV     #BEGPAT,R3  ;GET DATA PATTERN TABLE
837 003536 013700 001352      MOV     #1,$LPERR  ;SET UP SCOPE ADDRESS
838 003542 013701 001354      MOV     DRC5C,R0   ;GET CSRC
839 003546 010137 001122      MOV     DRDBC,R1   ;GET DBRC ADDRESS
840 003552 112760 000001 000001  MOV     R1,$BDADR  ;STORE DBRC ADDRESS
841 003560 011337 001124      MOVVB   #BIT0,1(R0) ;SET CSRC IN OUTPUT MODE
842 003564 005011      MOV     (R3),$GDDAT ;SAVE EXPECTED DATA
843 003566 051311      CLR     (R1)       ;CLEAR DBRC
844 003570 011115      BIS     (R3),(R1)  ;WRITE INTO DBRC
845 003572 023715 001124      MOV     (R1),(R5)  ;READ DBRC
846 003576 001401      CMP     $GDDAT,(R5) ;CHECK W/R DBRC
847 003600 104002      BEQ     2$          ;NEXT PAT. IF EQUAL
848 003602 005723      ERROR+  2          ;DBRC W/R ERROR
849 003604 020327 013572      TST     (R3)+       ;INC FOR NEXT PATTERN
850 003610 001363      CMP     R3,#ENDDAT ;CHECK FOR END
851
852
853

```

```

;*****
;+TEST 13 TEST DBRD W/R IN OUTPUT MODE
;*****

```

```

003612 000004
854 003614 004737 013164      TST13: SCOPE
855 003620 012703 013272      JSR     PC,CLRC5R   ;CLEAR ALL CSRS
856 003624 012737 003654 001110  MOV     #BEGPAT,R3  ;GET DATA PATTERN TABLE
857 003632 013700 001356      MOV     #1,$LPERR  ;SET UP SCOPE ADDRESS
858 003636 013701 001360      MOV     DRC5D,R0   ;GET CSRD
859 003642 010137 001122      MOV     DRDBD,R1   ;GET DBRD ADDRESS
860 003646 112760 000001 000001  MOV     R1,$BDADR  ;STORE DBRD ADDRESS
861 003654 011337 001124      MOVVB   #BIT0,1(R0) ;SET CSRD IN OUTPUT MODE
862 003660 005011      MOV     (R3),$GDDAT ;SAVE EXPECTED DATA
863 003662 051311      CLR     (R1)       ;CLEAR DBRD
864 003664 011115      BIS     (R3),(R1)  ;WRITE INTO DBRD
865 003666 023715 001124      MOV     (R1),(R5)  ;READ DBRD
866 003672 001401      CMP     $GDDAT,(R5) ;CHECK W/R DBRD
867 003674 104002      BEQ     2$          ;NEXT PAT. IF EQUAL
      ERROR+  2          ;DBRD W/R ERROR

```

N

T13 TEST DBRD W/R IN OUTPUT MODE

```
868 003000 005723          2$:   TST   (R3)+      ;INC FOR NEXT PATTERN
869 003700 020327 013572   CMP   R3,#ENDDAT ;CHECK FOR END
870 003704 001363          BNE   1$         ;DO NEXT PATTERN
```

134

T13 TEST DBRD W/R IN OUTPUT MODE

872
873
874

003706 000004
875 003710 004737 013164
876
877
878
879
880 003714 112760 000003 000001
881 003722 112763 000001 000001
882 003730 010037 001122
883 003734 012737 101700 001124
884 003742 011015
885 003744 042715 000007
886 003750 023715 001124
887 003754 001401
888 003756 104002
889 003760 010137 001122
890 003764 005037 001124
891 003770 011115
892 003772 023715 001124
893 003776 001401
894 004000 104002
895 004002 010337 001122
896 004006 012737 100400 001124
897 004014 011315
898 004016 023715 001124
899 004022 001401
900 004024 104002
901 004026 010237 001122
902 004032 012737 000200 001124
903 004040 011215
904 004042 042715 000007
905 004046 023715 001124
906 004052 001401
907 004054 104002
908
909

```

;*****
;+TEST 14 TEST CSR UNIQUENESS,CSRS (A-B),(C-D)
;*****
TST14: SCOPE
      JSR PC,CLRCSR ;CLEAR ALL CSRS
                        ;CSRA = R0
                        ;CSRB = R1
                        ;CSRC = R2
                        ;CSRD = R3
      MOVB #3,1(R0) ;CSRA OUTPUT MODE,I/E
      MOVB #BIT0,1(R3) ;CSRD OUTPUT MODE
      MOV RO,#BDADR
      MOV #101700,#GDDAT ;EXPECTED DATA
      MOV (R0),(R5)
      BIC #7,(R5) ;CLEAR UNDEFINED BITS
      CMP #GDDAT,(R5)
      BEQ 1$
      ERROR# 2 ;CSRA ERROR
1$: MOV R1,#BDADR ;CHECK CSRB
      CLR #GDDAT
      MOV (R1),(R5)
      CMP #GDDAT,(R5)
      BEQ 2$
      ERROR# 2 ;CSRB ERROR
2$: MOV R3,#BDADR
      MOV #100400,#GDDAT
      MOV (R3),(R5)
      CMP #GDDAT,(R5)
      BEQ 3$
      ERROR# 2 ;CSRD ERROR
3$: MOV R2,#BDADR ;CHECK CSRC
      MOV #BIT7,#GDDAT ;EXPECTED
      MOV (R2),(R5)
      BIC #7,(R5)
      CMP #GDDAT,(R5)
      BEQ TST15 ;BR IF EQUAL
      ERROR# 2 ;CSRC ERROR

```

004056 000004
910 004060 004737 013164
911
912
913
914
915 004064 112760 000003 000001
916 004072 112761 000001 000001
917 004100 010037 001122
918 004104 012737 101700 001124
919 004112 011015
920 004114 042715 000007
921 004120 023715 001124
922 004124 001400

```

;*****
;+TEST 15 TEST CSR UNIQUENESS,CSRS (A-D),(C-B)
;*****
TST15: SCOPE
      JSR PC,CLRCSR ;CLR ALL CSRS
                        ;CSRA = R0
                        ;CSRB = R1
                        ;CSRC = R2
                        ;CSRD = R3
      MOVB #3,1(R0) ;CSRA OUTPUT,I/E
      MOVB #BIT0,1(R1) ;CSRB OUTPUT MODE
      MOV RO,#BDADR ;CSRA ADDRESS
      MOV #101700,#GDDAT
      MOV (R0),(R5)
      BIC #7,(R5) ;CLEAR UNDEFINED BITS
      CMP #GDDAT,(R5)
      BEQ 1$

```

T15 TEST CSR UNIQUENESS, CSRS (A D),(C B)

```

923 004126 010137 001122 1$: MOV R1,$BDADR ;CHECK CSRB
924 004132 012737 100400 001124 MOV $100400,$GDDAT
925 004140 011115 MOV (R1),(R5)
926 004142 023715 001124 CMP $GDDAT,(R5)
927 004146 001401 BEQ 2$
928 004150 104002 ERROR+ 2 ;CSRB ERROR
929 004152 010237 001122 2$: MOV R2,$BDADR ;CHECK CSRC
930 004156 012737 000200 001124 MOV $BIT7,$GDDAT
931 004164 011215 MOV (R2),(R5)
932 004166 042715 000007 BIC $7,(R5)
933 004172 023715 001124 CMP $GDDAT,(R5)
934 004176 001401 BEQ 3$
935 004200 104002 ERROR+ 2 ;CSRC ERROR
936 004202 010337 001122 3$: MOV R3,$BDADR
937 004206 005037 001124 CLR $GDDAT
938 004212 011315 MOV (R3),(R5)
939 004214 023715 001124 CMP $GDDAT,(R5)
940 004220 001401 BEQ TST16 ;BR IF EQUAL
941 004222 104002 ERROR+ 2 ;CSRB ERROR
942
943
944

```

```

;*****
;+TEST 16 TEST PORT A TO PORT C INTERACTION
;*****

```

```

004224 000004
945 004226 004737 013164
946 004232 012703 013272
947 004236 012737 004266 001110
948 004244 013700 001342
949 004250 013701 001352
950 004254 013702 001346
951 004260 112762 000001 000001
952 004266 010037 001122 1$: MOVB $BIT0,1(R2) ;CSRB IN OUTPUT MODE
953 004272 005062 000002 MOV R0,$BDADR ;STORE CSRA ADDRESS
954 004276 105061 000001 CLR 2(R2) ;CLEAR DBWB
955 004302 112760 000001 000001 CLRB 1(R1) ;PORT C,CSRC,INPUT MODE
956 004310 011360 000002 MOVB $BIT0,1(R0) ;SET CSRA IN OUTPUT MODE
957 004314 016104 000002 MOV (R3),2(R0) ;WRITE INTO DBRA
958 004320 012737 100700 001124 MOV 2(R1),R4 ;READ DBRC
959 MOV $RDY!DIR!BIT7!BIT6,$GDDAT ;CSRA DIR SHOULD STAY SET
960 004326 011015 MOV (R0),(R5) ;READ CSRA
961 004330 042715 000007 BIC $7,(R5) ;CLEAR UNDEFINED BITS
962 004334 023715 001124 CMP $GDDAT,(R5)
963 004340 001401 BEQ 100$
964 004342 104002 ERROR+ 2 ;CSRA ERROR
965 004344 012737 000200 001124 100$: MOV $BIT7,$GDDAT
966 004352 010137 001122 MOV R1,$BDADR ;CSRC ADDRESS
967 004356 011115 MOV (R1),(R5) ;READ CSRC
968 004360 042715 000007 BIC $7,(R5) ;CLEAR UNDEFINED BITS
969 004364 023715 001124 CMP $GDDAT,(R5)
970 004370 001401 BEQ 101$
971 004372 104002 ERROR+ 2 ;CSRC ERROR
972 004374 013737 001354 001122 101$: MOV DRDBC,$BDADR ;STORE DBRC ADDRESS
973 004402 011337 001124 MOV (R3),$GDDAT ;SAVE EXPECTED
974 004406 010415 MOV R4,(R5) ;DBRC CONTENTS
975 004410 023715 001124 CMP $GDDAT,(R5) ;CHECK PORT C,DBRC
976 004414 001401 BEQ 2$ ;BEQ TO NEXT SUBTEST

```

T16 TEST PORT A TO PORT C INTERACTION

```

977 004416 104002          ERROR+ 2          ;DBRC REG ERROR
978 004420 005137 001124 2$: COM $GDDAT ;SET UP TO WRITE COM DATA FROM
979                                     ;PORT C TO PORT A
980 004424 013737 001344 001122 MOV DRDBA,$BDADR ;STORE DBRA ADDRESS
981 004432 013761 001124 000002 3$: MOV $GDDAT,2(R1) ;WRITE PORT C,INPUT MODE
982 004440 105060 000001 CLR RB 1(R0) ;MAKE PORT A INPUT MODE
983 004444 112761 000001 000001 MOV B $BIT0,1(R1) ;MAKE PORT C OUTPUT MODE
984 004452 016015 000002 MOV 2(R0),(R5) ;READ PORT A,DBRA
985 004456 023715 001124 CMP $GDDAT,(R5) ;PORT A =PORT C?
986 004462 001401 BEQ 4$ ;CHECK DBRB FOR NO DATA CHANGE
987 004464 104002          ERROR+ 2          ;PORT A,DBRA REG ERROR
988 004466 013737 001350 001122 4$: MOV DRDBB,$BDADR ;STORE DBRB ADDRESS
989 004474 005037 001124 CLR $GDDAT ;CONTENTS SHOULD STAY ZERO
990 004500 016215 000002 MOV 2(R2),(R5) ;READ DBRB FOR CLEAR
991 004504 023715 001124 CMP $GDDAT,(R5) ;CHECK FOR DBRB CLEAR
992 004510 001401 BEQ 5$ ;YES,CONTINUE
993 004512 104002          ERROR+ 2          ;DBRB INTERACTION ERROR
994 004514 005723 5$: TST (R3)+ ;INC FOR NEXT PATTERN
995 004516 020327 013572 CMP R3,$ENDDAT ;CHECK FOR END
996 004522 001261 BNE 1$ ;DO NEXT PATTERN
997
998
999

```

; *TEST 17 TEST PORT B TO PORT D INTERACTION
;*****

```

004524 000004
1000 004526 004737 013164          TST17: SCOPE
1001 004532 012703 013272          JSR PC,CLRC SR ;CLEAR ALL CSRS
1002 004536 012737 004566 001110 MOV $BEGPAT,R3 ;GET DATA PATTERN TABLE
1003 004544 013700 001346          MOV $1,$LPERR ;SET UP SCOPE ADDRESS
1004 004550 013701 001356          MOV DRCSB,R0 ;GET PORT B, CSRB ADDRESS
1005 004554 013702 001342          MOV DRCSA,R2 ;GET PORT D, CSRD ADDRESS
1006 004560 112762 000001 000001 MOV B $BIT0,1(R2) ;STORE CSRA ADDRESS
1007 004566 010037 001122 1$: MOV R0,$BDADR ;CSRA IN OUTPUT MODE
1008 004572 005062 000002          CLR 2(R2) ;STORE CSRB ADDRESS
1009 004576 105061 000001          CLR RB 1(R1) ;CLEAR DBRA
1010 004602 112760 000001 000001 MOV B $BIT0,1(R0) ;PORT D,CSRD,INPUT MODE
1011 004610 011360 000002          MOV (R3),2(R0) ;SET CSRB IN OUTPUT MODE
1012 004614 016104 000002          MOV 2(R1),R4 ;WRITE INTO DBRB
1013 004620 012737 100400 001124 MOV $RDY!DIR,$GDDAT ;DBRD CONTENTS
1014 004626 011015          MOV (R0),(R5) ;SAVE EXPECTED
1015 004630 023715 001124 CMP $GDDAT,(R5) ;READ CSRB
1016 004634 001401 BEQ 100$
1017 004636 104002          ERROR+ 2          ;CSRB ERROR
1018 004640 005037 001124 100$: CLR $GDDAT ;SAVE EXPECTED
1019 004644 010137 001122 MOV R1,$BDADR ;SAVE CSRD ADDRESS
1020 004650 011115          MOV (R1),(R5)
1021 004652 023715 001124 CMP $GDDAT,(R5)
1022 004656 001401 BEQ 101$
1023 004660 104002          ERROR+ 2          ;CSRD ERROR
1024 004662 013737 001360 001122 101$: MOV DRDBD,$BDADR ;SAVE DBRD ADDRESS
1025 004670 011337 001124 MOV (R3),$GDDAT ;SAVE EXPECTED
1026 004674 010415          MOV R4,(R5) ;DBRD CONTENTS
1027 004676 023715 001124 CMP $GDDAT,(R5) ;CHECK PORT D,DBRD
1028 004702 001401 BEQ 2$ ;BEQ TO NEXT SUBTEST
1029 004704 104002          ERROR+ 2          ;DBRD REG ERROR
1030 004706 005137 001124 2$: COM $GDDAT ;SET UP TO WRITE COM DATA FROM

```

T17 TEST PORT B TO PORT D INTERACTION

```

1031
1032 004712 013737 001350 001122      MOV      DRDBB,$BDADR      ;PORT D TO PORT B
1033 004720 013761 001124 000002 3$:  MOV      $GDDAT,2(R1)     ;STORE DBRB ADDRESS
1034 004726 105060 000001              CLRB     1(R0)            ;WRITE PORT D,INPUT MODE
1035 004732 112761 000001 000001      MOVVB   #BIT0,1(R1)      ;MAKE PORT B INPUT MODE
1036 004740 016015 000002              MOV      2(R0),(R5)      ;MAKE PORT D OUTPUT MODE
1037 004744 023715 001124              MOV      $GDDAT,(R5)    ;READ PORT B,DBRB
1038 004750 001401              CMP      $GDDAT,(R5)    ;PORT B =PORT D?
1039 004752 104002              BEQ     4$              ;CHECK DBRA FOR NO DATA CHANGE
1040 004754 013737 001344 001122 4$:  ERROR+  2              ;PORT B,DBRB REG ERROR
1041 004762 005037 001124              MOV      DRDBA,$BDADR   ;STORE DBRA ADDRESS
1042 004766 016215 000002              CLR     $GDDAT          ;CONTENTS = 0
1043 004772 023715 001124              MOV      2(R2),(R5)     ;READ DBRA FOR CLEAR
1044 004776 001401              CMP      $GDDAT,(R5)   ;DBRA CLEAR?
1045 005000 104002              BEQ     5$              ;YES,CONTINUE
1046 005002 005723              ERROR+  2              ;DBRA INTERACTION ERROR
1047 005004 020327 013572 5$:  TST     (R3)+           ;INC FOR NEXT PATTERN
1048 005010 001266              CMP      R3,#ENDDAT    ;CHECK FOR END
1049
1050
1051 BNE     1$              ;DO NEXT PATTERN

```

```

;*****
;*TEST 20 TEST PORT C TO PORT A INTERACTION
;*****

```

```

1052 005012 000004
1053 005014 004737 013164
1054 005020 012703 013272
1055 005024 012737 005054 001110
1056 005032 013700 001352
1057 005036 013701 001342
1058 005042 013702 001356
1059 005046 112762 000001 000001
1060 005054 010037 001122 1$:  MOVVB   #BIT0,1(R2)    ;CSRD IN OUTPUT MODE
1061 005060 005062 000002              MOV      R0,$BDADR     ;STORE CSRC ADDRESS
1062 005064 105061 000001              CLR     2(R2)          ;CLEAR DBRD
1063 005070 112760 000001 000001      CLRB     1(R1)         ;PORT A,CSRA,INPUT MODE
1064 005076 011360 000002              MOVVB   #BIT0,1(R0)   ;SET CSRC IN OUTPUT MODE
1065 005102 016104 000002              MOV      (R3),2(R0)   ;WRITE INTO DBRC
1066 005106 012737 100600 001124      MOV      2(R1),R4     ;READ DBRA
1067 005114 011015              MOV      #RDY!DIR!BIT7,$GDDAT ;CSRC DIR SHOULD BE SET
1068 005116 042715 000007              (R0),(R5)            ;READ CSRC
1069 005122 023715 001124              BIC     #7,(R5)       ;CLEAR UNDEFINED BITS
1070 005126 001401              CMP      $GDDAT,(R5)
1071 005130 104002              BEQ     100$          ;CSRC ERROR
1072 005132 012737 000300 001124 100$: ERROR+  2              ;CSRC ERROR
1073 005140 010137 001122              MOV      #BIT7!BIT6,$GDDAT
1074 005144 011115              MOV      R1,$BDADR    ;CSRA ADDRESS
1075 005146 042715 000007              MOV      (R1),(R5)    ;READ CSRA
1076 005152 023715 001124              BIC     #7,(R5)       ;CLEAR UNDEFINED BITS
1077 005156 001401              CMP      $GDDAT,(R5)
1078 005160 104002              BEQ     101$          ;CSRA ERROR
1079 005162 013737 001344 001122 101$: ERROR+  2              ;CSRA ERROR
1080 005170 011337 001124              MOV      DRDBA,$BDADR ;STORE DBRA ADDRESS
1081 005174 010415              MOV      (R3),$GDDAT  ;SAVE EXPECTED
1082 005176 023715 001124              MOV      R4,(R5)     ;DBRA CONTENTS
1083 005202 001401              CMP      $GDDAT,(R5) ;CHECK PORT A,DBRA
1084 005204 104002              BEQ     2$              ;BEQ TO NEXT SUBTEST
                          ERROR+  2              ;DBRA REG ERROR

```

T20 TEST PORT C TO PORT A INTERACTION

```

1085 005206 005137 001124      2$:  COM      $GDDAT      ;SET UP TO WRITE COM DATA FROM
1086                                     ;PORT A TO PORT C
1087 005212 013737 001354 001122      MOV      DRDBC,$BDADR ;STORE DBRC ADDRESS
1088 005220 013761 001124 000002 3$:  MOV      $GDDAT,2(R1) ;WRITE PORT A,INPUT MODE
1089 005226 105060 000001                                     CLR      1(R0)          ;MAKE PORT C INPUT MODE
1090 005232 112761 000001 000001      MOV      @BIT0,1(R1)   ;MAKE PORT A OUTPUT MODE
1091 005240 016015 000002                                     MOV      2(R0),(R5)    ;READ PORT C,DBRC
1092 005244 023715 001124                                     CMP      $GDDAT,(R5)   ;PORT C =PORT A?
1093 005250 001401                                     BEQ      4$            ;CHECK DBRD FOR NO DATA CHANGE
1094 005252 104002                                     ERROR+  2              ;PORT C,DBRC REG ERROR
1095 005254 013737 001360 001122 4$:  MOV      DRDBD,$BDADR ;STORE DBRD ADDRESS
1096 005262 005037 001124                                     CLR      $GDDAT        ;DBRD = 0 EXPECTED
1097 005266 016215 000002                                     MOV      2(R2),(R5)    ;READ DBRD FOR CLEAR
1098 005272 023715 001124                                     CMP      $GDDAT,(R5)   ;IS DBRD CLEAR?
1099 005276 001401                                     BEQ      5$            ;YES,CONTINUE
1100 005300 104002                                     ERROR+  2              ;DBRD INTERACTION ERROR
1101 005302 005723                                     TST      (R3)+         ;INC FOR NEXT PATTERN
1102 005304 020327 013572                                     CMP      R3,@ENDDAT    ;CHECK FOR END
1103 005310 001261                                     BNE     1$            ;DO NEXT PATTERN
1104
1105

```

; *TEST 21 TEST PORT D TO PORT B INTERACTION
; *****

```

005312 000004
1106 005314 004737 013164      TST21: SCOPE
1107 005320 012703 013272      JSR      PC,CLRCR      ;CLEAR ALL CSRS
1108 005324 012737 005354 001110      MOV      @BEGPAT,R3   ;GET DATA PATTERN TABLE
1109 005332 013700 001354                                     MOV      @1$, $LPERR  ;SET UP SCOPE ADDRESS
1110 005336 013701 001346                                     MOV      DRCS0,R0     ;GET PORT D, CSRD ADDRESS
1111 005342 013702 001352                                     MOV      DRCSB,R1     ;GET PORT B, CSRB ADDRESS
1112 005346 112762 000001 000001      MOV      DRCS0,R2     ;STORE CSRD ADDRESS
1113 005354 010037 001122      MOV      @BIT0,1(R2)   ;CSRD IN OUTPUT MODE
1114 005360 005062 000002      1$:  MOV      R0,$BDADR    ;STORE CSRD ADDRESS
1115 005364 105061 000001                                     CLR      2(R2)        ;CLEAR DBRC
1116 005370 112760 000001 000001      CLR      1(R1)        ;PORT B,CSRB,INPUT MODE
1117 005376 011360 000002                                     MOV      @BIT0,1(R0)  ;SET CSRD IN OUTPUT MODE
1118 005402 016104 000002                                     MOV      (R3),2(R0)   ;WRITE INTO DBRD
1119 005406 012737 100400 001124      MOV      2(R1),R4     ;READ DBRB
1120 005414 011015                                     MOV      @RDY!DIR,$GDDAT ;SAVE EXPECTED
1121 005416 023715 001124                                     MOV      (R0),(R5)    ;READ CSRD
1122 005422 001401                                     CMP      $GDDAT,(R5)
1123 005424 104002                                     BEQ      100$         ;CHECK DBRD
1124 005426 005037 001124      100$: CLR      $GDDAT     ;CSRD ERROR
1125 005432 010137 001122      MOV      R1,$BDADR    ;SAVE EXPECTED
1126 005436 011115                                     MOV      (R1),(R5)    ;SAVE CSRB ADDRESS
1127 005440 023715 001124      CMP      $GDDAT,(R5)
1128 005444 001401                                     BEQ      101$         ;CHECK CSRB
1129 005446 104002                                     ERROR+  2              ;CSRB ERROR
1130 005450 013737 001350 001122 101$: MOV      DRDBB,$BDADR ;SAVE DBRB ADDRESS
1131 005456 011337 001124      MOV      (R3),$GDDAT ;SAVE EXPECTED
1132 005462 010415                                     MOV      R4,(R5)     ;DBRB CONTENTS
1133 005464 023715 001124      CMP      $GDDAT,(R5) ;CHECK PORT B,DBRB
1134 005470 001401                                     BEQ      2$            ;BEQ TO NEXT SUBTEST
1135 005472 104002                                     ERROR+  2              ;DBRB REG ERROR
1136 005474 005137 001124      2$:  COM      $GDDAT   ;SET UP TO WRITE COM DATA FROM
1137                                     ;PORT B TO PORT D
1138 005500 013737 001360 001122      MOV      DRDBD,$BDADR ;STORE DBRD ADDRESS

```

(63)

T21 TEST PORT D TO PORT B INTERACTION

```

1139 005506 013761 001124 000002 3$: MOV $GDDAT,2(R1) ;WRITE PORT B,INPUT MODE
1140 005514 105060 000001 CLR 1(R0) ;MAKE PORT D INPUT MODE
1141 005520 112761 000001 000001 MOVB #BITC,1(R1) ;MAKE PORT B OUTPUT MODE
1142 005526 016015 000002 MOV 2(R0),(R5) ;READ PORT D,DBRD
1143 005532 023715 001124 CMP $GDDAT,(R5) ;PORT B =PORT D?
1144 005536 001401 BEQ 4$ ;CHECK DBRC FOR NO DATA CHANGE
1145 005540 104002 ERROR+ 2 ;PORT D,DBRD REG ERROR
1146 005542 013737 001354 001122 4$: MOV DRDBC,$BDADR ;STORE DBRC ADDRESS
1147 005550 005037 001124 CLR $GDDAT ;EXPECT DBRC = 0
1148 005554 016215 000002 MOV 2(R2),(R5) ;READ DBRC
1149 005560 023715 001124 CMP $GDDAT,(R5) ;IS DBRC = 0
1150 005564 001401 BEQ 5$ ;YES,CONTINUE
1151 005566 104002 ERROR+ 2 ;DBRC INTERACTION ERROR
1152 005570 005723 5$: TST (R3)+ ;INC FOR NEXT PATTERN
1153 005572 020327 013572 CMP R3,#ENDDAT ;CHECK FOR END
1154 005576 001266 BNE 1$ ;DO NEXT PATTERN
1155
1156

```

```

;*****
;+TEST 22 TEST GROUP 1,2 IMR,IRR,ACR WITH CHIP RESET
;*****

```

```

005600 000004
1157 005602 004737 013164 TST22: SCOPE
1158 005606 012702 000002 JSR PC,CLRCR ;CLEAR ALL CSRS
1159 005612 013700 001342 MOV #2,R2 ;TWO GROUPS TO TEST
1160 005616 013701 001346 MOV DRCSA,R0 ;STORE CSRA
1161 005622 004737 013234 MOV DRCSB,R1 ;STORE CSRB
1162 005626 010137 001122 JSR PC,CLRIRR ;CLEAR IRR REGISTERS
1163 005632 012737 000377 001124 111$: MOV R1,$BDADR ;STORE ADDRESS
1164 005640 112710 000244 MOVB #377,$GDDAT ;STORE EXPECTED DATA
1165 005644 111115 MOVB (R1),(R5) ;LOAD MODE BITS FOR IMR
1166 005646 023715 001124 CMP $GDDAT,(R5) ;READ IMR REGISTER
1167 005652 001401 BEQ 1$
1168 005654 104005 ERROR+ 5 ;IMR REG ERROR
1169 005656 005037 001124 1$: CLR $GDDAT ;STORE EXPECTED
1170 005662 112710 000250 MOVB #MIRR,(R0) ;LOAD MODE BITS FOR IRR
1171 005666 111115 MOVB (R1),(R5) ;READ IRR REGISTER
1172 005670 023715 001124 CMP $GDDAT,(R5)
1173 005674 001401 BEQ 2$
1174 005676 104003 ERROR+ 3 ;IRR REG ERROR
1175 005700 112710 000254 2$: MOVB #MACR,(R0) ;LOAD MODE BITS FOR ACR
1176 005704 111115 MOVB (R1),(R5) ;READ ACR REGISTER
1177 005706 023715 001124 CMP $GDDAT,(R5)
1178 005712 001401 BEQ 3$
1179 005714 104004 ERROR+ 4 ;ACR REG ERROR
1180 005716 005302 3$: DEC R2 ;FINISHED BOTH GROUPS?
1181 005720 001405 BEQ TST23 ;IF EQUAL
1182 005722 013700 001352 MOV DRCSA,R0
1183 005726 013701 001356 MOV DRCSB,R1
1184 005732 000735 BR 111$
1185
1186

```

```

;*****
;+TEST 23 TEST GROUPS 1 AND 2 ACR UNIQUENESS
;*****

```

```

005734 000004
1187 005736 004737 013164 TST23: SCOPE
1188 005742 013700 001342 JSR PC,CLRCR ;CLEAR ALL CSRS
1189 005746 013701 001346 MOV DRCSA,R0 ;CSRA ADDRESS
MOV DRCSB,R1 ;CSRB ADDRESS

```


14

T23 TEST GROUPS 1 AND 2 ACR UNIQUENESS

```

1190 005752 012703 000002      MOV      #2,R3          ;COUNTER FOR TESTING TWO GROUPS
1191 005756 004737 013234      JSR      PC,CLRIRR     ;CLEAR IRR REGS WITH CHIP RESET
1192 005762 010137 001122      MOV      R1,$BDADR    ;STORE ADDRESS
1193 005766 012737 000252      MOV      #252,$GDDAT  ;STORE EXPECTED
1194 005774 112710 000254      MOV      #MACR,(R0)   ;LOAD MODE BITS FOR ACR
1195 006000 112710 000300      MOV      #PACR,(R0)   ;PRESELECT ACR FOR WRITING
1196 006004 113711 001124      MOV      $GDDAT,(R1)  ;WRITE INTO DATA PORT
1197 006010 111115                MOV      (R1),(R5)    ;STORE DATA FOR COMPARE
1198 006012 023715 001124      CMP      $GDDAT,(R5)  ;CHECK ACR RESULTS
1199 006016 001401                BEQ      1$           ;
1200 006020 104004                ERROR+  4             ;ACR ERROR
1201 006022 112710 000244      MOV      #MIMR,(R0)  ;CHANGE TO IMR REGISTER
1202 006026 012737 000377      MOV      #377,$GDDAT ;STORE EXPECTED
1203 006034 111115                MOV      (R1),(R5)   ;READ IMR
1204 006036 023715 001124      CMP      $GDDAT,(R5) ;SHOULD STILL BE ALL 1'S
1205 006042 001401                BEQ      2$           ;
1206 006044 104005                ERROR+  5             ;IMR REG ERROR
1207 006046 112710 000240      MOV      #MISR,(R0)  ;LOAD MODE BITS FOR ISR
1208 006052 005037 001124      CLR      $GDDAT      ;STORE EXPECTED
1209 006056 111115                MOV      (R1),(R5)   ;READ ISR
1210 006060 023715 001124      CMP      $GDDAT,(R5) ;ISR SHOULD BE CLEARED
1211 006064 001401                BEQ      3$           ;
1212 006066 104006                ERROR+  6             ;ISR REG ERROR
1213 006070 112710 000250      MOV      #MIRR,(R0)  ;LOAD MODE BITS FOR IRR
1214 006074 111115                MOV      (R1),(R5)   ;READ IRR
1215 006076 023715 001124      CMP      $GDDAT,(R5) ;IRR SHOULD BE CLEARED
1216 006102 001401                BEQ      4$           ;
1217 006104 104003                ERROR+  3             ;IRR REG ERROR
1218 006106 105010                CLR      (R0)        ;CHIP RESET GROUP 1
1219 006110 112710 000254      MOV      #MACR,(R0)  ;LOAD MODE BITS FOR ACR
1220 006114 111115                MOV      (R1),(R5)   ;READ ACR
1221 006116 023715 001124      CMP      $GDDAT,(R5) ;ACR SHOULD BE CLEARED
1222 006122 001401                BEQ      5$           ;
1223 006124 104004                ERROR+  4             ;ACR REG ERROR
1224 006126 005303                DEC      R3          ;TEST GROUPS 1 AND 2
1225 006130 001405                BEQ      TST24       ;BR IF BOTH GROUPS TESTED
1226 006132 013700 001352      MOV      DRCSA,R0    ;GROUP 2 CONTROL PORT
1227 006136 013701 001356      MOV      DRCSB,R1    ;GROUP 2 DATA PORT
1228 006142 000707                BR      111$         ;TEST GROUP 2 ACR UNIQUENESS
1229
1230

```

```

;*****
;+TEST 24 TEST GROUPS 1 AND 2 IMR UNIQUENESS
;*****

```

```

006144 000004
1231
1232 006146 004737 013234      JSR      PC,CLRCSR   ;CLEAR ALL CSRS
1233 006152 013700 001342      JSR      PC,CLRIRR   ; *** VDRCA1 CHANGES THIS *** ;GPA
1234 006156 013701 001346      MOV      DRCSA,R0    ;CSRA ADDRESS
1235 006162 012703 000002      MOV      DRCSB,R1    ;CSRB ADDRESS
1236 006166 010137 001122      MOV      #2,R3      ;COUNTER FOR TWO GROUP TESTING
1237 006172 012737 000252      MOV      R1,$BDADR  ;STORE ADDRESS
1238 006200 112710 000244      MOV      #252,$GDDAT ;STORE EXPECTED
1239 006204 112710 000260      MOV      #MIMR,(R0) ;LOAD MODE BITS FOR IMR
1240 006210 113711 001124      MOV      #PIMR,(R0) ;PRESELECT IMR FOR WRITING
1241 006214 111115                MOV      $GDDAT,(R1) ;WRITE INTO DATA PORT
1242 006216 023715 001124      MOV      (R1),(R5)  ;STORE DATA FOR COMPARE
1243 006222 001401                CMP      $GDDAT,(R5) ;CHECK IMR RESULTS
                        BEQ      1$           ;

```

T24 TEST GROUPS 1 AND 2 IMR UNIQUENESS

```

1244 006224 104005          ERROR+ 5          ;IMR ERROR
1245 006226 112710 000254  1$:  MOVB  #MACR,(R0)  ;CHANGE TO ACR REGISTER
1246 006232 005037 001124    CLR  $GDDAT        ;STORE EXPECTED
1247 006236 111115          MOVB  (R1),(R5)    ;READ ACR
1248 006240 023715 001124    CMP  $GDDAT,(R5)  ;SHOULD STILL BE CLEARED
1249 006244 001401          BEQ  2$
1250 006246 104004          ERROR+ 4          ;ACR REG ERROR
1251 006250 112710 000240  2$:  MOVB  #MISR,(R0)  ;LOAD MODE BITS FOR ISR
1252 006254 111115          MOVB  (R1),(R5)    ;READ ISR
1253 006256 023715 001124    CMP  $GDDAT,(R5)  ;ISR SHOULD BE CLEARED
1254 006262 001401          BEQ  3$
1255 006264 104006          ERROR+ 6          ;ISR REG ERROR
1256 006266 112710 000250  3$:  MOVB  #MIRR,(R0)  ;LOAD MODE BITS FOR IRR
1257 006272 111115          MOVB  (R1),(R5)    ;READ IRR
1258 006274 023715 001124    CMP  $GDDAT,(R5)  ;IRR SHOULD BE CLEARED
1259 006300 001401          BEQ  4$
1260 006302 104003          ERROR+ 3          ;IRR REG ERROR
1261 006304 105010          CLRB  (R0)         ;CHIP RESET GROUP 1
1262 006306 112710 000244  4$:  MOVB  #MIMR,(R0)  ;LOAD MODE BITS FOR IMR
1263 006312 012737 000377 001124    MOV  #377,$GDDAT  ;STORE EXPECTED
1264 006320 111115          MOVB  (R1),(R5)    ;READ IMR
1265 006322 023715 001124    CMP  $GDDAT,(R5)  ;IMR SHOULD BE ALL ONES
1266 006326 001401          BEQ  5$
1267 006330 104005          ERROR+ 5          ;IMR REG ERROR
1268 006332 005303          DEC  R3           ;DO GROUPS 1 AND GROUP 2
1269 006334 001405          BEQ  TST25        ;BR IF BOTH GROUPS TESTED
1270 006336 013700 001352    MOV  DRCSA,R0     ;SET UP TO TEST GROUP 2
1271 006342 013701 001356    MOV  DRCSA,R1     ;GROUP 2 DATA PORT
1272 006346 000707          BR   111$        ;DO GROUP 2 IMR UNIQUENESS
1273
1274

```

```

;*****
;*TEST 25 TEST GROUPS 1 AND 2 IRR UNIQUENESS
;*****

```

```

TST25: SCOPE
1275 006350 000004          JSR  PC,CLRCSR    ;CLEAR ALL CSRS
1276 006352 004737 013164    MOV  DRCSA,R0     ;CSRA ADDRESS
1277 006356 013700 001342    MOV  DRCSB,R1     ;CSRB ADDRESS
1278 006362 012703 000002    MOV  #2,R3       ;COUNTER FOR TESTING TWO GROUPS
1279 006372 004737 013234    JSR  PC,CLRIRR   ;CLEAR IRR REGS WITH CHIP RESET
1280 006376 010137 001122  111$: MOV  R1,$BDADR    ;STORE ADDRESS
1281 006402 012737 000200 001124    MOV  #200,$GDDAT ;STORE EXPECTED
1282 006410 112710 000250    MOVB  #MIRR,(R0)  ;LOAD MODE BITS FOR IRR
1283 006414 112710 000137    MOVB  #137,(R0)   ;SET SINGLE IRR BIT7
1284 006420 111115          MOVB  (R1),(R5)    ;STORE DATA FOR COMPARE
1285 006422 023715 001124    CMP  $GDDAT,(R5)  ;CHECK IRR RESULTS
1286 006426 001401          BEQ  1$
1287 006430 104003          ERROR+ 3          ;IRR ERROR
1288 006432 112710 000244  1$:  MOVB  #MIMR,(R0)  ;CHANGE TO IMR REGISTER
1289 006436 012737 000377 001124    MOV  #377,$GDDAT ;STORE EXPECTED
1290 006444 111115          MOVB  (R1),(R5)    ;READ IMR
1291 006446 023715 001124    CMP  $GDDAT,(R5)  ;SHOULD STILL BE ALL 1'S
1292 006452 001401          BEQ  2$
1293 006454 104005          ERROR+ 5          ;IMR REG ERROR
1294 006456 112710 000240  2$:  MOVB  #MISR,(R0)  ;LOAD MODE BITS FOR ISR
1295 006462 005037 001124    CLR  $GDDAT        ;STORE EXPECTED
1296 006466 111115          MOVB  (R1),(R5)    ;READ ISR
1297 006470 023715 001124    CMP  $GDDAT,(R5)  ;ISR SHOULD BE CLEARED

```

T25 TEST GROUPS 1 AND 2 IRR UNIQUENESS

```

1298 006474 001401          BEQ      3$
1299 006476 104006          ERROR+  6          ;ISR REG ERROR
1300 006500 112710 000254   3$:      MOVB   $MACR,(R0)   ;LOAD MODE BITS FOR ACR
1301 006504 111115          MOVB   (R1),(R5)    ;READ ACR
1302 006506 023715 001124   CMP    $GDDAT,(R5) ;ACR SHOULD BE CLEARED
1303 006512 001401          BEQ      4$
1304 006514 104004          ERROR+  4          ;ACR REG ERROR
1305 006516 105010          CLRB   (R0)        ;CHIP RESET GROUP 1
1306 006520 112710 000250   4$:      MOVB   $MIRR,(R0)   ;LOAD MODE BITS FOR IRR
1307 006524 111115          MOVB   (R1),(R5)    ;READ IRR
1308 006526 023715 001124   CMP    $GDDAT,(R5) ;IRR SHOULD BE CLEARED
1309 006532 001401          BEQ      5$
1310 006534 104003          ERROR+  3          ;IRR REG ERROR
1311 006536 005303          DEC    R3          ;TEST GROUPS 1 AND 2
1312 006540 001405          BEQ    TST26       ;;BR IF BOTH GROUPS TESTED
1313 006542 013700 001352   MOV    DRCSA,R0    ;GROUP 2 CONTROL PORT
1314 006546 013701 001356   MOV    DRCSA,R1    ;GROUP 2 DATA PORT
1315 006552 000711          BR     111$        ;TEST GROUP 2 ACR UNIQUENESS
1316
1317
1318

```

;+TEST 26 TEST GROUPS 1,2 ACR WITH PATTERNS

```

006554 000004
1319 006556 004737 013164   TST26: SCOPE
1320 006562 012702 000002     JSR    PC,CLRCR    ;CLEAR ALL CSRS
1321 006566 012737 006614 001110   MOV    $2,R2      ;TEST TWO GROUPS
1322 006574 013700 001342     MOV    $1,$LPERR  ;SET UP LOOP RETURN
1323 006600 013701 001346     MOV    DRCSA,R0   ;STORE CSRA ADDRESS
1324 006604 012703 013272     MOV    DRCSB,R1   ;STORE CSRB ADDRESS
1325 006610 010137 001122   111$:  MOV    $BEGPAT,R3 ;SET UP PATTERN TABLE
1326 006614 112710 000254     MOV    R1,$BDADR  ;STORE ADDRESS
1327 006620 112710 000300   1$:      MOVB   $MACR,(R0)  ;LOAD MODE BITS FOR ACR
1328 006624 111337 001124     MOVB   $PACR,(R0) ;PRESELECT ACR FOR WRITING
1329 006630 111311          MOVB   (R3),$GDDAT ;STORE EXPECTED
1330 006632 111115          MOVB   (R3),(R1)  ;WRITE INTO ACR
1331 006634 023715 001124     MOVB   (R1),(R5)  ;READ OUT OF ACR
1332 006640 001401          CMP    $GDDAT,(R5)
1333 006642 104004          BEQ    2$
1334 006644 005723          ERROR+  4          ;ACR REGISTER ERROR
1335 006646 020327 013572   2$:      TST    (R3)+      ;INC FOR NEXT PATTERN
1336 006652 001360          CMP    R3,$ENDDAT ;CHECK FOR TABLE END
1337 006654 005302          BNE    1$        ;W/R NEXT PATTERN
1338 006656 001405          DEC    R2        ;FINISHED BOTH GROUPS?
1339 006660 013700 001352   BEQ    TST27       ;;BR IF EQUAL
1340 006664 013701 001356   MOV    DRCSA,R0
1341 006670 000745          MOV    DRCSA,R1
1342
1343          BR     111$        ;DO NEXT GROUP

```

;+TEST 27 TEST GROUPS 1,2 IMR WITH PATTERNS

```

006672 000004
1344 006674 004737 013164   TST27: SCOPE
1345 006700 012702 000002     JSR    PC,CLRCR    ;CLEAR ALL CSRS
1346 006704 012737 006732 001110   MOV    $2,R2      ;TEST TWO GROUPS
1347 006712 013700 001342     MOV    $1,$LPERR  ;SET UP LOOP RETURN
1348 006716 013701 001346     MOV    DRCSA,R0   ;STORE CSRA ADDRESS
1348 006716 013701 001346     MOV    DRCSB,R1   ;STORE CSRB ADDRESS

```

K3

T27 TEST GROUPS 1,2 IMR WITH PATTERNS

```

1349 006722 012703 013272      111$: MOV    #BEGPAT,R3      ;SET UP PATTERN TABLE
1350 006726 010137 001122      MOV    R1,$BDADR        ;STORE ADDRESS
1351 006732 112710 000244      1$:  MOVB  #MIMR,(R0)     ;LOAD MODE BITS FOR IMR
1352 006736 112710 000260      MOVB  #PIMR,(R0)       ;PRESELECT IMR FOR WRITING
1353 006742 111337 001124      MOVB  (R3),$GDDAT      ;STORE EXPECTED
1354 006746 111311              MOVB  (R3),(R1)        ;WRITE INTO IMR
1355 006750 111115              MOVB  (R1),(R5)        ;READ OUT OF IMR
1356 006752 023715 001124      CMP    $GDDAT,(R5)
1357 006756 001401              BEQ    2$
1358 006760 104005              ERROR+ 5
1359 006762 005723              2$:  TST    (R3),        ;IMR REGISTER ERROR
1360 006764 020327 013572      CMP    R3,#ENDDAT      ;INC FOR NEXT PATTERN
1361 006770 001360              BNE    1$              ;CHECK FOR TABLE END
1362 006772 005302              DEC    R2              ;W/R NEXT PATTERN
1363 006774 001405              BEQ    TST30          ;FINISHED BOTH GROUPS?
1364 006776 013700 001352      MOV    DRCSA,R0
1365 007002 013701 001356      MOV    DRCSB,R1
1366 007006 000745              BR     111$           ;DO NEXT GROUP
1367
1368
;*****
;+TEST 30      TEST GROUP 1,2 CLEAR IMR INSTR.
;*****
TST30:  SCOPE
1369 007010 000004              JSR    PC,CLRCSR      ;CLEAR ALL CSRS
1370 007012 004737 013164      MOV    #2,R4          ;COUNTER FOR TWO GROUPS
1371 007016 012704 000002      MOV    DRCSA,R0       ;CSRA ADDRESS
1372 007022 013700 001342      MOV    DRCSB,R1       ;CSRB ADDRESS
1373 007026 013701 001346      111$: MOV    R1,$BDADR      ;STORE ADDRESS
1374 007032 010137 001122      CLR    $GDDAT         ;EXPECTED DATA
1375 007036 005037 001124      MOVB  #MIMR,(R0)     ;LOAD MODE BITS TO READ IMR
1376 007042 112710 000244      MOVB  #CIMR,(R0)     ;CLEAR IMR COMMAND
1377 007046 112710 000040      MOVB  (R1),(R5)      ;READ DATA PORT
1378 007052 111115              CMP    $GDDAT,(R5)
1379 007054 023715 001124      BEQ    1$
1380 007060 001401              ERROR+ 5
1381 007062 104005              1$:  DEC    R4          ;ERROR ,IMR SHOULD BE CLEARED
1382 007064 005304              BEQ    TST31         ;FINISHED BOTH GROUPS?
1383 007066 001405              ;:BR IF BOTH GROUPS TESTED
1384 007070 013700 001352      MOV    DRCSA,R0
1385 007074 013701 001356      MOV    DRCSB,R1
1386 007100 000754              BR     111$           ;DO IMR TEST WITH GROUP 2
1387
;*****
;+TEST 31      TEST GROUP 1,2 SET IMR INSTR.
;*****
TST31:  SCOPE
1388 007102 000004              JSR    PC,CLRCSR      ;CLEAR ALL CSRS
1389 007104 004737 013164      MOV    #2,R4          ;COUNTER FOR TWO GROUPS
1390 007110 012704 000002      MOV    DRCSA,R0       ;CSRA ADDRESS
1391 007114 013700 001342      MOV    DRCSB,R1       ;CSRB ADDRESS
1392 007120 013701 001346      111$: MOV    R1,$BDADR      ;STORE ADDRESS
1393 007124 010137 001122      MOV    #377,$GDDAT    ;EXPECTED DATA
1394 007130 012737 000377 001124      MOVB  #MIMR,(R0)     ;LOAD MODE BITS TO READ IMR
1395 007136 112710 000244      MOVB  #CIMR,(R0)     ;CLEAR IMR
1396 007142 112710 000040      MOVB  #SIMR,(R0)     ;SET IMR COMMAND
1397 007146 112710 000060      MOVB  (R1),(R5)      ;READ DATA PORT
1398 007152 111115              CMP    $GDDAT,(R5)
1399 007154 023715 001124      BEQ    1$

```

T31 TEST GROUP 1,2 SET IMR INSTR.

```

1400 007162 104005          ERROR+ 5          ;ERROR ,IMR SHOULD BE SET
1401 007164 005304          1$: DEC R4          ;FINISHED BOTH GROUPS?
1402 007166 001405          BEQ TST32        ;;BR IF BOTH GROUPS TESTED
1403 007170 013700 001352   MOV DRCSB,R0     ;SETUP FOR GROUP 2
1404 007174 013701 001356   MOV DRCSB,R1
1405 007200 000751          BR 111$         ;DO IMR TEST WITH GROUP 2
1406
1407
;*****
;*TEST 32 TEST GROUP 1,2 CLEAR SINGLE IMR BIT INSTR.
;*****
TST32: SCOPE
1408 007202 000004          JSR PC,CLRCSR   ;CLEAR ALL CSRS
1409 007204 004737 013164   MOV #2,R4      ;GROUP COUNTER
1410 007214 012737 007252 001110  MOV #1,$LPERR  ;SCOPE RETURN ADDRESS
1411 007222 013700 001342   MOV DRCSA,R0   ;CSRA ADDRESS
1412 007226 013701 001346   MOV DRCSB,R1   ;CSRB ADDRESS
1413 007232 010137 001122   111$: MOV R1,$B0ADR  ;STORE ADDRESS
1414 007236 012703 013436   MOV #BGCHP4,R3 ;GOOD DATA PATTERN TABLE
1415 007242 112710 000244   MOVB #MIMR,(R0) ;LOAD MODE BITS FOR IMR
1416 007246 012702 000050   MOV #CSIMR,R2  ;SET SINGLE IMR BIT VALUE
1417 007252 111337 001124   1$: MOVB (R3),$GDDAT ;STORE EXPECTED
1418 007256 112710 000060   MOVB #SIMR,(R0) ;SET ALL IMR BITS
1419 007262 110210          MOVB R2,(R0)   ;CLEAR SINGLE IMR BIT
1420 007264 111115          MOVB (R1),(R5) ;READ DATA PORT
1421 007266 023715 001124   CMP $GDDAT,(R5)
1422 007272 001401          BEQ 2$
1423 007274 104005          ERROR+ 5
1424 007276 005723          2$: TST (R3)+    ;IMR REG ERROR
1425 007300 020327 013456   CMP R3,#EDCHP4 ;INC EXPECTED DATA TABLE
1426 007304 001402          BEQ 3$         ;CHECK FOR END
1427 007306 005202          INC R2
1428 007310 000760          BR 1$         ;SET UP TO CLEAR NEXT IMR BIT
1429 007312 005304          3$: DEC R4      ;CLEAR NEXT IMR BIT
1430 007314 001405          BEQ TST33     ;DO GROUPS 1 AND 2
1431 007316 013700 001352   MOV DRCSB,R0   ;;BR IF BOTH GROUPS TESTED
1432 007322 013701 001356   MOV DRCSB,R1   ;CSRB ADDRESS
1433 007326 000741          BR 111$       ;DO GROUP 2
1434
1435
1436
;*****
;*TEST 33 TEST GROUP 1,2 SET SINGLE IMR BIT INSTR.
;*****
TST33: SCOPE
1437 007330 000004          JSR PC,CLRCSR   ;CLEAR ALL CSRS
1438 007332 004737 013164   MOV #2,R4      ;GROUP COUNTER
1439 007342 012737 007400 001110  MOV #1,$LPERR  ;SCOPE RETURN ADDRESS
1440 007350 013700 001342   MOV DRCSA,R0   ;CSRA ADDRESS
1441 007354 013701 001346   MOV DRCSB,R1   ;CSRB ADDRESS
1442 007360 010137 001122   111$: MOV R1,$B0ADR  ;STORE ADDRESS
1443 007364 012703 013374   MOV #BGCHP3,R3 ;GOOD DATA PATTERN TABLE
1444 007370 112710 000244   MOVB #MIMR,(R0) ;LOAD MODE BITS FOR IMR
1445 007374 012702 000070   MOV #SSIMR,R2  ;SET SINGLE IMR BIT VALUE
1446 007400 111337 001124   1$: MOVB (R3),$GDDAT ;STORE EXPECTED
1447 007404 112710 000040   MOVB #CIMR,(R0) ;CLEAR ALL IMR BITS
1448 007410 110210          MOVB R2,(R0)   ;SET SINGLE IMR BIT
1449 007412 111115          MOVB (R1),(R5) ;READ DATA PORT
1450 007414 023715 001124   CMP $GDDAT,(R5)

```

T33 TEST GROUP 1,2 SET SINGLE IMR BIT INSTR.

```

1451 007420 001401      BEQ      2$
1452 007422 104005      ERROR+   5          ;IMR REG ERROR
1453 007424 005723      2$:      TST      (R3)+      ;INC EXPECTED DATA TABLE.
1454 007426 020327 013414  CMP      R3,#EDCHP3  ;CHECK FOR END
1455 007432 001402      BEQ      3$
1456 007434 005202      INC      R2          ;SET UP TO SET NEXT IMR BIT
1457 007436 000760      BR       1$          ;SET NEXT IMR BIT
1458 007440 005304      3$:      DEC      R4          ;DO GROUPS 1 AND 2
1459 007442 001405      BEQ      TST34       ;BR IF BOTH GROUPS TESTED
1460 007444 013700 001352  MOV      DRCSC,R0    ;CSRC ADDRESS
1461 007450 013701 001356  MOV      DRCSB,R1    ;CSRB ADDRESS
1462 007454 000741      BR       111$       ;DO GROUP 2
1463
1464

```

```

;*****
;*TEST 34 TEST GROUP 1,2 SET IRR INSTR.
;*****

```

```

007456 00C004
1465 007460 004737 013164  TST34: SCOPE
1466 007464 012704 000002  JSR      PC,CLRCSR   ;CLEAR ALL CSRS
1467 007470 013700 001342  MOV      #2,R4       ;COUNTER FOR TWO GROUPS
1468 007474 013701 001346  MOV      DRCSA,R0    ;CSRA ADDRESS
1469 007500 004737 013234  MOV      DRCSB,R1    ;CSRB ADDRESS
1470 007504 010137 001122  JSR      PC,CLRIRR   ;CLEAR IRR REGS WITH CHIP RESET
1471 007510 012737 000377 001124  111$:   MOV      R1,#BDADR   ;STORE ADDRESS
1472 007516 112710 000250  MOV      #377,$GDDAT ;EXPECTED DATA
1473 007522 112710 000120  MOV      #MIRR,(R0)  ;LOAD MODE BITS TO READ IRR
1474 007526 111115  MOV      #SIRR,(R0)  ;SET IRR COMMAND
1475 007530 023715 001124  MOV      (R1),(R5)   ;READ DATA PORT
1476 007534 001401      CMP      $GDDAT,(R5)
1477 007536 104003      BEQ      1$
1478 007540 005304      1$:     ERROR+   3          ;ERROR ,IRR SHOULD BE SET
1479 007542 001405      DEC      R4          ;FINISHED BOTH GROUPS?
1480 007544 013700 001352  BEQ      TST35       ;BR IF BOTH GROUPS TESTED
1481 007550 013701 001356  MOV      DRCSC,R0    ;SETUP FOR GROUP 2
1482 007554 000753      MOV      DRCSB,R1
1483      BR       111$     ;DO IRR TEST WITH GROUP 2
1484
1485

```

```

;*****
;*TEST 35 TEST GROUP 1,2 CLEAR IRR INSTR.
;*****

```

```

007556 000004
1486 007560 004737 013164  TST35: SCOPE
1487 007564 012704 000002  JSR      PC,CLRCSR   ;CLEAR ALL CSRS
1488 007570 013700 001342  MOV      #2,R4       ;COUNTER FOR TWO GROUPS
1489 007574 013701 001346  MOV      DRCSA,R0    ;CSRA ADDRESS
1490 007600 004737 013234  MOV      DRCSB,R1    ;CSRB ADDRESS
1491 007604 010137 001122  JSR      PC,CLRIRR   ;CLEAR IRR REGS WITH CHIP RESET
1492 007610 005037 001124  111$:   MOV      R1,#BDADR   ;STORE ADDRESS
1493 007614 112710 000250  CLR      $GDDAT      ;EXPECTED DATA
1494 007620 112710 000120  MOV      #MIRR,(R0)  ;LOAD MODE BITS TO READ IRR
1495 007624 112710 000100  MOV      #SIRR,(R0)  ;SET IRR BITS
1496 007630 111115  MOV      #CIRR,(R0)  ;CLEAR IRR COMMAND
1497 007632 023715 001124  MOV      (R1),(R5)   ;READ DATA PORT
1498 007636 001401      CMP      $GDDAT,(R5)
1499 007640 104003      BEQ      1$
1500 007642 005304      1$:     ERROR+   3          ;ERROR ,IRR SHOULD BE CLEARED
1501 007644 001405      DEC      R4          ;FINISHED BOTH GROUPS?
                        BEQ      TST36       ;BR IF BOTH GROUPS TESTED

```

T35 TEST GROUP 1,2 CLEAR IRR INSTR.

```

1502 00764 013700 001352      MOV      DRCSC,R0      ;SETUP FOR GROUP 2
1503 00765 013701 001356      MOV      DRCSD,R1
1504 00766 000752              BR       111$         ;DO IRR TEST WITH GROUP 2
1505
1506

```

```

;*****
;*TEST 36      TEST GROUP 1,2 CLEAR SINGLE IRR BIT INSTR.
;*****

```

```

TST36:  SCOPE
1507 007660 000004              JSR      PC,CLRCSR    ;CLEAR ALL CSRS
1508 007666 012704 000002      MOV      #2,R4       ;GROUP COUNTER
1509 007672 012737 007734 001110  MOV      #1,$LPERR   ;SCOPE RETURN ADDRESS
1510 007700 013700 001342      MOV      DRCSA,R0    ;CSRA ADDRESS
1511 007704 013701 001346      MOV      DRCSE,R1    ;CSRE ADDRESS
1512 007710 004737 013234      JSR      PC,CLRIRR   ;CLEAR IRR REGS WITH CHIP RESET
1513 007714 010137 001122      MOV      R1,$BDADR   ;STORE ADDRESS
1514 007720 012703 013436      MOV      #BGCHP4,R3  ;GOOD DATA PATTERN TABLE
1515 007724 112710 000250      MOV      #MIRR,(R0)  ;LOAD MODE BITS FOR IRR
1516 007730 012702 000110      MOV      #CSIRR,R2   ;SET SINGLE IRR BIT VALUE
1517 007734 111337 001124      MOV      (R3),$GDDAT ;STORE EXPECTED
1518 007740 112710 000120      MOV      #SIRR,(R0)  ;CLEAR ALL IRR BITS
1519 007744 110210              MOV      R2,(R0)     ;SET SINGLE IRR BIT
1520 007746 111115              MOV      (R1),(R5)   ;READ DATA PORT
1521 007750 023715 001124      CMP      $GDDAT,(R5)
1522 007754 001401              BEQ      2$
1523 007756 104003              ERROR+  3
1524 007760 005723              TST      (R3)+
1525 007762 020327 013456      CMP      R3,#EDCHP4  ;CHECK FOR END
1526 007766 001402              BEQ      3$
1527 007770 005202              INC      R2          ;SET UP TO CLEAR NEXT IRR BIT
1528 007772 000760              BR       1$         ;CLEAR NEXT IRR BIT
1529 007774 005304              DEC      R4          ;DO GROUPS 1 AND 2
1530 007776 001405              BEQ      TST37      ;BR IF BOTH GROUPS TESTED
1531 010000 013700 001352      MOV      DRCSC,R0    ;CSRC ADDRESS
1532 010004 013701 001356      MOV      DRCSD,R1    ;CSRD ADDRESS
1533 010010 000741              BR       111$       ;DO GROUP 2
1534
1535

```

```

;*****
;*TEST 37      TEST GROUP 1,2 SET SINGLE IRR BIT INSTR.
;*****

```

```

TST37:  SCOPE
1536 010012 000004              JSR      PC,CLRCSR    ;CLEAR ALL CSRS
1537 010014 004737 013164      MOV      #2,R4       ;GROUP COUNTER
1538 010020 012704 000002      MOV      #1,$LPERR   ;SCOPE RETURN ADDRESS
1539 010032 013700 001342      MOV      DRCSA,R0    ;CSRA ADDRESS
1540 010036 013701 001346      MOV      DRCSE,R1    ;CSRE ADDRESS
1541 010042 004737 013234      JSR      PC,CLRIRR   ;CLEAR IRR REGS WITH CHIP RESET
1542 010046 010137 001122      MOV      R1,$BDADR   ;STORE ADDRESS
1543 010052 012703 013374      MOV      #BGCHP3,R3  ;GOOD DATA PATTERN TABLE
1544 010056 112710 000250      MOV      #MIRR,(R0)  ;LOAD MODE BITS FOR IRR
1545 010062 012702 000130      MOV      #SSIRR,R2   ;SET SINGLE IRR BIT VALUE
1546 010066 111337 001124      MOV      (R3),$GDDAT ;STORE EXPECTED
1547 010072 112710 000100      MOV      #CIRR,(R0)  ;CLEAR ALL IRR BITS
1548 010076 110210              MOV      R2,(R0)     ;SET SINGLE IRR BIT
1549 010100 111115              MOV      (R1),(R5)   ;READ DATA PORT
1550 010102 023715 001124      CMP      $GDDAT,(R5)
1551 010106 001401              BEQ      2$
1552 010110 104003              ERROR+  3

```

T37 TEST GROUP 1,2 SET SINGLE IRR BIT INSTR.

```

1553 010112 005723          2$:  TST      (R5),          ;INC EXPECTED DATA TABLE
1554 010114 020327 013414    CMP      R3,#EDCHP3      ;CHECK FOR END
1555 010120 001402          BEQ      3$              ;
1556 010122 005202          INC      R2              ;SET UP TO SET NEXT IRR BIT
1557 010124 000760          BR       1$              ;SET NEXT IRR BIT
1558 010126 005304          3$:  DFC      R4              ;DO GROUPS 1 AND 2
1559 010130 001405          BEQ      TST40           ;BR IF BOTH GROUPS TESTED
1560 010132 013700 001352    MOV      DRCSB,R0        ;CSRB ADDRESS
1561 010136 013701 001356    MOV      DRCSA,R1        ;CSRA ADDRESS
1562 010142 000741          BR       111$           ;DO GROUP 2
1563
1564

```

```

;*****
; *TEST 40      TEST GROUP 1,2 CLEAR IRR+IMR INSTR.
;*****

```

```

TST40:  SCOPE
1565 010144 000004          JSR      PC,CLRCSR       ;CLEAR ALL CSRS
1566 010146 004737 013164    MOV      #2,R4           ;COUNTER FOR TWO GROUPS
1567 010152 012704 000002    MOV      DRCSA,R0        ;CSRA ADDRESS
1568 010162 013701 001346    MOV      DRCSB,R1        ;CSRB ADDRESS
1569 010166 004737 013234    JSR      PC,CLRIRR       ;CLEAR IRR REGS WITH CHIP RESET
1570 010172 010137 001122    111$:  MOV      R1,#BDADR      ;STORE ADDRESS
1571 010176 005037 001124    CLR      #GDDAT          ;EXPECTED DATA
1572 010202 112710 000250    MOVB    #MIRR,(R0)       ;LOAD MODE BITS TO READ IRR
1573 010206 112710 000120    MOVB    #SIRR,(R0)       ;SET IRR BITS
1574 010212 112710 000060    MOVB    #SIMR,(R0)       ;SET IMR BITS
1575 010216 112710 000020    MOVB    #CIRMR,(R0)      ;CLEAR IRR+IMR COMMAND
1576 010222 111115          MOVB    (R1),(R5)        ;READ DATA PORT FOR IRR
1577 010224 023715 001124    CMP      #GDDAT,(R5)
1578 010230 001401          BEQ      1$              ;
1579 010232 104003          ERROR+  3                ;ERROR ,IRR SHOULD BE CLEARED
1580 010234 112710 000244    1$:  MOVB    #MIMR,(R0)     ;LOAD MODE BITS TO READ IMR
1581 010240 111115          MOVB    (R1),(R5)        ;READ IMR REG
1582 010242 023715 001124    CMP      #GDDAT,(R5)
1583 010246 001401          BEQ      2$              ;
1584 010250 104005          ERROR+  5                ;IRR+IMR COMMAND DID NOT CLEAR IMR
1585 010252 005304          DEC      R4              ;FINISHED BOTH GROUPS?
1586 010254 001405          BEQ      TST41           ;BR IF BOTH GROUPS TESTED
1587 010256 013700 001352    MOV      DRCSB,R0        ;SETUP FOR GROUP 2
1588 010262 013701 001356    MOV      DRCSA,R1
1589 010266 000741          BR       111$           ;DO IRR+IMR TEST WITH GROUP 2
1590
1591

```

```

;*****
; *TEST 41      TEST GROUP 1,2 CLEAR SINGLE IRR+IMR BIT INSTR.
;*****

```

```

TST41:  SCOPE
1592 010270 000004          JSR      PC,CLRCSR       ;CLEAR ALL CSRS
1593 010272 004737 013164    MOV      #2,R4           ;GROUP COUNTER
1594 010302 012737 010340 001110  MOV      #11,#LPERR      ;SCOPE RETURN ADDRESS
1595 010310 013700 001342    MOV      DRCSA,R0        ;CSRA ADDRESS
1596 010314 013701 001346    MOV      DRCSB,R1        ;CSRB ADDRESS
1597 010320 004737 013234    JSR      PC,CLRIRR       ;CLEAR IRR REGS WITH CHIP RESET
1598 010324 010137 001122    111$:  MOV      R1,#BDADR      ;STORE ADDRESS
1599 010330 012703 013436    MOV      #BGCHP4,R3      ;GOOD DATA PATTERN TABLE
1600 010334 012702 000030    MOV      #CSIRMR,R2      ;CLEAR SINGLE IRR+IMR BIT VALUE
1601 010340 111337 001124    1$:  MOVB    (R3),#GDDAT     ;STORE EXPECTED
1602 010344 112710 000250    MOVB    #MIRR,(R0)       ;LOAD MODE BITS TO READ IRR
1603 010350 112710 000120    MOVB    #SIRR,(R0)       ;SET ALL IRR BITS

```


T41 TEST GROUP 1,2 CLEAR SINGLE IRR+IMR BIT INSTR.

```

1604 010354 112710 000060      MOVVB  #SIMR,(R0)      ;SET ALL IMR BITS
1605 010360 110210      MOVVB  R2,(R0)        ;CLEAR SINGLE IRR+IMP BIT
1606 010362 111115      MOVVB  (R1),(R5)      ;READ DATA PORT FOR IRR
1607 010364 023715 001124      CMP    $GDDAT,(R5)
1608 010370 001401      BEQ    2$
1609 010372 104003      ERROR+ 3             ;IRR REG ERROR
1610 010374 112710 000244      2$: MOVVB  #MIMR,(R0)    ;SET UP TO READ IMR
1611 010400 111115      MOVVB  (R1),(R5)      ;READ IMR REGISTER
1612 010402 023715 001124      CMP    $GDDAT,(R5)
1613 010406 001401      BEQ    3$
1614 010410 104005      ERROR+ 5             ;IMR REG ERROR
1615 010412 005723      3$: TST  (R3)+         ;INC EXPECTED DATA TABLE
1616 010414 020327 013456      CMP    R3,#EDCHP4     ;CHECK FOR END
1617 010420 001402      BEQ    4$
1618 010422 005202      INC    R2             ;SET UP TO CLEAR NEXT IRR+IMR BIT
1619 010424 000745      BR     1$            ;CLEAR NEXT IRR+IMR BIT
1620 010426 005304      4$: DEC    R4          ;DO GROUPS 1 AND 2
1621 010430 001405      BEQ    TST42         ;BR IF BOTH GROUPS TESTED
1622 010432 013700 001352      MOV    DRCSO,R0      ;CSRC ADDRESS
1623 010436 013701 001356      MOV    DRCSO,R1      ;CSRD ADDRESS
1624 010442 000730      BR     111$         ;DO GROUP 2
1625
1626      ;*****
;*TEST 4? TEST GROUPS 1,2 FOR GROUP UNIQUENESS
;*****
TST42: SCOPE
1627 010444 000004      JSR    PL,CLRCSR     ;CLEAR ALL CSRS
1628 010446 004737 013164      ;CSRA = R0
1629      ;CSRB = R1
1630      ;CSRC = R2
1631      ;CSRD = R3
1632 010452 012704 000002      MOV    #2,R4        ;COUNTER FOR TESTING TWO GROUPS
1633 010456 004737 013234      JSR    PC,CLRIRR    ;CLEAR IRR REGS WITH CHIP RESET
1634 010462 010337 001122      111$: MOV    R3,#BDADR   ;STORE ADDRESS
1635 010466 112710 000300      MOVVB  #PACR,(R0)    ;PRESELECT ACR FOR WRITING
1636 010472 112711 000377      MOVVB  #377,(R1)     ;WRITE INTO DATA PORT FOR ACR
1637 010476 112710 000120      MOVVB  #SIIR,(R0)    ;SET IRR TO ALL 1'S
1638 010502 112710 000040      MOVVB  #CIMR,(R0)    ;CLEAR IMR
1639 010506 112712 000254      MOVVB  #MACR,(R2)    ;LOAD MODE TO READ ACR
1640 010512 005037 001124      CLR    $GDDAT        ;EXPECTED
1641 010516 111315      MOVVB  (R3),(R5)     ;STORE DATA FOR COMPARE
1642 010520 023715 001124      CMP    $GDDAT,(R5)   ;CHECK ACR RESULTS
1643 010524 001401      BEQ    1$
1644 010526 104004      ERROR+ 4             ;ERROR, OTHER GROUP ACR SHOULD BE CLEARED
1645 010530 112712 000244      1$: MOVVB  #MIMR,(R2)  ;CHANGE TO IMR REGISTER
1646 010534 012737 000377 001124      MOV    #377,$GDDAT  ;STORE EXPECTED
1647 010542 111315      MOVVB  (R3),(R5)     ;READ IMR
1648 010544 023715 001124      CMP    $GDDAT,(R5)   ;SHOULD BE ALL 1'S
1649 010550 001401      BEQ    2$
1650 010552 104005      ERROR+ 5             ;ERROR, OTHER GROUP IMR SHOULD BE SET
1651 010554 112712 000240      2$: MOVVB  #MISR,(R2)  ;LOAD MODE BITS FOR ISR
1652 010560 005037 001124      CLR    $GDDAT        ;STORE EXPECTED
1653 010564 111315      MOVVB  (R3),(R5)     ;READ ISR
1654 010566 023715 001124      CMP    $GDDAT,(R5)   ;ISR SHOULD BE CLEARED
1655 010572 001401      BEQ    3$
1656 010574 104006      ERROR+ 6             ;ISR REG ERROR
1657 010576 112712 000250      3$: MOVVB  #MIIR,(R2)  ;LOAD MODE BITS FOR IRR

```

T42 TEST GROUPS 1,2 FOR GROUP UNIQUENESS

```

1658 010602 111315          MOVB   (R5),(R5)      ;HEAD IMM
1659 010604 023715 001124  CMP    %GDDAT,(R5)   ;IRR SHOULD BE CLEARED
1660 010610 001401          BEQ    4$
1661 010612 104003          ERROR+ 3             ;ERROR,OTHER GROUP IRR SHOULD BE CLEARED
1662 010614 005304          DEC    R4            ;TEST GROUPS 1 AND 2
1663 010616 001415          BEQ    TST43        ;;BR IF BOTH GROUPS TESTED
1664 010620 004737 013164  JSR    PC,CLRCSR     ;CLEAR ALL CSRS
1665 010624 013700 001352  MOV    DRCSA,R0      ;GROUP 2 CONTROL PORT
1666 010630 013701 001356  MOV    DRCSB,R1      ;GROUP 2 DATA PORT
1667 010634 013702 001342  MOV    DRCSA,R2      ;GROUP 1 CONTROL PORT
1668 010640 013703 001346  MOV    DRCSB,R3      ;GROUP 1 DATA PORT
1669 010644 004737 013234  JSR    PC,CLRIRR     ;CLEAR IRR REGS WITH CHIP RESET
1670 010650 000704          BR     111$         ;TEST GROUP 2 ACR UNIQUENESS
1671
1672

```

```

;*****
; *TEST 43 TEST STATUS BITS GINT,S2,S1,S0,GP1,?
;*****

```

```

010652 000004
1673 010654 004737 013164  TST43: SCOPE
1674 010660 013700 001342  JSR    PC,CLRCSR     ;CLEAR ALL CSRS
1675 010664 013701 001346  MOV    DRCSA,R0
1676 010670 012703 000002  MOV    DRCSB,R1
1677 010674 012704 000120  MOV    %2,R3         ;DO TWO GROUPS
1678 010700 005077 170436  MOV    %120,R4       ;EXPECTED STATUS BITS
1679 010704 005077 170442  CLR    %DRCSA        ;INIT CSRA
1680 010710 012702 013274  CLR    %DRCSB        ;INIT CSRB
1681 010714 112760 000001 000001  MOV    %BGPAT1,R2    ;EXPECTED IRR PATTERN
1682 010722 112777 000204 170412  MOVB   %BIT0,1(R0)   ;CSR TO OUTPUT MODE
1683 010730 112777 000204 170414  MOVB   %204,%DRCSA   ;POLLED MODE FOR CSRA,GROUP 1
1684 010736 112710 000020  MOVB   %204,%DRCSB   ;POLLED MODE FOR CSRB,GROUP 2
1685 010742 012737 000070 001372  MOV    %CIRMR,(R0)   ;CLEAR IMR + IRR
1686 010750 012737 000130 001376  MOV    %SSIMR,IMRLOC ;STORE CODE FOR SINGLE IMR
1687 010756 010037 001122  MOV    %SSIRR,IRRLOC ;STORE CODE FOR SINGLE IRR
1688 010762 010437 001124  112$: MOV    R0,%BDADR     ;CSR CHIP COMMAND ADDRESS
1689 010766 113710 001376  MOV    R4,%GDDAT     ;EXPECTED DATA
1690 010772 111015  MOVB   IRRLOC,(R0)   ;SET SINGLE IRR BIT
1691 010774 042715 000007  MOVB   (R0),(R5)    ;CHECK STATUS
1692 011000 023715 001124  BIC    %7,(R5)      ;: *** VDRCA1 ADDS THIS *** :GPA
1693 011004 001401  BEQ    1$
1694 011006 104007  ERROR+ 7             ;CHIP STATUS ERROR
1695 011010 005037 001124  1$: CLR    %GDDAT
1696 011014 010137 001122  MOV    R1,%BDADR     ;CSR CHIP DATA ADDRESS
1697 011020 111237 001124  MOVB   (R2),%GDDAT
1698 011024 112710 000250  MOVB   %MIRR,(R0)   ;READ IRR
1699 011030 111115  MOVB   (R1),(R5)
1700 011032 023715 001124  CMP    %GDDAT,(R5)  ;CHECK IRR
1701 011036 001401  BEQ    2$
1702 011040 104003  ERROR+ 3             ;IRR ERROR
1703 011042 010037 001122  2$: MOV    R0,%BDADR
1704 011046 113710 001372  MOVB   IMRLOC,(R0)  ;SET IMR BIT
1705 011052 012737 000320 001124  MOV    %320,%GDDAT  ;CSR EXPECTED DATA
1706 011060 111015  MOVB   (R0),(R5)
1707 011062 042715 000007  BIC    %7,(R5)      ;CLEAR UNDEFINED BITS
1708 011066 023715 001124  CMP    %GDDAT,(R5)
1709 011072 001401  BEQ    3$
1710 011074 104007  ERROR+ 7             ;CHIP STATUS ERROR
1711 011076 010137 001122  3$: MOV    R1,%BDADR

```

{ 4

T43 TEST STATUS BITS GINT,S2,S1,S0,GP1,2

```

1712 011102 011237 001124      MOV      (R2),%GDDAT      ;EXPECTED DATA
1713 011106 112710 000244      MOVB    %MIMR,(R0)      ;READ IMR BITS
1714 011112 111115              MOVB    (R1),(R5)      ;SAVE IMR READ
1715 011114 023715 001124      CMP     %GDDAT,(R5)
1716 011120 001401              BEQ     4$
1717 011122 104005              ERROR+  5              ;IMR ERROR
1718 011124 005722              4$:   TST     (R2)+      ;NEXT EXPECTED FOR IMR + IRR
1719 011126 020227 013314      CMP     R2,%EDCHP1     ;CHECK FOR END
1720 011132 001407              BEQ     5$
1721 011134 005237 001376      INC     IRRLOC        ;NEXT IRR BIT
1722 011140 005237 001372      INC     IMRLOC        ;NEXT IMR BIT
1723              ;;GPA  INC     R4          ;INDEX EXPECTED STATUS
1724 011144 000240              NOP
1725 011146 000137 010756      JMP     112$          ;; *** VDRCA1 DELETES INC R4 *** ;;GPA
1726 011152 005303              5$:   DEC     R3          ;DO NEXT STATUS CHECK
1727 011154 001406              BEQ     TST44        ;FINISHED BOTH GROUPS?
1728 011156 013700 001352      MOV     DRCSC,R0      ;;BR IF EQUAL
1729 011162 013701 001356      MOV     DRCSD,R1
1730 011166 000137 010674      JMP     111$          ;DO NEXT GROUP
1731
1732
1733

```

```

;*****
;+TEST 44      TEST POLLED MODE;CSRS A,B-OUT C,D-IN,ACTIVE LOW
;*****
TST44:

```

```

1734 011172 000004              SLOPE
1734 011174 004737 013164      JSR     PC,CLRCSR     ;CLEAR ALL CSRS
1735              ;R0 = CSRA-GROUP 1 CONTROL
1736              ;R1 = CSRB-GROUP 1 DATA
1737              ;R2 = CSRC-GROUP 2 CONTROL
1738              ;R3 = CSRD-GROUP 2 DATA
1739 011200 012737 011252 001110      MOV     %1,%LPERR     ;SET FOR SCOPE RETURN
1740 011206 012704 013272              MOV     %REGPA1,R4    ;START OF PATTERN TABLE
1741 011212 112760 000001 000001      MOVB   %BIT0,1(R0)    ;SET CSRA TO OUTPUT MODE
1742 011220 112761 000001 000001      MOVB   %BIT0,1(R1)    ;SET CSRB TO OUTPUT MODE
1743 011226 105010              CLRB   (R0)          ;CHTP RESET GROUP 1 CSRA
1744 011230 105012              CLRB   (R2)          ;CHTP RESET GROUP 2 CSRC
1745 011232 112710 000204              MOVB   %204,(R0)     ;LOAD MODE BITS FOR POLLED MODE,GR 1
1746 011236 112712 000204              MOVB   %204,(R2)     ;LOAD MODE BITS FOR POLLED MODE,GR2
1747 011242 112710 000250              MOVB   %MIRR,(R0)    ;LOAD BITS TO READ IRR GROUP 1
1748 011246 112712 000250              MOVB   %MIRR,(R2)    ;LOAD BITS TO READ IRR GROUP 2
1749 011252 011460 000002              1$:   MOV     (R4),2(R0)  ;SET PATTERN DBRA FROM H TO L
1750 011256 012760 177777 000002      MOV     %-1,2(R0)    ;FORCE ALL BITS IN DBRA HIGH
1751 011264 112710 000020              MOVB   %CIRMR,(R0)   ;CLEAR IMR+IRR GROUP 1
1752 011270 112712 000020              MOVB   %CIRMR,(R2)   ;CLEAR IMR+IRR GROUP 2
1753 011274 005114              COM    (R4)          ;COMPLEMENT TABLE DATA
1754 011276 011460 000002              MOV     (R4),2(R0)   ;XMIT CSR
1755 011302 012760 177777 000002      MOV     %-1,2(R0)    ;FORCE ALL BITS HIGH AGAIN
1756 011310 005114              COM    (R4)          ;RESTORE TABLE DATA
1757 011312 010137 001122              2$:   MOV     R1,%BDADR   ;GROUP 1 DATA PORT
1758 011316 111437 001124              MOVB   (R4),%GDDAT   ;
1759 011322 111115              MOVB   (R1),(R5)     ;READ IRR,GROUP 1
1760 011324 023715 001124      CMP     %GDDAT,(R5)
1761 011330 001401              BEQ     3$
1762 011332 104003              ERROR+  3              ;IRR ERROR,GROUP 1
1763 011334 010337 001122              3$:   MOV     R3,%BDADR   ;GROUP 2 DATA PORT
1764 011340 116437 000001 001124      MOVB   1(R4),%GDDAT ;BUILD EXPECTED DATA
1765 011346 042737 000360 001124      BIC    %360,%GDDAT   ;SAVE BITS 0-3

```

174

SEQ 0044

T44 TEST POLLED MODE;CSRS A,B=OUT C,D=IN,ACTIVE LOW

```

1766 011354 052737 000100 001124      BIS      #100,$GDDAT      ;EXPECTED 0-3,URPLY 6(C)
1767 011362 111315                MOV      (R3),(R5)      ;READ IRR BITS,GROUP 2
1768 011364 023715 001124      CMP      $GDDAT,(R5)
1769 011370 001401                BEQ      4$
1770 011372 104003                ERROR+  3                ;IRR ERROR,GROUP 2
1771 011374 005762 000002      4$:    TST      2(R2)          ;READ DBRC FOR RPLY 4(A)
1772 011400 052737 000020 001124      BIS      #20,$GDDAT      ;STORE EXPECTED
1773 011406 111315                MOV      (R3),(R5)      ;READ IRR BITS,GROUP 2
1774 011410 023715 001124      CMP      $GDDAT,(R5)
1775 011414 001401                BEQ      5$
1776 011416 104003                ERROR+  3                ;IRR ERROR,GROUP 2
1777 011420 005061 000002      5$:    CLR      2(R1)          ;CLEAR DBRB FOR RPLY 7(D)
1778 011424 052737 000200 001124      BIS      #200,$GDDAT     ;EXPECTED
1779 011432 111315                MOV      (R3),(R5)      ;READ IRR BITS GROUP 2
1780 011434 023715 001124      CMP      $GDDAT,(R5)
1781 011440 001401                BEQ      6$
1782 011442 104003                ERROR+  3                ;IRR ERROR,GROUP 2
1783 011444 005763 000002      6$:    TST      2(R3)          ;READ DBRD FOR RPLY 5(B)
1784 011450 052737 000040 001124      BIS      #40,$GDDAT     ;READ IRR BITS GROUP2
1785 011456 111315                MOV      (R3),(R5)
1786 011460 023715 001124      CMP      $GDDAT,(R5)
1787 011464 001401                BEQ      7$
1788 011466 104003                ERROR+  3                ;GET NEXT PATTERN
1789 011470 005724      7$:    TST      (R4)          ;IRR ERROR,GROUP 2
1790 011472 020427 013572      CMP      R4,#ENDDAT     ;INDEX DATA TABLE
1791 011476 001265                BNE     1$              ;CHECK FOR END
1792
1793
1794
;*****
;*TEST 45      TEST GROUPS 1,2 IN POLLED MODE,NO REPLY
;*****
TST45:  SCOPE
1795 011500 000004      JSR      PC,CLRCSR      ;CLEAR ALL CSRS
1796 011502 004737 013164
1797
1798
1799
1800 011506 012704 000002      MOV      #2,R4          ;R0 = CSRA-GROUP 1 CONTROL
1801
1802
1803
1804
1805 011512 112760 000001 000001 111$:  MOV      #BIT0,1(R0)    ;R1 = CSRB-GROUP 1 DATA
1806 011520 112761 000001 000001      MOV      #BIT0,1(R1)    ;R2 = CSRC-GROUP 2 CONTROL
1807 011526 012760 177777 000002      MOV      #1,2(R0)      ;R3 = CSRD-GROUP 2 DATA
1808 011534 105010                CLR      (R0)          ;TWO PASSES
1809 011536 105012                CLR      (R2)          ;FIRST PASS CSRA,CSRB = OUTPUT
1810 011540 112710 000204                MOV      #204,(R0)     ;CSRC,CSRD = INPUT
1811 011544 112712 000204                MOV      #204,(R2)     ;SEC PASS CSRC,CSRD = OUTPUT
1812 011550 112710 000020                MOV      #CIRMP,(R0)   ;CSRA,CSRB = INPUT
1813 011554 112712 000020                MOV      #CIRMP,(R2)
1814 011560 005760 000002      TST      2(R0)          ;SET CSR TO OUTPUT MODE
1815 011564 012737 000320 001124      MOV      #320,$GDDAT    ;SET CSR TO OUTPUT MODE
1816 011572 010037 001122      MOV      R0,#B0ADR     ;SET ALL ONES JBR FOR H TO L
1817 011576 111015                MOV      (R0),(R5)     ;CHIP RESET GROUP CSR
1818 011600 042715 000007      BIC      #7,(R5)       ;CHIP RESET GROUP CSR
1819 011604 023715 001124      CMP      $GDDAT,(R5)   ;LOAD MODE BITS FOR POLLED MODE
;LOAD MODE BITS FOR POLLED MODE
;CLEAR IMR+IRR
;CLEAR IMR+IRR
;READ DBR IN OUTPUT MODE,NO REPLY
;STORE EXPECTED
;STORE ADDRESS
;READ STATUS
;CLEAR UNDEFINED BITS
;CHECK STATUS

```

T45 TEST GROUPS 1,2 IN POLLED MODE,NO REPLY

```

1820 011610 001401      BEQ      1$
1821 011612 104007      ERROR+   7          ;CHIP STATUS ERROR
1822 011614 010237 001122 1$:      MOV      R2,$BDADR  ;STORE ADDRESS
1823 011620 111215      MOVVB   (R2),(R5)  ;READ STATUS
1824 011622 042715 000007      BIC     #7,(R5)    ;CLEAR UNDEFINED BITS
1825 011626 023715 001124      CMP     $GDDAT,(R5)
1826 011632 001401      BEQ     2$
1827 011634 104007      ERROR+   7          ; CHIP STATUS ERROR
1828 011636 012762 000000 000002 2$:      MOV     #0,2(R2)    ;WRITE ONLY,DBR INPUT MODE FOR NO REPLY
1829 011644 005761 000002      TST    2(R1)       ;READ DBR OUTPUT MODE,NO REPLY
1830 011650 012763 000000 000002      MOV     #0,2(R3)    ;WRITE ONLY, DBR INPUT MODE,NO REPLY
1831 011656 010137 001122      MOV     R1,$BDADR  ; CHIP DATA PORT
1832 011662 112710 000250      MOVVB  #MIRR,(R0)  ;LOAD BITS TO READ IRR
1833 011666 0C5037 001124      CLR     $GDDAT     ;IRR SHOULD BE ZERO
1834 011672 111115      MOVVB  (R1),(R5)   ;READ IRR
1835 011674 023715 001124      CMP     $GDDAT,(R5)
1836 011700 001412      BEQ     3$
1837 011702 005737 017344      TST    KXTFLAG    ; ON KXT11, READ-BEFORE-WRITE...;GPA
1838 011706 001406      BEQ     100$       ;...AT 2$ UPSETS EXPECTED IRR. ;GPA
1839 011710 012737 000300 001124      MOV     #300,$GDDAT ; TRY THE ALTERNATE VALUE. ;GPA
1840 011716 023715 001124      CMP     $GDDAT,(R5) ;GPA
1841 011722 001401      BEQ     3$         ;GPA
1842 011724 104003      ERROR+  3         ;IRR ERROR+ ;GPA
1843 011726 005037 001124 3$:      CLR     $GDDAT    ;GPA
1844 011732 010337 001122      MOV     R3,$BDADR ;CHIP DATA PORT
1845 011736 112712 000250      MOVVB  #MIRR,(R2) ;LOAD MODE BITS TO READ IRR
1846 011742 111315      MOVVB  (R3),(R5)  ;READ IRR BITS
1847 011744 023715 001124      CMP     $GDDAT,(R5)
1848 011750 001412      BEQ     4$
1849 011752 005737 017344      TST    KXTFLAG    ; ON KXT11, DITTO. ;GPA
1850 011756 001406      BEQ     101$      ;GPA
1851 011760 012737 000000 001124      MOV     #60,$GDDAT ; TRY THE ALTERNATE VALUE. ;GPA
1852 011766 023715 001124      CMP     $GDDAT,(R5) ;GPA
1853 011772 001401      BEQ     4$         ;GPA
1854 011774 104003      ERROR+  3         ;IRR ERROR+ ;GPA
1855 011776 005304 4$:      DEC     R4         ;FINISHED TWO PASSES
1856 012000 001413      BEQ     TST46     ;;BR IF EQUAL
1857 012002 004737 013164      JSR    PC,CLRCSR  ;CLEAR ALL CSRS
1858 012006 013700 001352      MOV     DRCSC,R0  ;SET UP FOR NEXT PASS
1859 012012 013701 001356      MOV     DRCSD,R1
1860 012016 013702 001342      MOV     DRCSA,R2
1861 012022 013703 001346      MOV     DRCSE,R3
1862 012026 000631      BR     111$       ;DO NEXT PASS
1863
1864
;*****
;*TEST 46 TEST POLLED MODE;CSRS C,D=OUT A,B=IN,ACTIVE LOW
;*****
TST46: SCOPE
1865 012030 000004      JSR    PC,CLRCSR  ;CLEAR ALL CSRS
1866 012032 004737 013164      ;R0 = CSRA-GROUP 1 CONTROL
1867 ;R1 = CSRB-GROUP 1 DATA
1868 ;R2 = CSRC-GROUP 2 CONTROL
1869 ;R3 = CSRD-GROUP 2 DATA
1870 012036 012737 012110 001110      MOV     #1,$LPERR  ;SCOPE LOOP RETURN
1871 012044 012704 013272      MOV     #BEGPAT,R4 ;PATTERN TABLE
1872 012050 112762 000001 000001      MOVVB  #BIT0,1(R2) ;SET CSRC TO OUTPUT MODE
1873 012056 112763 000001 000001      MOVVB  #BIT0,1(R3) ;SET CSRD TO OUTPUT MODE

```

T46 TEST POLLED MODE;CSRS C,D=OUT A,B=IN,ACTIVE LOW

```

1874 012064 105010          CLRAB (R0)          ;CHIP RESET GROUP 1 CSRA
1875 012066 105012          CLRAB (R2)          ;CHIP RESET GROUP 2 CSRC
1876 012070 112710 000204   MOVAB #204,(R0)     ;LOAD BITS FOR POLLED MODE,GR 1
1877 012074 112712 000204   MOVAB #204,(R2)     ;LOAD BITS FOR POLLED MODE,GR2
1878 012100 112710 000250   MOVAB #MIRR,(R0)    ;LOAD BITS TO READ IRR GRP 1
1879 012104 112712 000250   MOVAB #MIRR,(R2)    ;LOAD BITS TO READ IRR GRP 2
1880 012110 011462 000002   1$: MOV (R4),2(R2)    ;SET PATTERN DBRC FOR H TO L
1881 012114 012762 177777 000002   MOV #1,2(R2)        ;FORCE ALL BITS IN DRDBC HIGH
1882 012122 112710 000020   MOVAB #CIRMR,(R0)   ;CLEAR IMR+IRR GROUP 1
1883 012126 112712 000020   MOVAB #CIRMR,(R2)   ;CLEAR IMR+IRR GROUP 2
1884 012132 005114          COM (R4)            ;COMPLEMENT TABLE DATA
1885 012134 011462 000002   MOV (R4),2(R2)      ;XMIT CSR
1886 012140 012762 177777 000002   MOV #1,2(R2)        ;FORCE ALL BITS HIGH
1887 012146 005114          COM (R4)            ;RESTORE TABLE DATA
1888 012150 010137 001122   2$: MOV R1,#BDADR    ; GROUP 1 DATA PORT
1889 012154 111437 001124   MOVAB (R4),#GDDAT
1890 012160 111115          MOVAB (R1),(R5)     ;READ IRR,GROUP 1
1891 012162 023715 001124   CMP #GDDAT,(R5)
1892 012166 001401          BEQ 3$
1893 012170 104003          ERROR+ 3
1894 012172 010337 001122   3$: MOV R3,#BDADR    ; IRR ERROR,GROUP 1
1895 012176 116437 000001 001124   MOVAB 1(R4),#GDDAT ; GROUP 2 DATA PORT
1896 012204 042737 000360 001124   BIC #360,#GDDAT
1897 012212 052737 000020 001124   BIS #20,#GDDAT     ;SAVE BITS 0-3
1898 012220 111315          MOVAB (R3),(R5)     ;EXPECTED 0-3,URPLY 4(A)
1899 012222 023715 001124   CMP #GDDAT,(R5)    ;READ IRR BITS,GROUP 2
1900 012226 001401          BEQ 4$
1901 012230 104003          ERROR+ 3
1902 012232 005760 000002   4$: TST 2(R0)        ; IRR ERROR,GROUP 2
1903 012236 052737 000100 001124   BIS #100,#GDDAT    ;READ DBRA FOR RPLY 6(C)
1904 012244 111315          MOVAB (R3),(R5)     ;STORE EXPECTED
1905 012246 023715 001124   CMP #GDDAT,(R5)    ;READ IRR BITS,GROUP 2
1906 012252 001401          BEQ 5$
1907 012254 104003          ERROR+ 3
1908 012256 005063 000002   5$: CLR 2(R3)        ; IRR ERROR,GROUP 2
1909 012262 052737 000040 001124   BIS #40,#GDDAT     ;CLEAR DBRD FOR RPY 5(B)
1910 012270 111315          MOVAB (R3),(R5)     ;EXPECTED
1911 012272 023715 001124   CMP #GDDAT,(R5)    ;READ IRR BITS GROUP 2
1912 012276 001401          BEQ 6$
1913 012300 104003          ERROR+ 3
1914 012302 005761 000002   6$: TST 2(R1)        ; IRR ERROR,GROUP 2
1915 012306 052737 000200 001124   BIS #200,#GDDAT    ;READ DBRB FOR RPLY 7(D)
1916 012314 111315          MOVAB (R3),(R5)     ;READ IRR BITS GROUP2
1917 012316 023715 001124   CMP #GDDAT,(R5)
1918 012322 001401          BEQ 7$
1919 012324 104003          ERROR+ 3
1920 012326 005724   7$: TST (R4)        ; IRR ERROR,GROUP 2
1921 012330 020427 013572   CMP R4,#ENDDAT     ;INDEX DATA TABLE
1922 012334 001265          BNE 1$              ;CHECK FOR END
1923
1924
1925
1926

```

```

;*****
;+TEST 47 TEST IRR BITS WITH DATA PAT.,POLLED MODE,ACT. HIGH
;*****
TST47: SCOPE
JSR PC,CLRCR ;CLEAR ALL CSRS

```

```

1927 012336 000004
1927 012340 004737 013164

```

T47 TEST IRR BITS WITH DATA PAT., POLLED MODE, ACT. HIGH

```

1928 012344 012703 013272      MOV      #BEGPAT,R3      ;GET DATA PATTERN TABLE
1929 012350 012737 000001 001110  MOV      #1,$LPEERR      ;SET UP SCOPE ADDRESS
1930 012356 013700 001342      MOV      DRCSA,R0
1931 012362 013701 001346      MOV      DRCSB,R1
1932 012366 013702 001356      MOV      DRCSB,R2
1933 012372 112760 000001 000001  MOVB     #BIT0,1(R0)     ;CSRA OUTPUT MODE
1934 012400 112761 000001 000001  MOVB     #BIT0,1(R1)     ;CSRB OUTPUT MODE
1935 012406 112710 000224      MOVB     #224,(R0)       ;LOAD MODE BITS FOR POLLED MODE,GP1
1936 012412 112760 000224 000010  MOVB     #224,10(R0)     ;LOAD MODE BITS FOR POLLED MODE,GP2
1937 012420 005060 000002      1$: CLR      2(R0)         ;CLEAR DBRA
1938 012424 112710 000020      MOVB     #CIRMR,(R0)     ;CLEAR IMR + IRR GROUP 1
1939 012430 112760 000020 000010  MOVB     #CIRMR,10(R0)   ;CLEAR IMR + IRR GROUP 2
1940 012436 011360 000002      MOV      (R3),2(R0)      ;STORE PATTERN INTO DBRA
1941 012442 010137 001122      MOV      R1,$BDADR      ;CSRB ADDRESS
1942 012446 112710 000250      MOVB     #MIHR,(R0)     ;LOAD BITS TO READ IRR1
1943 012452 111337 001124      MOVB     (R3),$GDDAT
1944 012456 111115      MOVB     (R1),(R5)       ;READ IRR,GP1
1945 012460 023715 001124      CMP      $GDDAT,(R5)
1946 012464 001401      BEQ      2$
1947 012466 104003      ERROR+  3
1948 012470 010237 001122      2$: MOV      R2,$BDADR    ;IRR ERROR,GP1
1949 012474 112760 000250 000010  MOVB     #MIRR,10(R0)    ;CSRD ADDRESS
1950 012502 116337 000001 001124  MOVB     1(R3),$GDDAT    ;SET MODE TO READ IRR BITS GROUP 2
1951 012510 042737 000360 001124  BIC      #360,$GDDAT     ;BUILD EXPECTED DATA
1952 012516 052737 000100 001124  BIS      #100,$GDDAT     ;BITS 0-3 EXPECTED
1953 012524 111215      MOVB     (R2),(R5)       ;"A" REPLY EXPECTED
1954 012526 023715 001124      CMP      $GDDAT,(R5)
1955 012532 001401      BEQ      3$
1956 012534 104003      ERROR+  3
1957 012536 005723      3$: TST      (R3)+        ;IRR GROUP 2
1958 012540 020327 013572      CMP      R3,#ENDDAT     ;INDEX DATA TABLE
1959 012544 001325      BNE      1$             ;CHECK FOR PATTERN END
1960
1961
1962

```

; *TEST 50 TEST CSRA AND CSRB WITH RESET
;*****

```

012544 000004
1963 012550 012737 000001 001160  TST50: SCOPE
1964 012556 004737 013164      MOV      #1,$TIMES      ;DO 1 ITERATION
1965 012562 013700 001342      JSR      PC,CLRCR      ;CLEAR ALL CSRS
1966 012566 013701 001346      MOV      DRCSA,R0
1967 012572 112760 001001 000001  MOV      DRCSB,R1
1968 012600 112761 000001 000001  MOVB     #IE!BIT0,1(R0)  ;CSRA TO OUTPUT MODE
1969 012606 010037 001122      MOVB     #BIT0,1(R1)    ;SET CSRB TO OUTPUT MODE
1970 012612 012737 100300 001124  MOV      R0,$BDADR      ;STORE CSRA ADDRESS
1971 012620 000005      MOV      #100300,$GDDAT ;RDY + CHIP STATUS EXP'D
1972 012624 042715 000007      RESET
1973 012630 023715 001124      MOV      (R0),(R5)      ;INITIALIZE
1974 012634 001401      BIC      #7,(R5)        ;STORE REC'D
1975 012636 104002      CMP      $GDDAT,(R5)    ;CLEAR UNDEFINED BITS
1976 012640 012737 100000 001124  1$: BEQ      1$           ;MAKE COMPARE
1977 012646 010137 001122      ERROR+  2
1978 012652 011115      MOV      #100000,$GDDAT ;CSRA ERROR ON RESET
1979 012654 023715 001124      MOV      R1,$BDADR     ;STORE EXPECTED
1980 012660 001401      MOV      (R1),(R5)     ;CHECK CSRB
                                MOV      $GDDAT,(R5)   ;STORE IN $BDDAT
                                BEQ      TST51             ;MAKE COMPARE
                                ;BR IF EQUAL

```

T50 TEST CSRA AND CSRB WITH RESET

1981 012662 104002
1982
1983
1984

ERROR+ 2 ;CSRB ERROR WITH RESET

;;*****
; *TEST 51 TEST CSRC AND CSRD WITH RESET
;*****

012664 000004
012666 012737 000001 001160
1985 012674 004737 013164
1986 012700 013702 001352
1987 012704 013703 001356
1988 012710 112762 000001 000001
1989 012716 112763 000001 000001
1990 012724 010237 001122
1991 012730 012737 100200 001124
1992 012736 000005
1993 012740 011215
1994 012742 042715 000007
1995 012746 023715 001124
1996 012752 001401
1997 012754 100002
1998 012756 010337 001122
1999 012762 012737 100000 001124
2000 012770 011315
2001 012772 023715 001124
2002 012776 001401
2003 013000 104002
2004 013002
2005

TST51: SCOPE
MOV #1,\$TIMES ;DO 1 ITERATION
JSR PC,CLRCSR
MOV DRCS,R2
MOV DRCS,R3
MOVB #BIT0,1(R2) ;SET CSRC TO OUTPUT MODE
MOVB #BIT0,1(R3) ;SET CSRD TO OUTPUT MODE
MOV R2,\$BDADR ;STORE ADDRESS
MOV #100200,\$GDDAT ;RDY + CHIP STATUS
RESET ;INITIALIZE
MOV (R2),(R5) ;STORE CSRC
BIC #7,(R5) ;CLEAR UNDEFINED BITS
CMP \$GDDAT,(R5) ;MAKE COMPARE
BEQ 1\$
ERROR+ 2 ;CSRC ERROR WITH RESET
MOV R3,\$BDADR ;CHECK CSRD
MOV #100000,\$GDDAT ;STORE EXPECTED
MOV (R3),(R5) ;READ CSRD
CMP \$GDDAT,(R5) ;MAKE COMPARE
BEQ 2\$
ERROR+ 2 ;CSRD ERROR ON RESET

T51 TEST CSRC AND CSRD WITH RESFT

2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020

013002 013701 001342
013006 000241
013010 006037 001364
013014 001412
013016 162701 000020
013022 005237 001202
013026 032737 000001 001364
013034 001764
013036 000137 002100

```
;DON'T REPORT "EOP" UNTIL ALL SELECTED DRV11-J'S HAVE BEEN TESTED.
NXDEV: MOV DRCSA,R1 ;INIT TO SETUP NEXT DRV11J ADDRESSES
NXDEV1: CLC ;CLEAR CARRY FOR DEVICE MAP
ROR DMAP ;LOOK FOR NEXT DRV11J
BEQ $EOP ;BR IF ALL TESTED
SUB #20,R1 ;NEXT DRV11-J STARTS -20
INC $UNIT ;UPDATE UNIT NUMBER
BIT #1,DMAP ;IS UNIT SELECTED?
BEQ NXDEV1 ;NEXT,IF NOT SELECTED
JMP NEXPAS ;TEST NEXT DRV11-J
```

```
.SBTTL END OF PASS ROUTINE
;*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO START1
$EOP:
```

013042
013042 000240
013044 005037 001102
013050 005037 001160
013054 005237 001176
013060 042737 100000 001176
013066 005327
013070 000001
013072 003022
013074 012737
013076 000001
013100 013070
013102 104401 013147
013106 013746 001176
013112 104405
013114 104401 013144
013120 013700 000042
013124 001405
013126 000005
013130 004710
013132 000240
013134 000240
013136 000240
013140
013140 000137
013142 002034
013144 377 377 000
013147 015 012 105
013152 116 104 040
013155 120 101 123
013160 123 040 043
013163 000

```
NOP
CLR $TSTNM ;;ZERO THE TEST NUMBER
CLR $TTMES ;;ZERO THE NUMBER OF ITERATIONS
INC $PASS ;;INCREMENT THE PASS NUMBER
BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?
$EOPCT: .WORD 1
BGT $DOAGN ;;YES
MOV (PC)+,@(PC) ;;RESTORE COUNTER
$ENDCT: .WORD 1
TYPE , $ENDMG ;;TYPE "END PASS #"
MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE , $ENULL ;;TYPE A NULL CHARACTER
$GET42: MOV #042,R0 ;;GET MONITOR ADDRESS
BEQ $DOAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
$ENDAD: JSR PC,(R0) ;;GO TO MONITOR
NOP ;;SAVE ROOM
NOP ;;FOR
NOP ;;ACT11
$DOAGN: JMP @PC+ ;;RETURN
$RTNAD: .WORD START1
$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
$ENDMG: .ASCIZ <15><12>/END PASS #/
```

PROGRAM SUBROUTINES

```

2022          .SBTTL PROGRAM SUBROUTINES
2023
2024
2025          ;;*****
2026          ;CLEAR ALL CONTROL/STATUS REGISTERS
2027          ;INIT REGISTERS R0-R4 WITH CSRA-CSRD
2028          ;AND STORE $BDDAT INTO R5.
2029          ;;*****
2030 013164 012705 001126  CLRCR: MOV    $BDDAT,R5      ;BAD DATA STORAGE IN R5
2031 013170 013700 001342      MOV    DRCSA,R0      ;CSRA ADDRESS TO R0
2032 013174 013701 001346      MOV    DRCSB,R1      ;CSRB ADDRESS TO R1
2033 013200 013702 001352      MOV    DRCSA,R2      ;CSRC ADDRESS TO R2
2034 013204 013703 001356      MOV    DRCSA,R3      ;CSRD ADDRESS TO R3
2035 013210 005037 001124      CLR    $GDDAT        ;CLEAR EXPECTED
2036 013214 005015              CLR    (R5)          ;CLEAR REC'D
2037 013216 005010              CLR    (R0)          ;CLEAR CSRA;CHIP RESET GROUP 1
2038 013220 105061 000001      CLR    1(R1)         ;CLEAR HIGH BYTE CSRB
2039 013224 005012              CLR    (R2)          ;CLEAR CSRC;CHIP RESET GROUP 2
2040 013226 105063 000001      CLR    1(R3)         ;CLEAR HIGH BYTE CSRD
2041 013232 000207              RTS    PC
2042
2043
2044          ;CLEAR IRR REGISTERS,GROUP 1,GROUP 2 WITH CHIP RESET
2045 013234 010046              CLRIRR: MOV   R0,-(SP)
2046 013236 013700 001342      MOV    DRCSA,R0      ;START OF CSR ADDRESS
2047 013242 105060 000011      CLR    11(R0)        ;CSRC TO INPUT MODE
2048 013246 112760 000001 000001  MOV    $BIT0,1(R0)   ;CSRA TO OUTPUT MODE
2049 013254 005060 000002      CLR    2(R0)         ;CLEAR DBRA
2050 013260 105010              CLR    (R0)          ;CHIP RESET OF GROUP1
2051 013262 105060 000010      CLR    10(R0)        ;CHIP RESET OF GROUP 2
2052 013266 012600              MOV    (SP)+,R0     ;RESTORE REGISTER
2053 013270 000207              RTS    PC
2054

```

PROGRAM SUBROUTINES

```

2056
2057      .SBTTL PATTERNS FOR REGISTER R/W
2058      ;
2059      ;PATTERNS USED FOR LOADING/READING REGISTERS
2060
2061 013272 000000      BEGPAT: 0          ;GROWING 1
2062 013274 000001      BGPAT1: 1
2063 013276 000003          3
2064 013300 000007          7
2065 013302 000017          17
2066 013304 000037          37
2067 013306 000077          77
2068 013310 000177          177
2069 013312 000377          377
2070 013314 000777      EDCHP1: 777
2071 013316 001777          1777
2072 013320 003777          3777
2073 013322 007777          7777
2074 013324 017777          17777
2075 013326 037777          37777
2076 013330 077777          77777
2077 013332 177777          177777
2078 013334 177776      BGCHP2: 177776      ;GROWING 0
2079 013336 177774          177774
2080 013340 177770          177770
2081 013342 177760          177760
2082 013344 177740          177740
2083 013346 177700          177700
2084 013350 177600          177600
2085 013352 177400      EDCHP2: 177400
2086 013354 177000          177000
2087 013356 176000          176000
2088 013360 174000          174000
2089 013362 170000          170000
2090 013364 160000          160000
2091 013366 140000          140000
2092 013370 100000          100000
2093
2094 013372 000000      BGCHP3: 000000      ;WALKING 1
2095 013374 000001          1
2096 013376 000002          2
2097 013400 000004          4
2098 013402 000010          10
2099 013404 000020          20
2100 013406 000040          40
2101 013410 000100          100
2102 013412 000200          200
2103 013414 000400      EDCHP3: 400
2104 013416 001000          1000
2105 013420 002000          2000
2106 013422 004000          4000
2107 013424 010000          10000
2108 013426 020000          20000
2109 013430 040000          40000
2110 013432 100000          100000
2111 013434 177777          177777      ;WALKING 0
2112 013436 177776      BGCHP4: 177776

```

N4

PATTERNS FOR REGISTER R/W

2113	013440	177775	177775
2114	013442	177773	177773
2115	013444	177767	177767
2116	013446	177757	177757
2117	013450	177737	177737
2118	013452	177677	177677
2119	013454	177577	177577
2120	013456	177377	EDCHP4: 177377
2121	013460	176777	176777
2122	013462	175777	175777
2123	013464	173777	173777
2124	013466	167777	167777
2125	013470	157777	157777
2126	013472	137777	137777
2127	013474	077777	077777
2128	013476	177777	177777
2129	013500	000000	ENDPAT: 000000
2130			
2131			;DATA PATTERNS
2132	013502	155555	PATDAT: 155555
2133	013504	133333	133333
2134	013506	066666	066666
2135	013510	125252	125252
2136	013512	052525	052525
2137	013514	177777	177777
2138	013516	000000	000000
2139	013520	107070	107070
2140	013522	070707	070707
2141	013524	144444	144444
2142	013526	033333	033333
2143	013530	011111	011111
2144	013532	022222	022222
2145	013534	044444	044444
2146	013536	111111	111111
2147	013540	166666	166666
2148	013542	010421	010421
2149	013544	021042	021042
2150	013546	031463	031463
2151	013550	042104	042104
2152	013552	063146	063146
2153	013554	073567	073567
2154	013556	104210	104210
2155	013560	114631	114631
2156	013562	135673	135673
2157	013564	146314	146314
2158	013566	156735	156735
2159	013570	167356	167356
2160	013572	000000	ENDDAT: 000000
2161			

SYSMAC ROUTINES

2163
2164
2165

.SBTTL SYSMAC ROUTINES

```

.SBTTL TYPE ROUTINE
;*****
;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;NOTE1:      $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;NOTE2:      $FILLC CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;NOTE3:      $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;
;CALL:
;1) USING A TRAP INSTRUCTION
;*      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;OR
;*      TYPE
;*      MESADR
;
013574 105737 001157      $TYPE: 1STB      $TPFLG      ;;IS THERE A TERMINAL?
013600 100002      BPL      1$      ;;BR IF YES
013602 000000      HALT      ;;HALT HERE IF NO TERMINAL
013604 000430      BR      3$      ;;LEAVE
013606 010046      1$:  MOV      RO,-(SP)      ;;SAVE RO
013610 017600 000002      MOV      @2(SP),RO      ;;GET ADDRESS OF ASCIZ STRING
013614 122737 000001 001210      CMPB     @APTENV,$ENV      ;;RUNNING IN APT MODE
013622 001011      BNE      62$      ;;NO,GO CHECK FOR APT CONSOLE
013624 132737 000100 001211      BITB     @APTPOOL,$ENVM      ;;SPOOL MESSAGE TO APT
013632 001405      BEQ      62$      ;;NO,GO CHECK FOR CONSOLE
013634 010037 013644      MOV      RO,61$      ;;SETUP MESSAGE ADDRESS FOR APT
013640 004737 014136      JSR      PC,$ATY3      ;;SPOOL MESSAGE TO APT
013644 000000      61$:  .WORD      0      ;;MESSAGE ADDRESS
013646 132737 000040 001211 62$:  BITB     @APTCSUP,$ENVM      ;;APT CONSOLE SUPPRESSED
013654 001003      BNE      60$      ;;YES,SKIP TYPE OUT
013656 112046      2$:  MOVB     (RO)+,-(SP)      ;;PUSH CHARACTER TO BE TYPED ONTO STACK
013660 001005      BNE      4$      ;;BR IF IT ISN'T THE TERMINATOR
013662 005726      TST      (SP)+      ;;IF TERMINATOR POP IT OFF THE STACK
013664 012600      60$:  MOV      (SP)+,RO      ;;RESTORE RO
013666 062716 000002      3$:  ADD      @2,(SP)      ;;ADJUST RETURN PC
013672 000002      RTI      ;;RETURN
013674 122716 000C11      4$:  CMPB     @HT,(SP)      ;;BRANCH IF <HT>
013700 001430      BEQ      8$      ;;BRANCH IF NOT <CRLF>
013702 122716 000200      CMPB     @CRLF,(SP)
013706 001006      BNE      5$      ;;POP <CR><LF> EQUIV
013710 005726      TST      (SP)+      ;;TYPE A CR AND LF
013712 104401      TYPE
013714 001165      $CRLF
013716 105037 014124      CLRB     $CHARCNT      ;;CLEAR CHARACTER COUNT
013722 000755      BR      2$      ;;GET NEXT CHARACTER
013724 004737 014006      5$:  JSR      PC,$TYPEC      ;;GO TYPE THIS CHARACTER
013730 123726 001156      6$:  CMPB     $FILLC,(SP)+      ;;IS IT TIME FOR FILLER CHARS.?
013734 001350      BNE      2$      ;;IF NO GO GET NEXT CHAR.
013736 013746 001154      MOV      $NULL,-(SP)      ;;GET # OF FILLER CHARS. NEEDED
                                ;;AND THE NULL CHAR.
013742 105366 000001      7$:  DECB     1(SP)      ;;DOES A NULL NEED TO BE TYPED?
013746 002770      BLT      6$      ;;BR IF NO--GO POP THE NULL OFF OF $YACK
013750 004737 014006      JSR      PC,$TYPEC      ;;GO TYPE A NULL
013754 105337 014124      DECB     $CHARCNT      ;;DO NOT COUNT AS A COUNT
013760 000770      BR      7$      ;;LOOP

```

TYPE ROUTINE

```

;HORIZONTAL TAB PROCESSOR
013762 112716 000040      8$:  MOVB  0' ,(SP)      ;;REPLACE TAB WITH SPACE
013766 004737 014006      9$:  JSR   PC,$TYPEC     ;;TYPE A SPACE
013772 132737 000007 014124  BITB  07,$CHARCNT     ;;BRANCH IF NOT AT
014000 001372              BNE   9$                ;;TAB STOP
014002 005726              TST   (SP)+              ;;POP SPACE OFF STACK
014004 000724              BR    2$                ;;GET NEXT CHARACTER
014006              $TYPEC:
014006 105777 165132      TSTB  0$TKS           ;;CHAR IN KYBD BUFFER?      ;MJD001
014012 100022              BPL  10$             ;;BR IF NOT                ;MJD001
014014 017746 165126      MOV   0$TKB, -(SP)     ;;GET CHAR                  ;MJD001
014020 042716 177600      BIC  0177600,(SP)     ;;STRIP EXTRANEIOUS BITS  ;MJD001
014024 122716 000023      CMPB  0$XOFF,(SP)     ;;WAS CHAR XOFF           ;MJD001
014030 001012              BNE  102$            ;;BR IF NOT                ;MJD001
014032              101$:
014032 105777 165106      TSTB  0$TKS           ;;WAIT FOR CHAR            ;MJD001
014036 100375              BPL  101$            ;;BR IF NOT                ;MJD001
014040 117716 165102      MOVB  0$TKB,(SP)     ;;GET CHAR                  ;MJD001
014044 042716 177600      BIC  0177600,(SP)     ;;STRIP IT                 ;MJD001
014050 122716 000021      CMPB  0$XON,(SP)     ;;WAS IT XON?            ;MJD001
014054 001366              BNE  101$            ;;BR IF NOT                ;MJD001
014056              102$:
014056 005726              TST   (SP)+          ;;FIX STACK                ;MJD001
014060              10$:
014060 105777 165064      TSTB  0$TPS           ;;WAIT UNTIL PRINTER IS  ;MJD001
014064 100375              BPL  10$             ;;BR IF NOT                ;MJD001
014066 116677 000002 165056  MOVB  2(SP),0$TPB     ;;LOAD CHAR TO BE TYPED  ;MJD001
014074 122766 000015 000002  CMPB  0CR,2(SP)       ;;IS CHARACTER A LARRIGE  ;MJD001
014102 001003              BNE  1$              ;;BRANCH IF NO            ;MJD001
014104 105037 014124      CLRB  $CHARCNT       ;;YES--CLEAR CHARACTER    ;MJD001
014110 000406              BR    $TYPEX         ;;EXIT                     ;MJD001
014112 122766 000012 000002  1$:  CMPB  0LF,2(SP)       ;;IS CHARACTER A LINE    ;MJD001
014120 001402              BEQ  $TYPEX         ;;BRANCH IF YES           ;MJD001
014122 105227              INCB  (PC)+          ;;COUNT THE CHARACTER    ;MJD001
014124 000000              $CHARCNT: .WORD 0    ;;CHARACTER COUNT        ;MJD001
014126 000207              $TYPEX: RTS PC
2166  .SBTTL  APT COMMUNICATIONS ROUTINE
;*****
014130 112737 000001 014374  $ATY1: MOVB  01,$FFLG     ;;TO REPORT FATAL ERROR
014136 112737 000001 014372  $ATY3: MOVB  01,$MFLG     ;;TO TYPE A MESSAGE
014144 000403              BR    $ATYC
014146 112737 000001 014374  $ATY4: MOVB  01,$FFLG     ;;TO ONLY REPORT FATAL  ;MJD001
014154 010046              $ATYC:
014154 010146              MOV   R0, -(SP)      ;;PUSH R0 ON STACK
014156 010146              MOV   R1, -(SP)      ;;PUSH R1 ON STACK
014160 105737 014372      TSTB  $MFLG           ;;SHOULD TYPE A MESSAGE?
014164 001450              BEQ  5$              ;;IF NOT: BR
014166 122737 000001 001210  CMPB  0APTENV,$ENV     ;;OPERATING UNDER APT?
014174 001031              BNE  3$              ;;IF NOT: BR
014176 132737 000100 001211  BITB  0APTPOOL,$ENVM   ;;SHOULD SPOOL MESSAGES?
014204 001425              BEQ  3$              ;;IF NOT: BR
014206 017600 000004      MOV   04(SP),R0      ;;GET MESSAGE ADDR.
014212 062766 000002 000004  ADD   02,4(SP)        ;;BUMP RETURN ADDR.
014220 005737 001170      1$:  TST   $MSGTYPE       ;;SEE IF DONE W/ LAST XMISSION?
014224 001375              BNE  1$              ;;IF NOT: WAIT
014226 010037 001204      MOV   R0,$MSGAD      ;;PUT ADDR IN MAILBOX
014232 105720      2$:  TSTB  (R0)+          ;;FIND END OF MESSAGE

```

APT COMMUNICATIONS ROUTINE

```

014234 001376      BNE      2$
014236 163700 001204  SUB      $MSGAD,R0      ;;SUB START OF MESSAGE
014242 006200      ASK      R0              ;;GET MESSAGE LNPTH IN WORDS
014244 010037 001206  MOV      R0,$MSGLGT     ;;PUT LENGTH IN MAILBOX
014250 012737 000004 001170  MOV      04,$MSGTYPE    ;;TELL APT TO TAKE MSG.
014256 000413      BR       5$
014260 017637 000004 014304 3$:  MOV      04(SP),4$      ;;PUT MSG ADDR IN JSR LINKAGE
014266 062766 000002 000004  ADD      02,4(SP)      ;;BUMP RETURN ADDRESS
014274 013746 177776  MOV      177776,-(SP)   ;;PUSH 177776 ON STACK
014300 004737 013574  JSR     PC,$TYPE       ;;CALL TYPE MACRO
014304 000000      .WORD   0
014306      4$:
014306      5$:
014306 105737 014374 10$:  TSTB    $FFLG          ;;SHOULD REPORT FATAL ERROR?
014312 001416      BEQ     12$            ;;IF NOT: BR
014314 005737 001210  TST     $ENV           ;;RUNNING UNDER APT?
014320 001413      BEQ     12$            ;;IF NOT: BR
014322 005737 001170 11$:  TST     $MSGTYPE      ;;FINISHED LAST MESSAGE?
014326 001375      BNE     11$           ;;IF NOT: WAIT
014330 017637 000004 001172  MOV      04(SP),$FATAL  ;;GET ERROR #
014336 062766 000002 000004  ADD      02,4(SP)      ;;BUMP RETURN ADDR.
014344 005237 001170  INC     $MSGTYPE      ;;TELL APT TO TAKE ERROR
014350 105037 014374 12$:  CLRB    $FFLG          ;;CLEAR FATAL FLAG
014354 105037 014373  CLRB    $LFLG          ;;CLEAR LOG FLAG
014360 105037 014372  CLRB    $MFLG          ;;CLEAR MESSAGE FLAG
014364 012601      MOV     (SP)+,R1       ;;POP STACK INTO R1
014366 012600      MOV     (SP)+,R0       ;;POP STACK INTO R0
014370 000207      RTS     PC            ;;RETURN
014372      000      $MFLG: .BYTE 0      ;;MSSG. FLAG
014373      000      $LFLG: .BYTE 0      ;;LOG FLAG
014374      000      $FFLG: .BYTE 0      ;;FATAL FLAG

```

```

000200  APTSIZE=200
000001  APTENV=001
000100  APTSPOOL=100
000040  APTCSUP=040

```

2167

```

.SBTL  BINARY TO OCTAL (ASCII) AND TYPE
;*****
; THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
; OCTAL (ASCII) NUMBER AND TYPE IT.
; $TYPOS-- ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
; *CALL:
; *   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
; *   TYPOS    ;;CALL FOR TYPEOUT
; *   .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
; *   .BYTE   M              ;;M=1 OR 0
; *                               ;;1=TYPE LEADING ZEROS
; *                               ;;0=SUPPRESS LEADING ZEROS
; *
; * $TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
; * $TYPOS OR $TYPOC
; *CALL:
; *   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
; *   TYPON    ;;CALL FOR TYPEOUT
; *
; * $TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
; *CALL:
; *   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED

```

BINARY TO OCTAL (ASCII) AND TYPE

```

014376 017646 000000          ;*          TYP0C          ;;CALL FOR TYPEOUT
014402 116637 000001 014621 $TYP05: MOV      2(SP),-(SP)      ;;PICKUP THE MODE
014410 112637 014623          MOV      1(SP),%OFILL      ;;LOAD ZERO FILL SWITCH
014414 062716 000002          MOV      (SP)+,%OMODE+1    ;;NUMBER OF DIGITS TO TYPE
014420 000406                ADD      2,(SP)          ;;ADJUST RETURN ADDRESS
014422 112737 000001 014621 $TYP0C: MOV      21,%OFILL      ;;SET THE ZERO FILL SWITCH
014430 112737 000006 014623 MOV      26,%OMODE+1    ;;SET FOR SIX(6) DIGITS
014436 112737 000005 014620 $TYP0N: MOV      25,%OCNT      ;;SET THE ITERATION COUNT
014444 010346                MOV      R3,-(SP)       ;;SAVE R3
014446 010446                MOV      R4,-(SP)       ;;SAVE R4
014450 010546                MOV      R5,-(SP)       ;;SAVE R5
014452 113704 014623          MOV      %OMODE+1,R4    ;;GET THE NUMBER OF DIGITS TO TYPE
014456 005404                NEG      R4
014460 062704 000006          ADD      26,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
014464 110437 014622          MOV      R4,%OMODE      ;;SAVE IT FOR USE
014470 113704 014621          MOV      %OFILL,R4      ;;GET THE ZERO FILL SWITCH
014474 016605 000012          MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
014500 005003                CLR      R3              ;;CLEAR THE OUTPUT WORD
014502 005105                1$: ROL      R5          ;;ROTATE MSB INTO "C"
014504 000404                BR      3$              ;;GO DO MSB
014506 006105                2$: ROL      R5          ;;FORM THIS DIGIT
014510 006105                ROL      R5
014512 006105                ROL      R5
014514 010503                MOV      R5,R3
014516 006103                3$: ROL      R3          ;;GET LSB OF THIS DIGIT
014520 105337 014622          DECB    %OMODE          ;;TYPE THIS DIGIT?
014524 100016                BPL     7$              ;;BR IF NO
014526 042703 177770          BIC     2177770,R3      ;;GET RID OF JUNK
014532 001002                BNE     4$              ;;TEST FOR 0
014534 005704                TST     R4              ;;SUPPRESS THIS 0?
014536 001403                BEQ     5$              ;;BR IF YES
014540 005204                4$: INC     R4          ;;DON'T SUPPRESS ANYMORE 0'S
014542 052703 000060          BIS     2'0,R3         ;;MAKE THIS DIGIT ASCII
014546 052703 000040          5$: BIS     2',R3        ;;MAKE ASCII IF NOT ALREADY
014552 110337 014616          MOV      R3,8$         ;;SAVE FOR TYPING
014556 104401 014616          TYPE    ,8$           ;;GO TYPE THIS DIGIT
014562 105337 014620          7$: DECB    %OCNT      ;;COUNT BY 1
014566 003347                BGT     2$              ;;BR IF MORE TO DO
014570 002402                BLT     6$              ;;BR IF DONE
014572 005204                INC     R4              ;;INSURE LAST DIGIT ISN'T A BLANK
014574 000744                BR      2$              ;;GO DO THE LAST DIGIT
014576 012605                5$: MOV     (SP)+,R5      ;;RESTORE R5
014600 012604                MOV     (SP)+,R4      ;;RESTORE R4
014602 012603                MOV     (SP)+,R3      ;;RESTORE R3
014604 016666 000002 000004 MOV     2(SP),4(SP)     ;;SET THE STACK FOR RETURNING
014612 012616                MOV     (SP)+,(SP)
014614 000002                RTI
014616 000                8$: .BYTE 0          ;;RETURN
014617 000                .BYTE 0          ;;STORAGE FOR ASCII DIGIT
014620 000                $OCNT: .BYTE 0     ;;TERMINATOR FOR TYPE ROUTINE
014621 000                $OFILL: .BYTE 0    ;;OCTAL DIGIT COUNTER
014622 000000                $OMODE: .WORD 0    ;;ZERO FILL SWITCH
                                ;;NUMBER OF DIGITS TO TYPE
.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
;*****
;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT, DEPENDING ON WHETHER THE

```


CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
; *REPLACED WITH SPACES.
; *CALL:
; *
; *      MOV      NUM, -(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
; *      TYPDS   ;;GO TO THE ROUTINE
; *
; *TYPDS:
014624      MOV      R0, -(SP)          ;;PUSH R0 ON STACK
014626      MOV      R1, -(SP)          ;;PUSH R1 ON STACK
014630      MOV      R2, -(SP)          ;;PUSH R2 ON STACK
014632      MOV      R3, -(SP)          ;;PUSH R3 ON STACK
014634      MOV      R5, -(SP)          ;;PUSH R5 ON STACK
014636      MOV      #20200, -(SP)      ;;SET BLANK SWITCH AND SIGN
014642      MOV      20(SP), R5         ;;GET THE INPUT NUMBER
014646      BPL     1$                 ;;BR IF INPUT IS POS.
014650      NEG      R5                 ;;MAKE THE BINARY NUMBER POS.
014652      MOVVB   #'-, 1(SP)         ;;MAKE THE ASCII NUMBER NEG.
014660      CLR      R0                 ;;ZEPO THE CONSTANTS INDEX
014662      MOV      #DBLK, R3          ;;SETUP THE OUTPUT POINTER
014666      MOVVB   #' , (R3)+         ;;SET THE FIRST CHARACTER TO A BLANK
014672      CLR      R2                 ;;CLEAR THE BCD NUMBER
014674      MOV      $DTBL(R0), R1      ;;GET THE CONSTANT
014700      SUB      R1, R5             ;;FORM THIS BCD DIGIT
014702      BLT     4$                 ;;BR IF DONE
014704      INC      R2                 ;;INCREASE THE BCD DIGIT BY 1
014706      BR      3$
014710      ADD      R1, R5             ;;ADD BACK THE CONSTANT
014712      TST     R2                 ;;CHECK IF BCD DIGIT=0
014714      BNE     5$                 ;;FALL THROUGH IF 0
014716      TSTB   (SP)                ;;STILL DOING LEADING 0'S?
014720      BMI     7$                 ;;BR IF YES
014722      ASLB   (SP)                ;;MSD?
014724      BCC     6$                 ;;BR IF NO
014726      MOVVB   1(SP), -1(R3)      ;;YES--SET THE SIGN
014734      BIS     #'0, R2            ;;MAKE THE BCD DIGIT ASCII
014740      BIS     #' , R2            ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
014744      MOVVB   R2, (R3)+         ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
014746      TST     (R0)+             ;;JUST INCREMENTING
014750      CMP     R0, #10            ;;CHECK THE TABLE INDEX
014754      BLT     2$                 ;;GO DO THE NEXT DIGIT
014756      BGT     8$                 ;;GO TO EXIT
014760      MOV     R5, R2             ;;GET THE LSD
014762      BR      6$
014764      TSTB   (SP)+              ;;WAS THE LSD THE FIRST NON-ZERO?
014766      BPL     9$                 ;;BR IF NO
014770      MOVVB   -1(SP), -2(R3)    ;;YES--SET THE SIGN FOR TYPING
014776      CLR    (R3)                ;;SET THE TERMINATOR
015000      MOV     (SP)+, R5           ;;POP STACK INTO R5
015002      MOV     (SP)+, R3           ;;POP STACK INTO R3
015004      MOV     (SP)+, R2           ;;POP STACK INTO R2
015006      MOV     (SP)+, R1           ;;POP STACK INTO R1
015010      MOV     (SP)+, R0           ;;POP STACK INTO R0
015012      TYPE   , $DBLK             ;;NOW TYPE THE NUMBER
015016      MOV     2(SP), 4(SP)       ;;ADJUST THE STACK
015024      MOV     (SP)+, (SP)
015026      RTI
015030      $DTBL: 10000.
; *RETURN TO USER

```

CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

015032 001750          1000.
015034 000144          100.
015036 000012          10.
015040
0169 $DBLK: .BLKW 4
      .SBTTL ERROR HANDLER ROUTINE
      ;*****
      ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
      ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
      ;*AND GO TO SWRCK ON ERROR
      ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
      ;*SW15=1 HALT ON ERROR
      ;*SW13=1 INHIBIT ERROR TIMEOUTS
      ;*SWC9=1 LOOP ON ERROR
      ;*CALL
      ;* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER
015050 $ERROR:
015050 104407          CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
015052 104407          CKSWR ;GO LOOK FOR SWR CHANGE
015054 105237 001103 7$: INCB $ERFLG ;;SET THE ERROR FLAG
015060 001775          BEQ 7$ ;;DON'T LET THE FLAG GO TO ZERO
015062 013777 .001102 164052 MOV $TSTNM,$DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
015070 005237 001112 INC $ERTTL ;;INC THE ERROR COUNT
015074 011637 001116 MOV (SP),$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
015100 162737 000002 001116 SUB #2,$ERRPC
015106 117737 164004 001114 MOVB #1ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
015114 032777 020000 164016 BIT #BIT13,$SWR ;;SKIP TIMEOUT IF SET
015122 001004          BNE 20$ ;;SKIP TIMEOUTS
015124 004737 015224 JSR PC,SWRCK ;;GO TO USER ERROR ROUTINE
015130 104401 001165 TYPE ,#CRLF
015134
015134 122737 000001 001210 20$: CMPB #APTENV,$ENV ;;RUNNING IN APT MODE
015142 001007          BNE 2$ ;;NO,SKIP APT ERROR REPORT
015144 113737 001114 015156 MOVB $ITEMB,21$ ;;SET ITEM NUMBER AS ERROR NUMBER
015152 004737 014146 JSR PC,$ATY4 ;;REPORT FATAL ERROR TO APT
015156 000          .BYTE 0
015157 000          .BYTE 0
015160 000777          BR 22$ ;;APT ERROR LOOP
015162 005777 163752 2$: TST #SWR ;;HALT ON ERROR
015166 100002          BPL 3$ ;;SKIP IF CONTINUE
015170 000000          HALT ;;HALT ON ERROR!
015172 104407          CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
015174 032777 001000 163736 3$: BIT #BIT09,$SWR ;;LOOP ON ERROR SWITCH SET?
015202 001402          BEQ 4$ ;;BR IF NO
015204 013716 001110 MOV $LPERR,(SP) ;;FUDGE RETURN FOR LOOPING
015210 005737 001162 4$: TST $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
015214 001402          BEQ 5$ ;;BR IF NONE
015216 013716 001162 MOV $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
015222
015222 000002          5$: RTI ;;RETURN
2170 ;*****
2171 ;GO TYPE ERROR
2172 ;GO UPDATE SOFTWARE SWR IF 'CNTRL/G'
2173 ;*****
2174 015224 113737 001102 001362 SWRCK: MOVB $TSTNM,TSTNUM ;SET UP TEST # ON ER
2175 015232 004737 015242 JSR PC,$ERRTYP ;GO TYPE ERROR
2176 015236 104407 CKSWR ;GO LOOK FOR SWR CHANGE
2177 015240 000207 RTS PC ;RETURN TO ERROR HANDLER

```

ERROR MESSAGE TYPEOUT ROUTINE

2178

```

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE
;*****
;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
$ERRTYP:
015242      015242 104401 001165      TYPE      , $CRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
015246      015246 010046      MOV        RO, -(SP)    ;; SAVE RO
015250      015250 005000      CLR        RO          ;; PICKUP THE ITEM INDEX
015252      015252 153700 001114      BISB      @#$ITEMB,RO
015256      015256 001004      BNE       1$          ;; IF ITEM NUMBER IS ZERO, JUST
                                ;; TYPE THE PC OF THE ERROR
015260      015260 013746 001116      MOV        $ERRPC, -(SP) ;; SAVE $ERRPC FOR TYPEOUT
                                ;; ERROR ADDRESS
015264      015264 104402      TYPOC      ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
015266      015266 000426      BR         6$          ;; GET OUT
015270      015270 005300      1$: DEC     RO          ;; ADJUST THE INDEX SO THAT IT WILL
015272      015272 006300      ASL       RO          ;; WORK FOR THE ERROR TABLE
015274      015274 006300      ASL       RO
015276      015276 006300      ASL       RO
015300      015300 062700 001252      ADD        @#$ERRTB,RO  ;; FORM TABLE POINTER
015304      015304 012037 015314      MOV        (RO)+, 2$   ;; PICKUP "ERROR MESSAGE" POINTER
015310      015310 001404      BEQ       3$          ;; SKIP TYPEOUT IF NO POINTER
015312      015312 104401      TYPE      ;; TYPE THE "ERROR MESSAGE"
015314      015314 000000      2$: .WORD   0          ;; "ERROR MESSAGE" POINTER GOES HERE
015316      015316 104401 001165      TYPE      , $CRLF     ;; "CARRIAGE RETURN" & "LINE FEED"
015322      015322 012037 015332      3$: MOV        (RO)+, 4$   ;; PICKUP "DATA HEADER" POINTER
015326      015326 001404      BEQ       5$          ;; SKIP TYPEOUT IF 0
015330      015330 104401      TYPE      ;; TYPE THE "DATA HEADER"
015332      015332 000000      4$: .WORD   0          ;; "DATA HEADER" POINTER GOES HERE
015334      015334 104401 001165      TYPE      , $CRLF     ;; "CARRIAGE RETURN" & "LINE FEED"
015340      015340 011000      5$: MOV        (RO),RO   ;; PICKUP "DATA TABLE" POINTER
015342      015342 001004      BNE       7$          ;; GO TYPE THE DATA
015344      015344 012600      6$: MOV        (SP)+,RO   ;; RESTORE RO
015346      015346 104401 001165      TYPE      , $CRLF     ;; "CARRIAGE RETURN" & "LINE FEED"
015352      015352 000207      RTS       PC          ;; RETURN
015354      015354      7$:
015354      015354 013046      MOV        @$(RO)+, -(SP) ;; SAVE @$(RO)+ FOR TYPEOUT
015356      015356 104402      TYPOC      ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
015360      015360 005710      TST       (RO)        ;; IS THERE ANOTHER NUMBER?
015362      015362 001770      BEQ       6$          ;; BR IF NO
015364      015364 104401 015372      TYPE      , 8$        ;; TYPE TWO(2) SPACES
015370      015370 000771      BR         7$          ;; LOOP
015372      015372      040      000 8$: .ASCIZ  / /          ;; TWO(2) SPACES
                                .EVEN

```

2179

```

.SBTTL SCOPE HANDLER ROUTINE
;*****
;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;*SW14=1 LOOP ON TEST
;*SW11=1 INHIBIT ITERATIONS
;*SW09=1 LOOP ON ERROR
;*SW08=1 LOOP ON TEST IN SWR<7:0>
;*CALL
;* SCOPE      ;;SCOPE=10T

```

SCOPE HANDLER ROUTINE

```

015376          $SCOPE:
015376 104407          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
015400 032777 040000 163532 1$: BIT    #BIT14,#SWR          ;;LOOP ON PRESENT TEST?
015406 001114          BNE    $OVER          ;;YES IF SW14=1
          ;*****START OF CODE FOR THE XOR TESTER*****
015410 000416          $XTSTR: BR    6$          ;;IF RUNNING ON THE "XOR" TESTER CHANGE
          ;; THIS INSTRUCTION TO A "NOP" (NOP=240)
015412 013746 000004          MOV    #ERRVEC,-(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
015416 012737 015436 000004          MOV    #5,#ERRVEC          ;;SET FOR TIMEOUT
015424 005737 177060          TST    #177060          ;;TIME OUT ON XOR?
015430 012637 000004          MOV    (SP)+,#ERRVEC          ;;RESTORE THE ERROR VECTOR
015434 000463          BR    $SVLAD          ;;GO TO THE NEXT TEST
015436 022626          5$: CMP    (SP)+,(SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
015440 012637 000004          MOV    (SP)+,#ERRVEC          ;;RESTORE THE ERROR VECTOR
015444 000423          BR    7$          ;;LOOP ON THE PRESENT TEST
015446          6$: ;*****END OF CODE FOR THE XOR TESTER*****
015446 032777 000400 163464          BIT    #BIT08,#SWR          ;;LOOP ON SPEC. TEST?
015454 001404          BEQ    2$          ;;BR IF NO
015456 127737 163456 001102          CMPB  #SWR,$TSTNM          ;;ON THE RIGHT TEST? SWR<7:0>
015464 001465          BEQ    $OVER          ;;BR IF YES
015466 105737 001103          2$: TSTB  $ERFLG          ;;HAS AN ERROR OCCURRED?
015472 001421          BEQ    3$          ;;BR IF NO
015474 123737 001115 001103          CMPB  $ERMAX,$ERFLG          ;;MAX. ERRORS FOR THIS TEST OCCURRED?
015502 101015          BHI    3$          ;;BR IF NO
015504 032777 001000 163426          BIT    #BIT09,#SWR          ;;LOOP ON ERROR?
015512 001404          BEQ    4$          ;;BR IF NO
015514 013737 001110 001106          7$: MOV    $LPERR,$LPADR          ;;SET LOOP ADDRESS TO LAST SCOPE
015522 000446          BR    $OVER
015524 105037 001103          4$: CLRB  $ERFLG          ;;ZERO THE ERROR FLAG
015530 005037 001160          CLR    $TIMES          ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
015534 000415          BR    1$          ;;ESCAPE TO THE NEXT TEST
015536 032777 004000 163374          3$: BIT    #BIT11,#SWR          ;;INHIBIT ITERATIONS?
015544 001011          BNE    1$          ;;BR IF YES
015546 005737 001176          TST    $PASS          ;;IF FIRST PASS OF PROGRAM
015552 001406          BEQ    1$          ;;      INHIBIT ITERATIONS
015554 005237 001104          INC    $ICNT          ;;INCREMENT ITERATION COUNT
015560 023737 001160 001104          CMP    $TIMES,$ICNT          ;;CHECK THE NUMBER OF ITERATIONS MADE
015566 002024          BGE    $OVER          ;;BR IF MORE ITERATION REQUIRED
015570 012737 000001 001104          1$: MOV    #1,$ICNT          ;;REINITIALIZE THE ITERATION COUNTER
015576 013737 015654 001160          MOV    $MXCNT,$TIMES          ;;SET NUMBER OF ITERATIONS TO DO
015604 105237 001102          $SVLAD: INCB  $TSTNM          ;;COUNT TEST NUMBERS
015610 113737 001102 001174          MOVB  $TSTNM,$TESTN          ;;SET TEST NUMBER IN APT MAILBOX
015616 011637 001106          MOV    (SP),$LPADR          ;;SAVE SCOPE LOOP ADDRESS
015622 011637 001110          MOV    (SP),$LPERR          ;;SAVE ERROR LOOP ADDRESS
015626 005037 001162          CLR    $ESCAPE          ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
015632 112737 000001 001115          MOVB  #1,$ERMAX          ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
015640 013777 001102 163274          $OVER: MOV    $TSTNM,$DISPLAY          ;;DISPLAY TEST NUMBER
015646 013716 001106          MOV    $LPADR,(SP)          ;;FUDGE RETURN ADDRESS
015652 000002          RTI          ;;FIXES PS
015654 000062          $MXCNT: 50.          ;;MAX. NUMBER OF ITERATIONS

```

2180

```

.SBTTL TTY INPUT ROUTINE
;*****
.ENABL LSB
;*****
;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL

```

TTY INPUT ROUTINE

```

; *WHEN OPERATING IN TTY FLAG MODE.
015656 022737 000176 001140 $CKSWR: CMP      0SWREG,SWR      ;; IS THE SOFT-SWR SELECTED?
015664 001074                BNE      15$          ;; BRANCH IF NO
015666 105777 163252          TSTB    0$TKS        ;; CHAR THERE?
015672 100071                BPL      15$          ;; IF NO, DON'T WAIT AROUND
015674 117746 163246          MOVB    0$TKB,-(SP)   ;; SAVE THE CHAR
015700 042716 177600          BIC     0+C177,(SP)  ;; STRIP-OFF THE ASCII
015704 022726 000007          CMP     07,(SP)+    ;; IS IT A CONTROL G?
015710 001062                BNE      15$          ;; NO, RETURN TO USER
015712 123727 001134 000001  CMPB    $AUTOB,#1    ;; ARE WE RUNNING IN AUTO-MODE?
015720 001456                BEQ     15$          ;; BRANCH IF YES
015722 104401 016413          TYPE   , $CNTLG    ;; ECHO THE CONTROL-G (+G)
015726 104401 016420          $GTSWR: TYPE   , $MSWR  ;; TYPE CURRENT CONTENTS
015732 013746 000176          MOV    SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
015736 104402                TYPOC                ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
015740 104401 016431          TYPE   , $MNEW    ;; PROMPT FOR NEW SWR
015744 005046          19$: CLR    -(SP)    ;; CLEAR COUNTER
015746 005046          CLR    -(SP)    ;; THE NEW SWR
015750 105777 163170          7$: TSTB    0$TKS        ;; CHAR THERE?
015754 100375                BPL      7$          ;; IF NOT TRY AGAIN
015756 117746 163164          MOVB    0$TKB,-(SP)   ;; PICK UP CHAR
015762 042716 177600          BIC     0+C177,(SP)  ;; MAKE IT 7-BIT ASCII
015766 021627 000025          9$: CMP     (SP),#25  ;; IS IT A CONTROL-U?
015772 001005                BNE     10$         ;; BRANCH IF NOT
015774 104401 016406          TYPE   , $CNTLU   ;; YES, ECHO CONTROL-U (+U)
016000 062706 000006          20$: ADD    #6,SP    ;; IGNORE PREVIOUS INPUT
016004 000757                BR      19$         ;; LET'S TRY IT AGAIN
016006 021627 000015          10$: CMP    (SP),#15  ;; IS IT A <CR>?
016012 001022                BNE     16$         ;; BRANCH IF NO
016014 005766 000004          TST     4(SP)      ;; YES, IS IT THE FIRST CHAR?
016020 001403                BEQ     11$         ;; BRANCH IF YES
016022 016677 000002 163110  MOV     2(SP),0SWR   ;; SAVE NEW SWR
016030 062706 000006          11$: ADD    #6,SP    ;; CLEAR UP STACK
016034 104401 001165          14$: TYPE   , $CRLF  ;; ECHO <CR> AND <LF>
016040 123727 001135 000001  CMPB    $INTAG,#1    ;; RE-ENABLE TTY KBD INTERRUPTS?
016046 001003                BNE     15$         ;; BRANCH IF NOT
016050 012777 000100 163066  MOV     #100,0$TKS  ;; RE-ENABLE TTY KBD INTERRUPTS
016056 000002          15$: RTI                    ;; RETURN
016060 004737 014006          16$: JSR    PC,$TYPEC  ;; ECHO CHAR
016064 021627 000060          CMP    (SP),#60   ;; CHAR < 0?
016070 002420                BLT    18$         ;; BRANCH IF YES
016072 021627 000067          CMP    (SP),#67   ;; CHAR > 7?
016076 003015                BGT    18$         ;; BRANCH IF YES
016100 042726 000060          BIC     #60,(SP)+  ;; STRIP-OFF ASCII
016104 005766 000002          TST     2(SP)      ;; IS THIS THE FIRST CHAR
016110 001403                BEQ     17$         ;; BRANCH IF YES
016112 006316                ASL    (SP)        ;; NO, SHIFT PRESENT
016114 006316                ASL    (SP)        ;; CHAR OVER TO MAKE
016116 006316                ASL    (SP)        ;; ROOM FOR NEW ONE.
016120 005266 000002          17$: INC    2(SP)    ;; KEEP COUNT OF CHAR
016124 056616 177776          BIS    -2(SP),(SP) ;; SET IN NEW CHAR
016130 000707                BR      7$          ;; GET THE NEXT ONE
016132 104401 001164          18$: TYPE   , $QUES  ;; TYPE ?<CR><LF>
016136 000720                BR      20$         ;; SIMULATE CONTROL-U
.DSABL  LSB
;*****
; *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

```

TTY INPUT ROUTINE

```

;+CALL:
;+   RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
;+   RETURN HERE   ;;CHARACTER IS ON THE STACK
;+                ;;WITH PARITY BIT STRIPPED OFF
;
016140 011646      $RDCHR: MOV      (SP), -(SP)      ;;PUSH DOWN THE PC
016142 016666 000004 000002  MOV      4(SP), 2(SP)      ;;SAVE THE PS
016150 105777 162770 1$:      TSTB     @TKS          ;;WAIT FOR
016154 100375      BPL      1$          ;;A CHARACTER
016156 117766 162764 000004  MOVB     @TKB, 4(SP)      ;;READ THE TTY
016164 042766 177600 000004  BIC      @C<177>, 4(SP)  ;;GET RID OF JUNK IF ANY
016172 026627 000004 000023  CMP      4(SP), @23     ;;IS IT A CONTROL-5?
016200 001013      BNE      3$          ;;BRANCH IF NO
016202 105777 162736 2$:      TSTB     @TKS          ;;WAIT FOR A CHARACTER
016206 100375      BPL      2$          ;;LOOP UNTIL ITS THERE
016210 117746 162732  MOVB     @TKB, -(SP)      ;;GET CHARACTER
016214 042716 177600  BIC      @C177, (SP)    ;;MAKE IT 7-BIT ASCII
016220 022627 000021  CMP      (SP)+, @21     ;;IS IT A CONTROL-Q?
016224 001366      BNE      2$          ;;IF NOT DISCARD IT
016226 000750      BR       1$          ;;YES, RESUME
016230 026627 000004 000021 3$:      CMP      4(SP), @XON   ;;IS IT A RANDOM XON?
016236 001744      BEQ      1$          ;;BRANCH IF YES
016240 026627 000004 000140  CMP      4(SP), @140   ;;IS IT UPPER CASE?
016246 002407      BLT      4$          ;;BRANCH IF YES
016250 026627 000004 000175  CMP      4(SP), @175   ;;IS IT A SPECIAL CHAR?
016256 003003      BGT      4$          ;;BRANCH IF YES
016260 042766 000040 000004  BIC      @40, 4(SP)    ;;MAKE IT UPPER CASE
016266 000002 4$:      RTI          ;;GO BACK TO USER
;*****
;+THIS ROUTINE WILL INPUT A STRING FROM THE TTY
;+CALL:
;+   RDLIN          ;;INPUT A STRING FROM THE TTY
;+   RETURN HERE   ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
;+                ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
;
016270 010346      $RDLIN: MOV      R3, -(SP)      ;;SAVE R3
016272 012703 016376 1$:      MOV      @TTYIN, R3    ;;GET ADDRESS
016276 022703 016406 2$:      CMP      @TTYIN+8., R3  ;;BUFFER FULL?
016302 101405      BLOS     4$          ;;BR IF YES
016304 104410      RDCHR          ;;GO READ ONE CHARACTER FROM THE TTY
016306 112613      MOVB     (SP)+, (R3)    ;;GET CHARACTER
016310 122713 000177 10$:     CMPB     @177, (R3)      ;;IS IT A RUBOUT
016314 001003      BNE      3$          ;;SKIP IF NOT
016316 104401 001164 4$:      TYPE     , @QUES      ;;TYPE A '?'
016322 000763      BR       1$          ;;CLEAR THE BUFFER AND LOOP
016324 111337 016374 3$:      MOVB     (R3), 9$      ;;ECHO THE CHARACTER
016330 104401 016374      TYPE     , 9$
016334 122723 000015  CMPB     @15, (R3)+     ;;CHECK FOR RETURN
016340 001356      BNE      2$          ;;LOOP IF NOT RETURN
016342 105063 177777  CLRB     -1(R3)        ;;CLEAR RETURN (THE 15)
016346 104401 001166  TYPE     , @LF      ;;TYPE A LINE FEED
016352 012603      MOV      (SP)+, R3     ;;RESTORE R3
016354 011646      MOV      (SP), -(SP)   ;;ADJUST THE STACK AND PJT ADDRESS OF THE
016356 016666 000004 000002  MOV      4(SP), 2(SP)  ;;FIRST ASCII CHARACTER ON IT
016364 012766 016376 000004  MOV      @TTYIN, 4(SP)
016372 000002      RTI          ;;RETURN
016374 000      9$:      .BYTE    0          ;;STORAGE FOR ASCII CHAR, TO TYPE
016375 000      .BYTE    0          ;;TERMINATOR

```

TTY INPUT ROUTINE

```

016376          $TTYIN: .BLKB 8.          ;;RESERVE 8 BYTES FOR TTY INPUT
016406      136      125      015      $CNTLU: .ASCIZ /+U/<15><12>      ;;CONTROL "U"
016411          012      000
016413      136      107      015      $CNTLG: .ASCIZ /+G/<15><12>      ;;CONTROL "G"
016416          012      000
016420      015      012      123      $MSWR: .ASCIZ <15><12>/SWR = /
016423      127      122      040
016426      075      040      000
016431      040      040      116      $MNEW: .ASCIZ / NEW = /
016434      105      127      040
016437      075      040      000
2181
.SBTTL POWER DOWN AND UP ROUTINES
;*****
;POWER DOWN ROUTINE
016442      012737      016606      000024      $PWRDN: MOV      @ILLUP,@PWRVEC ;;SET FOR FAST UP
016450      012737      000340      000026      MOV      @340,@PWRVEC+2 ;;PRIO:7
016456      01C046      MOV      R0,-(SP) ;;PUSH R0 ON STACK
016460      010146      MOV      R1,-(SP) ;;PUSH R1 ON STACK
016462      010246      MOV      R2,-(SP) ;;PUSH R2 ON STACK
016464      010346      MOV      R3,-(SP) ;;PUSH R3 ON STACK
016466      010446      MOV      R4,-(SP) ;;PUSH R4 ON STACK
016470      010546      MOV      R5,-(SP) ;;PUSH R5 ON STACK
016472      017746      162442      MOV      @SWR,-(SP) ;;PUSH @SWR ON STACK
016476      010637      016612      MOV      SP,$SAVR6 ;;SAVE SP
016502      012737      016514      000024      MOV      @PWRUP,@PWRVEC ;;SET UP VECTOR
016510      000000      HALT
016512      000776      BR      -2 ;;HANG UP
;*****
;POWER UP ROUTINE
016514      012737      016606      000024      $PWRUP: MOV      @ILLUP,@PWRVEC ;;SET FOR FAST DOWN
016522      013706      016612      MOV      $SAVR6,SP ;;GET SP
016526      005037      016612      CLR      $SAVR6 ;;WAIT LOOP FOR THE TTY
016532      005237      016612      1$: INC      $SAVR6 ;;WAIT FOR THE INC
016536      001375      BNE      1$ ;;OF WORD
016540      012677      162374      MOV      (SP)+,@SWR ;;POP STACK INTO @SWR
016544      012605      MOV      (SP)+,R5 ;;POP STACK INTO R5
016546      012604      MOV      (SP)+,R4 ;;POP STACK INTO R4
016550      012603      MOV      (SP)+,R3 ;;POP STACK INTO R3
016552      012602      MOV      (SP)+,R2 ;;POP STACK INTO R2
016554      012601      MOV      (SP)+,R1 ;;POP STACK INTO R1
016556      012600      MOV      (SP)+,R0 ;;POP STACK INTO R0
016560      012737      016442      000024      MOV      @PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
016566      012737      000340      000026      MOV      @340,@PWRVEC+2 ;;PRIO:7
016574      104401      TYPE ;;REPORT THE POWER FAILURE
016576      016614      $PWRMG: .WORD PWRMSG ;;POWER FAIL MESSAGE POINTER
016600      012716      MOV      (PC)+,(SP) ;;RESTART AT START1
016602      002034      $PWRAD: .WORD START1 ;;RESTART ADDRESS
016604      000002      RTI
016606      000000      $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
016610      000776      BR      -2 ;;BEFORE THE POWER DOWN WAS COMPLETE
016612      000000      $SAVR6: 0 ;;PUT THE SP HERE
2182 016614          015      012      122      PWRMSG: .ASCIZ <15><12>/RESTARTED FROM PWR FAIL/
016617          105      123      124
016622          101      122      124
016625          105      104      040
016630          106      122      117
016633          115      040      120

```

POWER DOWN AND UP ROUTINES

2183 016636 127 122 040
 2184 016641 106 101 111
 016644 114 000

```
.EVEN
.SBTTL TRAP DECODER
;*****
;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;GO TO THAT ROUTINE.
```

016646 010046
 016650 016600 000002
 016654 005740
 016656 111000
 016660 006300
 016662 016000 016702
 016666 000200

```
$TRAP: MOV RO,-(SP) ;;SAVE RO
MOV 2(SP),RO ;;GET TRAP ADDRESS
TST -(RO) ;;BACKUP BY 2
MOVB (RO),RO ;;GET RIGHT BYTE OF TRAP
ASL RO ;;POSITION FOR INDEXING
MOV $TRPAD(RO),RO ;;INDEX TO TABLE
RTS RO ;;GO TO ROUTINE
```

016670 011646
 016672 016666 000004 000002
 016700 000002

```
;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
$TRAP2: MOV (SP),-(SP) ;;MOVE THE PC DOWN
MOV 4(SP),2(SP) ;;MOVE THE PSW DOWN
RTI ;;RESTORE THE PSW
```

```
.SBTTL TRAP TABLE
;THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;BY THE "TRAP" INSTRUCTION.
; ROUTINE
;-----
```

016702 016670
 016704 013574
 016706 014422
 016710 014376
 016712 014436
 016714 014624
 016716 015726
 016720 015656
 016722 016140
 016724 016270

```
$TRPAD: .WORD $TRAP2
$TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
$TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPDS ;;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
$GTSWR ;;CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING
$CKSWR ;;CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
$RDCHR ;;CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
$RDLIN ;;CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
```

2185 016726 015 012 103
 2186 016731 126 104 122
 2187 016734 103 103 040
 2188 016737 104 122 126
 2189 016742 061 061 112
 016745 040 104 111
 016750 101 107 040
 016753 124 105 123
 016756 124 040 120
 016761 101 122 124
 016764 040 061 040
 016767 040 015 012
 016772 000

```
.SBTTL ASCII MESSAGES
;;GPA TITLED: .ASCIZ <15><12>/CVDRCA DRV11J DIAG TEST PART 1 /<15><12>
;;JRS TITLED: .ASCIZ <15><12>/CVDRCB DRV11J DIAG TEST PART 1 /<15><12> ;;GPA
TITLED: .ASCIZ <15><12>/CVDRCC DRV11J DIAG TEST PART 1 /<15><12> ;;JRS
```

2190 016773 015 012 104
 016776 122 126 061
 017001 061 112 040
 017004 103 101 102

```
TLCABL: .ASCIZ <15><12>/DRV11J CABLE REQ'D/<15><12>
```


13.

SEQ 0066

ASCII MESSAGES

017246	122	040	040
017251	101	104	122
017254	123	040	040
017257	040	040	105
017262	130	120	103
017265	124	040	040
017270	040	122	103
017273	126	104	000

2201

2202

2203	017276	001116	001362	001122	DT1:	.EVEN \$ERRPC, TSTNUM, \$BDADR, \$GDDAT, \$BDDAT, 0
	017304	001124	001126	000000		
2204	017312	001116	001362	001122	DT2:	\$ERRPC, TSTNUM, \$BDADR, \$GDDAT, \$BDDAT, 0
	017320	001120	001124	001126		
	017326	000000				

FALCON (KXT 11) UPGRADE ROUTINES.

;;GPA

SEQ 0067

```

2206 .SBTTL FALCON (KXT 11) UPGRADE ROUTINES. ;:GPA
2207 ;
2208 ; THE FOLLOWING ROUTINES HAVE BEEN ADDED TO ALLOW DIAGNOSTIC(S)
2209 ; TO RUN ON A FALCON (KXT-11) BASED SYSTEM.
2210 ; TO DETERMINE WHETHER WE'RE A FALCON OR NOT, WE'LL SIZE THE 1ST 3/4 OF
2211 ; THE I/O PAGE (28K TO 31K). FALCON HAS 2KW LOCAL RAM AT 28K(+4) TO 30K
2212 ; AND A MACRO-ODT AT 30K TO 31K. CONSEQUENTLY, ALL I/O DEVICES MUST
2213 ; BE PLACED BETWEEN 174000 AND 177776. ADDITIONALLY, WE'LL STRAP THE
2214 ; EMT AND TRAP SERVICE LEVEL TO PRI6, AND SET THE HALT VECTOR SO THAT
2215 ; WE CAN STOP THE SUCKER !!
2216 ;
2217 ; TO MINIMIZE THE IMPACT OF THESE CHANGES ON FINAL PROGRAM SIZE, THE
2218 ; BULK OF THIS CODE IS PLACED IN THE FLOATING VECTOR SPACE (400-776).
2219 ; IF THE CPU AT HAND IS A FALCON (KXT11), IT STAYS THERE (NO HARM DONE).
2220 ; OTHERWISE, THE AREA IS RESTORED TO ITS ORIGINAL "TRAP-CATCHER" STATE.
2221 ;
2222 017330 005227 177777 FALCON: INC 0-1 ; ONCE-ONLY !!! ;:GPA
2223 017334 001002 BNE 11 ;:GPA
2224 017336 004737 000400 CALL KXTCHK ; EXECUTE FALCON CHECK ;:GPA
2225 017342 005727 11: TST (PC)+ ; TEST FALCON FLAG... ;:GPA
2226 017344 000000 KXTFLAG: 0 ; ...NZ = FALCON... ;:GPA
2227 017346 000207 RETURN ; ...AND RETURN TO CALLER... ;:GPA
2228 ;
2229 017350 $SVPC= ;:GPA
2230 000400 . = 400 ; RESTORE FROM 374:376 AT END ;:GPA
2231 000400 005037 017344 KXTCHK: CLR KXTFLAG ; ASSUME NOT FALCON. ;:GPA
2232 000404 013746 000004 MOV 004,-(SP) ; SAVE ERROR VECTOR. ;:GPA
2233 000410 012737 000504 000004 MOV 021,004 ; SET A TRAP CATCHER. ;:GPA
2234 000416 012700 160010 MOV 0160010,R0 ; FALCON RAM STARTS AT 28K+4. ;:GPA
2235 000422 005720 11: TST (R0)+ ; ;:GPA
2236 000424 000240 240 ;:GPA
2237 000426 020027 174000 CMP R0,0174000 ; SIZE TO 31K. ;:GPA
2238 000432 105773 11 BLO 11 ;:GPA
2239 000434 010037 017344 MOV R0,KXTFLAG ; MUST BE FALCON, SET THE FLAG ;:GPA
2240 000440 012700 000040 MOV 040,R0 ; GET PRI1 BIT... ;:GPA
2241 000444 040037 000006 BIC R0,006 ; ...AND LOWER BUS-ERROR... ;:GPA
2242 000450 040037 000016 BIC R0,0016 ; ...BPT... ;:GPA
2243 000454 040037 000022 BIC R0,0022 ; ...IOT... ;:GPA
2244 000460 040037 000032 BIC R0,0032 ; ...EMT... ;:GPA
2245 000464 040037 000036 BIC R0,0036 ; ...AND TRAP SERVICE TO PRI6 ;:GPA
2246 000470 012737 170000 000140 MOV 0170000,00140 ; ENABLE "BREAK" HALT. ;:GPA
2247 000476 012637 000004 MOV (SP)+,004 ; RESTORE ERROR VECTOR... ;:GPA
2248 000502 000207 RETURN ; ...AND RETURN. ;:GPA
2249 ;
2250 000504 012716 000512 21: MOV 031,(SP) ; TRAP -- NOT A FALCON... ;:GPA
2251 000510 000002 RTI ; ...CONTINUE. ;:GPA
2252 000512 012637 000004 31: MOV (SP)+,004 ; RESET ERROR VECTOR ;:GPA
2253 000516 012700 000402 MOV 0402,R0 ; SET-UP TO RESTORE FLOATING... ;:GPA
2254 000522 013701 000376 MOV 00376,R1 ; ...VECTORS (400 - 776). ;:GPA
2255 000526 010602 MOV SP,R2 ; SAVE STACK POINTER IN R2 ;:GPA
2256 000530 012704 000570 MOV 061,R4 ;:GPA
2257 000534 014446 41: MOV -(R4),-(SP) ; PUSH THE RESTORE CODE... ;:GPA
2258 000536 020427 000546 CMP R4,051 ; ...ONTO THE STACK, ;:GPA
2259 000542 101374 BHI 41 ;:GPA
2260 000544 010607 MOV SP,PC ; AND EXECUTE IT. ;:GPA

```

FALCON (KXT-11) UPGRADE ROUTINES.

::GPA

```

2262
2263
2264
2265 000546 010060 177776
2266 000552 010110
2267 000554 022020
2268 000556 020027 000776
2269 000562 101771
2270 000564 010206
2271 000566 000207
2272 000570
2273
2274
2275
2276
2277
2278      000104
2282
2283      017350
2284      017350
2285      000001

; THIS CODE IS RELOCATED TO AND EXECUTED IN THE STACK AREA.
5$:      MOV      R0, 2(R0)      ; RESTORE ..*2...      ::GPA
          MOV      R1,(R0)      ; ...HALT (OR IOT).      ::GPA
          CMP      (R0)*,(R0)*    ; ::GPA
          CMP      R0,0776      ; ::GPA
          BLOS    5$            ; LOOP 'TIL DONE      ::GPA
          MOV      R2,SP        ; THEN RESTORE SP...  ::GPA
          RETURN                    ; ...AND RETURN TO CALLER  ::GPA
6$:
; IF FALCON, THIS AREA IS FREE FOR ANY PROGRAM UNIQUE
; CHANGES OR DATA STRUCTURES.
; IF USED, YOU'D BETTER PROTECT IT !!!
$FREE*   <1000..>/2          ; FREE WORDS LEFT.      ::GPA
LASTAD*  .-$SVPC              ; ::GPA
          .END                  ; ::GPA

```

SYMBOL TABLE

ABASE = 164160	BGPAT1 013274	DSWR = 177570	PVMA = 000340	TST11 003422
ACDW1 = 000000	BIT0 = 000001	DT1 017276	PWRMSG 016614	TST12 003516
ACDW2 = 000000	BIT00 = 000001	DT2 017312	PWRVEC = 000024	TST13 003612
ACPUOP = 000000	BIT01 = 000002	EDCHP1 013314	RDCHR = 104410	TST14 003706
ACRLOC 001400	BIT02 = 000004	EDCHP2 013352	RDLIN = 104411	TST15 004056
ADDW0 = 000000	BIT03 = 000010	EDCHP3 013414	RDY = 100000	TST16 004224
ADDW1 = 000000	BIT04 = 000020	EDCHP4 013456	RESVEC = 000010	TST17 004524
ADDW10 = 000000	BIT05 = 000040	EMTVEC = 000030	R6 = 000006	TST2 002220
ADDW11 = 000000	BIT06 = 000100	EM1 017022	R7 = 000007	TST20 005012
ADDW12 = 000000	BIT07 = 000200	EM2 017041	SCOPE = 000004	TST21 005312
ADDW13 = 000000	BIT08 = 000400	EM3 017063	SIMR = 000060	TST22 005600
ADDW14 = 000000	BIT09 = 001000	EM4 017076	SIRR = 000120	TST23 005734
ADDW15 = 000000	BIT1 = 000002	EM5 017111	SSIMR = 000070	TST24 006144
ADDW2 = 000000	BIT10 = 002000	EM6 017124	SSIRR = 000130	TST25 006350
ADDW3 = 000000	BIT11 = 004000	EM7 017137	STACK = 001100	TST26 006554
ADDW4 = 000000	BIT12 = 010000	ENDDAT 013572	START 001402	TST27 006672
ADDW5 = 000000	BIT13 = 020000	ENDPAT 013500	START1 002034	TST3 002412
ADDW6 = 000000	BIT14 = 040000	ERROR = 104000	STKLMT = 177774	TST30 007010
ADDW7 = 000000	BIT15 = 100000	ERRVEC = 000004	SWR 001140	TST31 007102
ADDW8 = 000000	BIT2 = 000004	FALCON 017330	SWRCK 015224	TST32 007202
ADDW9 = 000000	BIT3 = 000010	GTSWR = 104406	SWREG 000176	TST33 007330
ADEVCT = 000000	BIT4 = 000020	HT = 000011	SW0 = 000001	TST34 007456
ADEV = 000001	BIT5 = 000040	IE = 001000	SW00 = 000001	TST35 007556
AENV = 000000	BIT6 = 000100	IMRLOC 001372	SW01 = 000002	TST36 007660
AENVM = 000000	BIT7 = 000200	INTFLG 001366	SW02 = 000004	TST37 010012
AFATAL = 000000	BIT8 = 000400	IOTVEC = 000020	SW03 = 000010	TST4 002522
AMADR1 = 000000	BIT9 = 001000	IRRLOC 001376	SW04 = 000020	TST40 010144
AMADR2 = 000000	BPTVEC = 000014	ISRLOC 001374	SW05 = 000040	TST41 010270
AMADR3 = 000000	CHPISR = 000140	KXTCHK 000400	SW06 = 000100	TST42 010444
AMADR4 = 000000	CIMR = 000040	KXTFLA 017344	SW07 = 000200	TST43 010652
AMAMS1 = 000000	CIRMR = 000020	LASTAD = 017350	SW08 = 000400	TST44 011172
AMAMS2 = 000000	CIRR = 000100	LF = 000012	SW09 = 001000	TST45 011500
AMAMS3 = 000000	CISR = 000160	LMD04 = 000200	SW1 = 000002	TST46 012030
AMAMS4 = 000000	CKSWR = 104407	LMD57 = 000240	SW10 = 002000	TST47 012336
AMSGAD = 000000	CLRCR = 013164	MACR = 000254	SW11 = 004000	TST5 002620
AMSGLG = 000000	CLRIRR = 013234	MIMR = 000244	SW12 = 010000	TST50 012546
AMSGTY = 000000	CR = 000015	MIRR = 000250	SW13 = 020000	TST51 012664
AMTYP1 = 000000	CRLF = 000200	MISR = 000240	SW14 = 040000	TST6 002766
AMTYP2 = 000000	CSIMR = 000050	NEXPAS 002100	SW15 = 100000	TST7 003160
AMTYP3 = 000000	CSIRMR = 000030	NEXPA1 002104	SW2 = 000004	TYPDS = 104405
AMTYP4 = 000000	CSIRR = 000110	NXDEV 013002	SW3 = 000010	TYPE = 104401
APASS = 000000	CSISR = 000170	NXDEV1 013006	SW4 = 000020	TYPOC = 104402
APRIOR = 000000	DDISP = 177570	PACR = 000300	SW5 = 000040	TYPON = 104404
APTCSU = 000040	DH1 017154	PATDAT 013502	SW6 = 000100	TYPOS = 104403
APTENV = 000001	DH2 017221	PIMR = 000260	SW7 = 000200	XXDP 001370
APTSIZ = 000200	DIR = 000400	PIRQ = 177772	SW8 = 000400	\$APTHD 001000
APTSPO = 000100	DISPLA 001142	PIRQVE = 000240	SW9 = 001000	\$ATYC 014154
ASWREG = 000000	DISPRE 000174	PRO = 000000	TBITVE = 000014	\$ATY1 014130
ATESTN = 000000	DMAP 001364	PR1 = 000040	TITLED 016726	\$ATY3 014136
AINIT = 000000	DRCSA 001342	PR2 = 000100	TKVEC = 000060	\$ATY4 014146
AUSWR = 000000	DRCSE 001346	PR3 = 000140	TLCABL 016773	\$AUTOB 001134
AVECT1 = 000000	DRCSC 001352	PR4 = 000200	TPVEC = 000064	\$BASE 001244
AVECT2 = 000000	DRCSD 001356	PR5 = 000240	TRAPVE = 000034	\$BDADR 001122
BEGPAT 013272	DRDBA 001344	PR6 = 000300	TRTVEC = 000014	\$BDDAT 001126
BGCHP2 013334	DRDBB 001350	PR7 = 000340	TSTNUM 001362	\$CDW1 001250
BGCHP3 013374	DRDBC 001354	PS = 177776	TST1 002142	\$CHARC 014124
BGCHP4 013436	DRDBD 001360	PSW = 177776	TST10 003326	\$CKSWR 015656

SYMBOL TABLE

\$CMTAG	001100	\$ESCAP	001162	\$MAIL	001170	\$PWRDN	016442	\$TRAP	016646
\$CM3	= 000000	\$FTABL	001210	\$MAMS1	001220	\$PWRMG	016576	\$TRAP2	016670
\$CNTLG	016413	\$ETEND	001252	\$MAMS2	001224	\$PWRUP	016514	\$TRP	= 000012
\$CNTLU	016406	\$FATAL	001172	\$MAMS3	001230	\$QUES	001164	\$TRPAD	016702
\$CPUOP	001216	\$FFLG	014374	\$MAMS4	001234	\$RDCHR	016140	\$TSTM	001004
\$CRLF	001165	\$FILLC	001156	\$MBADR	001002	\$RDLIN	016270	\$TSTM	001102
\$DBLK	015040	\$FILLS	001155	\$MFLG	014372	\$RDSZ	= 000010	\$TTYIN	016376
\$DEVCT	001200	\$FREE	= 000104	\$MNEW	016431	\$RTNAD	013142	\$TYPDS	014624
\$DEVH	001246	\$GDADR	001120	\$MSGAD	001204	\$SAVR6	016612	\$TYPE	013574
\$DOAGN	013140	\$GDDAT	001124	\$MSGLG	001206	\$SCOPE	015376	\$TYPEC	014006
\$DTBL	015030	\$GET42	013120	\$MSGTY	001170	\$SETUP	= 000117	\$TYPEX	014126
\$ENDAD	013130	\$GTSWR	015726	\$MSWR	016420	\$STUP	= 177777	\$TYPOC	014422
\$ENDCT	013076	\$HD	= 000003	\$MTYP1	001221	\$SVLAD	015604	\$TYPON	014436
\$ENDMG	013147	\$HIBTS	001000	\$MTYP2	001225	\$SVPC	= 017350	\$TYPOS	014376
\$ENULL	013144	\$ICNT	001104	\$MTYP3	001231	\$SWR	= 165400	\$UNIT	001202
\$ENV	001210	\$ILLUP	016606	\$MTYP4	001235	\$SWREG	001212	\$UNITM	001010
\$ENVH	001211	\$INTAG	001135	\$MXCNT	015654	\$SWRMK	= 000000	\$USWR	001214
\$EOP	013042	\$ITEMB	001114	\$NULL	001154	\$TESTN	001174	\$VECT1	001240
\$EOPCT	013070	\$LF	001166	\$NWTST	= 000001	\$TIMES	001160	\$VECT2	001242
\$ERFLG	001103	\$LFLG	014373	\$OCNT	014620	\$TKB	001146	\$XOFF	= 000023
\$ERMAX	001115	\$LPADR	001106	\$OMODE	014622	\$TKS	001144	\$XON	= 000021
\$ERROR	015050	\$LPERR	001110	\$OVER	015640	\$TN	= 000052	\$XTSTR	015410
\$ERRPC	001116	\$MADR1	001222	\$PASS	001176	\$TPB	001152	\$GET4	= 000000
\$ERRTB	001252	\$MADR2	001226	\$PASTM	001006	\$TFLG	001157	\$OFILL	014621
\$ERRTY	015242	\$MADR3	001232	\$PWRAD	016602	\$TPS	001150	.\$X	= 001000
\$ERTTL	001112	\$MADR4	001236						

. ABS. 017350 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 48544 WORDS (190 PAGES)
DYNAMIC MEMORY: 19748 WORDS (75 PAGES)
ELAPSED TIME: 00:03:02
CVDRCC.CVDRCC/-SP/CRF=SYSMAC.MLB/ML,CVDRCC.P11

(56)

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES								
ABASE	= 164160	08-424	10-473	10-473	11-521	11-522	11-523	11-524	11-525	11-526
		11-527	11-528	12-553						
ACDW1	= 000000	10-473	10-473							
ACDW2	= 000000	10-473	10-473							
ACPUOP	= 000000	10-473	10-473							
ACRLOC	001400	011-540								
ADDW0	= 000000	10-473								
ADDW1	= 000000	10-473								
ADDW10	= 000000	10-473								
ADDW11	= 000000	10-473								
ADDW12	= 000000	10-473								
ADDW13	= 000000	10-473								
ADDW14	= 000000	10-473								
ADDW15	= 000000	10-473								
ADDW2	= 000000	10-473								
ADDW3	= 000000	10-473								
ADDW4	= 000000	10-473								
ADDW5	= 000000	10-473								
ADDW6	= 000000	10-473								
ADDW7	= 000000	10-473								
ADDW8	= 000000	10-473								
ADDW9	= 000000	10-473								
ADEVCT	= 000000	10-473	10-473							
ADEVN	= 000001	08-425	10-473	10-473						
AENV	= 000000	10-473	10-473							
AENVN	= 000000	10-473	10-473							
AFATAL	= 000000	10-473	10-473							
AMADR1	= 000000	10-473	10-473							
AMADR2	= 000000	10-473	10-473							
AMADR3	= 000000	10-473	10-473							
AMADR4	= 000000	10-473	10-473							
AMAMS1	= 000000	10-473	10-473							
AMAMS2	= 000000	10-473	10-473							
AMAMS3	= 000000	10-473	10-473							
AMAMS4	= 000000	10-473	10-473							
AMSGAD	= 000000	10-473	10-473							
AMSGLG	= 000000	10-473	10-473							
AMSGTY	= 000000	10-473	10-473							
AMTYP1	= 000000	10-473	10-473							
AMTYP2	= 000000	10-473	10-473							
AMTYP3	= 000000	10-473	10-473							
AMTYP4	= 000000	10-473	10-473							
APASS	= 000000	10-473	10-473							
APRIOR	= 000000	10-473								
APTCSU	= 000040	17-2165	017-2166							
APTENV	= 000001	17-2165	17-2166	017-2166	17-2169					
APTSIZ	= 000200	12-544	017-2166							
APTSPO	= 000100	17-2165	17-2166	017-2166						
ASWREG	= 000000	10-473	10-473							
ATESTN	= 000000	10-473	10-473							
AUNIT	= 000000	10-473	10-473							
AUSWR	= 000000	10-473	10-473							

SYMBOL CROSS REFERENCE		CREF V01								
SYMBOL	VALUE	REFERENCES								
AVECT1	= 000000	10-473	10-473							
AVECT2	= 000000	10-473	10-473							
BEGPAT	013272	12-796	12-815	12-835	12-855	13-946	13-1001	13-1053	13-1107	13-1324
		13-1349	13-1740	13-1871	13-1928	16-2061				
BGCHP2	013334	16-2078								
BGCHP3	013374	13-1443	13-1543	16-2095						
BGCHP4	013436	13-1414	13-1514	13-1599	16-2112					
BGPAT1	013274	13-1680	15-2062							
BIT0	= 000001	8-423	12-626	12-648	12-659	12-681	12-703	12-722	12-734	12-756
		12-769	12-788	12-801	12-820	12-840	12-860	13-881	13-916	13-951
		13-955	13-983	13-1006	13-1010	13-1035	13-1058	13-1062	13-1090	13-1112
		13-1116	13-1141	13-1681	13-1741	13-1742	13-1805	13-1806	13-1872	13-1873
		13-1933	13-1934	13-1966	13-1967	13-1988	13-1989	15-2048		
BIT00	= 000001	8-423	8-423							
BIT01	= 000002	8-423	8-423							
BIT02	= 000004	8-423	8-423							
BIT03	= 000010	8-423	8-423							
BIT04	= 000020	8-423	8-423							
BIT05	= 000040	8-423	8-423							
BIT06	= 000100	8-423	8-423							
BIT07	= 000200	8-423	8-423							
BIT08	= 000400	8-423	8-423	17-2179						
BIT09	= 001000	8-423	8-423	17-2169	17-2179					
BIT1	= 000002	8-423	12-681							
BIT10	= 002000	8-423								
BIT11	= 004000	8-423	17-2179							
BIT12	= 010000	8-423								
BIT13	= 020000	8-423	17-2169							
BIT14	= 040000	8-423	17-2179							
BIT15	= 100000	8-423	8-426							
BIT2	= 000004	8-423								
BIT3	= 000010	8-423								
BIT4	= 000020	8-423								
BIT5	= 000040	8-423								
BIT6	= 000100	8-423	12-625	12-640	12-647	12-661	12-668	12-688	12-741	13-958
		13-1072								
BIT7	= 000200	8-423	12-625	12-633	12-640	12-647	12-661	12-668	12-688	12-733
		12-741	12-748	12-755	13-902	13-930	13-958	13-965	13-1065	13-1072
BIT8	= 000400	8-423	8-427							
BIT9	= 001000	8-423	8-428	12-661						
BPTVEC	= 000014	8-423								
CMPIR	= 000140	8-444								
CIMR	= 000040	8-434	13-1376	13-1395	13-1447	13-1638				
CIRMR	= 000020	8-421	13-1575	13-1684	13-1751	13-1752	13-1812	13-1813	13-1882	13-1883
		13-1938	13-1939							
CIRR	= 000100	8-439	13-1495	13-1547						
CISR	= 000160	8-445								
CKSWR	= 104407	17-2169	17-2169	17-2169	17-2176	17-2179	17-2184			
CLRCSR	013164	12-656	12-677	12-698	12-729	12-764	12-795	12-814	12-834	12-854
		13-875	13-910	13-945	13-1000	13-1052	13-1106	13-1157	13-1187	13-1275
		13-1319	13-1344	13-1369	13-1388	13-1408	13-1437	13-1465	13-1486	13-1507
		13-1536	13-1565	13-1592	13-1627	13-1664	13-1673	13-1734	13-1795	13-1857

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES
CLRTRR	013234	13-1865 13-1927 13-1963 13-1985 #15-2030 13-1161 13-1191 13-1232 13-1279 13 1469 13-1597 13-1633 13-1669 #15-2045 #8-423 17-2165 17-2165 #8-423 17-2165 17-2165
CR	* 000015	#8-423 17-2165 17-2165
CRLF	* 000200	#8-423 17-2165 17-2165
CSIMR	* 000050	#8-435 13-1416
CSIRMR	* 000030	#8-432 13-1600
CSIRR	* 000110	#8-440 13-1516
CSISR	* 000170	#8-446
DDISP	* 177570	#8-423 10-473 12-544
DH1	017154	11-476 11-482 11-488 11-494 11-500 11-506 11-513 #17 2199
DH2	017221	#17-2200
DIR	* 000400	#8-427 12-625 12-702 12-733 12-768 13-958 13-1013 13-1065 13-1119
DISPLA	001142	#10-473 *12-544 *12-544 17-2169 17-2179
DISPRE	000174	#8-462 12-544
DMAP	001364	#11-534 *12-583 *12-584 12-587 *14-2013 14-2017
DRCSA	001342	#11-521 *12-586 12-590 12-606 12-619 12-657 12-678 12-731 12-798 13-948 13-1005 13-1056 13-1159 13-1188 13-1233 13-1276 13-1322 13-1347 13-1371 13-1390 13-1411 13-1440 13-1467 13-1488 13-1510 13-1539 13-1567 13-1595 13-1667 13-1674 13-1678 13-1682 13-1860 13-1930 13-1964 14-2011 15-2031 15-2046
DRCSB	001346	#11-523 12-699 12-766 12-817 13-950 13-1003 13-1110 13-1160 13-1189 13-1234 13-1277 13-1323 13-1348 13-1372 13-1391 13-1412 13-1441 13-1468 13-1489 13-1511 13-1540 13-1568 13-1596 13-1668 13-1675 13-1861 13-1931 13-1965 15-2032
DR CSC	001352	#11-525 12-620 12-658 12-730 12-837 13-949 13-1055 13-1111 13-1182 13-1226 13-1270 13-1313 13-1339 13-1364 13-1383 13-1403 13-1431 13-1460 13-1480 13-1502 13-1531 13-1560 13-1587 13-1622 13-1665 13-1679 13-1683 13-1728 13-1858 13-1986 15-2033
DR CSD	001356	#11-527 12-700 12-765 12-857 13-1004 13-1057 13-1109 13-1183 13-1227 13-1271 13-1314 13-1340 13-1365 13-1384 13-1404 13-1432 13-1461 13-1481 13-1503 13-1532 13-1561 13-1588 13-1623 13-1666 13-1729 13-1859 13-1932 13-1987 15-2034
DRDBA	001344	#11-522 12-799 13-980 13-1040 13-1079
DRDBB	001350	#11-524 12-818 13-988 13-1032 13-1130
DRDBC	001354	#11-526 12-838 13-972 13-1087 13-1146
DRDBD	001360	#11-528 12-593 12-858 13-1024 13-1095 13-1138
DSWR	* 177570	#8-423 10-473 12-544
DT1	017276	11-477 11-483 11-489 11-495 11-501 11-507 11-514 #17-2203
DT2	017312	#17-2204
EDCHP1	013314	13-1719 #16-2070
EDCHP2	013352	#16-2085
EDCHP3	013414	13-1454 13-1554 #16-2103
EDCHP4	013456	13-1425 13-1525 13-1616 #16-2120
EMTVEC	* 000030	#8-423 *12-544 *12-544
EM1	017022	11-475 #17-2192
EM2	017041	11-481 #17-2193
EM3	017063	11-487 #17-2194
EM4	017076	11-493 #17-2195
EM5	017111	11-499 #17-2196
EM6	017124	11-505 #17-2197
EM7	017137	11-512 #17-2198

(16)

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES
ENDDAT	013572	12-810 12-829 12-849 12-869 13-995 13-1047 13-1102 13-1153 13-1335
ENDPA1	013500	13-1360 13-1790 13-1921 13-1958 16-2160
ERROR	* 104000	16-2129 18-423 12-615 12-631 12-638 12-646 12-653 12-667 12-674 12-687
		12-694 12-707 12-713 12-720 12-726 12-739 12-746 12-754 12-761
		12-773 12-779 12-786 12-792 12-808 12-827 12-847 12-867 13-888
		13-894 13-900 13-907 13-928 13-935 13-941 13-964 13-971 13-977
		13-987 13-993 13-1017 13-1023 13-1029 13-1039 13-1045 13-1071 13-1076
		13-1084 13-1094 13-1100 13-1123 13-1129 13-1135 13-1145 13-1151 13-1168
		13-1174 13-1179 13-1200 13-1206 13-1212 13-1217 13-1223 13-1244 13-1250
		13-1255 13-1260 13-1267 13-1287 13-1293 13-1299 13-1304 13-1310 13-1333
		13-1358 13-1380 13-1400 13-1423 13-1452 13-1477 13-1499 13-1523 13-1552
		13-1579 13-1584 13-1609 13-1614 13-1644 13-1650 13-1656 13-1661 13-1694
		13-1702 13-1710 13-1717 13-1762 13-1770 13-1776 13-1782 13-1788 13-1821
		13-1827 13-1842 13-1854 13-1893 13-1901 13-1907 13-1913 13-1919 13-1947
		13-1956 13-1975 13-1981 13-1997 13-2003
ERRVEC	* 000004	18-423 12-544 *12-544 *12-544 *12-605 12-616 *12-616 17-2179 *17-2179
FALCON	017330	*17-2179 *17-2179
GNS	* *****	12-548 18-2222 8-462 8-462 17-2184 17-2184 17-2184 17-2184 17-2184 17-2184 17-2184 17-2184 17-2184 17-2184
GTSWR	* 104406	17-2184 17-2184
HT	* 000011	12-581 17-2184
IE	* 001000	18-423 17-2165 17-2165
IMRLOC	001372	18-428 12-662 13-1966
INTFLG	001366	11-537 *13-1685 13-1704 *13-1722
IOTVEC	* 000020	11-535
IRRLOC	001376	18-423 *12-544 *12-544
ISRLOC	001374	11-539 *13-1686 13-1689 *13-1721
KXTCHK	000400	18-2224 18-2231
KXTFLA	017344	13-1837 13-1849 18-2226 *18-2231 *18-2239
LASTAD	* 017350	19-2284
LF	* 000012	18-423 17-2165 17-2165
LMD04	* 000200	18-448
LMD57	* 000240	18-449
MACR	* 000254	18-455 13-1175 13-1194 13-1219 13-1245 13-1300 13-1326 13-1639
MIMR	* 000244	18-453 13-1164 13-1201 13-1238 13-1262 13-1288 13-1351 13-1375 13-1394
		13-1415 13-1444 13-1580 13-1610 13-1645 13-1713
MIRR	* 000250	18-454 13-1170 13-1213 13-1256 13-1282 13-1306 13-1472 13-1493 13-1515
		13-1544 13-1572 13-1602 13-1657 13-1698 13-1747 13-1748 13-1832 13-1845
		13-1878 13-1879 13-1942 13-1949
MISR	* 000240	18-452 13-1207 13-1251 13-1294 13-1651
NEXPAS	002100	12-588 12-590 14-2019
NEXPA1	002104	12-591 12-594
NXDEV	013002	14-2011
NXDEV1	013006	12-589 14-2012 14-2018
PACR	* 000300	18-458 13-1195 13-1327 13-1635
PATDAT	013502	16-2132
PIMR	* 000260	18-459 13-1239 13-1352
PIRQ	* 177772	18-423
PIRQVE	* 000240	18-423

1/1

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES
PRO	= 000000	08-423
PR1	= 000040	08-423
PR2	= 000100	08-423
PR3	= 000140	08-423
PR4	= 000200	08-423
PR5	= 000240	08-423
PR6	= 000300	08-423
PR7	= 000340	08-423 12-598
PS	= 177776	08-423 8-423
PSW	= 177776	08-423
PVMA	= 000340	08-460
PWRMSG	016614	17-2181 017-2182
PWRVEC	= 000024	08-423 *12-544 *12-544 *17-2181 *17-2181 *17-2181 *17-2181 *17-2181 *17-2181
RDCHR	= 104410	17-2180 017-2184
RDLIN	= 104411	017-2184
RDY	= 100000	08-426 12-625 12-640 12-688 12-702 12-715 12-733 12-748 12-768
		12-781 13-958 13-1013 13-1065 13-1119
RESVEC	= 000010	08-423
R6	= 000006	08-423 *12-544 *12-544 12-544
R7	= 000007	08-423
SCOPE	= 000004	08-423 12-602 12-618 12-655 12-676 12-697 12-728 12-763 12-794
		12-813 12-833 12-853 13-874 13-909 13-944 13-999 13-1051 13-1105
		13-1156 13-1186 13-1230 13-1274 13-1318 13-1343 13-1368 13-1387 13-1407
		13-1436 13-1464 13-1485 13-1506 13-1535 13-1564 13-1591 13-1626 13-1672
		13-1733 13-1794 13-1864 13-1926 13-1962 13-1984
SIMR	= 000060	08-436 13-1396 13-1418 13-1574 13-1604
SIRR	= 000120	08-441 13-1473 13-1494 13-1518 13-1573 13-1603 13-1637
SSIMR	= 000070	08-437 13-1445 13-1685
SSIRR	= 000130	08-442 13-1545 13-1686
STACK	= 001100	08-423 12-595
START	001402	8-462 012-544
START1	002034	12-580 012-582 14-2020 17-2181
STKLMT	= 177774	08-423
SWR	001140	010-473 12-544 *12-544 12-544 *12-544 *12-544 17-2169 17-2169 17-2169
		17-2179 17-2179 17-2179 17-2179 17-2179 17-2180 17-2180 17-2181 17-2181
SWRCK	015224	17-2179 017-2174
SWREG	000176	08-462 12-544 17-2180 17-2180
SW0	= 000001	08-423
SW00	= 000001	08-423 8-423
SW01	= 000002	08-423 8-423
SW02	= 000004	08-423 8-423
SW03	= 000010	08-423 8-423
SW04	= 000020	08-423 8-423
SW05	= 000040	08-423 8-423
SW06	= 000100	08-423 8-423
SW07	= 000200	08-423 8-423
SW08	= 000400	08-423 8-423
SW09	= 001000	08-423 8-423
SW1	= 000002	08-423
SW10	= 002000	08-423
SW11	= 004000	08-423
SW12	= 010000	08-423

16

SEQ 0076

SYMBOL CROSS REFERENCE CREF V01

SYMBOL	VALUE	REFERENCES
SW13	= 020000	08-423
SW14	= 040000	08-423
SW15	= 100000	08-423
SW2	= 000004	08-423
SW3	= 000010	08-423
SW4	= 000020	08-423
SW5	= 000040	08-423
SW6	= 000100	08-423
SW7	= 000200	08-423
SW8	= 000400	08-423
SW9	= 001000	08-423
TBITVE	= 000014	08-423
TITLED	016726	12-575 017-2189
TKVEC	= 000060	08-423
TLCABL	016773	12-576 017-2190
TPVEC	= 000064	08-423
TRAPVE	= 000034	08-423 *12-544 *12-544
TRTVEC	= 000014	08-423
TSTNUM1	001362	011-533 *17-2174 17-2203 17-2204
TST1	002142	012-602
TST10	003326	12-791 012-794
TST11	003422	012-813
TST12	003516	012-833
TST13	003612	012-853
TST14	003706	013-874
TST15	004056	13-906 013-909
TST16	004224	13-940 013-944
TST17	004524	013-999
TST2	002220	012-618
TST20	005012	013-1051
TST21	005312	013-1105
TST22	005600	013-1156
TST23	005734	13-1181 013-1186
TST24	006144	13-1225 013-1230
TST25	006350	13-1269 013-1274
TST26	006554	13-1312 013-1318
TST27	006672	13-1338 013-1343
TST3	002412	12-652 012-655
TST30	007010	13-1363 013-1368
TST31	007102	13-1382 013-1387
TST32	007202	13-1402 013-1407
TST33	007330	13-1430 013-1436
TST34	007456	13-1459 013-1464
TST35	007556	13-1479 013-1485
TST36	007660	13-1501 013-1506
TST37	010012	13-1530 013-1535
TST4	002522	12-673 012-676
TST40	010144	13-1559 013-1564
TST41	010270	13-1586 013-1591
TST42	010444	13-1621 013-1626
TST43	010652	13-1663 013-1672
TST44	011172	13-1727 013-1733

SYMBOL CROSS REFERENCE

CREF V01

SYMBOL	VALUE	REFERENCES
\$ENDMG	013147	14-2020 #14-2020
\$ENULL	013144	14-2020 #14-2020
\$ENV	001210	#10-473 12-564 17-2165 17-2166 17-2166 17-2169
\$ENVM	001211	#10-473 12-544 17-2165 17-2165 17-2166
\$EOP	013042	14-2014 #14-2020
\$EOPCT	013070	#14-2020 14-2020
\$FRFLG	001103	#10-473 *17-2169 17-2169 17-2169 17-2179 17-2179 17-2179 *17-2179 17-2179
\$ERMAX	001115	#10-473 *12-544 17-2179 *17-2179 17-2179 17-2179
\$ERROR	015050	12-544 #17-2169
\$ERRPC	001116	#10-473 *17-2169 *17-2169 17-2169 17-2169 17-2169 17-2178 17-2203 17-2204
\$ERRTB	001252	#11-473 17-2178
\$ERRTY	015242	17-2175 #17-2178
\$ERTTL	001112	#10-473 *17-2169 17-2169 17-2169
\$ESCAP	001162	#10-473 *12-544 17-2169 17-2169 17-2169 17-2169 *17-2179
\$ETABL	001210	#10-473
\$ETEND	001252	9-472 #10-473
\$FATAL	001172	#10-473 *12-545 *17-2166 17-2166 *17-2166 #17-2166
\$FFLG	014374	*17-2166 *17-2166 17-2166 *17-2166 #17-2166
\$FILLC	001156	#10-473 17-2165 17-2165 17-2165
\$FILLS	001155	#10-473 17-2165 17-2165
\$FREE	000104	#19-2278 19-2279
\$GDAUR	001120	#10-473 17-2204
\$GDDAT	001124	#10-473 *12-603 *12-625 12-629 *12-633 12-636 *12-640 12-644 *12-647
		12-651 *12-661 12-665 *12-668 12-672 *12-680 12-685 *12-688 12-692
		*12-702 12-705 *12-709 12-711 *12-715 12-718 *12-721 12-724 *12-733
		12-737 *12-741 12-744 *12-748 12-752 *12-755 12-759 *12-768 12-771
		*12-775 12-777 *12-781 12-784 *12-787 12-790 *12-802 12-806 *12-821
		12-825 *12-841 12-845 *12-861 12-865 *13-883 13-886 *13-890 13-892
		*13-896 13-898 *13-902 13-905 *13-918 13-921 *13-924 13-926 *13-930
		13-933 *13-937 13-939 *13-958 13-962 *13-965 13-969 *13-973 13-975
		*13-978 13-981 13-985 *13-989 13-991 *13-1013 13-1015 *13-1018 13-1021
		*13-1025 13-1027 *13-1030 13-1033 13-1037 *13-1041 13-1043 *13-1065 13-1069
		*13-1072 13-1076 *13-1080 13-1082 *13-1085 13-1088 13-1092 *13-1096 13-1098
		*13-1119 13-1121 *13-1124 13-1127 *13-1131 13-1133 *13-1136 13-1139 13-1143
		*13-1147 13-1149 *13-1163 13-1166 *13-1169 13-1172 13-1177 *13-1193 13-1196
		13-1198 *13-1202 13-1204 *13-1208 13-1210 13-1215 13-1221 *13-1237 13-1240
		13-1242 *13-1246 13-1248 13-1253 13-1258 *13-1263 13-1265 *13-1281 13-1285
		*13-1289 13-1291 *13-1295 13-1297 13-1302 13-1308 *13-1320 13-1331 *13-1353
		13-1356 *13-1374 13-1378 *13-1393 13-1398 *13-1417 13-1431 *13-1446 13-1450
		*13-1471 13-1475 *13-1492 13-1497 *13-1517 13-1521 *13-1546 13-1550 *13-1571
		13-1577 13-1582 *13-1601 13-1607 13-1612 *13-1640 13-1642 *13-1646 13-1648
		*13-1652 13-1654 13-1659 *13-1688 13-1692 *13-1695 *13-1697 13-1700 *13-1705
		13-1708 *13-1712 13-1715 *13-1758 13-1760 *13-1764 *13-1765 *13-1766 13-1768
		*13-1772 13-1774 *13-1778 13-1780 *13-1784 13-1786 *13-1815 13-1819 13-1825
		*13-1833 13-1835 *13-1839 13-1840 *13-1843 13-1847 *13-1851 13-1852 *13-1889
		13-1891 *13-1895 *13-1896 *13-1897 13-1899 *13-1903 13-1905 *13-1909 13-1911
		*13-1915 13-1917 *13-1943 13-1945 *13-1950 *13-1951 *13-1952 13-1954 *13-1969
		13-1973 *13-1976 13-1979 *13-1991 13-1995 *13-1999 13-2001 *15-2035 17-2203
		17-2204
\$GET42	013120	#14-2020
\$GTSWR	015726	#17-2180 17-2184 17-2184

B.7

SEQ 0079

SYMBOL CROSS REFERENCE

REF V01

SYMBOL	VALUE	REFERENCES
\$HD	= 000003	8-414 8-414 8-414
\$HIBTS	001000	09-472
\$ICNT	001104	010-473 *17-2179 17-2179 *17-2179 17-2179 17-2179
\$ILLUP	016606	17-2181 17-2181 017-2181
\$INTAG	001135	010-473 17-2180 17-2180 17-2180
\$ITFMR	001114	010-473 *17-2169 17-2169 17-2169 17-2169 17-2169
\$LF	001166	010-473 17-2165 17-2165 17-2169 17-2169 17-2180 17-2180 17-2180
\$LFLG	014373	*17-2166 *17-2166
\$LPADR	001106	010-473 *12-544 *17-2179 *17-2179 17-2179 17-2179 17-2179
\$LPERR	001110	010-473 *12-544 *12-797 *12-816 *12-836 *12-856 *13-947 *13-1002 *13-1054 *13-1108 *13-1321 *13-1346 *13-1410 *13-1439 *13-1509 *13-1538 *13-1594 *13-1739 *13-1870 *13-1929 17-2169 17-2179 *17-2179 17-2179
\$MADR1	001222	010-473
\$MADR2	001226	010-473
\$MADR3	001232	010-473
\$MADR4	001236	010-473
\$MAIL	001170	9-472 9-472 010-473 12-544 17-2165 17-2169 17-2179
\$MAMS1	001220	010-473
\$MAMS2	001224	010-473
\$MAMS3	001230	010-473
\$MAMS4	001234	010-473
\$MBADR	001002	09-472
\$MFLG	014372	*17-2166 17-2166 *17-2166 017-2166
\$MNEW	016431	17-2180 017-2180
\$MSGAD	001204	010-473 *17-2166 17-2166
\$MSGLG	001206	010-473 *17-2166
\$MSGTY	001170	010-473 *12-546 17-2166 *17-2166 17-2166 *17-2166
\$MSWR	016420	17-2180 017-2180
\$MTYP1	001221	010-473
\$MTYP2	001225	010-473
\$MTYP3	001231	010-473
\$MTYP4	001235	010-473
\$MXCNT	015654	17-2179 17-2179 17-2179 017-2179
\$NULL	001154	010-473 17-2165 17-2165 17-2165
\$NWTST	= 000001	012-602 12-602 012-602 012-618 12-618 012-618 012-655 12-655 012-655 012-676 12-676 012-676 012-697 12-697 012-697 012-728 12-728 012-728 012-763 12-763 012-763 012-794 12-794 012-794 012-813 12-813 012-813 012-833 12-833 012-833 012-853 12-853 012-853 013-874 13-874 013-874 013-909 13-909 013-909 013-944 13-944 013-944 013-999 13-999 013-999 013-1051 13-1051 013-1051 013-1105 13-1105 013-1105 013-1156 13-1156 013-1156 013-1186 13-1186 013-1186 013-1230 13-1230 013-1230 013-1274 13-1274 013-1274 013-1318 13-1318 013-1318 013-1343 13-1343 013-1343 013-1368 13-1368 013-1368 013-1387 13-1387 013-1387 013-1407 13-1407 013-1407 013-1436 13-1436 013-1436 013-1464 13-1464 013-1464 013-1485 13-1485 013-1485 013-1506 13-1506 013-1506 013-1535 13-1535 013-1535 013-1564 13-1564 013-1564 013-1591 13-1591 013-1591 013-1626 13-1626 013-1626 013-1672 13-1672 013-1672 013-1733 13-1733 013-1733 013-1794 13-1794 013-1794 013-1864 13-1864 013-1864 013-1926 13-1926 013-1926 013-1962 13-1962 013-1962 013-1984 13-1984 013-1984
\$OCNT	014620	*17-2167 *17-2167 017-2167
\$OMODE	014622	*17-2167 *17-2167 17-2167 *17-2167 *17-2167 017-2167
\$OVER	015640	17-2179 17-2179 17-2179 17-2179 017-2179
\$PASS	001176	010-473 *12-544 *14-2020 *14-2020 14-2020 14-2020 14-2020 17-2179 17-2179

07

SYMBOL CROSS REFERENCE

CREF V01

SEQ 0081

SYMBOL	VALUE	REFERENCES
		13-906 13-909 13-909 013-909 13-940 13-944 13-944 013-944 13-999
		13-999 013-999 13-1051 13-1051 013-1051 13-1105 13-1105 013-1105 13-1156
		13-1156 013-1156 13-1181 13-1186 13-1186 013-1186 13-1225 13-1230 13-1230
		013-1230 13-1269 13-1274 13-1274 013-1274 13-1312 13-1318 13-1318 013-1318
		13-1338 13-1343 13-1343 013-1343 13-1363 13-1368 13-1368 013-1368 13-1382
		13-1387 13-1387 013-1387 13-1402 13-1407 13-1407 013-1407 13-1430 13-1436
		13-1436 013-1436 13-1459 13-1464 13-1464 013-1464 13-1479 13-1485 13-1485
		013-1485 13-1501 13-1506 13-1506 013-1506 13-1530 13-1535 13-1535 013-1535
		13-1559 13-1564 13-1564 013-1564 13-1566 13-1591 13-1591 013-1591 13-1621
		13-1626 13-1626 013-1626 13-1663 13-1672 13-1672 013-1672 13-1727 13-1733
		13-1733 013-1733 13-1794 13-1794 013-1794 13-1856 13-1864 13-1864 013-1864
		13-1926 13-1926 013-1926 13-1962 13-1962 013-1962 13-1980 13-1984 13-1984
		013-1984
\$TPB	001152	010-473 17-2165 17-2165 17-2165
\$TPFLG	001157	010-473 17-2165 17-2165 17-2165
\$TPS	001150	010-473 17-2165 17-2165
\$TRAP	016646	12-544 017-2184
\$TRAP2	016670	017-2184 17-2184
\$TRP	= 000012	017-2184 17-2184 17-2184 17-2184 17-2184 017-2184 17-2184 17-2184 17-2184
		17-2184 017-2184 17-2184 17-2184 17-2184 17-2184 017-2184 17-2184 17-2184
		17-2184 17-2184 017-2184 17-2184 17-2184 17-2184 17-2184 017-2184 17-2184
		17-2184 17-2184 17-2184 017-2184 17-2184 17-2184 17-2184 17-2184 17-2184
		17-2184 17-2184 17-2184 17-2184 017-2184 17-2184 17-2184 17-2184 17-2184
\$TRPAD	016702	017-2184 017-2184
\$TSTM	001004	09-472
\$TSTNM	001102	010-473 *14-2020 17-2169 17-2169 17-2169 17-2174 17-2179 17-2179 *17-2179
		17-2179 17-2179 17-2179 17-2179
\$TTYIN	016376	17-2180 17-2180 17-2180 017-2180
\$TYPRN	= *****	17-2184
\$TYPDS	014624	017-2168 17-2184 17-2184
\$TYPE	013574	017-2165 17-2166 17-2184 17-2184
\$TYPEC	014006	17-2165 17-2165 17-2165 017-2165 17-2180
\$TYPEX	014126	17-2165 17-2165 017-2165
\$TYPOC	014422	017-2167 17-2184 17-2184
\$TYPON	014436	17-2167 017-2167 17-2184
\$TYPOS	014376	017-2167 17-2184
\$UNIT	001202	010-473 *12-582 12-597 *14-2016
\$UNITM	001010	09-472
\$USMR	001214	010-473
\$VECT1	001240	010-473
\$VECT2	001242	010-473
\$XOFF	= 000023	17-2165 17-2165
\$XON	= 000021	17-2165 17-2165 17-2180
\$XTSTR	015410	017-2179
\$GET4	= 000000	014-2020 14-2020
\$OFILL	014621	*17-2167 *17-2167 17-2167 017-2167
\$OCAT	= *****	17-2169 17-2179
.\$ASTA	= *****	17-2166 17-2166
.\$X	= 001000	09-472 9-472

F7

SEQ 0083

MACRO CROSS REFERENCE

CREF V01

MACRO NAME	REFERENCES
\$\$SKIP	08-423 12-652 12-673 12-693 12-725 12-760 12-791 13-906 13-940 13-1181 13-1225 13-1269 13-1312 13-1338 13-1363 13-1382 13-1402 13-1430 13-1459 13-1479 13-1501 13-1530 13-1559 13-1586 13-1621 13-1663 13-1727 13-1856 13-1980
.EQUAT	08-408 8-423
.HEADE	08-407 8-414
.SETUP	08-407 12-542
.SWRHI	08-408 8-422
.SWRLO	08-422
.\$ACT1	08-410 9-467
.\$APT8	08-410 10-473 10-473
.\$APTH	08-410 9-472
.\$APTY	08-410 17-2166
.\$CATC	08-408 8-462
.\$CMTA	08-408 9-473
.\$EOP	08-409 14-2020
.\$ERRO	08-409 17-2169
.\$ERRT	08-409 17-2178
.\$POWE	08-408 17-2181
.\$RDOC	08-407
.\$READ	08-409 17-2180
.\$SCOP	08-409 17-2179
.\$TRAP	08-407 17-2184
.\$TYPD	08-409 17-2168
.\$TYPE	08-409 17-2165
.\$TYPO	08-408 17-2167

CVDRCC DRV11J DIAGB1B5
.....C1C5
.....D1D5
.....E1E5
.....F1F5
.....G1G5
.....H1H5
.....I1I5
.....J1J5
.....K1K5
.....L1L5
.....M1M5
.....N1N5

.....B2B6
.....C2C6
.....D2D6
.....E2E6
.....F2F6
.....G2G6
.....H2H6
.....I2I6
.....J2J6
.....K2K6
.....L2L6
.....M2M6
.....N2N6

.....B3B7
.....C3C7
.....D3D7
.....E3E7
.....F3F7
.....G3
.....H3
.....I3
.....J3
.....K3
.....L3
.....M3
.....N3

.....B4
.....C4
.....D4
.....E4
.....F4
.....G4
.....H4
.....I4
.....J4
.....K4
.....L4
.....M4
.....N4