

PROC
DDT CPM62.COM
IABOOTH1.HEX
R0D00
ICBIOSH3.HEX
R3E00
TC
SYSEEN

I/O PARTS 9/8/82!

00-07 SWBD
08-09 VIO-X
0A - 0B ^{SPDL Z 8}
48-4F MULTI I/O
50-53 - HDCA
C0-C1 PMMI

CB10SH3.PRN
8/25/82

INCLUDES I/O BYTE

OLD DECISION
THIS IS RUNNING ON M20

Removal of some conditions
added I/O BYTE

also CB10SH14 (DON'T USE)

TITLE '*** Cbios For CP/M Ver. 2.2 ***'

```

001D = REVNUM EQU 29 ;CBIOS REVISION NUMBER 2.9
0016 = CPMREV EQU 22 ;CP/M REVISION NUMBER 2.2
0001 = CONGRP EQU 1 ;CONSOLE PORT (1 = P1, 2 = P2, 3 = P3)
0003 = LSTGRP EQU 3 ;PRINTER PORT (1 = P1, 2 = P2, 3 = P3)
*0001 = MAXHD EQU 1 ;SET TO NUMBER OF HARD DISKS
*0001 = MAXFLOP EQU 1 ;SET TO NUMBER OF FLOPPIES
0003 = LOGDSK EQU 3 ;DEFAULT LOGICAL DISKS PER DRIVE
0014 = MREV EQU 20 ;HARD DISK TYPE
0015 = HDSPT EQU 21 ;SECTORS PER TRACK

```

```

*****
*
* THE FOLLOWING EQUATES RELATE THE MORROW DESIGNS 2D
* CONTROLLER. IF THE CONTROLLER IS NON STANDARD (0F800H)
* ONLY THE ORIGIN EQUATE NEED BE CHANGED.
*
*****

```

```

* F800 = ORIGIN EQU 0F800H
FC00 = DJRAM EQU ORIGIN+400H ;DISK JOCKEY 2D RAM ADDRESS
F800 = DJBOOT EQU ORIGIN ;DISK JOCKEY 2D INITIALIZATION
F803 = DJCIN EQU ORIGIN+3H ;DISK JOCKEY 2D CHARACTER INPUT ROUTINE
F806 = DJCOUT EQU ORIGIN+6H ;DISK JOCKEY 2D CHARACTER OUTPUT ROUTINE
F809 = DJHOME EQU ORIGIN+9H ;DISK JOCKEY 2D TRACK ZERO SEEK
F80C = DJTRK EQU ORIGIN+0CH ;DISK JOCKEY 2D TRACK SEEK ROUTINE
F80F = DJSEC EQU ORIGIN+0FH ;DISK JOCKEY 2D SET SECTOR ROUTINE
F812 = DJDMA EQU ORIGIN+012H ;DISK JOCKEY 2D SET DMA ADDRESS
F815 = DJREAD EQU ORIGIN+15H ;DISK JOCKEY 2D READ ROUTINE
F818 = DJWRITE EQU ORIGIN+18H ;DISK JOCKEY 2D WRITE ROUTINE
F81B = DJSEL EQU ORIGIN+1BH ;DISK JOCKEY 2D SELECT DRIVE ROUTINE
F821 = DJTSTAT EQU ORIGIN+21H ;DISK JOCKEY 2D TERMINAL STATUS ROUTINE
F827 = DJSTAT EQU ORIGIN+27H ;DISK JOCKEY 2D STATUS ROUTINE
F82A = DJERR EQU ORIGIN+2AH ;DISK JOCKEY 2D ERROR, FLASH LED
F82D = DJDEN EQU ORIGIN+2DH ;DISK JOCKEY 2D SET DENSITY ROUTINE
F830 = DJSIDE EQU ORIGIN+30H ;DISK JOCKEY 2D SET SIDE ROUTINE
0008 = DBLSID EQU 8 ;SIDE BIT FROM CONTROLLER
FBF8 = IO EQU ORIGIN+3F8H ;START OF I/O REGISTERS
FBF9 = DREG EQU IO+1
FBFC = CMDREG EQU IO+4
00D0 = CLRCMD EQU 0D0H

```

```

*****
*
* THE FOLLOWING EQUATES ARE FOR THE DISKUS HARD DISK WANTED.
*
*****

```

```

0050 = HDORG EQU 50H ;HARD DISK CONTROLLER ORIGIN
0050 = HDSTAT EQU HDORG ;HARD DISK STATUS
0050 = HDCNTL EQU HDORG ;HARD DISK CONTROL
0053 = HDDATA EQU HDORG+3 ;HARD DISK DATA
0052 = HDFUNC EQU HDORG+2 ;HARD DISK FUNCTION
0051 = HDCMND EQU HDORG+1 ;HARD DISK COMMAND
0051 = HDRESLT EQU HDORG+1 ;HARD DISK RESULT

```

```

0002 =      RETRY   EQU      2          ;RETRY BIT OF RESULT
0001 =      TKZERO  EQU      1          ;TRACK ZERO BIT OF STATUS
0002 =      OPDONE  EQU      2          ;OPERATION DONE BIT OF STATUS
0004 =      COMPLT  EQU      4          ;COMPLETE BIT OF STATUS
0008 =      TMOUT   EQU      8          ;TIME OUT BIT OF STATUS
0010 =      WFAULT  EQU     10H        ;WRITE FAULT BIT OF STATUS
0020 =      DRVRDY  EQU     20H        ;DRIVE READY BIT OF STATUS
0040 =      INDEX   EQU     40H        ;INDEX BIT OF STATUS
0004 =      PSTEP   EQU      4          ;STEP BIT OF FUNCTION
00FB =      NSTEP   EQU     0FBH       ;STEP BIT MASK OF FUNCTION
0004 =      HDRLEN  EQU      4          ;SECTOR HEADER LENGTH
0200 =      SECLEN  EQU     512        ;SECTOR DATA LENGTH
000F =      WENABL  EQU     0FH        ;WRITE ENABLE
000B =      WRESET  EQU     0BH        ;WRITE RESET OF FUNCTION
0005 =      SCENBL  EQU      5          ;CONTROLLER CONTROL
0007 =      DSKCLK  EQU      7          ;DISK CLOCK FOR CONTROL
00F7 =      MDIR    EQU     0F7H       ;DIRECTION MASK FOR FUNCTION
00FC =      NULL    EQU     0FCH       ;NULL COMMAND
0000 =      IDBUFF  EQU      0          ;INITIALIZE DATA COMMAND
0008 =      ISBUFF  EQU      8          ;INITIALIZE HEADER COMMAND
0001 =      RSECT   EQU      1          ;READ SECTOR COMMAND
0005 =      WSECT   EQU      5          ;WRITE SECTOR COMMAND

0048 =      MBASE   EQU     48H        ;BASE ADDRESS OF MULTI I/O OR DECISION I
004F =      GRPSEL  EQU     MBASE+7    ;GROUP SELECT PORT
0048 =      DLL     EQU     MBASE      ;DIVISOR (LSB)
0049 =      DLM     EQU     MBASE+1    ;DIVISOR (MSB)
0049 =      IER     EQU     MBASE+1    ;INTERUPT ENABLE REGISTER
004A =      CLK     EQU     MBASE+2    ;WB14 PRINTER SELECT PORT
004B =      LCR     EQU     MBASE+3    ;LINE CONTROL REGISTER
004D =      LSR     EQU     MBASE+5    ;LINE STATUS REGISTER
004E =      MSR     EQU     MBASE+6

0048 =      RBR     EQU     MBASE      ;READ DATA BUFFER
0048 =      THR     EQU     MBASE      ;TRANSMITTER DATA BUFFER
0080 =      DLAB    EQU     80H        ;DIVISOR LATCH ACCESS BIT
0020 =      THRE    EQU     20H        ;STATUS LINE THRE BIT
0010 =      CTS     EQU     10H        ;CLEAR TO SEND
0020 =      DSR     EQU     20H        ;DATA SET READY
0001 =      DR      EQU      1          ;LINE STATUS DR BIT
0001 =      WLS0    EQU      1          ;WORD LENGTH SELECT BIT 0
0002 =      WLS1    EQU      2          ;WORD LENGTH SELECT BIT 1 FOR 8 BIT WORD
0004 =      STB     EQU      4          ;STOP BIT COUNT - 2 STOP BITS

```

```

; DEFINE MULTI I/O PORTS ADDRESSES FOR GROUP ZERO

```

```

0000 =      GZERO   EQU      0
0048 =      DAISY0  EQU     MBASE      ;DAISY INPUT PORTS
0049 =      DAISY1  EQU     MBASE+1
0049 =      SENSESW EQU     MBASE+1    ;SENSE SWITCHES

0048 =      DAISI0  EQU     MBASE      ; FOR DECISION I AND MULTI I/O.
0049 =      DAISI1  EQU     MBASE+1    ;THESE TWO ARE THE DECISION I PORTS

```

```

; DEFINE GROUP SELECT BITS

```

```

0001 =      S0      EQU     01H        ;GROUP NUMBER (0-3)

```

```

0002 = S1 EQU 02H
0003 = SMASK EQU 03H
0004 = BANK EQU 04H
0008 = ENINT EQU 08H
0010 = RESTOR EQU 10H ;PRINTER RESTORE ON MULTI I/O
0020 = DENABLE EQU 20H ;DRIVER ENABLE ON MULTI I/O

```

```

*****
*
* CP/M SYSTEM EQUATES. IF RECONFIGURATION OF THE CP/M SYSTEM
* IS BEING DONE, THE CHANGES CAN BE MADE TO THE FOLLOWING
* EQUATES.
*
*****

```

```

003E = MSIZE EQU 62 ;MEMORY SIZE OF TARGET CP/M
A800 = BIAS EQU (MSIZE-20)*1024 ;MEMORY OFFSET FROM 20K SYSTEM
CD00 = CCP EQU 2500H+BIAS ;CONSOLE COMMAND PROCESSOR
D500 = BDOS EQU CCP+800H ;BDOS ADDRESS
E300 = BIOS EQU CCP+1600H ;CBIOS ADDRESS
3E00 = OFFSETC EQU 2100H-BIOS ;OFFSET FOR SYSGEN
0004 = CDISK EQU 4 ;ADDRESS OF LAST LOGGED DISK
0080 = BUFF EQU 80H ;DEFAULT BUFFER ADDRESS
0100 = TPA EQU 100H ;TRANSIENT MEMORY
00C0 = INTIOBY EQU 192 ;INITIAL IOBYTE
0003 = IOBYTE EQU 3 ;IOBYTE LOCATION
0000 = WBOT EQU 0 ;WARM BOOT JUMP ADDRESS
0005 = ENTRY EQU 5 ;BDOS ENTRY JUMP ADDRESS

```

```

*****
*
* THE FOLLOWING ARE INTERNAL CBIOS EQUATES. MOST ARE MISC.
* CONSTANTS.
*
*****

```

```

0003 = AETX EQU 3 ;ETX CHARACTER
0006 = AACK EQU 6 ;ACK CHARACTER
000A = ACR EQU 'J'-64 ;CARRIAGE RETURN
000D = ALF EQU 'M'-64 ;LINE FEED
000A = RETRIES EQU 10 ;MAX RETRIES ON DISK I/O BEFORE ERROR
001A = CLEAR EQU 'Z'-64 ;CLEAR SCREEN ON AN ADM 3

```

```

*****
*
* THE JUMP TABLE BELOW MUST REMAIN IN THE SAME ORDER, THE
* ROUTINES MAY BE CHANGED, BUT THE FUNCTION EXECUTED MUST BE
* THE SAME.
*
*****

```

```

E300 ORG BIOS ;CBIOS STARTING ADDRESS

E300 C3BFEB JMP CBOOT ;COLD BOOT ENTRY POINT
E303 C3D8E4 WBOOTE JMP WBOOT ;WARM BOOT ENTRY POINT
E306 C33BE3 JMP CONST ;CONSOLE STATUS ROUTINE

```

```

E309 C347E3      JMP      CONIN      ;CONSOLE INPUT
E30C C35CE3      JMP      CONOUT     ;CONSOLE OUTPUT
E30F C37CE3      JMP      LIST       ;LIST DEVICE OUTPUT
E312 C371E3      JMP      PUNCH      ;PUNCH DEVICE OUTPUT
E315 C367E3      JMP      READER     ;READER DEVICE INPUT
E318 C323E5      JMP      HOME       ;HOME DRIVE
E31B C365E5      JMP      SETDRV     ;SELECT DISK
E31E C325E5      JMP      SETTRK    ;SET TRACK
E321 C317E5      JMP      SETSEC     ;SET SECTOR
E324 C31DE5      JMP      SETDMA     ;SET DMA ADDRESS
E327 C3A4E6      JMP      READ       ;READ THE DISK
E32A C39DE6      JMP      WRITE      ;WRITE THE DISK
E32D C387E3      JMP      LISTST     ;LIST DEVICE STATUS
E330 C32AE5      JMP      SECTAN     ;SECTOR TRANSLATION
E333 C31BF8      DJDRV   JMP      DJSEL      ;HOOKUP FOR SINGLE.COM PROGRAM

```

```

E336 0600      DEFCON  DW      6      ;CONSOLE BAUD RATE

```

```

E338 0C00      DEFLST  DW     12     ;PRINTER BAUD RATE

```

```

E33A 00      GROUP   DB      0      ;GROUP BYTE

```

```

*****
*
* TERMINAL DRIVER ROUTINES. IOBYTE IS INITIALIZED BY THE COLD
* BOOT ROUTINE, TO MODIFY, CHANGE THE "INTIOBY" EQUATE. THE
* I/O ROUTINES THAT FOLLOW ALL WORK EXACTLY THE SAME WAY. USING
* IOBYTE, THEY OBTAIN THE ADDRESS TO JUMP TO IN ORDER TO EXECUTE
* THE DESIRED FUNCTION. THERE IS A TABLE WITH FOUR ENTRIES FOR
* EACH OF THE POSSIBLE ASSIGNMENTS FOR EACH DEVICE. TO MODIFY
* THE I/O ROUTINES FOR A DIFFERENT I/O CONFIGURATION, JUST
* CHANGE THE ENTRIES IN THE TABLES.
*
*****

```



```

F803 =      CITYY   EQU      DJCIN      ;INPUT FROM THE DISK JOCKEY 2D
F806 =      COTTY   EQU      DJCOUT     ;OUTPUT TO THE DISK JOCKEY 2D

```

```

*****
*
* CONST: GET THE STATUS FOR THE CURRENTLY ASSIGNED CONSOLE
* DEVICE. THE CONSOLE DEVICE CAN BE GOTTEN FROM IOBYTE,
* THEN A JUMP TO THE CORRECT CONSOLE STATUS ROUTINE IS
* PERFORMED.
*
*****

```

```

E33B 21B5E3      CONST   LXI      H,CSTBLE      ;BEGINNING OF JUMP TABLE
E33E C34DE3      JMP      CONIN1     ;SELECT CORRECT JUMP

```

```

*****
*
* CSREADER: IF THE CONSOLE IS ASSIGNED TO THE READER THEN A
* JUMP WILL BE MADE HERE, WHERE ANOTHER JUMP WILL
* OCCUR TO THE CORRECT READER STATUS.
*
*****

```

```

*****
E341 21BDE3 CSREADR LXI H,CSRTBLE ;BEGINNING OF READER STATUS TABLE
E344 C36AE3 JMP READERA

```

```

*****
*
* CONIN: TAKE THE CORRECT JUMP FOR THE CONSOLE INPUT ROUTINE. *
* THE JUMP IS BASED ON THE TWO LEAST SIGNIFICANT BITS OF *
* IOBYTE. *
*
*****

```

```

E347 CD17E7 CONIN CALL FLUSH ;FLUSH THE DISK BUFFER
E34A 218DE3 LXI H,CITBLE ;BEGINNING OF CHARACTER INPUT TABLE

```

```

*
* ENTRY AT CONIN1 WILL DECODE THE TWO LEAST SIGNIFICANT BITS
* OF IOBYTE. THIS IS USED BY CONIN,CONOUT, AND CONST.
*

```

```

E34D 3A0300 CONIN1 LDA IOBYTE
E350 17 RAL

```

```

*
* ENTRY AT SELDEV WILL FORM AN OFFSET INTO THE TABLE POINTED
* TO BY H&L AND THEN PICK UP THE ADDRESS AND JUMP THERE.
*

```

```

E351 E606 SELDEV ANI 6H ;STRIP OFF UNWANTED BITS
E353 1600 MVI D,0 ;FORM OFFSET
E355 5F MOV E,A
E356 19 DAD D ;ADD OFFSET
E357 7E MOV A,M ;PICK UP HIGH BYTE
E358 23 INX H
E359 66 MOV H,M ;PICK UP LOW BYTE
E35A 6F MOV L,A ;FORM ADDRESS
E35B E9 PCHL ;GO THERE !

```

```

*****
*
* CONOUT: TAKE THE PROPER BRANCH ADDRESS BASED ON THE TWO LEAST *
* SIGNIFICANT BITS OF IOBYTE. *
*
*****

```

```

E35C C5 CONOUT PUSH B ;SAVE THE CHARACTER
E35D CD17E7 CALL FLUSH ;FLUSH THE DISK BUFFER
E360 C1 POP B ;RESTORE THE CHARACTER
E361 2195E3 LXI H,COTBLE ;BEGINNING OF THE CHARACTER OUT TABLE
E364 C34DE3 JMP CONIN1 ;DO THE DECODE

```

```

*****
*
* READER: SELECT THE CORRECT READER DEVICE FOR INPUT. THE *
* READER IS SELECTED FROM BITS 2 AND 3 OF IOBYTE. *

```

*

E367 21ADE3 READER LXI H,RTBLE ;BEGINNING OF READER INPUT TABLE

*
* ENTRY AT READERA WILL DECODE BITS 2 & 3 OF IOBYTE, USED
* BY CSREADER.
*

E36A 3A0300 READERA LDA IOBYTE

*
* ENTRY AT READER1 WILL SHIFT THE BITS INTO POSITION, USED
* BY LIST AND PUNCH.
*

E36D 1F READR1 RAR
E36E C351E3 JMP SELDEV

*
* PUNCH: SELECT THE CORRECT PUNCH DEVICE. THE SELECTION COMES
* FROM BITS 4&5 OF IOBYTE.
*

E371 21A5E3 PUNCH LXI H,PTBLE ;BEGINNING OF PUNCH TABLE
E374 3A0300 LDA IOBYTE

*
* ENTRY AT PNCH1 ROTATES BITS A LITTLE MORE IN PREP FOR
* SELDEV, USED BY LIST.
*

E377 1F PNCH1 RAR
E378 1F RAR
E379 C36DE3 JMP READR1

*
* LIST: SELECT A LIST DEVICE BASED ON BITS 6&7 OF IOBYTE
*

E37C 219DE3 LIST LXI H,LTBLE ;BEGINNING OF THE LIST DEVICE ROUTINES
E37F 3A0300 LIST1 LDA IOBYTE
E382 1F RAR
E383 1F RAR
E384 C377E3 JMP PNCH1

*
* LISTST: GET THE STATUS OF THE CURRENTLY ASSIGNED LIST DEVICE
*

E387 21C5E3 LISTST LXI H,LSTBLE ;BEGINNING OF THE LIST DEVICE STATUS
E38A C37FE3 JMP LISTI

*
* IF CUSTOMIZING I/O ROUTINES IS BEING PERFORMED, THE TABLE *
* BELOW SHOULD BE MODIFIED TO REFLECT THE CHANGES. ALL I/O *
* DEVICES ARE DECODED OUT OF IOBYTE AND THE JUMP IS TAKEN FROM *
* THE FOLLOWING TABLES. *

*
* CONSOLE INPUT TABLE
*

CBIO5H4

E38D 4EE4 CITBLE DW MIOIN ;INPUT FROM I/O MASTER
E38F 0CE4 DW CICRT ;INPUT FROM CRT (CURRENTLY SWITCHBOARD
SERIAL PORT 1)
E391 F7E3 DW CIUCL ;INPUT FROM SWBD PARALLEL PORT 4
E393 03F8 DW CITY ;INPUT FROM TTY (CURRENTLY INPUT FROM
DISK JOCKEY 2D)

← CICRT

*
* CONSOLE OUTPUT TABLE
*

E395 61E4 COTBLE DW MIOOUT ;OUTPUT TO I/O MASTER
E397 31E4 DW COCRT ;OUTPUT TO CRT
E399 31E4 DW COCRT ;OUTPUT TO CRT
E39B 06F8 DW COTTY ;OUTPUT TO TTY (CURRENTLY OUTPUT TO
DISK JOCKEY 2D)

← MIOOUT
← COCRT
← COCRT
← MIOCRT

*
* LIST DEVICE TABLE
*

E39D 06F8 LTBLE DW COTTY ;OUTPUT TO TTY (CURRENTLY ASSIGNED
BY INTIOBY, OUTPUT TO 2D)
E39F 3CE4 DW COPTR ;OUTPUT TO PRINTER
E3A1 CDE3 DW COLPT ;OUTPUT TO LINE PRINTER (CURRENTLY
SWITCHBOARD SERIAL PORT 1)
E3A3 D8E3 DW COUL1 ;OUTPUT TO USER LINE PRINTER 1 (CURRENTLY
SWITCHBOARD SERIAL PORT 1)

— OKI

— diallo

*
* PUNCH DEVICE TABLE
*

E3A5 06F8 PTBLE DW COTTY ;OUTPUT TO THE TTY (CURRENTLY ASSIGNED

— diallo


```

;          BY INTIOBY, OUTPUT TO 2D)
E3A7 3CE4      DW      COPTR      ;OUTPUT TO PRINTER
;
E3A9 CDE3      DW      COUP1      ;OUTPUT TO USER PUNCH 1 (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)
E3AB CDE3      DW      COUP2      ;OUTPUT TO USER PUNCH 2 (CURRNTLLY
;          SWITCHBOARD SERIAL PORT 1)

```

```

*
* READER DEVICE INPUT TABLE
*

```

```

E3AD 03F8      RTBLE   DW      CITT      ;INPUT FROM TTY (CURRENTLY ASSIGNED
;          BY INTIOBY, INPUT FROM 2D)
E3AF 0CE4      DW      CIPTR      ;INPUT FROM PAPER TAPE READER (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)
E3B1 0CE4      DW      CIUR1      ;INPUT FROM USER READER 1 (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)
E3B3 0CE4      DW      CIUR2      ;INPUT FROM USER READER 2 (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)

```

```

*
* CONSOLE STATUS TABLE
*

```

```

E3B5 73E4      CSTBLE  DW      MIOSTAT 3 ;STATUS FROM I/O MASTER
;
E3B7 20E4      DW      CSCRT 1 ;STATUS FROM CRT (CURRENTLY SWITCHBOARD
;          SERIAL PORT 1)
E3B9 03E4      DW      CSUC1 2 ;STATUS FROM SWBD PARALLEL PORT 4, AS
;          READ FROM ATTN BIT 0
E3BB 18E4      DW      CSTTY 4 ;STATUS OF TTY (CURRENTLY STSTUS FROM
;          DISK JOCKEY 2D)

```

CBIOSH4
← CSRT

```

*
* STATUS FROM READER DEVICE
*

```

```

E3BD 18E4      CSRTBLE DW      CSTTY      ;STATUS FROM TTY (CURRENTLY ASSIGNED
;          BY INTIOBY, STATUS OF 2D)
E3BF 20E4      DW      CSPTR      ;STATUS FROM PAPER TAPE READER (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)
E3C1 20E4      DW      CSUR1      ;STATUS FROM USER READER 1 (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)
E3C3 20E4      DW      CSUR2      ;STATUS OF USER READER 2 (CURRENTLY
;          SWITCHBOARD SERIAL PORT 1)

```

```

*
* STATUS FROM LIST DEVICE
*

```

```

E3C5 2EE4      LSTBLE  DW      READY      ;CONSOLE ALWAYS READY
E3C7 2EE4      DW      READY      ;GET LIST STATUS
E3C9 29E4      DW      LSLPT
E3CB 29E4      DW      LSLPT

```

```

*
* THE FOLLOWING EQUATES SET OUTPUT DEVICE TO OUTPUT TO THE
* SWITCHBOARD SERIAL PORT 1.
*
*****

```

```

E3CD = COPTP EQU $ ;OUTPUT FROM PAPER TAPE PUNCH
E3CD = COUP1 EQU $ ;OUTPUT FROM USER PUNCH 1
E3CD = COUP2 EQU $ ;OUTPUT FROM USER PUNCH 2
E3CD DB02 COLPT IN 2 ;OUTPUT FROM LINE PRINTER,GET STATUS
E3CF E680 ANI 80H ;WAIT UNTIL OK TO SEND
E3D1 CACDE3 JZ COLPT
E3D4 79 MOV A,C ;OUTPUT THE CHARACTER
E3D5 D301 OUT 1
E3D7 C9 RET

```

```

*****
*
* CUSTOM I/O PRINTER DRIVER FOR DIABLO PRINTER WITH 1200 BAUD
* ETX/ACK HANDSHAKE.
*
*****

```

```

E3D8 CDCDE3 COUL1 CALL COLPT ;OUTPUT THE CHARACTER
E3DB 3AF6E3 LDA COUNT
E3DE 3D DCR A
E3DF 32F6E3 STA COUNT
E3E2 C0 RNZ
E3E3 3E4E MVI A,78
E3E5 32F6E3 STA COUNT
E3E8 0E03 MVI C,AETX
E3EA CDCDE3 CALL COLPT
E3ED CD0CE4 PWAIT CALL CIPTR
E3F0 FE06 CPI AACK
E3F2 C2EDE3 JNZ PWAIT
E3F5 C9 RET

E3F6 32 COUNT DB 50

```

```

*****
*
* THE FOLLOWING EQUATES SET THE INPUT TO COME FROM THE SWBD
* PARALLEL PORT 4, WITH STATUS ON ATTENTION PORT BIT 0.
*
*****

```

```

E3F7 DB03 CIUC1 IN 3 ;GET ATTENTION BYTE
E3F9 E601 ANI 1 ;GET BIT 0 ONLY
E3FB CAF7E3 JZ CIUC1 ;WAIT FOR CHARACTER
E3FE DB04 IN 4 ;GET CHARACTER
E400 E67F ANI 7FH ;STRIP OFF THE PARITY
E402 C9 RET

E403 DB03 CSUC1 IN 3 ;GET ATTENTION BYTE
E405 E601 ANI 1 ;GET BIT 0 ONLY
E407 EE01 XRI 1 ;CHANGE POLARITY

```

E409 C31BE4 JMP STAT ;RETURN PROPER INDICATION

*
* THE FOLLOWING EQUATES SET THE INPUT FROM THE DEVICES TO COME
* FROM THE SWITCHBOARD SERIAL PORT 1.
*

E40C = CICRT EQU \$;INPUT FROM CRT
E40C = CIUR1 EQU \$;INPUT FROM USER READER 1
E40C = CIUR2 EQU \$;INPUT FROM USER READER 2
E40C DB02 CIPTR IN 2 ;INPUT FROM PAPER TAPE READER, GET STATUS
E40E E640 ANI 40H ;WAIT FOR CHARACTER
E410 CA0CE4 JZ CIPTR
E413 DB01 IN 1
E415 E67F ANI 7FH ;STRIP OFF THE PARITY
E417 C9 RET

*
* CONSOLE STATUS ROUTINES, TEST IF A CHARACTER HAS ARRIVED.
*

E418 CD21F8 CSTTY CALL DJTSTAT ;STATUS FROM DISK JOCKEY 2D
E41B 3E00 STAT MVI A,0 ;PREP FOR ZERO RETURN
E41D C0 RNZ ;NOTHING FOUND
E41E 3D DCR A ;RETURN WITH 0FFH
E41F C9 RET

*
* THE FOLLOWING EQUATES CAUSE THE DEVICES TO GET STATUS FROM
* THE SWITCHBOARD SERIAL PORT 1.
*

E420 = CSUR1 EQU \$;STATUS OF USER READER 1
E420 = CSUR2 EQU \$;STATUS OF USER READER 2
E420 = CSPTR EQU \$;STATUS OF PAPER TAPE READER
E420 DB02 CSCRT IN 2 ;STATUS FROM CRT, GET STATUS
E422 E640 ANI 40H ;STRIP OF DATA READY BIT
E424 EE40 XRI 40H ;MAKE CORRECT POLARITY
E426 C31BE4 JMP STAT ;RETURN PROPER INDICATION

*
* LIST DEVICE STATUS ROUTINES.
*

E429 DB02 LSLPT IN 2 ;ALL OTHER DEVICES WAIT
E42B E680 ANI 80H
E42D C8 RZ
E42E 3EFF READY MVI A,0FFH

E430 C9 RET

*
* VIO-X VIDEO DRIVER
*

← CBIOS 44

E431 DB09 COCRT IN 9 ;READ STATUS PORT
E433 E601 ANI 1 ;MASK TXRDY BIT
E435 CA31E4 JZ COCRT ;WAIT FOR READY
E438 79 MOV A,C ;GET CHAR
E439 D308 OUT 8 ;OUTPUT IT
E43B C9 RET ;ALL DONE

*
* ROUTINE FOR OKIDATA PRINTER
* PRINTER IS ON PORT 0 WITH PRINTER READY ON PORT 5 BIT 1
*

E43C DB02 COPTR IN 2 ;INPUT FROM PORT 2
E43E E608 ANI 8 ;WAIT UNTIL OK TO SEND
E440 CA3CE4 JZ COPTR
E443 DB05 COPTR1 IN 5 ;BUFFER FULL?
E445 E601 ANI 1
E447 CA43E4 JZ COPTR1 ;WAIT UNTIL PRINTER READY
E44A 79 MOV A,C ;OUTPUT THE CHARACTER
E44B D300 OUT 0
E44D C9 RET

*
* TERMINAL ROUTINES FOR MULTI- I/O BOARD FOR USE AS CONSOLE
*

E44E 3A3AE3 MIOIN LDA GROUP ;GET GROUP BYTE
E451 F601 ORI CONGRP ;SELECT CONSOLE
E453 D34F OUT GRPSEL
E455 DB4D CONINA IN LSR ;READ STATUS REGISTER
E457 E601 ANI DR ;WAIT TILL CHARACTER READY
E459 CA55E4 JZ CONINA
E45C DB48 IN RBR ;READ CHARACTER
E45E E67F ANI 7FH ;STRIP PARITY
E460 C9 RET


E461 3A3AE3 MIOOUT LDA GROUP ;GET GROUP BYTE
E464 F601 ORI CONGRP ;SELECT CONSOLE
E466 D34F OUT GRPSEL
E468 DB4D CONOUT1 IN LSR ;READ STATUS
E46A E620 ANI THRE ;WAIT TILL TRANSMITTER BUFFER EMPTY
E46C CA68E4 JZ CONOUT1
E46F 79 MOV A,C ;CHARACTER IS IN (C)

```

E470 D348      OUT      THR          ;OUTPUT TO TRANSMITTER BUFFER
E472 C9        RET
E473 3A3AE3    MIOSTAT LDA      GROUP      ;GET GROUP BYTE
E476 F601     ORI      CONGRP     ;SELECT CONSOLE
E478 D34F     OUT      GRPSEL
E47A DB4D     IN       LSR        ;READ STATUS REGISTER
E47C E601     ANI      DR
E47E C8       RZ
E47F 3EFF     MVI      A,0FFH     ;CHARACTER READY
E481 C9        RET
    
```

```

*****
*
* GOCPM IS THE ENTRY POINT FROM COLD BOOTS, AND WARM BOOTS. IT
* INITIALIZES SOME OF THE LOCATIONS IN PAGE 0, AND SETS UP THE
* INITIAL DMA ADDRESS (80H).
*
*****
    
```



```

E482 218000    GOCPM  LXI      H,BUFF      ;SET UP INITIAL DMA ADDRESS
E485 CD1DE5    CALL     SETDMA
E488 3EC3      MVI      A,(JMP)      ;INITIALIZE JUMP TO WARM BOOT
E48A 320000    STA      WBOT
E48D 320500    STA      ENTRY      ;INITIALIZE JUMP TO BDOS
E490 2103E3    LXI      H,WBOOTE    ;ADDRESS IN WARM BOOT JUMP
E493 220100    SHLD    WBOT+1
E496 2106D5    LXI      H,BDOS+6    ;ADDRESS IN BDOS JUMP
E499 220600    SHLD    ENTRY+1
E49C AF        XRA      A          ;A ← 0
E49D 32F4EE    STA      BUFSEC     ;DISK JOCKEY BUFFER EMPTY
E4A0 3218E7    STA      BUFWRTN    ;SET BUFFER NOT DIRTY FLAG
E4A3 3A0400    LDA      CDISK      ;JUMP TO CP/M WITH CURRENTLY SELECTED DISK IN C
E4A6 4F        MOV      C,A
E4A7 3AD4E4    LDA      CWFLG
E4AA B7        ORA      A
E4AB 11D6E4    LXI      D,COLDBEG   ;BEGINNING OF INITIAL COMMAND
E4AE 3E01      MVI      A,COLDEND-COLDBEG+1 ;LENGTH OF COMMAND
E4B0 CAB8E4    JZ       CLDCMND
E4B3 11D7E4    LXI      D,WARBEG
E4B6 3E01      MVI      A,WARMEND-WARBEG+1
E4B8 2108CD    CLDCMND LXI      H,CCP+8   ;COMMAND BUFFER
E4BB 3207CD    STA      CCP+7
E4BE 47        MOV      B,A
E4BF CDE0E7    CALL     MOVLOP
E4C2 3AD4E4    LDA      CWFLG
E4C5 B7        ORA      A
E4C6 3AD5E4    LDA      AUTOFLG
E4C9 CACDE4    JZ       CLDBOT
E4CC 1F        RAR
E4CD 1F        CLDBOT RAR
E4CE DA00CD    JC       CCP
E4D1 C303CD    JMP      CCP+3      ;ENTER CP/M
E4D4 00        CWFLG  DB      0          ;COLD/WARM BOOT FLAG
    
```

```
*****
*
* THE FOLLOWING BYTE DETERMINES IF AN INITIAL COMMAND IS TO BE
* GIVEN TO CP/M ON WARM OR COLD BOOTS. THE VALUE OF THE BYTE IS
* USED TO GIVE THE COMMAND TO CP/M:
*
* 0 = NEVER GIVE COMMAND.
* 1 = GIVE COMMAND ON COLD BOOTS ONLY.
* 2 = GIVE THE COMMAND ON WARM BOOTS ONLY.
* 3 = GIVE THE COMMAND ON WARM AND COLD BOOTS.
*****
```

```
E4D5 00 AUTOFLG DB 0 ;AUTO COMMAND FEATURE
```

```
*****
*
* IF THERE IS A COMMAND INSERTED HERE, IT WILL BE GIVEN IF THE
* AUTO FEATURE IS ENABLED.
* FOR EXAMPLE:
*
* COLDBEG DB 'MBASIC MYPROG'
* COLDEND DB 0
*
* WILL EXECUTE MICROSOFT BASIC, AND MBASIC WILL EXECUTE THE
* "MYPROG" BASIC PROGRAM.
*****
```

```
E4D6 00 COLDBEG DB '' ;COLD BOOT COMMAND GOES HERE
COLDEND DB 0
E4D7 00 WARBEG DB '' ;WARM BOOT COMMAND GOES HERE
WARMEND DB 0
```

```
*****
*
* WBOOT LOADS IN ALL OF CP/M EXCEPT THE CBIOS, THEN INITIALIZES
* SYSTEM PARAMETERS AS IN COLD BOOT. SEE THE COLD BOOT LOADER
* LISTING FOR EXACTLY WHAT HAPPENS DURING WARM AND COLD BOOTS.
*****
```

```
E4D8 310001 WBOOT LXI SP,TPA ;SET UP STACK POINTER
E4DB 3E01 MVI A,1
E4DD 32D4E4 STA CWFLG ;SET COLD/WARM BOOT FLAG
E4E0 AF XRA A
E4E1 4F MOV C,A
E4E2 2100CB LXI H,CCP-200H ;INITIAL DMA ADDRESS
E4E5 E5 PUSH H
E4E6 3223E9 STA HEAD
E4E9 3E01 MVI A,1
E4EB F5 PUSH PSW ;SAVE FIRST SECTOR - 1
E4EC CDF5E7 CALL HDDRV ;SELECT DRIVE A
E4EF 0E00 MVI C,0
E4F1 CD14E8 CALL HDTRK ;HOME THE DRIVE
E4F4 F1 WARMLOD POP PSW ;RESTORE SECTOR
```

```

E4F5 E1      POP      H          ;RESTORE DMA ADDRESS
E4F6 3C      INR      A
E4F7 3207E9  STA      HDSECTR
E4FA FE0C    CPI      12         ;PAST BDOS ?
E4FC CA82E4  JZ       GOCPM          ;YES, ALL DONE
E4FF 24      INR      H          ;UPDATE DMA ADDRESS
E500 24      INR      H
E501 227EE8  SHLD     HDADD
E504 E5      PUSH     H
E505 F5      PUSH     PSW
E506 01000A  WARMRD  LXI      B,RETRIES*100H+0 ;RETRY COUNTER
E509 C5      WRMREAD PUSH     B          ;SAVE THE RETRY COUNT
E50A CD64E8  CALL     HDREAD        ;READ THE SECTOR
E50D C1      POP      B
E50E D2F4E4  JNC     WARMLOD        ;TEST FOR ERROR
E511 05      DCR     B          ;UPDATE THE ERROR COUNT
E512 C209E5  JNZ     WRMREAD        ;KEEP TRYING IF NOT TO MANY ERRORS
E515 76      HLT
E516 00      DB      0          ;TRY NOT TO SCREW UP DECISION CPU'S
    
```

```

*****
*
* SETSEC JUST SAVES THE DESIRED SECTOR TO SEEK TO UNTIL AN
* ACTUAL READ OR WRITE IS ATTEMPTED.
*
*****
    
```

```

E517 60      SETSEC  MOV      H,B
E518 69      MOV      L,C
E519 22ECEE  SHLD     CPMSEC
E51C C9      DONOP  RET          ;NULL SINGLE.COM HOOKUP FOR NO FLOPPIES
    
```

```

*****
*
* SETDMA SAVES THE DMA ADDRESS FOR THE DATA TRANSFER.
*
*****
    
```

```

E51D 60      SETDMA  MOV      H,B          ;HL <- BC
E51E 69      MOV      L,C
E51F 22F8E6  SHLD     CPMDMA        ;CP/M DMA ADDRESS
E522 C9      RET
    
```

```

*****
*
* HOME IS TRANSLATED INTO A SEEK TO TRACK ZERO.
*
*****
    
```

```

E523 0E00    HOME   MVI      C,0          ;TRACK TO SEEK TO
    
```

```

*****
*
* SETTRK SAVES THE TRACK # TO SEEK TO. NOTHING IS DONE AT THIS
* POINT, EVERYTHING IS DEFFERED UNTIL A READ OR WRITE.
*
*****
    
```

```

E525 79      SETTRK  MOV     A,C           ;A <- TRACK #
E526 32EFEE  STA     CPMTRK        ;CP/M TRACK #
E529 C9      RET
    
```

*
* SECTRAN TRANSLATES A LOGICAL SECTOR # INTO A PHYSICAL SECTOR *
* #. *
* *

```

E52A 3AE5EE  SECTRAN LDA     CPMDRV           ;GET THE DRIVE NUMBER
E52D FE03    CPI     MAXHD*LOGDSK    ;OVER THE # OF HARD DISKS ?
E52F DA61E5  JC      TRANHD
    
```

```

E532 03      TRANFP  INX     B
E533 D5      PUSH   D           ;SAVE TABLE ADDRESS
E534 C5      PUSH   B           ;SAVE SECTOR #
E535 CD7CE6  CALL  GETDPB          ;GET DPB ADDRESS INTO HL
E538 7E      MOV    A,M         ;GET # OF CP/M SECTORS/TRACK
E539 B7      ORA   A           ;CLEAR CARY
E53A 1F      RAR   A           ;DIVIDE BY TWO
E53B 91      SUB   C
E53C F5      PUSH  PSW          ;SAVE ADJUSTED SECTOR
E53D FA49E5  JM    SIDETWO
E540 F1      SIDEA  POP   PSW          ;DISCARD ADJUSTED SECTOR
E541 C1      POP   B           ;RESTORE SECTOR REQUESTED
E542 D1      POP   D           ;RESTOR ADDRESS OF XLT TABLE
E543 EB      SIDEONE XCHG    ;HL <- &(TRANSLATION TABLE)
E544 09      DAD   B           ;BC = OFFSET INTO TABLE
E545 6E      MOV   L,M         ;HL <- PHYSICAL SECTOR
E546 2600    MVI   H,0
E548 C9      RET
    
```

```

E549 010F00  SIDETWO LXI   B,15          ;OFFSET TO SIDE BIT
E54C 09      DAD   B
E54D 7E      MOV   A,M
E54E E608    ANI   8           ;TEST FOR DOUBLE SIDED
E550 CA40E5  JZ    SIDEA          ;MEDIA IS ONLY SINGLE SIDED
E553 F1      POP   PSW          ;RETRIEVE ADJUSTED SECTOR
E554 C1      POP   B
E555 2F      CMA          ;MAKE SECTOR REQUEST POSITIVE
E556 3C      INR   A
E557 4F      MOV   C,A         ;MAKE NEW SECTOR THE REQUESTED SECTOR
E558 D1      POP   D
E559 CD43E5  CALL  SIDEONE
E55C 3E80    MVI   A,80H          ;SIDE TWO BIT
E55E B4      ORA   H           ; AND SECTOR
E55F 67      MOV   H,A
E560 C9      RET
    
```

```

E561 60      TRANHD  MOV   H,B
E562 69      MOV   L,C
E563 23      INX   H
    
```


E564 C9 RET

```
*****
*
* SETDRV SELECTS THE NEXT DRIVE TO BE USED IN READ/WRITE
* OPERATIONS. IF THE DRIVE HAS NEVER BEEN SELECTED BEFORE, A
* PARAMETER TABLE IS CREATED WHICH CORRECTLY DESCRIBES THE
* DISKETTE CURRENTLY IN THE DRIVE. DISKETTES CAN BE OF FOUR
* DIFFERENT SECTOR SIZES:
*   1) 128 BYTES SINGLE DENSITY.
*   2) 256 BYTES DOUBLE DENSITY.
*   3) 512 BYTES DOUBLE DENSITY.
*   4) 1024 BYTES DOUBLE DENSITY.
*****
```

```
E565 79      SETDRV  MOV    A,C          ;SAVE THE DRIVE #
E566 32EEEE  STA    CPMDRV
E569 FE04    CPI    MAXFLOP+(MAXHD*LOGDSK) ;CHECK FOR A VALID DRIVE #
E56B D26DE6  JNC    ZRET          ;ILLEGAL DRIVE #
E56E 7B      MOV    A,E          ;TEST IF DRIVE EVER LOGGED IN BEFORE
E56F E601    ANI    1
E571 C254E6  JNZ    SETDRV1       ;BIT 0 OF E = 0 -> NEVER SELECTED BEFORE
E574 3AE5EE  LDA    CPMDRV       ;GET THE DRIVE NUMBER
E577 FE03    CPI    MAXHD*LOGDSK ;OVER THE # OF HARD DISKS ?
E579 DA27E6  JC     DRVHD
E57C D603    SUI    MAXHD*LOGDSK
E57E 4F      MOV    C,A          ;SAVE DRIVE #
E57F 3E00    MVI    A,0          ;HAVE THE FLOPPIES BEEN ACCESSED YET ?
E580 =      FLOPFLG EQU    $-1
E581 A7      ANA    A
E582 C2D2E5  JNZ    FLOPOK
E585 0611    MVI    B,17          ;FLOPPIES HAVN'T BEEN ACCESSED
E587 2100F8  LXI    H,DJBOOT     ;CHECK IF 2D CONTROLLER IS INSTALLED
E58A 3EC3    MVI    A,(JMP)
E58C BE      CLOPP  CMP    M
E58D C26DE6  JNZ    ZRET
E590 23      INX    H
E591 23      INX    H
E592 23      INX    H
E593 05      DCR    B
E594 C28CE5  JNZ    CLOPP
E597 11AFE5  LXI    D,DJINIT     ;INITIALIZATION SEQUENCE
E59A 21E2FF  LXI    H,ORIGIN+7E2H ;LOAD ADDRESS
E59D 061E    MVI    B,30          ;BYTE COUNT
E59F CDE0E7  CALL   MOVLOP
E5A2 3EFF    MVI    A,0FFH       ;START 1791
E5A4 32F9FB  STA    DREG
E5A7 3ED0    MVI    A,CLRCMD     ;1791 RESET
E5A9 32FCFB  STA    CMDREG
E5AC C3CDE5  JMP    DJNEXT

E5AF 0000001800DJINIT DB    0, 0, 0, 18H, 0, 0, 8, 0, 7EH, 0, 8, 0, 9, 0FFH, 9, 0FFH
E5BF 09FF09FF09      DB    9, 0FFH, 9, 0FFH, 9, 0, 1, 0, 0, 0, 0, 0, 0, 0

E5CD 3E01      DJNEXT MVI    A,1          ;SAVE 2D INITIALIZED FLAG
```

```

E5CF 3280E5          STA      FLOPFLG
E5D2 210100          FLOPOK LXI      H,1          ;SELECT SECTOR 1 OF TRACK 1
E5D5 22F0EE          SHLD    TRUESEC
E5D8 3E01            MVI     A,1
E5DA 32EFEE          STA     CPMTRK
E5DD CDAAE7          CALL    FILL          ;FLUSH BUFFER AND REFILL
E5E0 DA6DE6          JC      ZRET          ;TEST FOR ERROR RETURN
E5E3 CD27F8          CALL    DJSTAT        ;GET STATUS ON CURRENT DRIVE
E5E6 E60C            ANI     0CH           ;STRIP OFF UNWANTED BITS
E5E8 F5              PUSH    PSW           ;USED TO SELECT A DPB
E5E9 1F              RAR
E5EA 2195E6          LXI     H,XLTS        ;TABLE OF XLT ADDRESSES
E5ED 5F              MOV     E,A
E5EE 1600            MVI     D,0
E5F0 19              DAD     D
E5F1 E5              PUSH    H             ;SAVE POINTER TO PROPER XLT
E5F2 CD7CE6          CALL    GETDPB        ;GET DPH POINTER INTO DE
E5F5 EB              XCHG
E5F6 D1              POP     D
E5F7 0602            MVI     B,2           ;NUMBER OF BYTES TO MOVE
E5F9 CDE0E7          CALL    MOVLOP        ;MOVE THE ADDRESS OF XLT
E5FC 110800          LXI     D,8           ;OFFSET TO DPB POINTER
E5FF 19              DAD     D             ;HL <- &DPH.DPB
E600 E5              PUSH    H
E601 2A07F8          LHLD   ORIGIN+7      ;GET ADDRESS OF DJ TERMINAL OUT ROUTINE
E604 23              INX     H             ;BUMP TO LOOK AT ADDRESS OF
;                   ;      UART STATUS LOCATION

E605 7E              MOV     A,M
E606 EE03            XRI     3             ;ADJUST FOR PROPER REV DJ
E608 6F              MOV     L,A
E609 26FB            MVI     H,(ORIGIN+300H)/100H
E60B 7E              MOV     A,M
E60C E608            ANI     DBLSID        ;CHECK DOUBLE SIDED BIT
E60E 11FCE9          LXI     D,DPB128S    ;BASE FOR SINGLE SIDED DPB'S
E611 C217E6          JNZ     SIDEOK
E614 113CEA          LXI     D,DPB128D    ;BASE OF DOUBLE SIDED DPB'S
E617 EB              SIDEOK XCHG          ;HL <- DBP BASE, DE <- &DPH.DPB
E618 D1              POP     D             ;RESTORE DE (POINTER INTO DPH)
E619 F1              POP     PSW           ;OFFSET TO CORRECT DPB
E61A 17              RAL
E61B 17              RAL
E61C 4F              MOV     C,A
E61D 0600            MVI     B,0
E61F 09              DAD     B
E620 EB              XCHG          ;PUT DPB ADDRESS IN DPH
E621 73              MOV     M,E
E622 23              INX     H
E623 72              MOV     M,D
E624 C354E6          JMP     SETDRV1      ;SKIP OVER THE HARD DISK SELECT

E627 CD73E6          DRVHD CALL    DIVLOG        ;DIVIDE BY LOGICAL DISKS PER DRIVE
E62A 79              MOV     A,C
E62B 3229E9          STA     HDDISK
E62E CD17E9          CALL    DRVPTR
E631 7E              MOV     A,M
E632 3C              INR     A

```

```

E633 C254E6      JNZ      SETDRV1
E636 F6FC        ORI      NULL          ;SELECT DRIVE
E638 D352        OUT      HDFUNC
E63A 3E05        MVI      A,SCENBL      ;ENABLE THE CONTROLLER
E63C D350        OUT      HDCNTL
E63E 0EEF        MVI      C,239          ;WAIT APPROX 2 MINUTES FOR DISK TO READY
E640 210000      LXI      H,0
E643 2B          TDELAY DCX      H
E644 7C          MOV      A,H
E645 B5          ORA      L
E646 CC71E6      CZ       DCRC
E649 C8          RZ
E64A DB50        IN       HDSTAT      ;TEST IF READY YET
E64C E620        ANI      DRVRDY
E64E C243E6      JNZ      TDELAY
E651 CD06E8      CALL     HDHOME

E654 CD7CE6      SETDRV1 CALL    GETDPB      ;GET ADDRESS OF DPB IN HL
E657 010F00      LXI      B,15          ;OFFSET TO SECTOR SIZE
E65A 09          DAD      B
E65B 7E          MOV      A,M          ;GET SECTOR SIZE
E65C E607        ANI      7H
E65E 32A9E6      STA      SECSIZ
E661 7E          MOV      A,M
E662 1F          RAR
E663 1F          RAR
E664 1F          RAR
E665 1F          RAR
E666 E60F        ANI      0FH
E668 32E7E6      STA      SECPSEC
E66B EB          XCHG      ;HL <- DPH
E66C C9          RET

E66D 210000      ZRET     LXI      H,0          ;SELDRV ERROR EXIT
E670 C9          RET

E671 0D          DCRC     DCR      C          ;CONDITIONAL DECREMENT C ROUTINE
E672 C9          RET

E673 0E00        DIVLOG  MVI      C,0
E675 D603        DIVLOGX SUI      LOGDSK
E677 D8          RC
E678 0C          INR      C
E679 C375E6      JMP      DIVLOGX

```

```

*****
*
* GETDPB RETURNS HL POINTING TO THE DPB OF THE CURRENTLY
* SELECTED DRIVE, DE POINTING TO DPH.
*
*****

```

```

E67C 3AE000      GETDPB  LDA      CPMDRV
E67F 6F          MOV      L,A          ;FORM OFFSET
E680 2600        MVI      H,0
E682 29          DAD      H

```

```

E683 29      DAD      H
E684 29      DAD      H
E685 29      DAD      H
E686 11ACEA  LXI      D,DPBASE      ;BASE OF DPH'S
E689 19      DAD      D
E68A E5      PUSH     H      ;SAVE ADDRESS OF DPH
E68B 110A00  LXI      D,10      ;OFFSET TO DPB
E68E 19      DAD      D
E68F 7E      MOV      A,M      ;GET LOW BYTE OF DPB ADDRESS
E690 23      INX      H
E691 66      MOV      H,M      ;GET LOW BYTE OF DPB
E692 6F      MOV      L,A
E693 D1      POP      D
E694 C9      RET
    
```

```

*****
*
* XLTS IS A TABLE OF ADDRESS THAT POINT TO EACH OF THE XLT
* TABLES FOR EACH SECTOR SIZE.
*
*****
    
```

```

E695 2EE9  XLTS    DW      XLT128      ;XLT FOR 128 BYTE SECTORS
E697 49E9          DW      XLT256      ;XLT FOR 256 BYTE SECTORS
E699 7EE9          DW      XLT512      ;XLT FOR 512 BYTE SECTORS
E69B BBE9          DW      XLT124      ;XLT FOR 1024 BYTE SECTORS
    
```

```

*****
*
* WRITE ROUTINE MOVES DATA FROM MEMORY INTO THE BUFFER. IF THE
* DESIRED CP/M SECTOR IS NOT CONTAINED IN THE DISK BUFFER, THE
* BUFFER IS FIRST FLUSHED TO THE DISK IF IT HAS EVER BEEN
* WRITTEN INTO, THEN A READ IS PERFORMED INTO THE BUFFER TO GET
* THE DESIRED SECTOR. ONCE THE CORRECT SECTOR IS IN MEMORY, THE
* BUFFER WRITTEN INDICATOR IS SET, SO THE BUFFER WILL BE
* FLUSHED, THEN THE DATA IS TRANSFERRED INTO THE BUFFER.
*
*****
    
```

```

E69D 79      WRITE   MOV      A,C      ;SAVE WRITE COMMAND TYPE
E69E 320FE7  STA      WRITTP
E6A1 3E01    MVI      A,1      ;SET WRITE COMMAND
E6A3 06      DB      (MVI) OR (B*8) ;THIS "MVI B" INSTRUCTION CAUSES
                                     ; THE FOLLOWING "XRA A" TO
                                     ; BE SKIPPED OVER.
    
```

```

*****
*
* READ ROUTINE TO BUFFER DATA FROM THE DISK. IF THE SECTOR
* REQUESTED FROM CP/M IS IN THE BUFFER, THEN THE DATA IS SIMPLY
* TRANSFERRED FROM THE BUFFER TO THE DESIRED DMA ADDRESS. IF
* THE BUFFER DOES NOT CONTAIN THE DESIRED SECTOR, THE BUFFER IS
* FLUSHED TO THE DISK IF IT HAS EVER BEEN WRITTEN INTO, THEN
* FILLED WITH THE SECTOR FROM THE DISK THAT CONTAINS THE
* DESIRED CP/M SECTOR.
*
*****
    
```

```
E6A4 AF      READ  XRA  A      ;SET THE COMMAND TYPE TO READ
E6A5 32FBE6  STA  RDWR ;SAVE COMMAND TYPE
```

```
*
* REDWRT CALCULATES THE PHYSICAL SECTOR ON THE DISK THAT
* CONTAINS THE DESIRED CP/M SECTOR, THEN CHECKS IF IT IS THE
* SECTOR CURRENTLY IN THE BUFFER. IF NO MATCH IS MADE, THE
* BUFFER IS FLUSHED IF NECESSARY AND THE CORRECT SECTOR READ
* FROM THE DISK.
*
```

```
E6A8 0600    REDWRT MVI    B,0      ;THE 0 IS MODIFIED TO CONTAIN THE LOG2
E6A9 =       SECSIZ EQU    $-1     ;      OF THE PHYSICAL SECTOR SIZE/128
                                     ;      ON THE CURRENTLY SELECTED DISK.
E6AA 2AECEE          LHLD   CPMSEC  ;GET THE DESIRED CP/M SECTOR #
```

```
E6AD 7C          MOV    A,H
E6AE E680        ANI    80H      ;SAVE ONLY THE SIDE BIT
E6B0 4F          MOV    C,A      ;REMEMBER THE SIDE
E6B1 7C          MOV    A,H
E6B2 E67F        ANI    7FH      ;FORGET THE SIDE BIT
E6B4 67          MOV    H,A
E6B5 2B          DCX    H        ;TEMPORARY ADJUSTMENT
E6B6 05          DIVLOOP DCR    B   ;UPDATE REPEAT COUNT
E6B7 CAC4E6      JZ     DIVDONE
E6BA B7          ORA    A
E6BB 7C          MOV    A,H
E6BC 1F          RAR
E6BD 67          MOV    H,A
E6BE 7D          MOV    A,L
E6BF 1F          RAR            ;DIVIDE THE CP/M SECTOR # BY THE SIZE
                                     ;      OF THE PHYSICAL SECTORS
```

```
E6C0 6F          MOV    L,A
E6C1 C3B6E6      JMP    DIVLOOP
E6C4 23          DIVDONE INX    H
E6C5 7C          MOV    A,H
E6C6 B1          ORA    C        ;RESTORE THE SIDE BIT
E6C7 67          MOV    H,A
E6C8 22F0EE      SHLD   TRUESEC  ;SAVE THE PHYSICAL SECTOR NUMBER
E6CB 21EEEE      LXI    H,CPMDRV ;POINTER TO DESIRED DRIVE,TRACK, AND SECTOR
E6CE 11F2EE      LXI    D,BUFDRV  ;POINTER TO BUFFER DRIVE,TRACK, AND SECTOR
E6D1 0605        MVI    B,5      ;COUNT LOOP
E6D3 05          DTSLOP DCR    B   ;TEST IF DONE WITH COMPARE
E6D4 CAE2E6      JZ     MOVE      ;YES, MATCH. GO MOVE THE DATA
E6D7 1A          LDAX   D        ;GET A BYTE TO COMPARE
E6D8 BE          CMP    M        ;TEST FOR MATCH
E6D9 23          INX    H        ;BUMP POINTERS TO NEXT DATA ITEM
E6DA 13          INX    D
E6DB CAD3E6      JZ     DTSLOP   ;MATCH, CONTINUE TESTING
```

```
*
* DRIVE, TRACK, AND SECTOR DON'T MATCH, FLUSH THE BUFFER IF
*
```

* NECESSARY AND THEN REFILL. *
 * *

E6DE CDAAE7 CALL FILL ;FILL THE BUFFER WITH CORRECT PHYSICAL SECTOR
 E6E1 D8 RC ;NO GOOD, RETURN WITH ERROR INDICATION

 * *
 * MOVE HAS BEEN MODIFIED TO CAUSE EITHER A TRANSFER INTO OR OUT *
 * THE BUFFER. *
 * *

E6E2 3AECEE MOVE LDA CPMSEC ;GET THE CP/M SECTOR TO TRANSFER
 E6E5 3D DCR A ;ADJUST TO PROPER SECTOR IN BUFFER
 E6E6 E600 ANI 0 ;STRIP OFF HIGH ORDERED BITS
 E6E7 = SECPSEC EQU \$-1 ;THE 0 IS MODIFIED TO REPRESENT THE # OF
 ; CP/M SECTORS PER PHYSICAL SECTORS
 ; PUT INTO HL
 E6E8 6F MOV L,A
 E6E9 2600 MVI H,0
 E6EB 29 DAD H ;FORM OFFSET INTO BUFFER
 E6EC 29 DAD H
 E6ED 29 DAD H
 E6EE 29 DAD H
 E6EF 29 DAD H
 E6F0 29 DAD H
 E6F1 29 DAD H
 E6F2 11ECEA LXI D,BUFFER ;BEGINNING ADDRESS OF BUFFER
 E6F5 19 DAD D ;FORM BEGINNING ADDRESS OF SECTGR TO TRANSFER
 E6F6 EB XCHG ;DE = ADDRESS IN BUFFER
 E6F7 210000 LXI H,0 ;GET DMA ADDRESS, THE 0 IS MODIFIED T/
 ; CONTAIN THE DMA ADDRESS
 E6F8 = CPMDMA EQU \$-2
 E6FA 3E00 MVI A,0 ;THE ZERO GETS MODIFIED TO CONTAIN
 ; A ZERO IF A READ, OR A 1 IF WRITE
 E6FB = RDWR EQU \$-1
 E6FC A7 ANA A ;TEST WHICH KIND OF OPERATION
 E6FD C205E7 JNZ INTO ;TRANSFER DATA INTO THE BUFFER
 E700 CDDEE7 OUTOF CALL MOVER
 E703 AF XRA A
 E704 C9 RET
 E705 EB INTO XCHG ;
 E706 CDDEE7 CALL MOVER ;MOVE THE DATA, HL = DESTINATION
 ; DE = SOURCE
 E709 3E01 MVI A,1
 E70B 3218E7 STA BUFWRN ;SET BUFFER WRITTEN INTO FLAG
 E70E 3E00 MVI A,0 ;CHECK FOR DIRECTORY WRITE
 E70F = WRITYP EQU \$-1
 E710 3D DCR A
 E711 3E00 MVI A,0
 E713 320FE7 STA WRITYP ;SET NO DIRECTORY WRITE
 E716 C0 RNZ ;NO ERROR EXIT

```

*
* FLUSH WRITES THE CONTENTS OF THE BUFFER OUT TO THE DISK IF
* IT HAS EVER BEEN WRITTEN INTO.
*
*****

```

```

E717 3E00      FLUSH  MVI    A,0          ;THE 0 IS MODIFIED TO REFLECT IF
                ;          THE BUFFER HAS BEEN WRITTEN INTO
E718 =        BUFWRN EQU    $-1
E719 A7        ANA     A          ;TEST IF WRITTEN INTO
E71A C8        RZ           ;NOT WRITTEN, ALL DONE

E71B 2118F8    LXI     H,DJWRITE ;WRITE OPERATION FOR DISK JOCKEY
E71E 1199E8    LXI     D,HDWRITE ;WRITE OPERATION FOR HARD DISK
E721 CDEDE7    CALL    DECIDE

```

```

*****
*
* PREP PREPARES TO READ/WRITE THE DISK. RETRIES ARE ATTEMPTED.
* UPON ENTRY, H&L MUST CONTAIN THE READ OR WRITE OPERATION
* ADDRESS.
*
*****

```

```

E724 F3        PREP   DI          ;RESET INTERRUPTS
E725 AF        XRA     A          ;RESET BUFFER WRITTEN FLAG
E726 3218E7    STA     BUFWRN
E729 228BE7    SHLD   RETRYOP    ;SET UP THE READ/WRITE OPERATION
E72C 060A      MVI     B,RETRIES ;MAXIMUM NUMBER OF RETRIES TO ATTEMPT
E72E C5        RETRYLP PUSH    B    ;SAVE THE RETRY COUNT
E72F 3AF2EE    LDA     BUFDRV    ;GET DRIVE NUMBER INVOLVED IN THE OPERATION
E732 FE03      CPI     MAXHD*LOGDSK
E734 DA39E7    JC      NOADJST
E737 D603      SUI     MAXHD*LOGDSK

E739 4F        NOADJST MOV    C,A
E73A 2133E3    LXI     H,DJDRV    ;SELECT DRIVE
E73D 11F5E7    LXI     D,HDRV
E740 CDE9E7    CALL    DECIDGO
E743 3AF3EE    LDA     BUFTRK
E746 A7        ANA     A          ;TEST FOR TRACK ZERO
E747 4F        MOV     C,A
E748 C5        PUSH    B
E749 2109F8    LXI     H,DJHOME
E74C 1106E8    LXI     D,HDHOME
E74F CCE9E7    CZ      DECIDGO
E752 C1        POP     B          ;RESTORE TRACK #
E753 210CF8    LXI     H,DJTRK
E756 1114E8    LXI     D,HDTRK
E759 CDE9E7    CALL    DECIDGO
E75C 2AF4EE    LHLD   BUFSEC
E75F 7C        MOV     A,H      ;GET SECTOR INVOLVED IN OPERATION
E760 07        RLC          ;BIT 0 OF A EQUALS SIDE #
E761 E601      ANI     1          ;STRIP OFF UNNECESSARY BITS
E763 4F        MOV     C,A      ;C <- SIDE #
E764 2130F8    LXI     H,DJSIDE

```

```

E767 113DE8      LXI      D,HDSIDE
E76A CDE9E7      CALL     DECIDGO
E76D 2AF4EE      LHL D    BUFSEC
E770 7C          MOV      A,H
E771 E67F        ANI      7FH          ;STRIP OFF SIDE BIT
E773 47          MOV      B,A          ;C <- SECTOR #
E774 4D          MOV      C,L
E775 210FF8      LXI      H,DJSEC
E778 1146E8      LXI      D,HDSEC
E77B CDE9E7      CALL     DECIDGO
E77E 01ECEA      LXI      B,BUFFER     ;SET THE DMA ADDRESS
E781 2112F8      LXI      H,DJDMA
E784 1138E8      LXI      D,HDDMA
E787 CDE9E7      CALL     DECIDGO
E78A CD0000      CALL     0             ;GET OPERATION ADDRESS
E78B =          RETRYOP EQU    $-2
E78D C1          POP      B             ;RESTORE THE RETRY COUNTER
E78E 3E00        MVI      A,0           ;NO ERROR EXIT STATUS
E790 D0          RNC
E791 05          DCR      B             ;RETURN NO ERROR
E792 37          STC
E793 3EFF        MVI      A,0FFH       ;UPDATE THE RETRY COUNTER
E795 C8          RZ                   ;ASSUME RETRY COUNT EXPIRED
E796 78          MOV      A,B           ;ERROR RETURN
E797 FE05        CPI      RETRIES/2     ;RETURN SAD NEWS
E799 C22EE7      JNZ      RETRYLP       ;RESEEK AFTER HALF RETRIES DONE
E79C C5          PUSH     B             ;TRY AGAIN
E79D 2109F8      LXI      H,DJHOME
E7A0 1106E8      LXI      D,HDHOME
E7A3 CCE9E7      CZ       DECIDGO
E7A6 C1          POP      B
E7A7 C32EE7      JMP      RETRYLP       ;TRY AGAIN
    
```

```

*****
*
* FILL FILLS THE BUFFER WITH A NEW SECTOR FROM THE DISK.
*
*****
    
```

```

E7AA CD17E7      FILL     CALL     FLUSH          ;FLUSH BUFFER FIRST
E7AD D8          RC              ;CHECK FOR ERROR
E7AE 11EEEE      LXI      D,CPMDRV       ;UPDATE THE DRIVE, TRACK, AND SECTOR
E7B1 21F2EE      LXI      H,BUFDRV
E7B4 0604        MVI      B,4           ;NUMBER OF BYTES TO MOVE
E7B6 CDE0E7      CALL     MOVLOP        ;COPY THE DATA
E7B9 3AFBE6      LDA      RDWR
E7BC A7          ANA      A
E7BD CAD2E7      JZ       FREAD
E7C0 3A0FE7      LDA      WRITTP
E7C3 3D          DCR      A
E7C4 3D          DCR      A
E7C5 C8          RZ
E7C6 CD7CE6      CALL     GETDPB
E7C9 110F00      LXI      D,15
E7CC 19          DAD      D
E7CD 7E          MOV      A,M
    
```


E7CE E603 ANI 3
 E7D0 3D DCR A
 E7D1 C8 RZ

E7D2 = FREAD EQU \$
 E7D2 2115F8 LXI H,DJREAD
 E7D5 1164E8 LXI D,HDREAD
 E7D8 CDEDE7 CALL DECIDE
 E7DB C324E7 JMP PREP ;SELECT DRIVE, TRACK, AND SECTOR.
 ; THEN READ THE BUFFER

 *
 * MOVER MOVES 128 BYTES OF DATA. SOURCE POINTER IN DE, DEST *
 * POINTER IN HL. *
 *

E7DE 0680 MOVER MVI B,128 ;LENGTH OF TRANSFER
 E7E0 1A MOVLOP LDAX D ;GET A BTE OF SOURCE
 E7E1 77 MOV M,A ;MOVE IT
 E7E2 13 INX D ;BUMP POINTERS
 E7E3 23 INX H
 E7E4 05 DCR B ;UPDATE COUNTER
 E7E5 C2E0E7 JNZ MOVLOP ;CONTINUE MOVING UNTIL DONE
 E7E8 C9 RET

 *
 * ROUTINES TO DECIDE WHICH CONTROLLER TO USE. *
 *

E7E9 CDEDE7 DECIDGO CALL DECIDE ;WHICH CONTROLLER ?
 E7EC E9 PCHL

E7ED 3AF2EE DECIDE LDA BUFDRV ;GET PROPER ROUTINE INTO H&L, BASED
 E7F0 FE03 CPI MAXHD*LOGDSK
 E7F2 D0 RNC
 E7F3 EB XCHG
 E7F4 C9 RET

 *
 * THE FOLLOWING IS THE EQUIVALENT OF THE LOWEST LEVEL DRIVERS *
 * FOR THE HARD DISK. *
 *

E7F5 79 HDDRV MOV A,C ;SELECT HARD DISK DRIVE
 E7F6 CD73E6 CALL DIVLOG ;GET THE PHYSICAL DRIVE #
 E7F9 79 MOV A,C
 E7FA 3229E9 STA HDDISK ;SELECT THE DRIVE
 E7FD F6FC ORI NULL
 E7FF D352 OUT HDFUNC
 E801 3E0F MVI A,WENABL

```

E803 D350      OUT      HDCNTL
E805 C9        RET

E806 CD17E9    HDHOME   CALL      DRVPTN
E809 3600      MVI      M,0      ;SET TRACK TO ZERO
E80B DB50      IN        HDSTAT  ;TEST STATUS
E80D E601      ANI      TKZERO  ;AT TRACK ZERO ?
E80F C8        RZ
E810 AF        XRA      A      ;YES
E811 C325E8    JMP      ACCOK

E814 CD17E9    HDTRK   CALL      DRVPTN  ;GET POINTER TO CURRENT TRACK
E817 5E        MOV      E,M      ;GET CURRENT TRACK
E818 71        MOV      M,C      ;UPDATE THE TRACK
E819 7B        MOV      A,E      ;NEED TO SEEK AT ALL ?
E81A 91        SUB      C
E81B C8        RZ
E81C 3F        CMC
E81D DA22E8    JC        HDTRK2  ;GET CARRY INTO DIRECTION
E820 2F        CMA
E821 3C        INR      A
E822 C325E8    HDTRK2  JMP      ACCOK
E825 47        ACCOK   MOV      B,A      ;PREP FOR BUILD
E826 CD22E9    CALL     BUILD
E829 E6FB      SLOOP   ANI      NSTEP  ;GET STEP PULSE LOW
E82B D352      OUT     HDFUNC  ;OUTPUT LOW STEP LINE
E82D F604      ORI     PSTEP  ;SET STEP LINE HIGH
E82F D352      OUT     HDFUNC  ;OUTPUT HIGH STEP LINE
E831 05        DCR     B      ;UPDATE REPEAT COUNT
E832 C229E8    JNZ     SLOOP  ;KEEP GOING THE REQUIRED # OF TRACKS
E835 C33EE8    JMP     WSDONE

E838 60        HDDMA   MOV     H,B      ;SAVE THE DMA ADDRESS
E839 69        MOV     L,C
E83A 227EE8    SHLD   HDADD
E83D =         HDSIDE  EQU     $
E83D C9        RET

E83E DB50      WSDONE  IN      HDSTAT  ;WAIT FOR SEEK COMPLETE TO FINISH
E840 E604      ANI     COMPLT
E842 CA3EE8    JZ     WSDONE
E845 C9        RET

E846 79        HDSEC   MOV     A,C
E847 CD5BE8    CALL   DIVSPT
E84A C615      ADI     HDSPT
E84C A7        ANA     A
E84D CC57E8    CZ     GETSPT
E850 3207E9    STA     HDSECTR
E853 79        MOV     A,C
E854 3223E9    STA     HEAD
E857 3E15      GETSPT  MVI     A,HDSPT
E859 0D        DCR     C
E85A C9        RET

E85B 0E00      DIVSPT  MVI     C,0

```

E85D D615	DIVSPTX	SUI	HDSPT	
E85F D8		RC		
E860 0C		INR	C	
E861 C35DE8		JMP	DIVSPTX	
E864 CDE2E8	HDREAD	CALL	HDPREP	
E867 D8		RC		
E868 AF		XRA	A	
E869 D351		OUT	HDCMND	
E86B 2F		CMA		
E86C D353		OUT	HDDATA	
E86E D353		OUT	HDDATA	
E870 3E01		MVI	A, RSECT	; READ SECTOR COMMAND
E872 D351		OUT	HDCMND	
E874 CDC8E8		CALL	PROCESS	
E877 D8		RC		
E878 AF		XRA	A	
E879 D351		OUT	HDCMND	
E87B 0680		MVI	B, SECLN/4	
E87D 210000		LXI	H, 0	
E87E =	HDADD	EQU	\$-2	
E880 DB53		IN	HDDATA	
E882 DB53		IN	HDDATA	
E884 DB53	RTL00P	IN	HDDATA	; MOVE FOUR BYTES
E886 77		MOV	M, A	
E887 23		INX	H	
E888 DB53		IN	HDDATA	
E88A 77		MOV	M, A	
E88B 23		INX	H	
E88C DB53		IN	HDDATA	
E88E 77		MOV	M, A	
E88F 23		INX	H	
E890 DB53		IN	HDDATA	
E892 77		MOV	M, A	
E893 23		INX	H	
E894 05		DCR	B	
E895 C284E8		JNZ	RTL00P	
E898 C9		RET		
E899 CDE2E8	HDWRITE	CALL	HDPREP	; PREPARE HEADER
E89C D8		RC		
E89D AF		XRA	A	
E89E D351		OUT	HDCMND	
E8A0 2A7EE8		LHLD	HDADD	
E8A3 0680		MVI	B, SECLN/4	
E8A5 7E	WTLOOP	MOV	A, M	; MOVE 4 BYTES
E8A6 D353		OUT	HDDATA	
E8A8 23		INX	H	
E8A9 7E		MOV	A, M	
E8AA D353		OUT	HDDATA	
E8AC 23		INX	H	
E8AD 7E		MOV	A, M	
E8AE D353		OUT	HDDATA	
E8B0 23		INX	H	
E8B1 7E		MOV	A, M	
E8B2 D353		OUT	HDDATA	

```

E8B4 23      INX      H
E8B5 05      DCR      B
E8B6 C2A5E8  JNZ      WTLOOP
E8B9 3E05    MVI      A,WSECT      ;ISSUE WRITE SECTOR COMMAND
E8BB D351    OUT      HDCMND
E8BD CDC8E8  CALL     PROCESS
E8C0 D8      RC
E8C1 3E10    MVI      A,WFAULT
E8C3 A0      ANA      B
E8C4 37      STC
E8C5 C8      RZ
E8C6 AF      XRA      A
E8C7 C9      RET

E8C8 DB50    PROCESS IN      HDSTAT      ;WAIT FOR COMMAND TO FINISH
E8CA 47      MOV      B,A
E8CB E602    ANI      OPDONE
E8CD CAC8E8  JZ       PROCESS
E8D0 3E07    MVI      A,DSKCLK
E8D2 D350    OUT      HDCNTL
E8D4 DB50    IN      HDSTAT
E8D6 E608    ANI      TMOUT      ;TIMED OUT ?
E8D8 37      STC
E8D9 C0      RNZ
E8DA DB51    IN      HDRESLT
E8DC E602    ANI      RETRY      ;ANY RETRIES ?
E8DE 37      STC
E8DF C0      RNZ
E8E0 AF      XRA      A
E8E1 C9      RET

E8E2 DB50    HDPREP  IN      HDSTAT
E8E4 E620    ANI      DRVRDY
E8E6 37      STC
E8E7 C0      RNZ
E8E8 3E08    MVI      A,ISBUFF    ;INITIALIZE POINTER
E8EA D351    OUT      HDCMND
E8EC CD22E9  CALL     BUILD
E8EF F60C    ORI      0CH
E8F1 D352    OUT      HDFUNC
E8F3 3A23E9  LDA      HEAD
E8F6 D353    OUT      HDDATA      ;FORM HEAD BYTE
E8F8 CD17E9  CALL     DRVPTR
E8FB 7E      MOV      A,M          ;FORM TRACK BYTE
E8FC D353    OUT      HDDATA
E8FE A7      ANA      A
E8FF 0680    MVI      B,80H
E901 CA06E9  JZ       ZKEY
E904 0600    MVI      B,0
E906 3E00    ZKEY    MVI      A,0      ;FORM SECTOR BYTE
E907 =      HDSECTR EQU      $-1
E908 D353    OUT      HDDATA
E90A 78      MOV      A,B
E90B D353    OUT      HDDATA
E90D 3E07    MVI      A,DSKCLK
E90F D350    OUT      HDCNTL

```

E911 3E0F MVI A,WENABL
 E913 D350 OUT HDCNTL
 E915 AF XRA A
 E916 C9 RET

E917 2A29E9 DRVPTR LHLD HDDISK
 E91A EB XCHG
 E91B 1600 MVI D,0
 E91D 212DE9 LXI H,DRIVES
 E920 19 DAD D
 E921 C9 RET

E922 3E00 BUILD MVI A,0
 E923 = HEAD EQU \$-1
 E924 17 RAL
 E925 17 RAL
 E926 17 RAL
 E927 17 RAL
 E928 F600 ORI 0
 E929 = HDDISK EQU \$-1
 E92A EEF0 XRI 0FF0H
 E92C C9 RET

E92D = DRIVES EQU \$
 REPT MAXHD
 DB 0FFH
 ENDM
 E92D+FF DB 0FFH

 *
 * XLT TABLES (SECTOR SKEW TABLES) FOR CP/M 2.0. THESE TABLES *
 * DEFINE THE SECTOR TRANSLATION THAT OCCURS WHEN MAPPING CP/M *
 * SECTORS TO PHYSICAL SECTORS ON THE DISK. THERE IS ONE SKEW *
 * TABLE FOR EACH OF THE POSSIBLE SECTOR SIZES. CURRENTLY THE *
 * TABLES ARE LOCATED ON TRACK 0 SECTORS 6 AND 8. THEY ARE *
 * LOADED INTO MEMORY IN THE CBIOS RAM BY THE COLD BOOT ROUTINE. *
 *

E92E 00 XLT128 DB 0
 E92F 01070D1319 DB 1,7,13,19,25
 E934 050B1117 DB 5,11,17,23
 E938 03090F15 DB 3,9,15,21
 E93C 02080E141A DB 2,8,14,20,26
 E941 060C1218 DB 6,12,18,24
 E945 040A1016 DB 4,10,16,22

E949 00 XLT256 DB 0
 E94A 0102131425 DB 1,2,19,20,37,38
 E950 0304151627 DB 3,4,21,22,39,40
 E956 0506171829 DB 5,6,23,24,41,42
 E95C 0708191A2B DB 7,8,25,26,43,44
 E962 090A1B1C2D DB 9,10,27,28,45,46
 E968 0B0C1D1E2F DB 11,12,29,30,47,48
 E96E 0D0E1F2031 DB 13,14,31,32,49,50

E974	0F10212233	DB	15,16,33,34,51,52
E97A	11122324	DB	17,18,35,36
E97E	00	XLT512 DB	0
E97F	0102030411	DB	1,2,3,4,17,18,19,20
E987	2122232431	DB	33,34,35,36,49,50,51,52
E98F	0506070815	DB	5,6,7,8,21,22,23,24
E997	2526272835	DB	37,38,39,40,53,54,55,56
E99F	090A0B0C19	DB	9,10,11,12,25,26,27,28
E9A7	292A2B2C39	DB	41,42,43,44,57,58,59,60
E9AF	0D0E0F101D	DB	13,14,15,16,29,30,31,32
E9B7	2D2E2F30	DB	45,46,47,48

E9BB	00	XLT124 DB	0
E9BC	0102030405	DB	1,2,3,4,5,6,7,8
E9C4	191A1B1C1D	DB	25,26,27,28,29,30,31,32
E9CC	3132333435	DB	49,50,51,52,53,54,55,56
E9D4	090A0B0C0D	DB	9,10,11,12,13,14,15,16
E9DC	2122232425	DB	33,34,35,36,37,38,39,40
E9E4	393A3B3C3D	DB	57,58,59,60,61,62,63,64
E9EC	1112131415	DB	17,18,19,20,21,22,23,24
E9F4	292A2B2C2D	DB	41,42,43,44,45,46,47,48

```
*****
*
* EACH OF THE FOLLOWING TABLES DESCRIBES A DISKETTE WITH THE
* SPECIFIED CHARACTERISTICS.
*
```

```
*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 128 BYTE SECTORS,
* SINGLE DENSITY, AND SINGLE SIDED.
*
```

E9FC	1A00	DPB128S DW	26	;CP/M SECTORS/TRACK
E9FE	03	DB	3	;BSH
E9FF	07	DB	7	;BLM
EA00	00	DB	0	;EXM
EA01	F200	DW	242	;DSM
EA03	3F00	DW	63	;DRM
EA05	C0	DB	0C0H	;AL0
EA06	00	DB	0	;AL1
EA07	1000	DW	16	;CKS
EA09	0200	DW	2	;OFF
EA0B	01	DB	1H	;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
				;LOG2(#BYTES PER SECTOR/128) + 1 +
				;8 IF DOUBLE SIDED.

```
*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 256 BYTE SECTORS,
* DOUBLE DENSITY, AND SINGLE SIDED.
*
```

```
EA0C 3400 DPB256S DW 52 ;CP/M SECTORS/TRACK
EA0E 04 DB 4 ;BSH
EA0F 0F DB 15 ;BLM
EA10 00 DB 0 ;EXM
EA11 F200 DW 242 ;DSM
EA13 7F00 DW 127 ;DRM
EA15 C0 DB 0C0H ;AL0
EA16 00 DB 0 ;AL1
EA17 2000 DW 32 ;CKS
EA19 0200 DW 2 ;OFF
EA1B 12 DB 12H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.
```

```
*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 512 BYTE SECTORS,
* DOUBLE DENSITY, AND SINGLE SIDED.
*
```

```
EA1C 3C00 DPB512S DW 60 ;CP/M SECTORS/TRACK
EA1E 04 DB 4 ;BSH
EA1F 0F DB 15 ;BLM
EA20 00 DB 0 ;EXM
EA21 1801 DW 280 ;DSM
EA23 7F00 DW 127 ;DRM
EA25 C0 DB 0C0H ;AL0
EA26 00 DB 0 ;AL1
EA27 2000 DW 32 ;CKS
EA29 0200 DW 2 ;OFF
EA2B 33 DB 33H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.
```

```
*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 1024 BYTE SECTORS,
* DOUBLE DENSITY, AND SINGLE SIDED.
*
```

```
EA2C 4000 DP1024S DW 64 ;CP/M SECTORS/TRACK
EA2E 04 DB 4 ;BSH
EA2F 0F DB 15 ;BLM
EA30 00 DB 0 ;EXM
EA31 2B01 DW 299 ;DSM
EA33 7F00 DW 127 ;DRM
EA35 C0 DB 0C0H ;AL0
EA36 00 DB 0 ;AL1
EA37 2000 DW 32 ;CKS
EA39 0200 DW 2 ;OFF
EA3B 74 DB 74H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
```

;8 IF DOUBLE SIDED.

*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 128 BYTE SECTORS,
* SINGLE DENSITY, AND DOUBLE SIDED.
*

EA3C 3400 DPB128D DW 52 ;CP/M SECTORS/TRACK
EA3E 04 DB 4 ;BSH
EA3F 0F DB 15 ;BLM
EA40 01 DB 1 ;EXM
EA41 F200 DW 242 ;DSM
EA43 7F00 DW 127 ;DRM
EA45 C0 DB 0C0H ;AL0
EA46 00 DB 0 ;AL1
EA47 2000 DW 32 ;CKS
EA49 0200 DW 2 ;OFF
EA4B 09 DB 9H

*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 256 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*

EA4C 6800 DPB256D DW 104 ;CP/M SECTORS/TRACK
EA4E 04 DB 4 ;BSH
EA4F 0F DB 15 ;BLM
EA50 00 DB 0 ;EXM
EA51 E601 DW 486 ;DSM
EA53 FF00 DW 255 ;DRM
EA55 F0 DB 0F0H ;AL0
EA56 00 DB 0 ;AL1
EA57 4000 DW 64 ;CKS
EA59 0200 DW 2 ;OFF
EA5B 1A DB 1AH

*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 512 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*

EA5C 7800 DPB512D DW 120 ;CP/M SECTORS/TRACK
EA5E 04 DB 4 ;BSH
EA5F 0F DB 15 ;BLM
EA60 00 DB 0 ;EXM
EA61 3102 DW 561 ;DSM
EA63 FF00 DW 255 ;DRM
EA65 F0 DB 0F0H ;AL0
EA66 00 DB 0 ;AL1
EA67 4000 DW 64 ;CKS

EA69 0200 DW 2 ;OFF
EA6B 3B DB 3BH

*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 1024 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*

EA6C 8000 DP1024D DW 128 ;CP/M SECTORS/TRACK
EA6E 04 DB 4 ;BSH
EA6F 0F DB 15 ;BLM
EA70 00 DB 0 ;EXM
EA71 5702 DW 599 ;DSM
EA73 FF00 DW 255 ;DRM
EA75 F0 DB 0F0H ;AL0
EA76 00 DB 0 ;AL1
EA77 4000 DW 64 ;CKS
EA79 0200 DW 2 ;OFF
EA7B 7C DB 7CH

*
* THE FOLLOWING DPB'S ARE FOR THE STANDARD FORMAT TO BE
* COMPATABLE WITH OLDER VERSIONS OF THE CBIOS.
*

EA7C A002 DPBHD1 DW 672 ;CP/M SECTORS/TRACK
EA7E 05 DB 5 ;BSH
EA7F 1F DB 31 ;BLM
EA80 01 DB 1 ;EXM
EA81 DF07 DW 2015 ;DSM
EA83 FF01 DW 511 ;DRM
EA85 FF DB 0FFH ;AL0
EA86 FF DB 0FFH ;AL1
EA87 0000 DW 0 ;CKS
EA89 0100 DW 1 ;OFF
EA8B 33 DB 33H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.

EA8C A002 DPBHD2 DW 672 ;CP/M SECTORS/TRACK
EA8E 05 DB 5 ;BSH
EA8F 1F DB 31 ;BLM
EA90 01 DB 1 ;EXM
EA91 DF07 DW 2015 ;DSM
EA93 FF01 DW 511 ;DRM
EA95 FF DB 0FFH ;AL0
EA96 FF DB 0FFH ;AL1
EA97 0000 DW 0 ;CKS
EA99 6200 DW 98 ;OFF
EA9B 33 DB 33H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.

```
EA9C A002      DPBHD3 DW      672      ;CP/M SECTORS/TRACK
EA9E 05        DB        5          ;BSH
EA9F 1F        DB        31         ;BLM
EAA0 01        DB        1          ;EXM
EAA1 0404      DW      1028         ;DSM
EAA3 FF01      DW      511         ;DRM
EAA5 FF        DB      0FFH        ;AL0
EAA6 FF        DB      0FFH        ;AL1
EAA7 0000      DW        0          ;CKS
EAA9 C300      DW      195         ;OFF
EAAB 33        DB      33H         ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.
```

```
*****
*
* CP/M DISK PARAMETER HEADERS, UNINITIALIZED.
*
*****
```

```
HEADER MACRO ND,DPB
DW      0          ;TRANSLATION TABLE FILLED IN LATER
DW      0,0,0     ;SCRATCH
DW      DIRBUF    ;DIRECTORY BUFFER
DW      DPB       ;DPB FILLED IN LATER
DW      CSV&ND    ;DIRECTORY CHECK VECTOR
DW      ALV&ND    ;ALLOCATION VECTOR
ENDM
```

```
EAAC = DPBASE EQU $
0000 # DN SET 0
REPT MAXHD ;GENERATE HARD DISK DPH'S FOLLOWED
HEADER %DN,DPBHD1 ; BY FLOPPY DPH'S
DN SET DN+1
HEADER %DN,DPBHD2
DN SET DN+1
HEADER %DN,DPBHD3
DN SET DN+1
ENDM
EAAC+0000 DW 0 ;TRANSLATION TABLE FILLED IN LATER
EAAE+000000000000 DW 0,0,0 ;SCRATCH
EAB4+F6EE DW DIRBUF ;DIRECTORY BUFFER
EAB6+7CEA DW DPBHD1 ;DPB FILLED IN LATER
EAB8+72F0 DW CSV0 ;DIRECTORY CHECK VECTOR
EABA+76EF DW ALV0 ;ALLOCATION VECTOR
EABC+0000 DW 0 ;TRANSLATION TABLE FILLED IN LATER
EABE+000000000000 DW 0,0,0 ;SCRATCH
EAC4+F6EE DW DIRBUF ;DIRECTORY BUFFER
EAC6+8CEA DW DPBHD2 ;DPB FILLED IN LATER
EAC8+6EF1 DW CSV1 ;DIRECTORY CHECK VECTOR
EACA+72F0 DW ALV1 ;ALLOCATION VECTOR
EACC+0000 DW 0 ;TRANSLATION TABLE FILLED IN LATER
EACE+000000000000 DW 0,0,0 ;SCRATCH
EAD4+F6EE DW DIRBUF ;DIRECTORY BUFFER
EAD6+9CEA DW DPBHD3 ;DPB FILLED IN LATER
```

```

EAD8+EFF1      DW      CSV2          ;DIRECTORY CHECK VECTOR
EADA+6EF1      DW      ALV2          ;ALLOCATION VECTOR
              REPT    MAXFLOP
              HEADER  %DN,0
              SET     DN+1
              ENDM
EADC+0000      DW      0            ;TRANSLATION TABLE FILLED IN LATER
EADE+000000000000 DW    0,0,0      ;SCRATCH
EAE4+F6EE      DW      DIRBUF       ;DIRECTORY BUFFER
EAE6+0000      DW      0            ;DPB FILLED IN LATER
EAE8+3AF2      DW      CSV3         ;DIRECTORY CHECK VECTOR
EAEA+EFF1      DW      ALV3         ;ALLOCATION VECTOR
    
```

```
EAEC = BUFFER EQU $
```

```

*****
*
* SIGNON MESSAGE OUTPUT DURING COLD BOOT.
*
*****
    
```

```

EAEC 801A      PROMPT DB      80H, CLEAR          ;CLEAN BUFFER AND SCREEN
EAEE 0A0D0A0D0A DB      ACR,ALF,ACR,ALF,ACR,ALF
EAF4 4D6F72726F DB      'Morrow Designs '
EB03 36        DB      '0'+MSIZE/10             ;CP/M MEMORY SIZE
EB04 32        DB      '0'+(MSIZE MOD 10)
EB05 4B2043502F DB    'K CP/M '                 ;CP/M VERSION NUMBER
EB0C 32        DB      CPMREV/10+'0'
EB0D 2E        DB      '.'
EB0E 32        DB      (CPMREV MOD 10)+'0'
EB0F 2C20436269 DB    ', Cbios rev '
EB1B 322E      DB      REVNUM/10+'0', '.'       ;CBIOS REVISION NUMBER
EB1D 39        DB      REVNUM MOD 10+'0'
EB1E 2E        DB      '.'
EB1F 32        DB      MREV/10+'0'
EB20 30        DB      MREV MOD 10+'0'
EB21 0A0D      DB      ACR,ALF
EB23 466F7220  DB      'For '
EB27 6120446973 DB    'a Disk Jockey 2D/B'
EB39 20616E6420 DB    ' and '
EB3E 6120      DB      'a '
EB40 46756A6974 DB    'Fujitsu M20 '
EB4C 6861726420 DB    'hard disk'
EB55 2E        DB      '.'
EB56 0A0D0A0D  DB      ACR,ALF,ACR,ALF
EB5A 2020202020 DB    ' THE W6GO/K6HHD LIST'
EB74 0A0D      DB      ACR,ALF
EB76 2020202020 DB    ' Electronics Enterprises'
EB92 0A0D      DB      ACR,ALF
EB94 2020202020 DB    ' Rio Linda, California'
EBAF 0A0D      DB      ACR,ALF
EBB1 00        DB      0                ;END OF MESSAGE
    
```

```

*****
*
* UTILITY ROUTINE TO OUTPUT THE MESSAGE POINTED AT BY H&L,
*
*****
    
```

* TERMINATED WITH A NULL. *
 * *

```

EBB2 7E MESSAGE MOV A,M ;GET A CHARACTER OF THE MESSAGE
EBB3 23 INX H ;BUMP TEXT POINTER
EBB4 B7 ORA A ;TEST FOR END
EBB5 C8 RZ ;RETURN IF DONE
EBB6 E5 PUSH H ;SAVE POINTER TO TEXT
EBB7 4F MOV C,A ;OUTPUT CHARACTER IN C
EBB8 CD5CE3 CALL CONOUT ;OUTPUT THE CHARACTER
EBBB E1 POP H ;RESTORE THE POINTER
EBBC C3B2EB JMP MESSAGE ;CONTINUE UNTIL NULL REACHED
    
```

 *
 * CBOOT IS THE COLD BOOT LOADER. ALL OF CP/M HAS BEEN LOADED IN *
 * WHEN CONTROL IS PASSED HERE. *
 * *

```

EBBF 310001 CBOOT LXI SP,TPA ;SET UP STACK

EBC2 AF XRA A ;CLEAR COLD BOOT FLAG
EBC3 32D4E4 STA CWFLG
EBC6 323AE3 STA GROUP ;CLEAR GROUP SELECT BYTE
EBC9 2100FC LXI H,DJRAM ; OF THE JUMP TABLE.
EBCC 1100F8 LXI D,ORIGIN
EBCF 0633 MVI B,33H ;SIZE OF JUMP TABLE
EBD1 CDE0E7 CALL MOVLOP ;COPY TABLE
EBD4 3EC0 MVI A,INTIOBY
EBD6 320300 STA IOBYTE
EBD9 CDFFEF CALL TINIT ;INITIALIZE THE TERMINAL
EBDC CD34EC CALL LINIT ;INITIALIZE THE LIST DEVICE
EBDF 21ECEA LXI H,PROMPT ;PREP FOR SENDING SIGNON MESSAGE
EBE2 CDB2EB CALL MESSAGE ;SEND THE PROMPT
EBE5 AF XRA A ;SELECT DISK A
EBE6 32EEEE STA CPMDRV
EBE9 320400 STA CDISK
EBEC 3280E5 STA FLOPFLG
EBEF 2103E3 LXI H,BIOS+3 ;PATCH COLD BOOT TO WARM CODE
EBF2 2201E3 SHLD BIOS+1
EBF5 C382E4 JMP GOCPM
    
```

 *
 * TERMINAL INITIALIZATION ROUTINE *
 * *
 * *
 * THIS INITIALIZING ROUTINE SAMPLES BIT 0 OF SWBD PORT 7 TO *
 * DETERMINE IF THE KEYBOARD IS PLUGGED IN. IF THE KEYBOARD IS *
 * PLUGGED IN, THE LSB RETURNS A 0. OTHERWISE, IT IS A 1. *
 * THIS 1 IS ADDED TO IOBYTE TO CHANGE THE CONSOLE INPUT FROM *
 * THE SWBD PARALLEL PORT 4 (THE KEYBOARD) TO THE SWBD SERIAL *
 * PORT THAT RECEIVES RS232 DATA FROM THE RS232 TERMINAL. *
 * *



```
EBF8 1B7B3F TV950 DB 1BH,7BH,3FH ;TELEVIDEO COMMAND SEQUENCE
EBFB 31373100 DB '171',0
```

```
EBFF 21F8EB TINIT LXI H,TV950 ;SET TELEVIDEO 950 TO 19.2KB
EC02 CDB2EB CALL MESSAGE
```

```
EC05 2AFFFF LHL D0FFFF ;WAIT FOR TERMINAL
EC08 2B WAITC DCX H
EC09 7C MOV A,H
EC0A B5 ORA L
EC0B C208EC JNZ WAITC
EC0E 3A3AE3 LDA GROUP 0 ;GET GROUP BYTE
EC11 F601 ORI CONGRP 1 ;SELECT CONSOLE DEVICE
EC13 D34F (+7) OUT GRPSEL (+7)
EC15 DB48 IN RBR Base ;CLEAR RECIEVER BUFFERS
EC17 DB48 IN RBR Base
```

```
EC19 AF XRA A
EC1A D34D OUT LSR +5 ;CLEAR STATUS LINE STATUS REGISTER
EC1C D349 OUT IER +1 ;SET NO INTERRUPTS INTERRUPT ENABLE REGISTER
EC1E 2A36E3 LHL DEFCON (6) ;GET DEFAULT BAUD RATE
EC21 EB XCHG
EC22 3E87 MVI A,DLAB+WLS1+WLS0+STB 80H 2 1 4 = 87H ;ENABLE DIVISOR ACCESS LATCH
EC24 D34B OUT LCR +3 Line ctrl reg ;SET THE BAUD RATE IN (DE)
EC26 7A MOV A,D
EC27 D349 OUT DLM Divisor (MSB) +1 ;SET UPPER DIVISOR
EC29 7B MOV A,E
EC2A D348 OUT DLL Divisor (LSB) 0 ;SET LOWER DIVISOR
EC2C 3E07 MVI A,WLS1+WLS0+STB = 7H
EC2E D34B OUT LCR 2 1 4
```

```
EC30 AF DONE XRA A ;CLEAR STATUS REGISTER
EC31 D34D OUT LSR
; IN 7 ;GET KEYBOARD INTERLOCK BYTE
; ANI 1 ;GET BIT 1 ONLY
; ADI INTIOBY ;ADD INTIOBY TO KEYBOARD BIT
; STA IOBYTE ;INITIALIZE IOBYTE
```

```
EC33 C9 RET
EC34 3A3AE3 LINIT LDA GROUP 0 ;GET GROUP BYTE
EC37 F603 ORI LSTGRP ;SELECT LIST DEVICE
EC39 D34F OUT GRPSEL
EC3B 3E80 MVI A,DLAB ;ACCESS DIVISOR LATCH
EC3D D34B OUT LCR
EC3F 2A38E3 LHL DEFLLST (12) ;GET LST: BAUD RATE DIVISOR
EC42 7C MOV A,H
EC43 D349 OUT DLM ;SET UPPER BAUD RATE
EC45 7D MOV A,L
EC46 D348 OUT DLL
EC48 3E07 MVI A,STB+WLS0+WLS1
EC4A D34B OUT LCR
EC4C DB48 IN RBR ;CLEAR INPUT BUFFER
EC4E AF XRA A
EC4F D349 OUT IER ;NO INTERUPTS
```

DIVISOR LATCH ACCESS BIT 80H
WLS1 WORD LENGTH SELECT BIT 1 FOR 8 BIT WORD
WLS0 WORD LENGTH SELECT BIT 0
STB STOP BIT COUNT - 2 STOP BITS

~~LDA~~ ORI

```

EC51 C9          RET
EC52 00FF00     DB      0,0FFH,0
EC55           DS      512-(S-BUFFER) ;MAXIMUM SIZE BUFFER FOR 512 BYTE SECTORS
ECEC           DS      512           ;ADDITIONAL SPACE FOR FLOPPIES 1K SECTORS

```

```

*****
*
* CBIOS RAM LOCATIONS THAT DON'T NEED INITIALIZATION.
*
*****

```

```

EEEC 0000     CPMSEC  DW      0           ;CP/M SECTOR #
EEEE 00       CPMDRV  DB      0           ;CP/M DRIVE #
EEEF 00       CPMTRK  DB      0           ;CP/M TRACK #
EEF0 0000     TRUESEC DW      0           ;DISK JOCKEY SECTOR THAT CONTAINS CP/M SECTOR
EEF2 00       BUFDRV  DB      0           ;DRIVE THAT BUFFER BELONGS TO
EEF3 00       BUFTRK  DB      0           ;TRACK THAT BUFFER BELONGS TO
EEF4 0000     BUFSEC  DW      0           ;SECTOR THAT BUFFER BELONGS TO
EEF6         DIRBUF  DS      128          ;DIRECTORY BUFFER
          ALLOC  MACRO  ND,AL,CS
          ALV&ND DS      AL
          CSV&ND DS      CS
          ENDM

```

```

0000 #        DN      SET      0
          REPT     MAXHD
          ALLOC   %DN,252,0
          DN      SET      DN+1
          ALLOC   %DN,252,0
          DN      SET      DN+1
          ALLOC   %DN,129,0
          DN      SET      DN+1
          ENDM

```

```

EF76+        ALV0     DS      252
F072+        CSV0     DS      0
F072+        ALV1     DS      252
F16E+        CSV1     DS      0
F16E+        ALV2     DS      129
F1EF+        CSV2     DS      0
          REPT     MAXFLOP
          ALLOC   %DN,75,64
          DN      SET      DN+1
          ENDM

```

```

F1EF+        ALV3     DS      75
F23A+        CSV3     DS      64

```

```

F27A         END

```

0006 AACK	E825 ACCOK	000A ACR	0003 AETX	000D ALF
EF76 ALV0	F072 ALV1	F16E ALV2	F1EF ALV3	E4D5 AUTOFLG
0004 BANK	D500 BDOS	A800 BIAS	E300 BIOS	EEF2 BUFDRV
0080 BUFF	EAEC BUFFER	EEF4 BUFSEC	EEF3 BUFTRK	E718 BUFWRN
E922 BUILD	EBBF CBOOT	CD00 CCP	0004 CDISK	E40C CICRT
E40C CIPTR	E38D CITBLE	F803 CTTY	E3F7 CIUC1	E40C CIUR1
E40C CIUR2	E4CD CLDBOT	E4B8 CLDCMND	001A CLEAR	004A CLK
E58C CLOPP	00D0 CLRCMD	FBFC CMDREG	E431 COCRT	E4D6 COLDBEG
E4D6 COLDEND	E3CD COLPT	0004 COMPLT	0001 CONGRP	E347 CONIN
E34D CONIN1	E455 CONINA	E35C CONOUT	E468 CONOUT1	E33B CONST
E3CD COPTP	E43C COPTR	E443 COPTR1	E395 COTBLE	F806 COTTY
E3D8 COUL1	E3F6 COUNT	E3CD COUP1	E3CD COUP2	E6F8 CPMDMA
EEEE CPMDRV	0016 CPMREV	EEEC CPMSEC	EEEF CPMTRK	E420 CSCRT
E420 CSPTR	E341 CSREADR	E3BD CSRTBLE	E3B5 CSTBLE	E418 CSTTY
E403 CSUC1	E420 CSUR1	E420 CSUR2	F072 CSV0	F16E CSV1
F1EF CSV2	F23A CSV3	0010 CTS	E4D4 CWFLG	0048 DAISI0
0049 DAISI1	0048 DAISY0	0049 DAISY1	0008 DBLSID	E671 DCRC
E7ED DECIDE	E7E9 DECIDGO	E336 DEFCON	E338 DEFLST	0020 DENABLE
EEF6 DIRBUF	E6C4 DIVDONE	E673 DIVLOG	E675 DIVLOGX	E6B6 DIVLOOP
E85B DIVSPT	E85D DIVSPTX	F800 DJBOOT	F803 DJCIN	F806 DJCOUT
F82D DJDEN	F812 DJDMA	E333 DJDRV	F82A DJERR	F809 DJHOME
E5AF DJINIT	E5CD DJNEXT	FC00 DJRAM	F815 DJREAD	F80F DJSEC
F81B DJSEL	F830 DJSIDE	F827 DJSTAT	F80C DJTRK	F821 DJTSTAT
F818 DJWRITE	0080 DLAB	0048 DLL	0049 DLM	EC30 DONE
E51C DONOP	EA6C DP1024D	EA2C DP1024S	EA3C DPB128D	E9FC DPB128S
EA4C DPB256D	EA0C DPB256S	EA5C DPB512D	EA1C DPB512S	EAAC DPBASE
EA7C DPBHD1	EA8C DPBHD2	EA9C DPBHD3	FBF9 DREG	0001 DR
E92D DRIVES	E627 DRVHD	E917 DRVPTR	0020 DRVRDY	0007 DSKCLK
0020 DSR	E6D3 DTSLOP	0008 ENINT	0005 ENTRY	E7AA FILL
E580 FLOPFLG	E5D2 FLOPOK	E717 FLUSH	E7D2 FREAD	E67C GETDPB
E857 GETSPT	E482 GOCPM	E33A GROUP	004F GRPSEL	0000 GZERO
E87E HDADD	0051 HDCMND	0050 HDCNTL	0053 HDDATA	E929 HDDISK
E838 HDDMA	E7F5 HDDRV	0052 HDFUNC	E806 HDHOME	0050 HDORG
E8E2 HDPREP	E864 HDREAD	0051 HDRESLT	0004 HDRLEN	E846 HDSEC
E907 HDSECTR	E83D HDSIDE	0015 HDSPT	0050 HDSTAT	E814 HDTRK
E822 HDTRK2	E899 HDWRITE	E923 HEAD	E523 HOME	0000 IDBUFF
0049 IER	0040 INDEX	00C0 INTIOBY	E705 INTO	FBF8 IO
0003 IOBYTE	0008 ISBUFF	004B LCR	EC34 LINIT	E37C LIST
E37F LIST1	E387 LISTST	0003 LOGDSK	E429 LSLPT	004D LSR
E3C5 LSTBLE	0003 LSTGRP	E39D LTBLE	0001 MAXFLOP	0001 MAXHD
0048 MBASE	00F7 MDIR	EBB2 MESSAGE	E44E MIOIN	E461 MIOOUT
E473 MIOSTAT	E6E2 MOVE	E7DE MOVER	E7E0 MOVLOP	0014 MREV
003E MSIZE	004E MSR	E739 NOADJST	00FB NSTEP	00FC NULL
3E00 OFFSETC	0002 OPDONE	F800 ORIGIN	E700 OUTOF	E377 PNCH1
E724 PREP	E8C8 PROCESS	EAEC PROMPT	0004 PSTEP	E3A5 PTBLE
E371 PUNCH	E3ED PWAIT	0048 RBR	E6FB RDWR	E367 READER
E6A4 READ	E36A READERA	E36D READR1	E42E READY	E6A8 REDWRT
0010 RESTOR	000A RETRIES	0002 RETRY	E72E RETRYLP	E78B RETRYOP
001D REVNUM	0001 RSECT	E3AD RTBLE	E884 RTLOOP	0001 S0
0002 S1	0005 SCENBL	0200 SECLN	E6E7 SECPSEC	E6A9 SECSIZ
E52A SECTRAN	E351 SELDEV	0049 SENSESW	E51D SETDMA	E565 SETDRV
E654 SETDRV1	E517 SETSEC	E525 SETTRK	E540 SIDEA	E617 SIDEOK
E543 SIDEONE	E549 SIDETWO	E829 SLOOP	0003 SMASK	E41B STAT
0004 STB	E643 TDELAY	0048 THR	0020 THRE	EBFF TINIT
0001 TKZERO	0008 TMOUT	0100 TPA	E532 TRANFP	E561 TRANHD
EEF0 TRUESEC	EBF8 TV950	EC08 WAITC	E4D7 WARMBEG	E4D7 WARMEND

E4F4 WARMLOD	E506 WARMRD	E303 WBOOTE	E4D8 WBOOT	0000 WBOT
000F WENABL	0010 WFAULT	0001 WLS0	0002 WLS1	000B WRESET
E69D WRITE	E70F WRITYP	E509 WRMREAD	E83E WSDONE	0005 WSECT
E8A5 WTLOOP	E9BB XLT124	E92E XLT128	E949 XLT256	E97E XLT512
E695 XLTS	E906 ZKEY	E66D ZRET		